

IDENTIFICATION

PRODUCT CODE: AC-F135B-MC
PRODUCT NAME: CZRLMB0 RL01/02 BAD SECTOR FILE TOOL
DATE CREATED: 5-JAN-79
REVISED: 7-DEC-79
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: C. CAMPBELL

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1979, DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.1.1	STRUCTURE OF PROGRAMS
1.1.2	DIAGNOSTIC INFORMATION
1.2	SYSTEM REQUIREMENTS
1.2.1	HARDWARE REQUIREMENTS
1.2.2	SOFTWARE REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	HOW TO RUN THIS DIAGNOSTIC
2.1.1	THE FIVE STEPS OF EXECUTION
2.1.2	SAMPLE RUN-THROUGH
2.2	DETAILS OF COMMANDS AND SYNTAX
2.2.1	TABLE OF COMMAND VALIDITY
2.2.2	COMMAND SYNTAX
2.3	HARDWARE PARAMETERS
2.4	SOFTWARE PARAMETERS
3.0	ERROR INFORMATION
3.1	ERROR REPORTING
3.2	ERROR HALTS
4.0	PERFORMANCE AND PROGRESS REPORTS
4.1	PERFORMANCE REPORTS
4.2	PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	UTILITY-SUMMARY OF COMMANDS

1.0 GENERAL INFORMATION1.1 PROGRAM ABSTRACT1.1.1 STRUCTURE OF PROGRAM

THIS DIAGNOSTIC IS COMPATIBLE WITH BOTH XXDP+ AND ACT. IT IS TO BE RUN STANDALONE UNDER XXDP+. AND CAN BE CHAINED UNDER XXDP+. ACT AND APT IN ACT MODE (SEE 2.2 'CHAIN MODE OPERATION' FOR DETAILS OF CHAINING PROCEDURE). IT IS A SINGLE PROGRAM FROM THE STANDPOINT OF THE DIAGNOSTIC USER, WHICH AT RUN TIME IS APPENDED TO A COMMON FRONT-END PIECE OF SUPERVISOR SOFTWARE THROUGH WHICH THE DIAGNOSTIC PROGRAM INTERFACES TO THE ENVIRONMENT AS IT EXECUTES.

WHEN THIS DIAGNOSTIC IS STARTED, CONTROL GOES FIRST TO THE SUPERVISOR PORTION, WHICH WILL ASK CERTAIN 'HARD CORE' QUESTIONS ABOUT THE ENVIRONMENT. THEN IT WILL ENTER COMMAND MODE, INDICATED BY A PROMPT CHARACTER (DR>). AT COMMAND MODE THE OPERATOR MAY ENTER ANY OF SEVERAL COMMANDS AS DESCRIBED IN 2.0 'OPERATING INSTRUCTIONS'.

THE DIAGNOSTIC PROGRAM IS LOADED IN THE LOWER 8K OF MEMORY. THE DIAGNOSTIC SUPERVISOR CODING OCCUPIES 6.25K OF THE UPPER PART OF MEMORY JUST BELOW THE XXDP+ MONITOR WHICH RESIDES IN THE UPPERMOST 1.5K OF MEMORY SPACE.

1.1.2 DIAGNOSTIC INFORMATION

THERE IS NO SPECIFIC RUN TIME ASSOCIATED WITH THIS UTILITY PROGRAM. HOWEVER, TO WRITE THE WORST CASE DATA PATTERN ON THE DISK AND THEN VERIFY THE DATA BY READING SHOULD TAKE LESS THAN 1 MINUTE FOR AN RL01 AND LESS THAN 2 MINUTES FOR AN RL02.

1.2 SYSTEM REQUIREMENTS1.2.1 HARDWARE REQUIREMENTS

- * PDP-11/LSI-11 PROCESSOR WITH 16K OR MORE OF MEMORY
- * CONSOLE DEVICE (LA30, LA36, VT50, ETC.)
- * 1 OR 2 RL11/RLV11 CONTROLLER(S) WITH:

- 1 - 8 RL01 DRIVES WITH RL01K CARTRIDGES CONTAINING A 'BAD
SECTOR FILE'
- 1 - 8 RL02 DRIVES WITH RL02K CARTRIDGES CONTAINING A 'BAD
SECTOR FILE'

- * KW11-L OR KW11-P CLOCK
- * LINE PRINTER (OPTIONAL)

1.2.2 SOFTWARE REQUIREMENTS

CZRLMBO RL01/02 BAD SECTOR FILE TOOL

1.3 RELATED DOCUMENTS AND STANDARDS

RL01 DISK SUBSYSTEM USER'S GUIDE (EK-RL01-UG-002)
XXDP+/SUPERVISOR USER'S MANUAL

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THE RL01/02 SUBSYSTEM SHOULD HAVE SUCCESSFULLY RUN THE FOLLOWING
PROGRAMS:

CVRLABO	RLV11 RL01/02 DISKLESS TEST (RLV11 ONLY)
CZRLGBO	RL11/RLV11 RL01/02 CONTROLLER TEST (PART 1)
CZRLHBO	RL11/RLV11 RL01/02 CONTROLLER TEST (PART 2)
CZRLIBO	RL01/02 DRIVE TEST (PART 1)
CZRLJBO	RL01/02 DRIVE TEST (PART 2)
CZRLKBO	RL11/RLV11 RL01/02 PERFORMANCE EXERCISER
CZRLNAO	RL01/02 DRIVE TEST (PART 3)

1.5 ASSUMPTIONS

THE HARDWARE OTHER THAN THE RL01/02 SUBSYSTEM IS ASSUMED TO WORK
PROPERLY. FALSE ERRORS MAY BE REPORTED IF THE PROCESSOR, ETC., DO
NOT FUNCTION PROPERLY.

THIS UTILITY WILL CONFORM TO ALL INTERFACE SPECIFICATIONS FOR THE
DIAGNOSTIC SUPERVISOR.

THE INTERNAL FORMAT OF THE BAD SECTOR FILE WILL BE THE SAME AS
DESCRIBED BY THE DEC STD-144 DOCUMENT FOR REPORTING AND UPDATING
THE INFORMATION CONTAINED IN THAT FILE.

NO SUPPORT WILL BE GIVEN FOR THE RL8A/RL01 DISK CONTROLLER ON ANY PDP-8 SYSTEM...THIS IS A PDP-11 UTILITY ONLY!

2.0 OPERATING INSTRUCTIONS

2.1 HOW TO RUN THIS DIAGNOSTIC

2.1.1 THE FIVE STEPS OF EXECUTION

THIS UTILITY PROGRAM SHOULD BE LOADED AND STARTED USING NORMAL XXDP+ PROCEDURES. START THE EXECUTION OF THE XXDP+ MONITOR BY USING THE APPROPRIATE BOOTSTRAP PROGRAM. THE MONITOR WILL PRINT A MESSAGE IDENTIFYING ITSELF AND REQUESTING THAT THE CURRENT DATE BE ENTERED. AN EXAMPLE OF THIS MESSAGE IS GIVEN BELOW FOR THE XXDP+ MONITOR:

```
CHMDKAO XXDP+ D: MONITOR NAK
BOOTED VIA UNIT 0
ENTER DATE (DD-MMM-YY):
```

AFTER THE DATE HAS BEEN ACCEPTED BY THE MONITOR THE RESTART ADDRESS OF THE MONITOR IS PRINTED. THEN THE FOLLOWING TWO QUESTIONS ARE ASKED:

```
50 HZ? N
LSI? N
```

THE DEFAULTS ARE BOTH 'NO'. TYPE 'R' AND THE PROGRAM NAME TO RUN THE PROGRAM. DO NOT TYPE THE EXTENSION.

WHEN THIS UTILITY PROGRAM IS STARTED, THE FOLLOWING 5 STEPS WILL OCCUR:

```
*****
* STEP 1 *
*****
```

THE UTILITY WILL ISSUE THE PROMPT 'DR>'. FROM THIS POINT UNTIL THE TIME WHEN YOU RESTART XXDP+, YOU WILL BE TALKING TO THE UTILITY, NOT XXDP+. WE WILL REFER TO THE PRESENCE OF THIS PROMPT AS BEING IN DIAGNOSTIC COMMAND MODE, AS OPPOSED TO XXDP+ COMMAND MODE.

AT THIS POINT YOU WILL ENTER A 'START' COMMAND. THIS IS NOT THE SAME AS THE XXDP+ 'START' COMMAND, WHICH YOU ALREADY ISSUED IN RESPONSE TO THE XXDP+ DOT PROMPT. THIS 'START' COMMAND CAN TAKE A NUMBER OF SWITCHES AND FLAGS (ALL OPTIONAL). HOWEVER, IN ORDER TO USE THE PROGRAM, ALL YOU NEED TO SAY IS SOMETHING LIKE THIS:

```
STA/PASS:1/FLAGS:HOE
```

THINGS TO NOTE HERE: ONLY THE FIRST THREE CHARACTERS OF THIS OR ANY COMMAND AT THE 'DR>' LEVEL NEED TO BE TYPED. THE 'FLAGS' SWITCH MAY SPECIFY ANY OF A NUMBER OF FLAGS, BUT THE MAIN USEFUL ONES ARE:

PNT	PRINT NUMBER OF TEST BEING EXECUTED
HOE	HALT ON ERROR
IER	INHIBIT ERROR PRINTOUT

* STEP 2 *

WHEN YOU HAVE TYPED IN A 'START' COMMAND, THE UTILITY WILL COME BACK WITH THE QUESTION '# UNITS?' TO WHICH YOU SHOULD RESPOND BY TYPING IN THE NUMBER OF DEVICES YOU WISH TO TEST (THE UTILITY USES ONLY 1 DRIVE).

* STEP 3 *

WHEN YOU HAVE TYPED IN THE NUMBER OF UNITS TO BE TESTED, THE UTILITY WILL ASK YOU THE 'HARDWARE QUESTIONS'. THE ANSWERS TO THESE QUESTIONS ARE USED TO BUILD TABLES IN CORE, CALLED 'HARDWARE P-TABLES'. ONE HARDWARE P-TABLE WILL BE BUILT FOR EACH UNIT TO BE TESTED.

THERE ARE SEVERAL HARDWARE QUESTIONS AND THE ENTIRE SERIES WILL BE POSED N TIMES, WHERE N IS THE NUMBER OF UNITS.

THIS REPRESENTS A NEW PHILOSOPHY IN DIAGNOSTIC ENGINEERING. DIAGNOSTICS IN THE FUTURE WILL NOT BE WRITTEN TO AUTOSIZE OR ASSUME STANDARD ADDRESSES: INSTEAD, THEY WILL ASK THE OPERATOR FOR ALL THE INFORMATION THEY NEED TO TEST THE DEVICE.

* STEP 4 *

AFTER YOU HAVE ANSWERED ALL THE HARDWARE QUESTIONS FOR ALL THE UNITS, YOU WILL BE ASKED 'CHANGE SW?' IF YOU WANT TO BE ASKED THE SOFTWARE QUESTIONS THAT DETERMINE THE BEHAVIOR OF THIS PROGRAM, TYPE 'Y'. IF YOU WANT TO TAKE ALL THE DEFAULTS TO THESE QUESTIONS, TYPE 'N'. IF YOU TYPE 'Y' YOU WILL BE ASKED THE SOFTWARE QUESTIONS, AND THE ANSWERS WILL BE PUT INTO THE SOFTWARE P-TABLE IN THE PROGRAM.

* STEP 5 *

AFTER YOU HAVE ANSWERED THE SOFTWARE QUESTIONS, THE UTILITY WILL BEGIN TO EXECUTE. THERE ARE SEVERAL THINGS THAT CAN HAPPEN NEXT, DEPENDING ON WHETHER A HARDWARE ERROR IS ENCOUNTERED AND ALSO ON WHAT SWITCH VALUES YOU SELECTED ON THE START COMMAND.

IF AN ERROR IS ENCOUNTERED, THEN ONE OF THREE THINGS HAPPENS, DEPENDING ON THE SETTINGS OF THE HOE AND LOE FLAGS.

HOE SET: THE ERROR WILL BE REPORTED ON THE CONSOLE AND THE UTILITY WILL RETURN TO COMMAND MODE.

LOE SET: THE UTILITY WILL LOOP ENDLESSLY ON THE BLOCK OF CODE THAT DETECTED THE ERROR.

NEITHER HOE NOR LOE SET: THE ERROR WILL BE REPORTED ON THE CONSOLE AND NORMAL EXECUTION WILL RESUME AS IF NO ERROR HAD OCCURRED.

2.1.2 SAMPLE RUN-THROUGH

LET'S SEE HOW ALL THIS WORKS IN A REAL SITUATION. RECALL THAT WE ENTERED THE COMMAND 'STA/PASS:1/FLAGS:HOE'. THIS WOULD BE A VERY TYPICAL WAY TO RUN THE DIAGNOSTIC. IF NO ERRORS ARE ENCOUNTERED, THE SINGLE REQUESTED PASS WILL BE EXECUTED AND THE PROMPT WILL BE RE-ISSUED.

IF AN ERROR IS ENCOUNTERED, THE ERROR WILL BE REPORTED AND THE PROMPT WILL BE REISSUED (BECAUSE THE HOE FLAG IS SET). AT THIS POINT THERE ARE FOUR DIFFERENT WAYS YOU CAN GET THE PROGRAM GOING AGAIN:

1. ISSUE ANOTHER 'START' COMMAND (THUS GOING THRU ALL OF STEPS 1, 2, 3, 4, AND 5 AGAIN).
2. ISSUE A 'RESTART' COMMAND (SAME AS START COMMAND EXCEPT THAT THE HARDWARE QUESTIONS ARE NOT ASKED)
3. ISSUE A 'CONTINUE' COMMAND (EXECUTION WILL RESUME AT THE BEGINNING OF THE PARTICULAR HARDWARE TEST (MOST DIAGNOSTICS CONSIST OF A NUMBER OF THESE) THAT IT WAS IN WHEN THE ERROR HALT OCCURRED. NO QUESTIONS ASKED.
4. ISSUE A 'PROCEED' COMMAND: EXECUTION WILL RESUME AT THE INSTRUCTION FOLLOWING THE ERROR REPORT (THIS IS A SPECIAL COMMAND AND CAN BE ISSUED ONLY AT A HALT ON ERROR).

THE MOST TYPICAL THING TO DO HERE IS TO ISSUE THE PROCEED, BUT WITH DIFFERENT FLAG SETTINGS. PROBABLY YOU WOULD WANT TO SAY:

PRO/FLAGS:IER:LOE:HOE=0

THIS WILL DO THE FOLLOWING:

1. TURN ON THE IER (INHIBIT ERROR PRINTOUT) FLAG
2. TURN ON THE LOE FLAG
3. TURN OFF THE HOE FLAG
4. RESUME EXECUTION AT INSTRUCTION AFTER ERROR REPORT

THE DIAGNOSTIC WILL NOW LOOP ON THE BLOCK OF CODE THAT DETECTED AND REPORTED THE ERROR, BUT NO ERROR PRINTOUT WILL OCCUR. THUS YOU CAN STUDY THE ERROR OR SCOPE IT OR WHATEVER.

WHEN YOU'VE SEEN ENOUGH, YOU MAY HIT CONTROL/C. THIS WILL TAKE YOU OUT OF THE LOOP AND PUT YOU BACK INTO COMMAND MODE. YOU NOW HAVE THREE CHOICES:

1. START
2. RESTART
3. CONTINUE

LET'S SAY YOU'VE REPAIRED THE DEFECT FOUND ABOVE AND WANT TO FINISH RUNNING THE DIAGNOSTIC. YOU WOULD TYPE

CON/FLAGS:HOE:IER=0:LOE=0

THIS WILL RESTORE THE FLAGS TO THEIR ORIGINAL VALUES AND RESUME EXECUTION AT THE BEGINNING OF THE HARDWARE TEST YOU WERE IN. IF THE ERROR DOES NOT RECUR, THE EXECUTION WILL FLOW RIGHT ON THRU TO THE NEXT ERROR OR TO END OF PASS.

IF AT END OF PASS YOU WANT TO RUN THE DIAGNOSTIC AGAIN, YOU HAVE TWO CHOICES:

1. START
2. RESTART

YOU WOULD CHOOSE ONE, DEPENDING ON WHETHER YOU WANTED TO ANSWER THE HARDWARE QUESTIONS AGAIN.

THE FULL PRINT-OUT FROM THE ABOVE DIALOGUE MIGHT LOOK LIKE THIS
(O=OPERATOR, D=DIAGNOSTIC):

	BY WHOM ENTERED: -----
.R CZRLMB	O
DRS LOADED	D
DIAG. RUN-TIME SERVICES REV. D APR-79	D
CZRLM-B-0	D
CZRLM IS A UTILITY PROGRAM FOR FORMATTING	D
BAD SECTOR FILES	
UNIT IS RL01, RL02	D
DR>STA/PASS:1/FLAGS:HOE	D,O
CHANGE HW (L) ? Y	D,O
# UNITS (D) ? 2	D,O
UNIT 0	D
BUS ADDRESS (O) 17440C ?	D,O
DRIVE (O) 0 ?	D,O
UNIT 1	D
BUS ADDRESS (O) 174400?	D,O
DRIVE (O) 0 ? 1	D,O
CHANGE SW (L) ? Y	D,O
SAWTOOTH WRITE CYCLE ? (L) Y ?	D,O
WRITE CYCLES PER TRACK ? (D) 2 ?	D,O
CZRLM HRD ERR 00004 TST 003 SUB 002 PC:004130	
ERR HLT	
DR>PRO/FLAGS:IER:LOE:HOE=0	D,O

AT THIS POINT THE DIAGNOSTIC IS LOOPING ON THE	
ERROR WITHOUT PRINTING ANYTHING. YOU CAN SCOPE	
THE ERROR UNTIL YOU HAVE LOCATED IT, THEN ^C OUT.	

^C	O
DR>CON/FLAGS:HOE:IER:LOE=0	D,O
CHANGE SW (L) ? N	D,O
^C	

```
DR>RESTART/PASS:1          D.O
CHANGE SW (L) ? N          D.O
-----
-----
-----
-----
```

2.2 DETAILS OF COMMANDS AND SYNTAX

2.2.1 TABLE OF COMMAND VALIDITY

THERE ARE FOUR WAYS OF ENTERING DIAGNOSTIC COMMAND MODE, AND
DIFFERENT SUBSETS OF THE DIAG COMMAND SET ARE AVAILABLE WITH EACH:

HOW ENTERED -----	LEGAL COMMANDS -----
1. OPERATOR ENTERED 'RUN DIAG'	START PRINT DISPLAY FLAGS ZFLAGS EXIT
2. DIAGNOSTIC HAS FINISHED ALL ITS REQUESTED PASSES	START RESTART PRINT DISPLAY FLAGS ZFLAGS EXIT
3. OPERATOR INTERRUPTED THE DIAGNOSTIC WITH CTRL/C	START RESTART CONTINUE PRINT DISPLAY FLAGS ZFLAGS EXIT
4. AN ERROR WAS ENCOUNTERED WITH THE HOE FLAG SET SET	START RESTART CONTINUE PROCEED PRINT DISPLAY FLAGS ZFLAGS EXIT

2.2.2

COMMAND SYNTAX

S'A(RT)/TESTS:TEST-LIST/PASS:PASS-CNT/FLAGS:FLAG-LIST/EOP:EOP-INCR

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. THE MESSAGE '# UNITS?' IS PRINTED. THE START COMMAND MAY BE ISSUED WHEN DIAGNOSTIC COMMAND MODE HAS BEEN ENTERED VIA ONE OF THE FOLLOWING: A) OPERATOR TYPED 'RUN DIAGNOSTIC' B) DIAGNOSTIC FINISHED EXECUTING C) ERROR WAS ENCOUNTERED WITH HOE FLAG SET D) OPERATOR ENTERED CONTROL/C. AFTER THE OPERATOR RESPONDS TO '# UNITS?', THE HARDWARE DIALOGUE IS INITIATED. WHEN IT IS COMPLETED, THE QUESTIONS 'CHANGE SW?' IS ISSUED, AND THE ANSWERS, IF GIVEN, BECOME THE NEW DEFAULTS. THEREFORE IT IS NECESSARY TO RELOAD THE PROGRAM IN ORDER TO RETURN TO THE LOAD DEFAULTS.

THE SWITCH ARGUMENTS ARE AS FOLLOWS:

'TEST-LIST' IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.) THAT SPECIFY THE TESTS TO BE EXECUTED. THE NUMBERS ARE SEPARATED BY COLONS. THE NUMBERS RANGE FROM 1 TO THE LARGEST TEST NUMBER IN THE DIAGNOSTIC. THEY MAY BE SPECIFIED IN ANY ORDER. TESTS WILL BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF THE ORDER OF SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS.

'PASS-CNT' IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL DIAGNOSTIC (ALL SELECTED TESTS) AGAINST ALL UNITS SUBMITTED. THE DEFAULT IS NON-ENDING TEST EXECUTION. 'FLAG-LIST' IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>, <FLAG=1>, OR <FLAG=0>, SEPARATED BY COLONS, WHERE <FLAG> HAS ONE OF THE FOLLOWING VALUES:

HOE HALT ON ERROR, CAUSING COMMAND MODE TO BE ENTERED WHEN AN ERROR IS ENCOUNTERED

LOE LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAINING THE ERROR

IER INHIBIT ERROR REPORTING

IBE INHIBIT BASIC ERROR REPORTS

IXE INHIBIT EXTENDED ERROR REPORTS

PRI DIRECT ALL MESSAGES TO A LINE PRINTER

PNT PRINT NUMBER OF TEST BEING EXECUTED
BOE BELL ON ERROR
UAM RUN IN UNATTENDED MODE, BYPASSING MANUAL INTERVENTION TESTS
ISR INHIBIT STATISTICAL REPORTS
IDU INHIBIT DROPPING OF UNITS BY DIAGNOSTIC
ADR EXECUTE AUTODROP CODE
LOT LOOP ON TEST
EVL EVALUATE

THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0 ARE CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS SWITCH IS NOT GIVEN ALL FLAGS ARE CLEARED.

'EOP-INCR' IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE PRINTED. THE DEFAULT IS AT THE END OF EVERY PASS.

RES(TART)/TEST:TEST-LIST/PASS:PASS-CNT/FLAGS:FLAG-LIST/EOP:EOP-INCR/UNITS:UNIT-LIST

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. HOWEVER, NEW 'P-TABLES' ARE NOT BUILT. INSTEAD, THE ONES IN CORE ARE USED.

THE QUESTION 'CHANGE SW?' IS ASKED AND THE ANSWERS GIVEN BECOME THE NEW DEFAULTS. THE COMMAND MAY BE ISSUED WHEN COMMAND MODE HAS BEEN ENTERED VIA A) DIAGNOSTIC IS FINISHED B) HALT ON ERROR C) CONTROL/C.

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

1. 'UNIT-LIST' IS A SEQUENCE OF LOGICAL UNIT NUMBERS RANGING FROM 1 THRU N (N = NUMBER OF UNITS BEING TESTED) SPECIFYING WHICH UNITS ARE TO BE TESTED. THE LOGICAL UNIT NUMBER DESIGNATES THE POSITION OF THE P-TABLE IN CORE, ACCORDING TO THE ORDER IN WHICH THEY WERE BUILT. THE UNITS SPECIFIED MUST NOT HAVE BEEN DROPPED BY THE OPERATOR DROP COMMAND. THE UNIT-LIST DEFAULTS TO 'ALL THAT HAVE NOT BEEN DROPPED BY OPERATOR COMMAND'. THE EFFECT OF THE UNIT-LIST LASTS UNTIL THE NEXT START (WHERE IT IS AUTOMATICALLY RESET TO 'ALL') OR THE NEXT RESTART.
2. ALL UNSPECIFIED FLAG SETTINGS ARE UNCHANGED.

CON(TINUE)/PASS:<PASS-CNT/FLAGS:<FLAG-LIST>

COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALLY BE RE-EXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

1. DEFAULT FOR PASS-CNT IS THE UNSATISFIED PASS-CNT FROM THE PREVIOUS START OR RESTART
2. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

PRO(CEED)/FLAGS:<FLAG-LIST>

COMMAND MODE MUST HAVE BEEN ENTERED VIA A HALT ON ERROR. THE EFFECT OF THE COMMAND IS TO BEGIN EXECUTION AT THE LOCATION FOLLOWING THE ERROR CALL. NEITHER HARDWARE NOR SOFTWARE PARAMETERS BY BE ALTERED.

THE SWITCH ARGUMENTS ARE THE SAME AS THE START COMMAND EXCEPT:

1. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

EXIT

RETURN TO XXDP+ PROMPT MODE.

DRO(P)/UNITS:UNIT-LIST

THE UNITS SPECIFIED ARE DROPPED FROM TESTING UNTIL THEY ARE ADDED BACK OR UNTIL A START COMMAND IS GIVEN. A DROP CANNOT BE FOLLOWED BY A PROCEED.

THERE IS ALSO A 'DROP' MACRO INTERNAL TO THE DIAGNOSTIC, WHICH GIVES THE FACILITY OF AUTO-DROPPING. THE DURATION OF A PROGRAM DROP, HOWEVER, IS ONLY UNTIL THE NEXT START OR RESTART.

ADD/UNITS:UNIT-LIST

THE UNITS SPECIFIED ARE ADDED BACK (THEY MUST HAVE BEEN PREVIOUSLY DROPPED BY THE DROP COMMAND) TO THE TEST SEQUENCE. AN ADD CANNOT BE FOLLOWED BY A PROCEED.

PRI(NT)

ALL STATISTICS TABLES ACCUMULATED BY THE DIAGNOSTIC ARE PRINTED. THE ISR (INHIBIT STATISTICAL REPORTING) FLAG IS CLEARED.

DIS(PLAY)/UNITS-<UNIT-LIST>

THE HARDWARE P-TABLES FOR ALL UNITS UNDER TEST ARE PRINTED OUT IN THE FORMAT IN WHICH THEY WERE ENTERED. ANY UNITS THAT WERE DROPPED BY THE OPERATOR 'DROP' COMMAND ARE SO DESIGNATED.

FLA(GS)

THE CURRENT SETTINGS OF ALL FLAGS ARE PRINTED.

ZFL(AGS)

ALL FLAGS ARE CLEARED.

2.3 HARDWARE PARAMETERS

THE FOLLOWING QUESTIONS WILL BE ASKED ON A START COMMAND. THE VALUE LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ON A CARRIAGE RETURN RESPONSE.

BUS ADDRESS (0) 174400?

ANSWER WITH THE BUS ADDRESS OF THE CONTROLLER.

DRIVE (0) 0?

ANSWER WITH THE DRIVE(S) CONNECTED TO THE CONTROLLER

2.4 SOFTWARE PARAMETERS

THE FOLLOWING QUESTIONS ARE ASKED IF REQUESTED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES. THE SOFTWARE PARAMETERS GIVE THE PROGRAM FLEXIBILITY IN THE WAY IT RUNS. THE PARAMETERS CAN BE MODIFIED ON A START, RESTART, OR CONTINUE BY ANSWERING (Y)ES TO THE FOLLOWING QUESTION:

'CHANGE S.W. ?'

A YES ANSWER WILL ASK THE FOLLOWING SOFTWARE PARAMETER QUESTIONS, WITH THE PRESENT DEFAULT VALUE PRINTED TO THE LEFT OF THE QUESTION MARK. (THE LAST ANSWER GIVEN IS THE DEFAULT) THE DEFAULT IS TAKEN ON A <CR>. CONTROL Z (^Z) WILL DEFAULT ALL REMAINING QUESTIONS AND START THE TEST.

'SAWTOOTH WRITE CYCLE? (L) Y ?'

IF 'Y' THEN THE WRITE PACK COMMAND (#5) WILL CAUSE THE PACK TO BE WRITTEN IN A FORWARD AND REVERSE DIRECTION UTILIZING A 'SAWTOOTH' SEEK PATTERN. THIS WILL ATTEMPT TO DETECT POSITIONER PROBLEMS. IF 'N' FOR NO, THEN THE PACK WILL BE WRITTEN FORWARD AND REVERSE USING AN INCREMENTAL SEEK - THIS IS THE FASTEST BUT NOT NECESSARILY THE MOST DIFFICULT.

'WRITE CYCLES PER TRACK? (D) 2 ?'

THE DEFAULT NUMBER OF TIMES TO WRITE A SELECTED TRACK DURING THE WRITE PACK COMMAND (#5). IF A HIGHER NUMBER IS SELECTED, THEN IT MAY BE POSSIBLE TO DETECT A TRACK DRIFTING POSITIONER PROBLEM.

3.0 ERROR INFORMATION

ERROR INFORMATION IS COMPLETE IN GIVING ALL INFORMATION NECESSARY.

THE 'RLCS' AND DRIVE STATUS REGISTER ARE GIVEN AS WELL AS CYLINDER, TRACK, SECTOR AND DRIVE INVOLVED IN ERROR.

ANY DETECTED HARDWARE FAILURES WILL RESULT IN AN APPROPRIATE ERROR MESSAGE (THE PROPER DISK SUBSYSTEM DIAGNOSTIC(S) SHOULD BE PERFORMED).

UNEXPECTED 'TRAPS' WILL RESULT IN A PROPER ERROR MESSAGE AND WILL CAUSE THE UTILITY TO RESTART.

A POWER FAILURE WILL CAUSE THE PROGRAM TO RESTART.

SOFTWARE DETECTED FAILURES - SUCH AS THE DETECTION OF A MISSING BAD SECTOR FILE OR A PARTIALLY DESTROYED BAD SECTOR FILE - WILL CAUSE THE UTILITY TO RESTART AFTER THE FAILURE IS DIAGNOSED AND A DIAGNOSTIC ERROR MESSAGE PRINTED.

3.1 ERROR REPORTING

ALL ERROR INFORMATION IS PRINTED ON THE CONSOLE DEVICE. ERROR REPORTS ARE AIMED AT BEING SELF EXPLANATORY.

REGISTER DESCRIPTIONS CAN BE FOUND IN SECTION 5.0.

ERROR MESSAGES:

'DRIVE IS NOT READY FOR USE''

THIS MESSAGE IS PRINTED WHEN THE SELECTED DRIVE IS NOT ABLE TO PERFORM A GIVEN TASK. THE DRIVE WILL BE ELIMINATED FROM THE TEST TABLE.

'SEEK ERR''

AN ERROR IS DETECTED AFTER A SEEK COMMAND WAS ISSUED.

'DR ERR WILL NOT RESET''

ISSUING A DRIVE RESET WOULD NOT CLEAR THE DRIVE ERROR CONDITION.

'DR WOULD NOT LOAD''

ON PROGRAM START, THE SELECTED DRIVE DID NOT HAVE 'HEADS OVER PACK' BIT SET.

'PACK IS WRITE LOCKED''

THIS IS JUST A WARNING MESSAGE. IF A WRITE COMMAND IS ISSUED, THEN THIS WOULD INDICATE AN ERROR.

'TIMEOUT - DR NOT RDY''

THE DRIVE WAS EXPECTED TO BE 'READY' AFTER A COMMAND WAS ISSUED AND IT NEVER FINISHED THE FUNCTION.

'NO DRIVES''

THE PROGRAM TRYED TO SELECT A DRIVE FOR USE BUT FAILED TO FIND ONE.

'UPDATING DENIED - INVALID PASSWORD''

NORMALLY, THIS PROGRAM WILL NEVER PRINT THIS MESSAGE! PROGRAM PASSWORD CHECKING IS NORMALLY INHIBITED. A USER MAY INVOKE THE PASSWORD CHECK IF THE WORD 'PASWD' AT ADDRESS 2274 IS CHANGED TO A NON-ZERO NUMBER...THIS 'NUMBER' THEN BECOMES THE PROGRAM PASSWORD AND MUST BE USED TO ENABLE ANY WRITING ON THE SELECTED PACK.

'CAN'T UPDATE THE BAD SECTOR FILE ON PACK''

THIS IS AN INDICATION THAT THE PACK IS WRITE PROTECTED OR THE FUNCTION 'WRITE' CANNOT BE COMPLETED.

'BAD READ OF BAD SECTOR FILE)''

AN ERROR WAS DETECTED WHILE TRYING TO READ 10 SECTORS OF DATA FROM THE 'FACTORY' OR 'FIELD' AREAS IN THE BAD SECTOR FILE.

'MORE THAN 25. BAD SPOTS FOUND ON THIS PACK''

THIS MESSAGE WARNS THE USER THAT THE SELECTED PACK ALREADY HAS MORE THAN 25. ENTRIES IN THE BAD SECTOR FILE. THE PACK SPECIFICATION ALLOWS ONLY 16. BAD SPOTS ON THE PACK BEFORE THE PACK IS CLASSIFIED AS 'BAD'.

'SOFT ERR ENCOUNTERED''

DURING A WRITE OR READ DATA FUNCTION, AN ERROR HAS BEEN DETECTED. THE ERROR WILL ALSO REPORT THE STARTING SECTOR NUMBER OF THE DATA TRANSFER AND THE CONTENTS OF THE DRIVE 'RLCS' REGISTER AND THE DRIVE STATUS.

'HARD ERROR''

THIS MESSAGE IS TO INFORM THE USER THAT THE 'SOFT' COULD NOT BE RECOVERED. THE STARTING SECTOR NUMBER OF THE DATA TRANSFER WILL BE RECORDED FOR LATER USE IN UPDATING THE BAD SECTOR FILE.

'RL01 MAX CYL = 255.''

THE USER CANNOT ADD TO OR DELETE FROM THE BAD SECTOR FILE ANY INVALID DISK ADDRESS.

'ENTRY ALREADY EXISTS IN THE BAD SECTOR FILE''

A REDUNDANT ENTRY CANNOT BE ENTERED INTO THE BAD SECTOR FILE.

'NO SUCH ENTRY IN THE 'FIELD' FILE''

IF AN ENTRY DOES NOT EXIST IN THE 'FIELD' AREA OF THE BAD SECTOR FILE, THEN IT CANNOT BE REMOVED FROM THE FILE. THIS PROTECTS ENTRIES IN THE 'FACTORY' FILE FROM BEING DELETED.

'NO FACTORY FILE FOUND'

THE PROGRAM TRIED TO READ THE FIRST 10 SECTORS OF THE LAST TRACK TO IDENTIFY THE 'FACTORY' BAD SECTOR FILE...AND FAILED TO MAKE THAT IDENTIFICATION. EITHER THE 'FACTORY' FILE WAS DESTROYED OR THE DATA ON THIS TRACK DOES NOT CONFORM TO THE 'DEC STD-144' SPEC.

'NO FIELD FILE FOUND'

SAME AS FOR THE 'FACTORY' FILE MESSAGE ABOVE.

3.2 ERROR HALTS

ERROR HALTS ARE SUPPORTED PER DESCRIBED IN THE PREVIOUS SECTION WITH /FLAG:HOE. THERE ARE NO OTHER HALTS.

4.0 PERFORMANCE AND PROGRESS REPORTS

4.1 PERFORMANCE REPORTS

THIS PROGRAM WILL NOT GIVE ANY PERFORMANCE REPORTS.

4.2 PROGRESS REPORTS

THIS PROGRAM WILL NOT GIVE ANY PROGRESS REPORTS.

5.0 DEVICE INFORMATION TABLES

THE RL11/RLV11 CONTROLLER HAS THE FOLLOWING FOUR(4) REGISTERS FOR CONTROL OF THE SUBSYSTEM.

RLCS - CONTROL AND STATUS REGISTER (XXXXX0)

BIT 15 - COMPOSITE ERROR
BIT 14 - DRIVE ERROR
BIT 13 - NON EXISTENT MEMORY ERROR
BIT 12 - HEADER NOT FOUND (WITH BIT 10 SET)
 - DATA LATE (WITH BIT 10 CLEAR)
BIT 11 - HEADER CRC (WITH BIT 10 SET)
 - DATA CRC (WITH BIT 10 CLEAR)

BIT 10 - OPERATION INCOMPLETE
 BIT 9/8 - DRIVE SELECT (0-3)
 BIT 7 - CONTROLLER READY
 BIT 6 - INTERRUPT ENABLE
 BIT 5 - EXTENDED BUS ADDRESS (BIT 17)
 BIT 4 - EXTENDED BUS ADDRESS (BIT 16)
 BIT 3-1 - FUNCTION CODE
 0 - NOP (PDP-11) MAINT (LSI-11)
 1 - WRITE CHECK
 2 - GET DRIVE STATUS
 3 - SEEK
 4 - READ HEADER
 5 - WRITE DATA
 6 - READ DATA
 7 - READ WITHOUT HEADER COMPARE

BIT 0 - DRIVE READY

RLBA - BUS ADDRESS REGISTER (XXXXX2)

BITS 15-1 BUS ADDRESS OF DATA TRANSFER
 BIT 0 SHOULD BE 0

RLDA - DISK ADDRESS REGISTER (XXXXX4)

FOR READ/WRITE FUNCTIONS

BIT 15-7 - CYLINDER ADDRESS FOR TRANSFER
 BIT 6 - SURFACE FOR TRANSFER
 BIT 5-0 - SECTOR FOR TRANSFER (1-40.)

FOR SEEK FUNCTION

BIT 15-7 - DIFFERENCE TO NEW CYLINDER
 BIT 6-5 - MUST BE ZERO (0)
 BIT 4 - SURFACE (0=UPPER, 1=LOWER)
 BIT 3 - MUST BE ZERO (0)
 BIT 2 - SEEK DIRECTION(1=IN / 0=OUT)
 BIT 1 - MUST BE ZERO (0)
 BIT 0 - MUST BE ONE (1)

FOR GET STATUS FUNCTION

BIT 15-4 - IGNORED SHOULD BE ZERO (0)
 BIT 3 - DRIVE RESET
 BIT 2 - MUST BE ZERO (0)
 BIT 1 - MUST BE ONE (1)
 BIT 0 - MUST BE ONE (1)

RLMP - MULTIPURPOSE REGISTER

FOR READ/WRITE FUNCTION

BIT 15 - 0 - WORD COUNT (TWO'S COMPLIMENT)

FOR READ HEADER FUNCTIONBIT 15-0 - DISK HEADER OF SECTOR (FIRST READ)
- ZERO WORD (SECOND READ)
- HEADER CRC (THIRD READ)FOR GET STATUS FUNCTION

HAS DRIVE STATUS

BIT 15 - WRITE DATA ERROR
BIT 14 - CURRENT HEAD ERROR (CHE)
BIT 13 - WRITE LOCK STATUS (WL)
BIT 12 - SEEK TIME OUT (SKTO)
BIT 11 - SPIN ERROR (SPE)
BIT 10 - WRITE GATE ERROR (WGE)
BIT 9 - VOLUME CHECK (VC)
BIT 8 - DRIVE SELECT ERROR (DSE)
BIT 7 - DRIVE TYPE IS RL02 IF SET
BIT 6 - SURFACE (0=UPPER, 1=LOWER)
BIT 5 - COVER OPEN
BIT 4 - HEADS HOME
BIT 3 - BRUSHES HOME
BIT 2-0 - STATE BITS
0 - LOAD STATE
1 - SPIN UP
2 - BRUSH CYCLE
3 - LOAD HEADS
4 - SEEK - TRACK COUNTING
5 - SEEK - LINEAR MODE
6 - UNLOAD HEADS
7 - SPIN DOWN

6.0 UTILITY - SUMMARY OF COMMANDS

THIS UTILITY HAS THE FOLLOWING COMMANDS:

<u>INPUT</u>	<u>ACTION</u>
1	REPORT THE CONTENTS OF THE BAD SECTOR FILE BOTH THE 'FACTORY' AREA AND THE 'FIELD' AREA
2	ADD A SECTOR TO THE BAD SECTOR FILE IN THE 'FIELD' AREA OF THAT FILE
3	REMOVE A SECTOR FROM THE BAD SECTOR FILE - (ONLY IN THE 'FIELD' AREA)
4	READ THE PACK TO FIND BAD SPOTS (READ ONLY)
5	WRITE THE PACK WITH THE WORST CASE DATA PATTERN. THEN ISSUE THE 'VERIFY' COMMAND TO FIND BAD SPOTS.
6	ATTEMPT TO GENERATE THE BAD SECTOR FILE IF IT HAS BEEN DESTROYED ACCIDENTLY. ONLY THE 'DUMMY' ENTRY WILL BE MADE FOR THE 'FACTORY' AREA!

CZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 J 2
CZRLMB.MAC 12-DEC-79 14:06 TABLE OF CONTENTS

SE .

23	BIT AND OFFSET DEFINITIONS
90	MACRO DEFINITIONS
116	GLOBAL DATA AND CONSTANTS
219	GLOBAL MESSAGES
325	ERROR MESSAGES
408	STATISTIC CODE
416	LOAD PROTECTION TABLE
426	INITIALIZATION CODE
568	AUTO DROP SECTION
654	CLOCK INTERRUPT SERVICE ROUTINES
715	GLOBAL SUBROUTINES
841	PROGRAM MAIN LOOP
888	COMMAND QUERY LOOP
934	GLOBAL SUBROUTINES
1880	ROUTINE TO LOAD FUNCTION
1902	INTERRUPT SERVICE ROUTINE
1908	BAD SECTOR FILE ROUTINE
2135	ROUTINE TO WAIT FOR CONTROLLER READY
2157	GET STATUS/DRIVE RESET ROUTINE
2178	ROUTINE TO WRITE PACKS INITIALLY
2409	HEADS HOME ROUTINE
2445	SEEK ROUTINE
2497	ROUTINE TO CHECK FOR BAD SECTOR

CZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 ^{K 2} PAGE 1
 CZRLMB.MAC 12-DEC-79 14:06

SEQ 0023

1			.TITLE CZRLMB0 RL01/02 BD SEC FIL TL
2			.ENABLE AMA
3			.ENABLE ABS
4	002000		.=2000
5			.MCALL SVC
6			
7	002000		SVC
8		000000	SVCINS=0
9		000000	SVCTAG=0
10			
11	002000		POINTER BGNRPT,BGNSW,BGNSFT,BGNAU,BGNDU
12			
13			
14	002000		BGNMOD MDHEDR
15	002000		HEADER CZRLM,B,0,0,1
(4)	002000	103	.ASCII /C/
(4)	002001	132	.ASCII /Z/
(4)	002002	122	.ASCII /R/
(4)	002003	114	.ASCII /L/
(4)	002004	115	.ASCII /M/
(6)	002005	000	.BYTE 0
(6)	002006	000	.BYTE 0
(5)	002007	000	.BYTE 0
(4)	002010	102	.ASCII /B/
(4)	002011	060	.ASCII /O/
(4)	002012	000000	.WORD 0
(4)	002014	000000	.WORD 0
(4)	002016	035534	.WORD L\$HARD
(4)	002020	035602	.WORD L\$SOFT
(4)	002022	010122	.WORD L\$HW
(4)	002024	010130	.WORD L\$SW
(4)	002026	035704	.WORD L\$LAST
(4)	002030	000000	.WORD 0
(4)	002032	000000	.WORD 0
(4)	002034	000001	.WORD 1
(4)	002036	000000	.WORD 0
(4)	002040	010136	.WORD L\$DISPATCH
(4)	002042	000000	.WORD 0
(4)	002044	000000	.WORD 0
(4)	002046	000000	.WORD 0
(4)	002050	003	.BYTE C\$REVISION
(3)	002051	003	.BYTE C\$EDIT
(4)	002052	000000	.WORD 0
(5)	002054	000000	.WORD 0
(4)	002056	000000	.WORD 0
(4)	002060	002216	.WORD L\$DVTYP
(4)	002062	010140	.WORD L\$RPT
(4)	002064	000000	.WORD 0
(4)	002066	000000	.WORD 0
(4)	002070	011726	.WORD L\$AU
(4)	002072	011730	.WORD L\$DU
(4)	002074	000000	.WORD 0
(4)	002076	002122	.WORD L\$DESC
(4)	002100	104035	EMT E\$LOAD
(4)	002102	000000	.WORD 0
(4)	002104	010150	.WORD L\$INIT

CZRLM0 RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 L² PAGE 1-1
 CZRLMB.MAC 12-DEC-79 14:06

SEQ 0024

```

(4) 002106 011644 .WORD L$CLEAN
(4) 002110 011224 .WORD L$AUTO
(4) 002112 010142 .WORD L$PROT
(4) 002114 000000 .WORD 0
(4) 002116 000000 .WORD 0
(4) 002120 000000 .WORD 0
16 002122 ENDMOD
17
18

```

```

19 002122 DESCRIPT <CZRLM IS A UTILITY PROGRAM FOR FORMATTING BAD SECTOR FILES>
(3) 002122 055103 046122 020115 .ASCIZ /CZRLM IS A UTILITY PROGRAM FOR FORMATTING BAD SECTOR FILES/
(3) 002130 051511 040440 052440
(3) 002136 044524 044514 054524
(3) 002144 050040 047522 051107
(3) 002152 046501 043040 051117
(3) 002160 043040 051117 040515
(3) 002166 052124 047111 020107
(3) 002174 040502 020104 042523
(3) 002202 052103 051117 043040
(3) 002210 046111 051505 000
(2) 002216 .EVEN
20
21 002216 DEVTYP <RL01,RL02>
(3) 002216 046122 030460 051054 .ASCIZ /RL01,RL02/
(3) 002224 030114 000062
(2) .EVEN
22
23 .SBTTL BIT AND OFFSET DEFINITIONS
24
25 ;DEFINITIONS
26
27 002230 BGNMOD GLBEQAT
28
29 002230 EQUALS
(1) ;
(1) ; BIT DEFINITIONS
(1) ;
(1) 100000 BIT15== 100000
(1) 040000 BIT14== 40000
(1) 020000 BIT13== 20000
(1) 010000 BIT12== 10000
(1) 004000 BIT11== 4000
(1) 002000 BIT10== 2000
(1) 001000 BIT09== 1000
(1) 000400 BIT08== 400
(1) 000200 BIT07== 200
(1) 000100 BIT06== 100
(1) 000040 BIT05== 40
(1) 000020 BIT04== 20
(1) 000010 BIT03== 10
(1) 000004 BIT02== 4
(1) 000002 BIT01== 2
(1) 000001 BIT00== 1
(1) ;
(1) 001000 BIT9== BIT09
(1) 000400 BIT8== BIT08

```


CZRLMB0 RLO1/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 M 2
BIT AND OFFSET DEFINITIONS PAGE 1-2

SEQ 002

(1)	000200	BIT7==	BIT07	
(1)	000100	BIT6==	BIT06	
(1)	000040	BIT5==	BIT05	
(1)	000020	BIT4==	BIT04	
(1)	000010	BIT3==	BIT03	
(1)	000004	BIT2==	BIT02	
(1)	000002	BIT1==	BIT01	
(1)	000001	BIT0==	BIT00	
(1)		:		
(1)		:	EVENT FLAG DEFINITIONS	
(1)		:	EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION	
(1)		:		
(1)	000040	EF.START==	32.	: START COMMAND WAS ISSUED
(1)	000037	EF.RESTART==	31.	: RESTART COMMAND WAS ISSUED
(1)	000036	EF.CONTINUE==	30.	: CONTINUE COMMAND WAS ISSUED
(1)	000035	EF.NEW==	29.	: A NEW PASS HAS BEEN STARTED
(1)	000034	EF.PWR==	28.	: A POWER-FAIL/POWER-UP OCCURRED
(1)		:		
(1)		:	PRIORITY LEVEL DEFINITIONS	
(1)		:		
(1)	000340	PRI07==	340	
(1)	000300	PRI06==	300	
(1)	000240	PRI05==	240	
(1)	000200	PRI04==	200	
(1)	000140	PRI03==	140	
(1)	000100	PRI02==	100	
(1)	000040	PRI01==	40	
(1)	000000	PRI00==	0	
(1)		:		
(1)		:	OPERATOR FLAG BITS	
(1)		:		
(1)	000004	EVL==	4	
(1)	000010	LOT==	10	
(1)	000020	ADR==	20	
(1)	000040	IDU==	40	
(1)	000100	ISR==	100	
(1)	000200	UAM==	200	
(1)	000400	BOE==	400	
(1)	001000	PNT==	1000	
(1)	002000	PRJ==	2000	
(1)	004000	IXE==	4000	
(1)	010000	IBE==	10000	
(1)	020000	IER==	20000	
(1)	040000	LOE==	40000	
(1)	100000	HOE==	100000	
30				
31	000000	CS=0		: CONTROL AND STATUS OFFSET
32	000002	BA=2		: BUS ADDRESS OFFSET
33	000004	DA=4		: DISK ADDRESS OFFSET
34	000006	MP=6		: MULTI PURPOSE OFFSET
35				
36		:	CSR REGISTER	
37				
38	000001	SKDON=BIT0		
39	000001	DRDY=BIT0		: DRIVE READY

CZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A('052) 17-DEC-79 10:53 PAGE 1-3
 CZRLMB.MAC 12-DEC-79 14:06 BIT AND OFFSET DEFINITIONS

N 2

```

40      000100      INTEN=BIT6      ;INTERRUPT ENABLE
41      100000      ERR=BIT15      ;COMPOSITE ERROR
42      040000      DERR=BIT14      ;DRIVE ERROR
43      020000      NXM=BIT13      ;NON-EXISTENT MEMORY ERROR
44      010000      DLT=BIT12      ;DATA LATE
45      004000      DCRC=BIT11      ;DATA CRC ERROR
46      004000      HCRC=BIT11      ;HEADER CRC ERROR
47      010000      HNF=BIT12      ;HEADER NOT FOUND ERROR
48      002000      OPI=BIT10      ;OPERATION INCOMPLETE ERROR
49      000200      CRDY=BIT7      ;CONTROLLER READY
50      000040      BA17=BIT5      ;EXTENDED BUS ADDRESS BIT 17
51      000020      BA16=BIT4      ;EXTENDED BUS ADDRESS BIT 16
52
53      ;GET STATUS BITS
54
55      100000      WDE=BIT15      ;WRITE DATA ERROR
56      040000      HCE=BIT14      ;HEAD CURRENT ERROR
57      020000      WL=BIT13      ;WRITE LOCK
58      010000      SKTO=BIT12      ;SEEK TIMEOUT ERROR
59      004000      SPE=BIT11      ;SPINDLE TIMEOUT/UNDER/OVER SPEED
60      002000      WGE=BIT10      ;WRITE GATE ERROR
61      001000      VC=BIT9      ;VOLUME CHECK
62      000400      DSE=BIT8      ;DRIVE SELECT ERROR
63      000040      COP=BIT5      ;TOP COVER OPEN
64      000020      HOP=BIT4      ;HEADS OVER PACK
65      000010      BRHM=BIT3      ;BRUSHES HOME
66
67      ;COMMANDS
68
69      000002      WRCHK=BIT1      ;WRITE CHECK FUNCTION CODE
70      000004      GSTAT=BIT2      ;GET DRIVE STATUS FUNCTION CODE
71      000006      SEEK=BIT1!BIT2      ;SEEK FUNCTION CODE
72      000010      RDHDR=BIT3      ;READ HEADER FUNCTION CODE
73      000012      WRITE=BIT3!BIT1      ;WRITE FUNCTION CODE
74      000014      READ=BIT3!BIT2      ;READ FUNCTION CODE
75      000013      DRST=BIT3!BIT1!BIT0      ;DRIVE RESET COMMAND CODE FOR DRIVE COMMAND WORD
76      000003      GSBIT=BIT1!BIT0      ;GET STATUS COMMAND CODE FOR DRIVE COMMAND WORD
77      000001      MK=BIT0      ;MARKER BIT FOR DRIVE COMMAND WORD(SEEK,GET STATUS)
78      000004      SIGN=BIT2      ;DIRECTION FOR SEEK(0=AWAY FROM SPINDLE)
79      000020      SKHS=BIT4      ;HEAD SELECT FOR SEEK
80      000100      HEAD=BIT6      ;HEAD SELECT FOR READ,WRITE,GET STATUS
81
82      ;OFFSET FOR HARDWARE P-TABLE
83      000000      CSR=0
84      000002      DRBT=2
85
86      002230      ENDMOD
87
88

```

```

90      .SBTTL  MACRO DEFINITIONS
91
92      ;DELAY EXECUTION OF PROGRAM A SPECIFIED NUMBER OF 100-MILLISECOND TIME COUNTS
93      .MACRO  WAITMS  ARG,?WAIT
94              MOV     #ARG,DLYCNT      ;INITIALIZE DELAY COUNTER
95              ASL     DLYCNT           ;MULTIPLY ARGUMENT BY 2
96              ASL     DLYCNT           ;MULTIPLY ARGUMENT BY 2 AGAIN
97      WAIT:   DELAY   #250.           ;IMPLEMENT 25-MS TIME DELAY
98              DEC     DLYCNT           ;DECREMENT DELAY COUNT
99              BNE     WAIT             ;BRANCH IF TIME DELAY NOT EXPIRED
100     .ENDM
101
102      ;DELAY EXECUTION OF PROGRAM A SPECIFIED NUMBER OF 100-MICROSECOND TIME COUNTS
103      .MACRO  WAITUS  ARG
104              DELAY   #ARG             ;IMPLEMENT 100-US TIME DELAY, ARGUMENT SPECIFIES
105                                           ;/THE NUMBER OF 100-US TIME COUNTS
106      .ENDM
107
108      ;ACTIVATE THE CLOCK TO INITIATE THE GENERATION OF CLOCK INTERRUPTS
109      .MACRO  CLKON
110              JSR     PC,CLKINI        ;INITIALIZE THE CLOCK
111              JSR     PC,CLKST        ;START THE CLOCK
112
113      .ENDM
114

```

```

116          .SBTTL  GLOBAL DATA AND CONSTANTS
117
118 002230      BGNMOD  GLBDAT
119 002230      ERRCNT: .WORD 0          ;ERROR COUNT - HARD
120 002232      SFTCNT: .WORD 0          ;ERROR COUNT - SOFT
121 002234      SKECNT: .WORD 0          ;SEEK ERROR COUNT
122 002236      DERCNT: .WORD 0          ;DRIVE ERROR COUNT
123 002240      WRTCNT: .WORD 0          ;WRITE PASS COUNT PER TRACK
124 002242      RETRY:  .WORD 0          ;PRESENT RETRY NUMBER
125 002244      BDA:    .WORD 0          ;DISK ADDRESS CONTENTS
126 002246      BMP:    .WORD 0          ;PRESENT MULTIPURPOSE CONTENTS
127 002250      DCS:    .WORD 0          ;CSR ADDRESS
128 002252      E.DCS:  .WORD 0          ;CONTENTS OF RLCS AT ERROR
129 002254      E.STAT: .WORD 0          ;STATUS AT FAILURE TIME
130 002256      BBA:    .WORD 0          ;PRESENT BUS ADDRESS CONTENTS
131 002260      FUNC:   .WORD 0          ;LAST FUNCTION LOADED
132 002262      BCSADR: .WORD 0          ;CSR IMAGE OF LAST COMMAND
133 002264      LSTHDR: .WORD 0          ;LAST POSITION ON DISK
134 002266      PRFLGS: .WORD 0          ;INTERNAL FLAGS
135 002270      LSTDA:  .WORD 0          ;DISK ADDRESS AT SOFT ERROR
136 002272      DIFWD:  .WORD 0          ;LAST DIFFERENCE WORD OF SEEK
137 002274      SERNM1: .WORD 0          ;SERIAL NUMBER OF CARTRIDGE
138 002276      SERNM2: .WORD 0          ;SERIAL NUMBER OF CARTRIDGE
139 002300      NEWFAC: .WORD 0          ;FLAG TO BUILD A DUMMY FACTORY FILE
140 002302      DRSEL:  .WORD 0          ;DRIVE SELECT BITS(8,9)
141 002304      BSECPT: .WORD 0          ;PCINTER TO BAD SECTOR FILE DATA STORAGE
142 002306      RSEEK:  .WORD 0          ;SEEK IN PROCESS OF RECOVERY
143 002310      SOFTCS: .WORD 0          ;CSR OF SOFT ERROR
144 002312      FWDFLG: .WORD 0          ;SAWTOOTH WRITE CONTROL FLAG
145 002314      CVFLG:  .WORD 0          ;'CALL' FLAG FOR VERIFY ROUTINE
146 002316      TDR:    .WORD 0          ;TYPE OF DRIVE... RL01=1 RL02=2
147 002320      WRIPG:  .WORD 0          ;WRITE IN PROGRESS FLAG
148 002322      PRPOS:  .WORD 0          ;PRESENT POSITION ON DISK
149 002324      NEWPOS: .WORD 0          ;NEW DESIRED CYLINDER ADDRESS
150 002326      RECNT:  .WORD 0          ;READ ERROR COUNT
151 002330      NXTUNI: .WORD 0          ;POINTER OF UNIT SELECT SLOT IN 'SELTL'
152 002332      SYMSK:  .WORD 0          ;MASK FOR 0-7 DRIVES
153 002334      CYLSK:  .WORD 100177     ;MASK FOR CYLINDER ONLY (RL01)
154 002336      SECMSK: .WORD 100077     ;MASK OUT SECTOR BITS (RL01)
155 002340      CMSK:   .WORD 000177     ;CYL MASK FOR RL02
156 002342      SMSK:   .WORD 000077     ;SECT MASK FOR RL02
157 002344      PASWD:  .WORD 000000     ;PASSWORD (IF=0 THEN NO CHECKING)
158 002346      WRINIT: .WORD 0          ;WRITE INIT FLAG
159 002350      BVEC:    .WORD 160        ;VECTOR
160 002352      BPRIOR: .WORD 240        ;PRIORITY 5
161 002354      CLKFRQ: .WORD 0          ;CLOCK FREQUENCY FLAG, 1=60HZ, 2=50HZ
162 002356      CLKTP:  .WORD 0          ;CLOCK TYPE FLAG, 1=P-CLOCK, 2=L-CLOCK
163 002360      CLKADR: .WORD 0          ;POINTER TO ADDRESS OF SUPERVISOR CLOCK TABLE
164 002362      DLYCNT: .WORD 0          ;DELAY COUNTER FOR WAITMS TIMING MACRO
165 002364      CLKSON: .WORD 0          ;'CLOCK ON' INDICATOR
166 002366      CLKCNT: .WORD 0          ;CLOCK COUNTER TO STORE CLOCK TICK COUNT
167 002370      CLKBFR: .WORD 0          ;CLOCK BUFFER TO STORE CLOCK TICK COUNT
168 002372      SYSClk: .WORD 0          ;FLAG INDICATING PRESENCE OF A SYSTEM CLOCK
169 002374      LOGUNIT: .WORD 0          ;LOGICAL UNIT UNDER TEST
170 002376      CLKFLD: .WORD 0          ;CLOCK FIELD TO CHECK IF LSI-11 CLOCK
171          ;/IS 'TICKING'

```

```

172
173
174
175
176 002400 000000 LSTDR1: .WORD 0 ;BUFFER POINTER OF DRIVE
177 002402 000000 BCSR: .WORD 0 ;CSR FROM P-TABLE
178 002404 000000 BDRSEL: .WORD 0 ;DRIVE UNIT NUMBER FROM P-TABLE
179 002406 000000 HDRFND: .WORD 0 ;FLAG TO INDICATE HDR IN BAD LIST
180 002410 000000 CHKSEC: .WORD 0 ;SECTOR OF ERROR - USED BY BAD SECTOR LOCATION
181 002412 000000 DECNT: .WORD 0 ;DATA ERROR COUNT
182 002414 000000 TEMPO: .WORD 0 ;TEMP LOCATION
183 002416 000000 TEMP1: .WORD 0 ;TEMP LOCATION
184 002420 000000 TEMP2: .WORD 0 ;TEMP LOCATION
185 002422 000000 TEMP3: .WORD 0 ;TEMP LOCATION
186 002424 000000 TICK: .WORD 0 ;STORAGE FOR TICK COUNT
187 002426 000000 SECOND: .WORD 0 ;SECONDS OF SYSTEM CLOCK
188 002430 000000 MINUTE: .WORD 0 ;MINUTES OF SYSTEM CLOCK
189 002432 000000 HOUR: .WORD 0 ;HOURS OF SYSTEM CLOCK
190 002434 000000 E.CS: .WORD 0 ;IMAGES OF REGISTERS
191 002436 000000 E.BA: .WORD 0 ;ON INTERRUPT
192 002440 000000 E.DA: .WORD 0 ;
193 002442 000000 E.MP: .WORD 0 ;
194 002444 000000 E.MP1: .WORD 0 ;
195 002446 000000 E.MP2: .WORD 0 ;
196 002450 000000 BUF1: .WORD 0 ;BUFFER FOR FIRST CONTROLLER
197 002452 000000 MAXWC: .WORD 0 ;MAX WORD COUNT DETERMINED BY CORE
198 002454 000000 UUT: .WORD 0 ;NUMBER OF UNITS ON SYSTEM
199 002456 000000 SN1: .WORD 0 ;TYPED SERIAL # - LOW
200 002460 000000 SN2: .WORD 0 ; " " " " " " HIGH
201 002462 000000 WRTLOK: .WORD 0 ;WRITE LOCK FLAG
202 002464 000000 ACCESS: .WORD 0 ;ACCESS PRIV FOR UPDATING
203 002466 000000 PWRFLG: .WORD 0 ;POWER FAIL INDICATOR
204 002470 000000 TRPFLG: .WORD 0 ;TRAP OCCURRENCE FLAG
205 002472 000000 CNTFLG: .WORD 0 ;CONTINUE FLAG
206 002474 000000 STFLG: .WORD 0 ;START FLAG
207 002476 000000 BSFFLG: .WORD 0 ;BAD SECTOR FILE FLAG (FACTORY BSF=0, FIELD BSF=1)
208 002500 000000 CPYCNT: .WORD 0 ;COUNTER FOR DUPLICATING COPIES OF THE 'FIELD'
209 ;/BAD SECTOR FILE ON THE PACK
210 002502 000000 FRSIER: .WORD 0 ;ADDRESS OF ERROR FOUND IN MAIN PROGRAM
211 ;
212 ;END OF MASS CLEAR
213 ;
214 002504 000004 ERRVEC: .WORD 4 ;ERROR VECTOR
215
216 002506
217 ENDMOD

```

: GLOBAL TEXT

277 003004

046122	051503	C20072
050	046122	051503
040520	045503	051440
054503	044514	042116
040	042510	042101
052	025052	025052
055	026440	026440
047	044506	046105
043047	041501	047524
047	047523	052106
044047	051101	023504
123	043117	020124
102	044525	042114
102	044525	042114
040	042523	052103
101	020124	047105
123	042505	020113
047523	052106	042440
104	044522	042526
051104	053111	020105
040510	042122	042440
104	044522	042526
040520	045503	044440
120	041501	020113
047516	043040	041501
047516	043040	041501
047516	043040	042511
047516	043040	042511
047516	051440	041525
047503	050115	042514
120	047522	051107
124	046511	047505
116	020117	051104
040	051104	053111
047105	042524	020122
125	042120	052101
105	052116	054522
122	040505	044504
051127	052111	020105
020061	020040	042522
062	020040	040440
063	020040	042040
020064	020040	042526
020065	020040	051127
066	020040	046440
020067	020040	051120
105	052116	051105
047503	052116	047105

```

MRLCS: .ASCII2 'RLCS: ''
CRLCS: .ASCII2 ''(RLCS): ''
CACT: .ASCII2 /PACK SERIAL NO.: /
CMMSG: .ASCII2 /CYLINDER: /
HMSG: .ASCII2 / HEAD: /
STARTMSG: .ASCII2 /*****
HYPHEN: .ASCII2 /- - - - -
TFMSG: .ASCII2 /'FIELD' ENTRIES = /
TFMSG: .ASCII2 /'FACTORY' ENTRIES = /
TSOFT: .ASCII2 /'SOFT' ERRORS FOUND = /
THARD: .ASCII2 /'HARD' ERRORS FOUND = /
MSREC: .ASCII2 /SOFT ERROR RECOVERED.../
MBLD: .ASCII2 /BUILD A DUMMY BAD SECTOR FILE/
BUILD: .ASCII2 /BUILD A BAD SECTOR FILE/
SMSG: .ASCII2 / SECTOR: /
BSEND: .ASCII2 /AT END OF FILE /
MSKER: .ASCII2 /SEEK ERROR/
MSFER: .ASCII2 /SOFT ERROR ENCOUNTERED/
MDERS: .ASCII2 /DRIVE ERROR WILL NOT RESET/
MRDER: .ASCII2 /DRIVE ERROR RECOVERED/
MHDER: .ASCII2 /HARD ERROR/
NOLOAD: .ASCII2 /DRIVE WOULD NOT LOAD/
WRTLCK: .ASCII2 /PACK IS WRITE LOCKED/
NEWLD: .ASCII2 /PACK WAS JUST LOADED/
HWSEC: .ASCII2 /NO FACTORY FILE ENTRIES/
NHWSEC: .ASCII2 /NO FACTORY FILE FOUND/
SWSEC: .ASCII2 /NO FIELD FILE ENTRIES/
NSWSEC: .ASCII2 /NO FIELD FILE FOUND/
NOFLDE: .ASCII2 /NO SUCH ENTRY IN 'FIELD' FILE/
MDONE: .ASCII2 /COMPLETED.../
PRGER: .ASCII2 /PROGRAM 'BUG' - DRIVE NOT READY/
NOCRDY: .ASCII2 /TIMEOUT - NO 'CRDY'/
NODRIV: .ASCII2 /NO DRIVES/
DRVM: .ASCII2 / DRIVE: /
PASWORD: .ASCII2 /ENTER PASSWORD TO ENABLE BAD SECTOR FILE UPDATES/
DENIED: .ASCII2 /UPDATING DENIED - INVALID PASSWORD!/
EXISTS: .ASCII2 /ENTRY ALREADY EXISTS IN BAD SECTOR FILE/
VERIFY: .ASCII2 /READING PACK/
MWRT: .ASCII2 /WRITE PACK WITH WORST CASE DATA PATTERN/
CMD1: .ASCII2 /1 REPORT CONTENTS OF THE BAD SECTOR FILE/
CMD2: .ASCII2 /2 ADD A SECTOR TO THE 'FIELD' BAD SECTOR FILE/
CMD3: .ASCII2 /3 DELETE A SECTOR FROM THE 'FIELD' BAD SECTOR FILE/
CMD4: .ASCII2 /4 VERIFY PACK - READ ONLY/
CMD5: .ASCII2 /5 WRITE PACK WITH WORST CASE DATA PATTERN AND VERIFY/
CMD6: .ASCII2 /6 MAKE A BAD SECTOR FILE/
CMD7: .ASCII2 /7 PRINT HELP MESSAGE/
CMDDO: .ASCII2 /ENTER COMMAND (1 - 7) - /
BSRM: .ASCII2 /CONTENTS OF THE 'FACTORY' BAD SECTOR FILE:/

```

```

278 005057      103 047117 042524 BSRF: .ASCIZ /CONTENTS OF THE 'FIELD' BAD SECTOR FILE:/
279 005130      040502 020104 042522 BADBSF: .ASCIZ /BAD READ OF BAD SECTOR FILE/
280 005164      042101 020104 054503 ABSMSG: .ASCIZ /ADD CYLINDER, SECTOR, & HEAD TO 'FIELD' BAD SECTOR FILE/
281 005254      054503 044514 042116 DELCYL: .ASCIZ /CYLINDER (0 TO 511.) - /
282 005254      042523 052103 051117 ABSSECT: .ASCIZ /SECTOR (0 TO 39.) - /
283 005304      042523 052103 051117 DELHDT: .ASCIZ /HEAD (0 OR 1) - /
284 005331      047516 041440 051101 ABSSER: .ASCIZ /NO CARTRIDGE SERIAL NO. - ADD ONE?/
285 005331      047516 041440 051101 ABSSNL: .ASCIZ /INPUT THE LOW 5 OCTAL DIGITS OF SERIAL NO. /
286 005331      047516 041440 051101 ABSSNH: .ASCIZ /INPUT THE HIGH 5 OCTAL DIGITS OF SERIAL NO. /
287 005352      047516 041440 051101 DOWRT: .ASCIZ /WRITE THE UPDATED BAD SECTOR FILE/
288 005415      047516 041440 051101 BADWRT: .ASCIZ /CANNOT UPDATE BAD SECTOR FILE ON PACK/
289 005471      047516 041440 051101 DELMSG: .ASCIZ /DELETE A 'FIELD' BAD SECTOR FILE ENTRY/
290 005546      047516 041440 051101 NOENTRY: .ASCIZ /NO SUCH ENTRY TO DELETE!/
291 005610      047516 041440 051101 RL1CLM: .ASCIZ /RL01 MAX CYLINDER = 255./
292 005656      047516 041440 051101 VALSN: .ASCIZ /IS THIS SERIAL NO. VALID/
293 005725      047516 041440 051101 TBLFUL: .ASCIZ /MORE THAN 25. BAD SPOTS FOUND ON THIS PACK./
294 006007      047516 041440 051101 TILLEND: .ASCIZ /CONTINUE TO END OF FILE/
295 006040      047516 041440 051101 MSTWRT: .ASCIZ /WRITE ON ALL SELECTED PACKS/
296 006114      047516 041440 051101 NEWENT: .ASCIZ /NEW ENTRY.../
297 006144      047516 041440 051101 ERRAT: .ASCIZ /XFER ERROR AT PACK ADDRESS /
298 006200      047516 041440 051101 OVRMAX: .ASCIZ /RL01-RL02 CARTRIDGE SPEC ALLOWS MAX OF 16. BAD SECTORS/
299 006215      047516 041440 051101 OK: .ASCIZ /FOUND/
300 006251      047516 041440 051101 INBSF: .ASCIZ /ABOVE SECTOR IS IN BAD SECTOR FILE/
301 006340      047516 041440 051101 CKFACT: .ASCIZ /CHECKING FOR 'FACTOR,' FILE.../
302 006346      047516 041440 051101 CKFLD: .ASCIZ /CHECKING FOR 'FIELD' FILE.../
303 006411      047516 041440 051101 NOTRDY: .ASCIZ /DRIVE DROPPED - DID NOT RESPOND WITH 'READY'/
304 006450      047516 041440 051101 MDRTYP: .ASCIZ /DRIVE TYPE = RL0/
305 006505      047516 041440 051101 SAWFWD: .ASCIZ /- SAWTOOTH FROM CYLINDER 0/
306 006562      047516 041440 051101 SAWREV: .ASCIZ /- SAWTOOTH FROM LAST CYLINDER/
307 006603      047516 041440 051101 WRPKF: .ASCIZ /WRITING PACK FORWARD /
308 006636      047516 041440 051101 WRPKR: .ASCIZ /WRITING PACK REVERSE /
309 006674      047516 041440 051101 THISDRV: .ASCIZ /USE THIS SELECTED UNIT/
310 006722      047516 041440 051101 NOCLK: .ASCIZ /SYSTEM CLOCK IS NOT AVAILABLE/
311 006750      047516 041440 051101 NOTIM: .ASCIZ /RUN TIMES CANNOT BE REPORTED/
312 006777      047516 041440 051101 NOCTLR: .ASCIZ /DRIVE DROPPED - NO CONTROLLER/
313 007035      047516 041440 051101
314 007072      047516 041440 051101
315
316
317 .NLIST CND,MD,ME
318 .LIST BEX
319 .EVEN
320
321 007130
322
  
```

ENDMOD

```

324
325
326 .SBTTL ERROR MESSAGES
327 BGNMOD GLBERR
328
329 BGNMSG ERR1
330 007130 010146 MOV R1,-(SP) ;SAVE R1
331 ;ROUTINE TO REPORT THE POSITION OF CYLINDER, SECTOR & HEAD
332
333 007132 004537 012502 JSR R5,PTIME ;PRINT RUN TIME
334 007136 013737 002410 015334 MOV CHKSEC,BSFSEC ;GET THE SECTOR IN ERROR
335 007144 042737 177700 015334 BIC #177700,BSFSEC ;CLEAR THE JUNK BITS
336 007152 005037 015336 CLR BSFHD ;CLEAR THE HEAD #
337 007156 032737 000100 002410 BIT #100,CHKSEC ;HEAD ???
338 007164 001402 BEQ 1$ ;NO
339 007166 005237 015336 INC BSFHD ;YES - SET IT TO 1
340 007172 013737 002410 015332 1$: MOV CHKSEC,BSFCYL ;GET ADDR AGAIN FOR THE CYLINDER
341 007200 042737 000177 015332 BIC #177,BSFCYL ;CLEAR THE HEAD & SECTOR #
342 007206 000337 015332 SWAB BSFCYL
343 007212 000241 CLC ;CLEAR THE 'C' BIT
344 007214 006137 015332 ROL BSFCYL ;POSITION
345 007220 103002 BCC 2$ ;BR IF DON'T NEED OTHER BIT
346 007222 005237 015332 INC BSFCYL ;ADD IN THE LOW ORDER BIT
347 007226 2$: PRINTB #FMT16,#ERRAT,#CMMSG,BSFCYL,#SMSG,BSFSEC,#HMSG,BSFHD
(14) 007226 013746 015336 MOV BSFHD,-(SP)
(13) 007232 012746 002563 MOV #HMSG,-(SP)
(12) 007236 013746 015334 MOV BSFSEC,-(SP)
(11) 007242 012746 003243 MOV #SMSG,-(SP)
(10) 007246 013746 015332 MOV BSFCYL,-(SP)
(9) 007252 012746 002550 MOV #CMMSG,-(SP)
(8) 007256 012746 006215 MOV #ERRAT,-(SP)
(7) 007262 012746 007503 MOV #FMT16,-(SP)
(6) 007266 012746 000010 MOV #10,-(SP)
(3) 007272 010600 MOV SP,R0
(4) 007274 104414 TRAP C$PNTB
(4) 007276 062706 000022 ADD #22,SP
348 007302 004537 025422 JSR R5,GETDST ;GET THE DRIVE STATUS
349 007306 010137 002254 MOV R1,E.STAT
350 007312 PRINTB #FMT17A,#CRLCS,E.DCS,E.STAT,E.DA
(11) 007312 013746 002440 MOV E.DA,-(SP)
(10) 007316 013746 002254 MOV E.STAT,-(SP)
(9) 007322 013746 002252 MOV E.DCS,-(SP)
(8) 007326 012746 002515 MOV #CRLCS,-(SP)
(7) 007332 012746 007554 MOV #FMT17A,-(SP)
(6) 007336 012746 000005 MOV #5,-(SP)
(3) 007342 010600 MOV SP,R0
(4) 007344 104414 TRAP C$PNTB
(4) 007346 062706 000014 ADD #14,SP
351 007352 PRINTB #MCRLF
(7) 007352 012746 010041 MOV #MCRLF,-(SP)
(6) 007356 012746 000001 MOV #1,-(SP)
(3) 007362 010600 MOV SP,R0
(4) 007364 104414 TRAP C$PNTB
(4) 007366 062706 000004 ADD #4,SP
352 007372 012601 MOV (SP)+,R1 ;RESET R1
353 007374 ENDMMSG

```



```
(3) 007374 L10000:
(3) 007374 104423 TRAP C$MSG
354
355 007376 BGNMSG ERR2
356 007376 010146 MOV R1,-(SP) ;SAVE R1
357 007400 004537 025422 JSR R5,GETDST ;GET THE DRIVE STATUS
358 007404 010137 002254 MOV R1,E,STAT ;SAVE STATUS FOR PRINTING
359 007410 PRINTB #FMT17A,#CRLCS,E.DCS,E,STAT,E,DA
(11) 007410 013746 002440 MOV E,DA,-(SP)
(10) 007414 013746 002254 MOV E,STAT,-(SP)
(9) 007420 013746 002252 MOV E,DCS,-(SP)
(8) 007424 012746 002515 MOV #CRLCS,-(SP)
(7) 007430 012746 007554 MOV #FMT17A,-(SP)
(6) 007434 012746 000005 MOV #5,-(SP)
(3) 007440 010600 MOV SP,R0
(4) 007442 104414 TRAP C$PNTB
(4) 007444 062706 000014 ADD #14,SP
360 007450 PRINTB #MCRLF
(7) 007450 012746 010041 MOV #MCRLF,-(SP)
(6) 007454 012746 000001 MOV #1,-(SP)
(3) 007460 010600 MOV SP,R0
(4) 007462 104414 TRAP C$PNTB
(4) 007464 062706 000004 ADD #4,SP
361 007470 012601 MOV (SP)+,R1 ;RESET R1
362 007472 ENDMMSG
(3) 007472 L10001:
(3) 007472 104423 TRAP C$MSG
366 007474 047045 052045 047045 FMT15: .ASCIZ /%N%T%N/
367 007503 045 022516 022524 FMT16: .ASCIZ /%N%T%T%Z3%A.%T%Z2%A.%T%D1%N/
368 007537 045 022516 022524 FMT17: .ASCIZ /%N%T%06%T%01/
369 007554 052045 047445 022466 FMT17A: .ASCIZ /%T%06%A STATUS WAS: %06%A (DA): %06%N/
370 007624 047045 052045 000 FMT18: .ASCIZ /%N%T/
371 007631 045 022516 022516 FMT19: .ASCIZ /%N%N%T/
372 007640 047045 040445 040502 FMT20: .ASCIZ /%N%ABAD SECTOR FILE HAS %Z3%A. ENTRIES/
373 007707 045 022516 022524 FMT21: .ASCIZ /%N%T%05%05%N/
374 007724 047045 052045 055045 FMTTB: .ASCIZ /%N%T%Z3%A./
375 007737 045 022516 031132 FMTCSH: .ASCIZ /%N%Z2%A. %T%Z3%A.%T%Z2%A.%T%D1/
376 007777 045 022516 022516 FMTMS: .ASCIZ /%N%N%ACOMMANDS AVAILABLE ARE:%N%T/
377 010041 045 000116 MCRLF: .ASCIZ /%N/
378 010044 052045 000 MSG: .ASCIZ /%T/
379 010047 045 022516 052101 TIME: .ASCIZ /%N%ATIME: %Z2%A:%Z2%A:%Z2%A /
380 010105 045 022516 022524 FDTYP: .ASCIZ /%N%T%01%N/
381
385
386 010120 .EVEN
387 010120 ENDMOD
388
389 010120 BGNMOD HPTCODE
390 010120 BGNHW
(3) 010120 000002 .WORD L10002-L$HW/2
391 010122 174400 .WORD 174400 ;CSR BASE ADDRESS DEFAULT
392 010124 000000 .WORD 0 ;DRIVE UNIT NUMBER DEFAULT
393 010126 ENDMOD
(3) 010126 L10002: ENDMOD
394 010126 BGNMOD SPTCODE
395 010126
```

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-11
ERROR MESSAGES

SEQ 0034

```

396 010126          BGNSW
(3) 010126 000002    WRTSAW: .WORD  L10003-LSSW/2
397 010130 000001    WRTLIM: .WORD  1      ;DEFAULT TO SAWTOOTH WRITE CYCLE
398 010132 000002    ENDSW      ;DEFAULT TO 2 WRITE PASSES PER TRACK
399 010134
(3) 010134          L10003:
400 010134          ENDMOD
401
402 010134          BGNMOD  DSPCODE
403
404 010134          DISPATCH  1
(4) 010134 000001    .WORD  1
(6) 010136 012716    .WORD  T1
405
406 010140          ENDMOD
407
408          .SBTTL  STATISTIC CODE
409
410 010140          BGNMOD  RPTCODE
411 010140          BGNRPT
412 010140          ENDRPT
(3) 010140          L10004:
(3) 010140 104425    TRAP      CSRPT
413 010142          ENDMOD
414
415
416          .SBTTL  LOAD PROTECTION TABLE
417
418 010142          BGNPROT
419 010142 000000    .WORD  0      ;P-TABLE OFFSET OF CSR
420 010144 177777    .WORD  -1     ;NOT A MASS-BUS DRIVE
421 010146 000010    .WORD  10     ;P-TABLE OFFSET OF DRIVE
422 010150          ENDPROT
423
424

```

CZRLMBO RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 J 3
INITIALIZATION CODE PAGE 1-12

SEQ 0034

```

426          .SBTTL  INITIALIZATION CODE
427
428 010150      BGNMOD  INITCODE          ;START OF INITIALIZE CODE
429
430 010150      BGNINIT
431
432 010150      SETPRI  #340              ;PRIORITY TO 7 TO INHIBIT INTERRUPTS
(3) 010150 012700 000340      MOV      #340,R0
(3) 010154 104441      TRAP      C$SPRI
433
434 010156      BRESET                    ;FOR LSI-11 CPU'S
(3) 010156 104433      TRAP      C$RESET
435 010160 005037 002474      CLR      STFLG
436 010164 005037 002472      CLR      CNTFLG
437 010170 005037 002466      CLR      PWRFLG
438          ;CHECK FOR PRESENCE OF A SYSTEM CLOCK
439 010174      CLOCK  P,CLKADR          ;P-CLOCK?
(3) 010174 012700 000120      MOV      #P,R0
(3) 010200 104462      TRAP      C$CLK
(3) 010202 010037 002360      MOV      R0,CLKADR
440 010206      BNCOMPLETE  LCLKCH      ;BRANCH IF NO P-CLOCK
(2) 010206 103006      BCC      LCLKCH
441 010210 012737 000001 002356      MOV      #1,CLKTYP
442 010216 005237 002372      INC      SYSCLK
443 010222 000522      BR      PWRCH
444 010224      LCLKCH: CLOCK  L,CLKADR  ;L-CLOCK?
(3) 010224 012700 000114      MOV      #L,R0
(3) 010230 104462      TRAP      C$CLK
(3) 010232 010037 002360      MOV      R0,CLKADR
445 010236      BCOMPLETE  1$          ;BRANCH IF L-CLOCK
(2) 010236 103401      BCS      1$
446 010240 000467      BR      NILCLK
447 010242      1$:  READBUS
(3) 010242 104407      TRAP      C$RDBU
448 010244      BNCOMPLETE  2$          ;BRANCH IF NOT Q-BUS
(2) 010244 103057      BCC      2$
449 010246 005037 002376      CLR      CLKFLD
450 010252      SETVEC  #100,#CLKTIK,#340
(7) 010252 012746 000340      MOV      #340,-(SP)
(6) 010256 012746 012124      MOV      #CLKTIK,-(SP)
(5) 010262 012746 000100      MOV      #100,-(SP)
(4) 010266 012746 000003      MOV      #3,-(SP)
(3) 010272 104437      TRAP      C$SVEC
(2) 010274 062706 000010      ADD      #10,SP
451
452 010300      SETPRI  #240              ;/IF CLOCK IS 'TICKING'
(3) 010300 012700 000240      MOV      #240,R0
(3) 010304 104441      TRAP      C$SPRI
453 010306      WAITMS  #5              ;SET PRIORITY TO 5 TO ALLOW CLOCK INTERRUPTS
(3) 010324 012727 000372      MOV      ##250.,(PC)+
(3) 010330 000000      .WORD      0
(3) 010332 013727 002116      MOV      L$DLY,(PC)+
(3) 010336 000000      .WORD      0
(3) 010340 005367 177772      DEC      -6(PC)
(3) 010344 001375      BNE      -4
(3) 010346 005367 177756      DEC      -22(PC)

```

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 K 3
INITIALIZATION CODE

SEQ 0034

```

(3) 010352 001367      BNE      -20
454 010362             SETPRI   #340      ;RESTORE PRIORITY TO 7 TO INHIBIT INTERRUPTS
(3) 010362 012700 000340 MOV      #340,R0
(3) 010366 104441      TRAP     C$SPRI
455 010370             CLRVEC   #100      ;CLEAR L-CLOCK INTERRUPT VECTOR
(3) 010370 012700 000100 MOV      #100,R0
(3) 010374 104436      TRAP     C$CVEC
456 010376 005737 002376 TST      CLKFLD
457 010402 001406      BEQ      NILCLK    ;L-CLOCK 'TICKS'?
458 010404 012737 000002 002356 2$: MOV    #2,CLKTYP ;BRANCH IF NO 'TICKS':
459 010412 005237 002372      INC     SYSCLK ;IDENTIFY L-CLOCK TYPE
460 010416 000424      BR       PWRCH     ;INDICATE PRESENCE OF A SYSTEM CLOCK
461 010420             NILCLK: PRINTF #FMT15,#NOCLK ;BRANCH TO CHECK POWER
(8) 010420 012746 006777      MOV      #NOCLK,-(SP) ;REPORT 'SYSTEM CLOCK IS NOT AVAILABLE'
(7) 010424 012746 007474      MOV      #FMT15,-(SP)
(6) 010430 012746 000002      MOV      #2,-(SP)
(3) 010434 010600      MOV      SP,R0
(4) 010436 104417      TRAP     C$PNTF
(4) 010440 062706 000006      ADD      #6,SP
462 010444             PRINTF   #FMT15,#NOTIM ;PRINT 'RUN TIMES CANNOT BE REPORTED'
(8) 010444 012746 007035      MOV      #NOTIM,-(SP)
(7) 010450 012746 007474      MOV      #FMT15,-(SP)
(6) 010454 012746 000002      MOV      #2,-(SP)
(3) 010460 010600      MOV      SP,R0
(4) 010462 104417      TRAP     C$PNTF
(4) 010464 062706 000006      ADD      #6,SP
463             ;POWER FAIL SEQUENCE
464 010470             PWRCH: REAFDF #EF.PWR
(3) 010470 012700 000034      MOV      #EF.PWR,R0
(3) 010474 104447      TRAP     C$REFG
465 010476             BNCOMPLETE 3$
(2) 010476 103106      BCC      3$
466 010500 005237 002466      INC      PWRFLG
467 010504 013702 002454      MOV      UUT,R2
468 010510 005302      DEC      R2
469 010512 006302      ASL      R2
470 010514 006302      ASL      R2
471 010516 062702 011162      ADD      #SELTBL,R2
472 010522 012237 002250      11$: MOV    (R2)+,DCS ;POINT TO THE CORRECT SLOT
473 010526 011237 002302      MOV      (R2),DRSEL ;GET THE DCS ADDRESS
474 010532 052737 000200 002302      BIS      #200,DRSEL ;AND GET THE DRIVE BITS
475 010540 013777 002302 171502      MOV      DRSEL,ADCS ;ADD IN THE CRDY BIT
476 010546 012701 000170      MOV      #120,R1 ;SELECT THE DRIVE
477 010552 032777 000001 171470 12$: BIT    #1,ADCS ;INITIALIZE WAIT COUNT
478 010560 001040      BNE      14$      ;DRIVE READY UP?
479             ;YES - RESET DRIVE & HEADS HOME
480 010562             WAITMS   #10.      ;WAIT A WHILE
(3) 010600 012727 000372      MOV      #250.,(PC)+
(3) 010604 000000      .WORD    0
(3) 010606 013727 002116      MOV      L$DLY,(PC)+
(3) 010612 000000      .WORD    0
(3) 010614 005367 177772      DEC      -6(PC)
(3) 010620 001375      BNE      -4
(3) 010622 005367 177756      DEC      -22(PC)
(3) 010626 001367      BNE      -20
481 010636 005301      DEC      R1      ;UPDATE THE TIMER

```

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-14
INITIALIZATION CODE

L 3

SEG 003'

```

482 010640 001344          BNE      12$          ;IF MORE TIME, THEN TRY AGAIN
483
484          ;DRIVE NOT READY IN TIME - KILL THE ENTRY
485 010642 005742          TST      -(R2)          ;CORRECT THE POINTER
486 010644 005022          CLR      (R2)+          ;KILL THE ENTRY WORD FOR DCS
487
488 010646 162702 000004    13$: SUB      #4,R2          ;POINT TO THE NEXT ENTRY IN LIST
489 010652 022702 011162    CMP      #SELTL,R2          ;DONE?
490 010656 003721          BLE      11$          ;NO - DO THIS UNIT ALSO
491 010660 000404          BR       15$          ;YES - PROCEED
492
493 010662 004537 025436    14$: JSR      R5,ISDRST          ;RESET THE DRIVE SELECTED
494 010666 004537 026754    JSP      R5,MDHOME          ;AND BRING THE HEADS HOME
495
496 010672 005737 002372    15$: TST      SYSClk          ;CLOCK TICK?
497 010676 001404          BEQ      4$          ;BR IF NO
498 010700          CLKON          ;YES - SET FOR 1 SEC INTERVALS
499 010710 000137 011160    4$: JMP      POWER
500
501          ;'CONTINUE' COMMAND SEQUENCE
502 010714          3$: REDEF      #EF.CONTINUE          ;CONTINUE FROM CONSOLE?
503 (3) 010714 012700 000036 MOV      #EF.CONTINUE,R0
504 (3) 010720 104447 TRAP      C$REFG
505 010722          BNCOMPLETE 1$          ;NO, CONTINUE W/ INIT CODE
506 (2) 010722 103004 BCC      1$
507
508 010724 005237 002472    INC      CNTFLG          ;YES SET CONT FLAG, GO TO END OF INIT
509 010730 000137 011030    JMP      END
510
511 010734 004537 027316    1$: JSR      R5,CLEAR          ;CLEAR ALL DRIVE STORAGE BUFFERS
512
513 010740 012700 002400    2$: MOV      #LSTDR1,R0          ;CLEAR FLAGS
514 010744 005020          CLRDAT: CLR      (R0)+          ;
515 010746 020027 002476    CMP      R0,#STFLG+2          ;MASS CLEAR OF GLOBAL DATA AREA
516 010752 001374          BNE      CLRDAT          ;DO TILL TABLE IS ZEROED
517
518 010754 012700 011162    CLRSTB: MOV      #SELTL,R0          ;INIT THE SELECT TABLE
519 010760 012720 177777    MOV      #-1,(R0)+          ;END OF THE TABLE?
520 010764 020027 011222    CMP      R0,#STBLE          ;NO CLEAR THE NEXT
521 010770 001373          BNE      CLRSTB
522
523 010772 013703 002012    MOV      L$UNIT,R3          ;GET NUMBER OF UNITS
524 010776 010337 002454    MOV      R3,UUT          ;SAVE L$UNIT
525 011002 012704 011162    MOV      #SELTL,R4          ;INIT SELECT TABLE POINTER
526 011006 005001          CLR      R1          ;INIT P-TABLE
527 011010          1$: GPHARD  R1,R0          ;GET A P-TABLE
528 (3) 011010 010100    MOV      R1,R0
529 (3) 011012 104442    TRAP      C$GPHRD
530 011014          BNCOMPLETE 2$
531 (2) 011014 103002    BCC      2$
532
533          ;MOVE P-TABLE CONTENTS TO LOCAL STORAGE
534 011016 012024          MOV      (R0)+,(R4)+          ;GET CSR INTO SELECT TABLE STORAGE
535 011020 011024          MOV      (R0),(R4)+          ;GET DRIVE INTO TABLE
536 011022 005201          2$: INC      R1          ;POINT TO NEXT
537 011024 005303          DEC      R3          ;DOWN COUNT
538 011026 001370          BNE      1$          ;DO WHILE

```

ZRLMB0 RL01/02 BD SEC FIL TL
 CZRLMB.MAC 12-DEC-79 14:06

MACV11 30A(1052) 17-DEC-79 10:53 PAGE 1-15
 INITIALIZATION CODE

SEQ 0038

532
 533 011030
 534 011030 013704 002454
 535 011034 006304
 536 011036 006304
 537 011040 062704 011162
 538 011044 012704 177777
 539
 540 011050
 (3) 011050 012700 000040
 (3) 011054 104447
 541 011056
 (2) 011056 103002
 542 011060 005237 002474
 543
 544 011064
 545 011064
 (7) 011064 013746 002352
 (6) 011070 012746 023646
 (5) 011074 013746 002350
 (4) 011100 012746 000003
 (3) 011104 104437
 (2) 011106 062706 000010
 546
 547 011112 012737 030530 002450
 548 011120 012737 002400 002452
 549 011126 012737 002450 002256
 550 011134 012737 027416 002304
 551 011142 005737 002472
 552 011146 001004
 553
 554 011150
 555
 556
 557 011160
 558 011160
 (3) 011160
 (3) 011160 104411
 559
 560
 561 011162 000020
 562 011222 177777
 563
 564 011224
 565
 566

END:

MOV OUT,R4
 ASL R4
 ASL R4
 ADD #SELTBL,R4
 MOV #-1,R4

;POINT TO THE SELECT TABLE
 ;FORCE A TERMINATE IN THE TABLE

; 'START' COMMAND SEQUENCE

REDEF #EF.START
 MOV #EF.START,R0
 TRAP CSREFG
 BNCOMplete RESTART
 BC RESTART
 INC STFLG

; START COMMAND

; NO. CHK RESTART

; SET START INDICATOR

RESTART:

SETVEC BVEC,#INTR1,BPRIOR
 MOV BPRIOR,-(SP)
 MOV #INTR1,-(SP)
 MOV BVEC,-(SP)
 MOV #3,-(SP)
 TRAP CSVEC
 ADD #10,SP

; SET CONTROLLER VECTOR

FINDBF: MOV #BSFILE,BUF1
 MOV #1280,MAXWC
 MOV #BUF1,BBA
 MOV #BSECO,BSECP
 TST CNFLG
 BNE POWER

; ALL XFERS TO BSFILE STORAGE
 ; MAX XFER SIZE - 1/4 TRACK
 ; POINT TO THE DATA STORAGE AREA
 ; POINT TO THE BAD SECTOR FILE DATA
 ; HERE FROM 'CON' CMD
 ; BR IF TRUE

CLKON

; ACTIVATE SYSTEM CLOCK TO INITIATE GENERATION
 ; /OF TIMING INTERVALS

POWER:

ENDINIT

L10006:

TRAP CSINIT

SELTBL: .BLKW 16.
 STBLE: .WORD -1

ENDMOD

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-16
AUTO DROP SECTION

N 3

```

568 .SBTTL AUTO DROP SECTION
569
570 ;THE AUTO DROP SECTION IS CONDITIONALLY EXECUTED AFTER THE INITIALIZATION CODE
571 ;WHEN THE OPERATOR 'ADR' FLAG IS SET. EACH DRIVE IS CHECKED TO DETERMINE IF IT
572 ;RESPONDS WITH 'READY' AND IS DROPPED FROM THE TEST CYCLE IF IT DOES NOT. THE
573 ;HARDWARE TESTS ARE PERFORMED IMMEDIATELY AFTER THE READY STATUS OF ALL DRIVES
574 ;HAVE BEEN CHECKED.
575 BGNAUTO
576 011224 010146 MOV R1,-(SP) ;SAVE CONTENTS OF REGISTERS
577 011226 010246 MOV R2,-(SP)
578 011230 010346 MOV R3,-(SP)
579 011232 013703 002012 MOV L$UNIT,R3 ;INITIALIZE NUMBER OF UNITS
580 011236 012702 011162 MOV #SELTBL,R2 ;INITIALIZE START OF SELECT TABLE
581 011242 005037 002374 CLR LOGUNIT ;CLEAR LOGICAL UNIT NUMBER
582 011246 005037 002470 1$: CLR TRPFLG ;CLEAR TRAP FLAG
583 011252 SETVEC ERRVEC,#TRPHAN,#340 ;SET UP TIME-OUT VECTOR TO DETECT
(7) 011252 012746 000340 MOV #340,-(SP)
(6) 011256 012746 012474 MOV #TRPHAN,-(SP)
(5) 011262 013746 002504 MOV ERRVEC,-(SP)
(4) 011266 012746 000003 MOV #3,-(SP)
(3) 011272 104437 TRAP C$SVEC
(2) 011274 062706 000010 ADD #10,SP
584 ;/NON-EXISTENT CONTROLLER
585 011300 011237 002250 MOV @R2,DCS ;GET CONTROL STATUS REGISTER ADDRESS
586 011304 016237 000002 002302 MOV 2(R2),DRSEL ;GET DRIVE SELECT BITS
587 011312 005777 170732 TST @DCS ;ACCESS CONTROLLER
588 011316 005737 002470 TST TRPFLG ;DID TRAP OCCUR?
589 011322 001441 BEQ 2$ ;BRANCH TO CHECK DRIVE IF TRAP DID NOT
590 ;/OCCUR
591 PRINTF #FMT17,#MRLCS,DCS,#DRNM,<B,DRSEL+1> ;GIVE CONTROL STATUS AND
(11) 011324 005046 CLR -(SP)
(11) 011326 153716 002303 BISB DRSEL+1,(SP)
(10) 011332 012746 004033 MOV #DRNM,-(SP)
(9) 011336 013746 002250 MOV DCS,-(SP)
(8) 011342 012746 002506 MOV #MRLCS,-(SP)
(7) 011346 012746 007537 MOV #FMT17,-(SP)
(6) 011352 012746 000005 MOV #5,-(SP)
(3) 011356 010600 MOV SP,R0
(4) 011360 104417 TRAP C$PNTF
(4) 011362 062706 000014 ADD #14,SP
592 ;/DRIVE INFORMATION
593 PRINTF #FMT15,#NOCTLR ;MSG. 'DROPPING DRIVE - NO CONTROLLER'
(8) 011366 012746 007072 MOV #NOCTLR,-(SP)
(7) 011372 012746 007474 MOV #FMT15,-(SP)
(6) 011376 012746 000002 MOV #2,-(SP)
(3) 011402 010600 MOV SP,R0
(4) 011404 104417 TRAP C$PNTF
(4) 011406 062706 000006 ADD #6,SP
594 DODU LOGUNIT ;DO DROP UNIT ON DRIVE FROM TEST CYCLE
(3) 011412 013700 002374 MOV LOGUNIT,R0
(3) 011416 104451 TRAP C$DODU
595 011420 005022 CLR (R2)+ ;CLEAR CONTROL STATUS REGISTER ADDRESS
596 ;/ENTRY IN SELECT TABLE
597 011422 005022 CLR (R2)+ ;CLEAR DRIVE SELECT ENTRY IN SELECT TABLE
598 011424 000474 BR 5$ ;BRANCH TO ACCESS NEXT DRIVE
599 011426 052737 000200 002302 2$: BIS #200,DRSEL ;ADD IN THE CRDY BIT

```

CZRLMBO RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-17
AUTO DROP SECTION

B 4

SEQ 0040

```

600 011434 013777 002302 170606      MOV      DRSEL,DCS      ;SELECT THE DRIVE
601 011442 012701 000074      MOV      #60.,R1      ;INITIALIZE TIMER
602 011446 032777 000001 170574 3$: BIT      #1,DCS      ;DRIVE READY?
603 011454 001057      BNE      4$      ;BRANCH TO ACCESS NEXT DRIVE IF READY
604 011456      WAITUS    #10.      ;IMPLEMENT A TIME DELAY
(3) 011456 012727 000012      MOV      ###10.,(PC)+
(3) 011462 000000      .WORD    0
(3) 011464 013727 002116      MOV      L$DLY,(PC)+
(3) 011470 000000      .WORD    0
(3) 011472 005367 177772      DEC      -6(PC)
(3) 011476 001375      BNE      -4
(3) 011500 005367 177756      DEC      -22(PC)
(3) 011504 001367      BNE      -20
605 011506 005301      DEC      R1      ;DECREMENT THE TIMER
606 011510 001356      BNE      3$      ;BRANCH IF TIME NOT ELAPSED
607 011512      PRINTF    #FMT17,#MRLCS,DCS,#DRNM,<B,DRSEL+1> ;GIVE CONTROL STATUS AND
(11) 011512 005046      CLR      -(SP)
(11) 011514 153716 002303      BISB     DRSEL+1,(SP)
(10) 011520 012746 004033      MOV      #DRNM,-(SP)
(9) 011524 013746 002250      MOV      DCS,-(SP)
(8) 011530 012746 002506      MOV      #MRLCS,-(SP)
(7) 011534 012746 007537      MOV      #FMT17,-(SP)
(6) 011540 012746 000005      MOV      #5,-(SP)
(3) 011544 010600      MOV      SP,RO
(4) 011546 104417      TRAP     C$PNTF
(4) 011550 062706 000014      ADD      #14,SP

608                                ;/DRIVE INFORMATION
609 011554      PRINTF    #FMT15,#NOTRDY ;MSG. 'DRIVE DROPPED - DID NOT RESPOND
(8) 011554 012746 006505      MOV      #NOTRDY,-(SP)
(7) 011560 012746 007474      MOV      #FMT15,-(SP)
(6) 011564 012746 000002      MOV      #2,-(SP)
(3) 011570 010600      MOV      SP,RO
(4) 011572 104417      TRAP     C$PNTF
(4) 011574 062706 000006      ADD      #6,SP

610                                ;/WITH 'READY''
611 011600      DODU      LOGUNIT ;DO DROP UNIT ON DRIVE FROM TEST CYCLE
(3) 011600 013700 002374      MOV      LOGUNIT,RO
(3) 011604 104451      TRAP     C$DODU
612 011606 005022      CLR      (R2)+
613                                ;CLEAR CONTROL STATUS REGISTER ADDRESS
614 011610 005022      CLR      (R2)+ ;/ENTRY IN SELECT TABLE
615 011612 000401      BR      5$      ;CLEAR DRIVE SELECT ENTRY IN SELECT TABLE
616 011614 022222      CMP      (R2)+,(R2)+ ;BRANCH TO ACCESS NEXT DRIVE
617 011616 005237 002374 4$: INC      LOGUNIT ;ACCESS NEXT DRIVE IN SELECT TABLE
618 011622 005303      DEC      R3      ;INCREMENT LOGICAL UNIT NUMBER
619 011624 001210      BNE      1$      ;DECREMENT DRIVE COUNT
620 011626      CLRVEC    ERRVEC ;BRANCH TO GET NEXT DRIVE IF MORE
(3) 011626 013700 002504      MOV      ERRVEC,RO ;RELEASE THE ERROR VECTOR
(3) 011632 104436      TRAP     C$VEC
621 011634 012603      MOV      (SP)+,R3
622 011636 012602      MOV      (SP)+,R2
623 011640 012601      MOV      (SP)+,R1
624 011642      ENDAUTO    L10007:
(3) 011642      TRAP     C$AUTO
(3) 011642 104461
625

```


CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 C 4
PAGE 1-18
AUTO DROP SECTION

SEQ 0041

627	011644			BGNMOD	CLNCODE	
628	011644				BGNCLN	
629						
630	011644				SETVEC	ERRVEC,#TRPHAN,#340
(7)	011644	012746	000340		MOV	#340,-(SP)
(6)	011650	012746	012474		MOV	#TRPHAN,-(SP)
(5)	011654	013746	002504		MOV	ERRVEC,-(SP)
(4)	011660	012746	0000C3		MOV	#3,-(SP)
(3)	011664	104437			TRAP	C\$SVEC
(2)	011666	062706	000010		ADD	#10,SP
631	011672				SETPRI	#PRI00
(3)	011672	012700	000000		MOV	#PRI00,R0
(3)	011676	104441			TRAP	C\$SPRI
632	011700				CLRVEC	BVEC
(3)	011700	013700	002350		MOV	BVEC,R0
(3)	011704	104436			TRAP	C\$CVEC
633						
634	011706			3\$:	CLRVEC	ERRVEC
(3)	011706	013700	002504		MOV	ERRVEC,R0
(3)	011712	104436			TRAP	C\$CVEC
635	011714	005737	002372		TST	SYSCLK
636	011720	001400			BEQ	4\$
637	011722			4\$:	BRESET	
(3)	011722	104433			TRAP	C\$RESET
638	011724				ENDCLN	
(3)	011724			L10010:		
(3)	011724	104412			TRAP	C\$CLEAN
639						
640	011726				ENDMOD	
641						
642	011726			BGNMOD	ADDCODE	
643	011726			BGNAU		
644	011726			ENDAU		
(3)	011726			L10011:		
(3)	011726	104452			TRAP	C\$AU
645	011730			ENDMOD		
646						
647	011730			BGNMOD	DROPCODE	
648	011730			BGNDU		
649	011730			ENDDU		
(3)	011730			L10012:		
(3)	011730	104453			TRAP	C\$DU
650	011732			ENDMOD		
651						
652						

;PRIORITY TO ZERO

;RELEASE VECTOR OF FIRST CONTROLLER

;TAKE CARE OF LSI-11

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACV11 30A(1052) 17-DEC-79 10:53 PAGE 1-19
CLOCK INTERRUPT SERVICE ROUTINES

SEQ 0042

```

654 .SBTTL CLOCK INTERRUPT SERVICE ROUTINES
655
656 011732 STARS
657 (2) :*****
658 :UPDATES TIME EVERY 1/60 SECOND (60 HZ) OR EVERY 1/50 SECOND
659 011732 : (50 HZ)
660 (2) STARS
661 :*****
662 011732 BGNSRV UPDATE
663 011732 010446 MOV R4,-(SP) ;SAVE R4
664 :CLEAR CLOCK INTERRUPT ENABLE TO INHIBIT CLOCK INTERRUPTS DURING UPDATING
665 011734 022737 000001 002356 :OF TIME FIELDS
666 011742 001004 CMP #1,CLKTYP ;P-CLOCK?
667 011744 042737 000100 172540 BNE 1$ ;BRANCH IF NOT P-CLOCK
668 011752 000403 BIC #100,#172540 ;DISABLE P-CLOCK INTERRUPT FACILITY
669 011754 042737 000100 177546 1$: BIC #100,#177546 ;DISABLE L-CLOCK INTERRUPT FACILITY
670 :UPDATE TIME FIELDS
671 011762 012704 002424 2$: MOV #TICK,R4 ;INITIALIZE TICK ADDRESS
672 011766 005214 INC (R4) ;INCREMENT TICK TIME FIELD
673 011770 023727 002354 000002 CMP CLKFRQ,#2 ;50 HZ CLOCK?
674 011776 001005 BNE 3$ ;NO - BRANCH FOR SERVICING 60 HZ CLOCK
675 012000 021427 000062 CMF (R4),#50. ;((R4))=50?
676 012004 001024 BNE EXIT ;IF NOT,UPDATING IS COMPLETE
677 012006 005014 CLR (R4) ;ELSE,((R4))=0 (RESET COUNT)
678 012010 000404 BR 4$ ;BRANCH TO UPDATE 'SECOND' TIME FIELD
679 012012 021427 000074 3$: CMP (R4),#60. ;((R4))=60?
680 012016 001017 BNE EXIT ;IF NOT,UPDATING IS COMPLETE
681 012020 005014 CLR (R4) ;ELSE,((R4))=0 (RESET COUNT)
682 012022 005724 4$: TST (R4)+ ;((R4))=(R4)+2 (GO TO NEXT TIME FIELD)
683 012024 005214 INC (R4) ;INCREMENT 'SECOND' TIME FIELD
684 012026 021427 000074 CMF (R4),#60. ;((R4))=60?
685 012032 001011 BNE EXIT ;IF NOT,UPDATING IS COMPLETE
686 012034 005014 CLR (R4) ;ELSE,((R4))=0 (RESET COUNT)
687 012036 005724 TST (R4)+ ;ACCESS 'MINUTE' TIME FIELD
688 012040 005214 INC (R4) ;INCREMENT 'MINUTE' TIME FIELD
689 012042 021427 000074 CMF (R4),#60. ;((R4))=60?
690 012046 001003 BNE EX' ;IF NOT,UPDATING IS COMPLETE
691 012050 005014 CLR (R4) ;ELSE,((R4))=0 (RESET COUNT)
692 012052 005724 TST (R4)+ ;ACCESS 'HOUR' TIME FIELD
693 012054 005214 INC (R4) ;INCREMENT 'HOUR' TIME FIELD
694 012056 005337 002370 EXIT: DEC CLKBFR ;COUNT CLOCK TICKS
695 012062 003003 BGT 5$ ;TIME NOT EXPIRED
696 012064 013737 002366 002370 MOV CLKCNT,CLKBFR ;RE-INITIALIZE TIME INCREMENT
697 :RE-ENABLE CLOCK INTERRUPT FACILITY
698 012072 022737 000001 002356 5$: CMP #1,CLKTYP ;P-CLOCK?
699 012100 001004 BNE 6$ ;BRANCH IF NOT P-CLOCK
700 012102 052737 000100 172540 BIS #100,#172540 ;SET P-CLOCK INTERRUPT ENABLE BIT
701 012110 000403 BR 7$ ;EXIT
702 012112 052737 000100 177546 6$: BIS #100,#177546 ;SET L-CLOCK INTERRUPT ENABLE BIT
703 012120 012604 7$: MOV (SP)+,R4 ;RESTORE R4
704 ENDSRV
705 (3) L10013: RTI
706 (2)
707

```

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

E 4
'ACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-20
CLOCK INTERRUPT SERVICE ROUTINES

SEQ 0043

706

707 012124

708

709 012124 005237 002376

710

711

712 012130

(3) 012130

(2) 012130 000002

713

;L-CLOCK 'TICK' CHECK ROUTINE FOR LSI-11
BGNSRV CLKTIK

INC

CLKFLD

;INCREMENT CLOCK FIELD TO INDICATE
;/THAT CLOCK IS 'TICKING'

ENDSRV

L10014:

RTI

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 F 4
GLOBAL SUBROUTINES

SEQ 0044

```

715 .SBTTL GLOBAL SUBROUTINES
716
717 012132 BGNMOD GLBSUB
718
719
720 012132 STARS
(2) ::*****
721 :SET UP CLOCK INTERRUPT VECTOR, CLOCK COUNT, AND IDENTIFY THE
722 :CLOCK FREQUENCY
723 012132 STARS
(2) ::*****
724
725 012132 010346 CLKINI: MOV R3,-(SP) ;SAVE R3
726 012134 022737 000001 002356 CMP #1,CLKTYP ;P-CLOCK?
727 012142 001014 BNE LCLK ;BRANCH IF NOT P-CLOCK
728 012144 SETVEC #104,#UPDATE,#340 ;SET P-CLOCK INTERRUPT VECTOR
(7) 012144 012746 000340 MOV #340,-(SP)
(6) 012150 012746 011732 MOV #UPDATE,-(SP)
(5) 012154 012746 000104 MOV #104,-(SP)
(4) 012160 012746 000003 MOV #3,-(SP)
(3) 012164 104437 TRAP C$SVEC
(2) 012166 062706 000010 ADD #10,SP
729 012172 000417 BR FRQCHK ;BRANCH FOR SYSTEM FREQUENCY CHECK
730 012174 022737 000002 002356 LCLK: CMP #2,CLKTYP ;L-CLOCK?
731 012202 001036 BNE ENDINI ;BRANCH IF NO CLOCK
732 012204 SETVEC #100,#UPDATE,#340 ;SET L-CLOCK INTERRUPT VECTOR
(7) 012204 012746 000340 MOV #340,-(SP)
(6) 012210 012746 011732 MOV #UPDATE,-(SP)
(5) 012214 012746 000100 MOV #100,-(SP)
(4) 012220 012746 000003 MOV #3,-(SP)
(3) 012224 104437 TRAP C$SVEC
(2) 012226 062706 000010 ADD #10,SP
733 012232 013703 002360 FRQCHK: MOV CLKADR,R3 ;GET BASE ADDRESS OF THE SUPERVISOR CLOCK TABLE
734 012236 022763 000074 000006 CMP #60,6(R3) ;60 HZ?
735 012244 001007 BNE FRQ50 ;BRANCH FOR 50 HZ
736 012246 012737 000074 002366 MOV #60,CLKCNT ;INITIALIZE CLOCK COUNT FOR 60 TICKS PER SECOND
737 012254 012737 000001 002354 MOV #1,CLKFRQ ;IDENTIFY CLOCK FREQUENCY IS 60 HZ
738 012262 000406 BR ENDINI ;RETURN
739 012264 012737 000062 002366 FRQ50: MOV #50,CLKCNT ;INITIALIZE CLOCK COUNT FOR 50 TICKS PER SECOND
740 012272 012737 000002 002354 MOV #2,CLKFRQ ;IDENTIFY CLOCK FREQUENCY IS 50 HZ
741 012300 012603 ENDINI: MOV (SP)+,R3 ;RESTORE R3
742
743 012302 000207 RTS PC ;RETURN
744
745

```

```

747
748 012304      STARS
(2)             :*****
749             :START CLOCK OPERATION
750 012304      STARS
(2)             :*****
751
752 012304 022737 000002 002356 CLKST:  CMP    #2,CLKTYP    ;L-CLOCK?
753 012312 001006                BNE     1$            ;BRANCH FOR P-CLOCK
754 012314 012737 000100 177546      MOV     #100,#177546 ;SET INTERRUPT ENABLE BIT TO 1
755 012322 005237 002364                INC     CLKSON      ;INDICATE CLOCK IS 'ON'
756 012326 000414                BR      2$            ;BRANCH TO SET UP TIME INCREMENTS
757 012330 022737 000001 002356 1$:  CMP     #1,CLKTYP    ;P-CLOCK?
758 012336 001013                BNE     3$            ;BRANCH IF NO CLOCK
759 012340 012737 000001 172542      MOV     #1,#172542   ;SET UP P-CLOCK FOR 1 INTERRUPT PER TICK
760 012346 012737 000115 172540      MOV     #115,#172540 ;SET INTERRUPT ENABLE, REPEAT INTERRUPT MODE,
761                                     ;/LINE FREQUENCY RATE, START CLOCK
762 012354 005237 002364                INC     CLKSON      ;INDICATE CLOCK IS 'ON'
763 012360 013737 002366 002370 2$:  MOV     CLKCNT,CLKBFR ;SET UP TIME INCREMENTS
764 012366 000207                3$:  RTS      PC          ;RETURN
765
766 012370      STARS
(2)             :*****
767             :FIRST & SELDRV -- DRIVE SELECT ROUTINE
768 012370      STARS
(2)             :*****
769
770 012370 012704 011162      FIRST:  MOV     #SELTBL,R4      ;POINT TO THE SELECT TABLE
771 012374 010437 002330      MOV     R4,NXTUNI
772
773 012400 013704 002330      SELDRV: MOV     NXTUNI,R4      ;SETUP THE POINTER
774 012404 005714      10$:  TST      (R4)                ;CHECK FOR A VALID ENTRY
775 012406 000402      BMI      1$                        ;OK TO GO ON
776 012410 022124      CMP      (R4)+,(R4)+              ;POINT TO THE NEXT ENTRY SLOT
777 012412 000774      BR      10$                       ;AND TRY AGAIN
778
779 012414 012437 002250      1$:  MOV     (R4)+,DCS        ;GET THE CSR ADDR FROM TABLE
780 012420 022737 177777 002250      CMP     #-1,DCS        ;END OF THE TABLE?
781 012426 001001      BNE     2$                        ;NO - CONTINUE
782 012430 000416      BR      4$                        ;EXIT +1
783
784 012432 012437 002302      2$:  MOV     (R4)+,DRSEL      ;GET THE DRIVE SELECT BITS
785 012436 004537 025422      JSR      R5,GETDST          ;GET THE DRIVE STATUS
786 012442 012737 000001 002316      MOV     #1,TDR        ;DEFAULT TO RL01 TYPE
787 012450 032701 000200      BIT      #BIT7,R1          ;IS IT AN RL02?
788 012454 001403      BEQ      3$                        ;NO
789 012456 012737 000002 002316      MOV     #2,TDR        ;YES - SET FOR AN RL02
790
791 012464 022525      3$:  CMP     (R5)+,(R5)+          ;RETURN +2 - NORMAL EXIT
792 012466 010437 002330      4$:  MOV     R4,NXTUNI      ;SAVE THE 'NEXT' SLOT POINTER
793 012472 000205      RTS      R5                       ;EXIT
794
795 012474 005237 002470      TRPHAN: INC     TRPFLG
796 012500 000002      R*1
797
798

```

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-23
GLOBAL SUBROUTINES

H 4

SEG 004

799 012502
(2)
800
801 012502
(2)
802
803 012502 005737 002372
804 012506 001416
805 012510
(10) 012510 013746 002426
(9) 012514 013746 002430
(8) 012520 013746 002432
(7) 012524 012746 010047
(6) 012530 012746 000004
(3) 012534 010600
(4) 012536 104414
(4) 012540 062706 000012
806 012544 000205
807 012546
(2)
808
809 012546
(2)
810
811 012546
(11) 012546 005046
(11) 012550 153716 002303
(10) 012554 012746 004033
(9) 012560 013746 002250
(8) 012564 012746 002506
(7) 012570 012746 007537
(6) 012574 012746 000005
(3) 012600 010600
(4) 012602 104417
(4) 012604 062706 000014
812 012610
(9) 012610 013746 002316
(8) 012614 012746 006562
(7) 012620 012746 010105
(6) 012624 012746 000003
(3) 012630 010600
(4) 012632 104417
(4) 012634 062706 000010
813 012640 000205
814
815 012642
(2)
816
817 012642
(2)
818
819 012642 004537 012546
820 012646
(8) 012646 012746 006505
(7) 012652 012746 010044
(6) 012656 012746 000002

STARS
:*****
:PTIME -- ROUTINE TO PRINT THE SYSTEM RUNTIME IF A CLOCK IS PRESENT
STARS
:*****
PTIME: TST SYCLK ;CLOCK PRESENT?
BEQ 1\$;NO
PRINTB #TIME,HOUR,MINUTE,SECOND
MOV SECOND,-(SP)
MOV MINUTE,-(SP)
MOV HOUR,-(SP)
MOV #TIME,-(SP)
MOV #4,-(SP)
MOV SP,R0
TRAP C\$PNTB
ADD #12,SP
1\$: RTS R5 ;EXIT
STARS
:*****
:DRVID -- ROUTINE TO PRINT THE SELECTED UNIT IDENTIFICATION
STARS
:*****
DRVID: PRINTF #FMT17,#MRLCS,DCS,#DRNM,<B,DRSEL+1>
CLR -(SP)
BISB DRSEL+1,(SP)
MOV #DRNM,-(SP)
MOV DCS,-(SP)
MOV #MRLCS,-(SP)
MOV #FMT17,-(SP)
MOV #5,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #14,SP
PRINTF #FDTYP,#MDRTYP,TDR
MOV TDR,-(SP)
MOV #MDRTYP,-(SP)
MOV #FDTYP,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #10,SP
RTS R5
STARS
:*****
:DRRDY -- ROUTINE TO PRINT THE DRIVE SELECTED ISN'T READY
STARS
:*****
DRRDY: PRINTF #FMT17,#MRLCS,DCS,#DRNM,<B,DRSEL+1>
CLR -(SP)
BISB DRSEL+1,(SP)
MOV #DRNM,-(SP)
MOV DCS,-(SP)
MOV #MRLCS,-(SP)
MOV #FMT17,-(SP)
MOV #5,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #14,SP
PRINTF #FDTYP,#MDRTYP,TDR
MOV TDR,-(SP)
MOV #MDRTYP,-(SP)
MOV #FDTYP,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #10,SP
RTS R5

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MAC(11 30A(10,2) 17-DEC-79 10:53 PAGE 1-24
GLOBAL SUBROUTINES

SF0 0047

```

(3) 012662 010600      MOV      SP,R0
(4) 012664 104417      TRAP     C$PNTF
(4) 012666 062706 000006 ADD      #6,SP
821 012672 004537 012700 JSR      R5,DRDRV      ;DROP THE DRIVE SELECTED
822 012676 000205      RTS      R5
823
824 012700      STARS
(2) ::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::
825      ;DRDRV -- ROUTINE TO KILL A UNIT ENTRY INTO THE SELTBL AREA IF THE
826      ;      PGM DETERMINES A UNIT IS NOT ABLE TO BE USED
827 012700      STARS
(2) ::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::
828
829 012700 013704 002330 DRDRV:  MOV      NXTUNI,R4      ;POINT TO THE 'NEXT' UNIT SLOT
830 012704 162704 000004      SUB      #4,R4      ;POINT TO THE CURRENT UNIT
831 012710 005024      CLR      (R4)+      ;KILL THE ENTRY
832 012712 005024      CLR      (R4)+      ;KILL DRSEL ENTRY
833 012714 000205      RTS      R5      ;EXIT
834
835
836 012716      ENDMOD
837
838
839

```

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-25
PROGRAM MAIN LOOP

SEQ 047

```

841 .SBTTL PROGRAM MAIN LOOP
842
843 012716 BGNTST
844 012716 STARS
(2) ::*****
845 :THIS IS WHERE CONTROL IS PASSED AFTER THE INITIAL QUESTIONS HAVE
846 :BEEN ANSWERED FOR THE P-TABLE STORAGE.
847 012716 STARS
(2) ::*****
848
849 012716 MTEST:
850 012716 004537 012370 JSR R5,FIRST ;SELECT THE 1ST DRIVE
851 012722 000137 013216 JMP WHATCMD ;NO - UNITS
852 012726 000404 BR 2$
853 012730 004537 012400 1$: JSR R5,SELDRV ;SELECT ANOTHER UNIT
854 012734 000137 013216 JMP WHATCMD ;NO MORE TO SELECT
855 012740 012777 000200 167302 2$: MOV #200,@DCS ;CHECK IF DRIVE THERE
856 012746 053777 002302 167274 BIS DRSEL,@DCS
857 012754 012700 000000 MOV #0.,R0 ;STALL
858 012760 005300 13$: DEC R0
859 012762 001376 BNE 13$
860 012764 004537 025422 JSR R5,GETDST ;GET THE CURRENT DRIVE STATUS
861 012770 010137 002414 MOV R1,TEMPO ;SAVE THE STATUS
862 012774 PRINTF #MCRLF
(7) MOV #MCRLF,-(SP)
(6) MOV #1,-(SP)
(3) MOV SP,R0
(4) TRAP C$PNTF
(4) 013010 062706 000004 ADD #4,SP
863 013014 004537 012546 JSR R5,DRVID ;TELL OPR THE UNIT SELECTED
864
865 013020 032737 000020 002414 130$: BIT #HOP,TEMPO ;ARE THE HEADS LOADED?
866 013026 001015 BNE 131$ ;BR IF OK
867 013030 PRINTF #FMT18,#NOLOAD ;NO
(8) MOV #NOLOAD,-(SP)
(7) MOV #FMT18,-(SP)
(6) MOV #2,-(SP)
(3) MOV SP,R0
(4) TRAP C$PNTF
(4) 013050 062706 000006 ADD #6,SP
868 013054 004537 012700 JSR R5,DRDRV ;DROP THIS DRIVE
869 013060 000452 BR 15$
870 013062 032737 020000 002414 131$: BIT #WL,TEMPO ;IS THE PACK WRITE LOCKED?
871 013070 001414 BEQ 132$ ;BR IF NOT WRT LOCKED
872 013072 PRINTF #FMT18,#WRTLCK ;TELL OPR
(8) MOV #WRTLCK,-(SP)
(7) MOV #FMT18,-(SP)
(6) MOV #2,-(SP)
(3) MOV SP,R0
(4) TRAP C$PNTF
(4) 013112 062706 000006 ADD #6,SP
873 013116 005237 002462 INC WRTLCK ;SET THE WRITE LOCK FLAG
874 013122 032737 001000 002414 132$: BIT #VC,TEMPO ;PACK JUST LOADED?
875 013130 001412 BEQ 133$ ;JUMP IF NOT
876 013132 PRINTF #FMT18,#NEWLD ;TELL OPR
(8) 013132 012746 003505 MOV #NEWLD,-(SP)

```


CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 K 4
PROGRAM MAIN LOOP PAGE 1-26

(7)	013136	012746	007624		MOV	#FMT18,-(SP)	
(6)	013142	012746	000002		MOV	#2,-(SP)	
(3)	013146	010600			MOV	SP,R0	
(4)	013150	104417			TRAP	C\$PNTF	
(4)	013152	062706	000006		ADD	#6,SP	
877	013156	004537	025436	133\$:	JSR	R5,ISDRST	;RESET THE DRIVE
878	013162	004537	025422		JSR	R5,GETDST	;GET THE DRIVE STATUS AGAIN
879	013166	032777	100000	167054	BIT	#ERR,@DCS	;COMPOSITE ERROR STILL SET?
880	013174	001404			BEQ	15\$;NOPE - SKIP OVER
881	013176				ERRDF	170.,MDERS	
(4)	013176	104455			TRAP	C\$ERDF	
(5)	013200	000252			.WORD	170	
(5)	013202	003337			.WORD	MDERS	
(5)	013204	000000			.WORD	0	
882							
883	013206			15\$:	SETPRI	#0	;PRIORITY TO ZERO
(3)	013206	012700	000000		MOV	#0,R0	
(3)	013212	104441			TRAP	C\$SPRI	
884	013214	000645			BR	1\$;SELECT THE NEXT UNIT
885							
886							

888
 889
 890 013216
 (2)
 891
 892 013216
 (2)
 893
 894 013216 005737 002474
 895 013222 001551
 896 013224 005737 002344
 897 013230 001440
 898 013232
 (7) 013232 012746 010041
 (6) 013236 012746 000001
 (3) 013242 010600
 (4) 013244 104417
 (4) 013246 062706 000004
 899 013252
 (3) 013252 104443
 (3) 013254 000406
 (4) 013256 002414
 (5) 013260 000022
 (5) 013262 004044
 (5) 013264 177777
 (5) 013266 000001
 (5) 013270 177777
 (3) 013272
 900 013 023737 002344 002414
 901 013500 001414
 902 013302 005237 002464
 903 013306
 (8) 013306 012746 004125
 (7) 013312 012746 007624
 (6) 013316 012746 000002
 (3) 013322 010600
 (4) 013324 104417
 (4) 013326 062706 000006
 904
 905 013332
 (8) 013332 012746 004326
 (7) 013336 012746 007777
 (6) 013342 012746 000002
 (3) 013346 010600
 (4) 013350 104417
 (4) 013352 062706 000006
 906 013356
 (8) 013356 012746 004401
 (7) 013362 012746 007624
 (6) 013366 012746 000002
 (3) 013372 010600
 (4) 013374 104417
 (4) 013376 062706 000006
 907 013402
 (8) 013402 012746 004461
 (7) 013406 012746 007624

.SBTTL COMMAND QUERY LOOP
 STARS
 ::.....
 :HERE IS THE 'CMD>' QUERY LOOP FOR COMMANDS TO PERFORM
 STARS
 ::.....
 WHATCMD: WHATCMD: TST STFLG ;JUST STARTING?
 BEQ NXTCMD ;NO - BYPASS THE STARTING BLURB
 TST PASWD ;DO THE PASSWORD STUFF?
 BEQ HLPMSG ;NO - PRINT THE HELP MESSAGE
 PRINTF #MCRLF
 MOV #MCRLF,-(SP,
 MOV #1,-(SP)
 MOV SP,RO
 TRAP C\$PNTF
 ADD #4,SP
 GMANID PASWD,TEMPO,0,177777,1,177777,NO ;GET THE PASSWORD
 TRAP C\$GMAN
 BR 10000\$
 .WORD TEMPO
 .WORD T\$CODE
 .WORD PASWD
 .WORD 177777
 .WORD T\$LOLIM
 .WORD T\$HILIM
 10000\$:
 CMP PASWD,TEMPO ;CORRECT PASSWORD?
 BEQ HLPMSG ;YES
 INC ACCESS ;SET THE DENIED FLAG
 PRINTF #FMT18,#DENIED ;& TELL OPR
 MOV #DENIED,-(SP)
 MOV #FMT18,-(SP)
 MOV #2,-(SP)
 MOV SP,RO
 TRAP C\$PNTF
 ADD #6,SP
 HLPMSG: PRINTF #FMTMS,#CMD1 ;PRINT THE HELP MESSAGE
 MOV #CMD1,-(SP)
 MOV #FMTMS,-(SP)
 MOV #2,-(SP)
 MOV SP,RO
 TRAP C\$PNTF
 ADD #6,SP
 PRINTF #FMT18,#CMD2
 MOV #CMD2,-(SP)
 MOV #FMT18,-(SP)
 MOV #2,-(SP)
 MOV SP,RO
 TRAP C\$PNTF
 ADD #6,SP
 PRINTF #FMT18,#CMD3
 MOV #CMD3,-(SP)
 MOV #FMT18,-(SP)

ZRLMB0 RL01/02 BC SEC FIL TL
ZRLMB.MAC 12-DEC-79 14:06

MACV11 30A.1052) 17-DEC-79 10:53 PAGE 1-28
COMMAND QUERY LOOP

(6) 013412 012746 000002
(3) 013416 010600
(4) 013420 104417
(4) 013422 062706 000006
908 013426
(8) 013426 012746 004546
(7) 013432 012746 007624
(6) 013436 012746 000002
(3) 013442 010600
(4) 013444 104417
(4) 013446 062706 000006
909 013452
(8) 013452 012746 004602
(7) 013456 012746 007624
(6) 013462 012746 000002
(3) 013466 010600
(4) 013470 104417
(4) 013472 062706 000006
910 013476
(8) 013476 012746 004671
(7) 013502 012746 007624
(6) 013506 012746 000002
(3) 013512 010600
(4) 013514 104417
(4) 013516 062706 000006
911 013522
(8) 013522 012746 004724
(7) 013526 012746 007624
(6) 013532 012746 000002
(3) 013536 010600
(4) 013540 104417
(4) 013542 062706 000006
912
913 013546 005037 015330
914 013552 005037 015326
915 013556
(7) 013556 012746 010041
(6) 013562 012746 000001
(3) 013566 010600
(4) 013570 104417
(4) 013572 062706 000004
916 013576
(3) 013576 104443
(3) 013600 000406
(4) 013602 013650
(5) 013604 000042
(5) 013606 004753
(5) 013610 000007
(5) 013612 000001
(5) 013614 000007
(3) 013616
917
918 013616 013700 013650
919 013622 006300
920 013624 000170 013630
921

MOV #2,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #6,SP
PRINTF #FMT18,#CMD4
MOV #CMD4,-(SP)
MOV #FMT18,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #6,SP
PRINTF #FMT18,#CMD5
MOV #CMD5,-(SP)
MOV #FMT18,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #6,SP
PRINTF #FMT18,#CMD6
MOV #CMD6,-(SP)
MOV #FMT18,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #6,SP
PRINTF #FMT18,#CMD7
MOV #CMD7,-(SP)
MOV #FMT18,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #6,SP

NXTCMD: CLR FACNUM ;CLEAR ENTRY COUNTER

CLR FLDNUM
PRINTF #MCRLF
MOV #MCRLF,-(SP)
MOV #1,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #4,SP
G\$MANID CMD0,INPUT,D,7,1,7,NO
TRAP C\$G\$MAN
BR 10001\$
.WORD INPUT
.WORD T\$CODE
.WORD CMD0
.WORD 7
.WORD T\$LOLIM
.WORD T\$HILIM

10001\$:

MOV INPUT,R0 ;GET THE CMD REQUEST TYPED
ASL R0 ;SHIFT FOR PROPER INDEX INTO LIST
JMP @LIST(R0) ;DO THE FUNCTION REQUESTED

CZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 N 4 PAGE 1-29
CZRLMB.MAC 12-DEC-79 14:06 COMMAND QUERY LOOP

922 013630 000000
923 013632 013652
924 013634 015754
925 013636 017352
926 013640 020644
927 013642 020172
928 013644 023030
929 013646 013332
930
931 013650 000000
932

LIST: .WORD 0
BSRPT
BSADD
BSDEL
BSVERIFY
BSWRITE
BSMAKE
HLPMSG

INPUT: .WORD 0

;NOTHING FOR FUNCTION '0'
; 1 REPORT CONTENTS OF BAD SECTOR FILES
; 2 ADD AN ENTRY INTO 'FIELD' FILE
; 3 DELETE AN ENTRY FROM 'FIELD' FILE
; 4 VERIFY PACK - READ ONLY
; 5 WRITE THE PACK
; 6 MAKE A BAD SECTOR FILE
; 7 PRINT THE COMMANDS AVAILABLE

;STORAGE FOR TYPED COMMAND

934
935
936 013652
(2)
937
938
939
940
941
942 013652
(2)
943
944 013652 004537 012370
945 013656 000137 013546
946 013662 000404
947 013664 004537 012400
948 013670 000137 013546
949 013674 004537 025246
950 013700 005737 002414
951 013704 001404
952 013706 004537 012642
953 013712 000137 013664
954
955 013716
(8) 013716 012746 002573
(7) 013722 012746 007631
(6) 013726 012746 000002
(3) 013732 010600
(4) 013734 104417
(4) 013736 062706 000006
956 013742 004537 023556
957 013746
(7) 013746 012746 010041
(6) 013752 012746 000001
(3) 013756 010600
(4) 013760 104417
(4) 013762 062706 000004
958 013766 004537 012546
959 013772
(7) 013772 012746 010041
(6) 013776 012746 000001
(3) 014002 010600
(4) 014004 104417
(4) 014006 062706 000004
960 014012 005037 015350
961
962
963 014016 004537 025032
964 014022
(8) 014022 012746 005004
(7) 014026 012746 007624
(6) 014032 012746 000002
(3) 014036 010600
(4) 014040 104417
(4) 014042 062706 000006
965 014046 005037 015330

.SBTTL GLOBAL SUBROUTINES

STARS

:THIS IS THE ROUTINE TO REPORT THE CONTENTS OF THE BAD SECTOR FILE
:FOR THE DRIVE SELECTED. 'BSFILE' CONTAINS AN IMAGE OF THE
:CARTRIDGE BAD SECTOR FILE. FIRST REPORT THE CARTRIDGE SERIAL
:NUMBER FOLLOWED BY THE CONTENTS OF THE 'FACTORY' BAD SECTOR FILE
:AND THEN THE CONTENTS OF THE 'FIELD' BAD SECTOR FILE.
STARS

BSRPT: JSR R5,FIRST ;SELECT A DRIVE
JMP NXTCMD ;NONE AVAIL!
BR BSRPTL
BSRPTS: JSR R5,SELDRV ;SELECT THE NEXT UNIT
JMP NXTCMD ;ALL DONE
BSRPTL: JSR R5,LOADED ;SEE IF DRIVE READY FOR OPR
TST TEMPO ;READY?
BEQ 1\$;YES
JSR R5,DNRDY
JMP BSRPTS ;SELECT THE NEXT UNIT

1\$: PRINTF #FMT19,#STARMMSG
MOV #STARMMSG,-(SP)
MOV #FMT19,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #6,SP
JSR R5,RDSDSC ;READ THE BAD SECTOR FILE
PRINTF #MCRLF
MOV #MCRLF,-(SP)
MOV #1,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #4,SP
JSR R5,DRVID
PRINTF #MCRLF
MOV #MCRLF,-(SP)
MOV #1,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #4,SP
CLR PSNFG ;CLEAR THE PRINT FLAG FOR SER # MSG

:HERE TO REPORT CONTENTS OF THE 'FACTORY' FILE
BSRFAC: JSR R5,RDFACT ;READ THE FACTORY FILE FROM BD SEC FILE
PRINTF #FMT18,#BSRM
MOV #BSRM,-(SP)
MOV #FMT18,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #6,SP
CLR FACNUM ;INIT THE FACTORY ENTRY COUNTER

```
966 014052 012737 000020 015340 MOV #16.,SECMAX ;LAST SECTOR PAIR IN FACTORY FILE
967 014060 005037 015342 CLR SECNUM ;POINT TO THE 1ST PAIR OF SECTORS
968 014064 005002 CLR R2 ;CLEAR THE INDEX INTO THE BSFILE STORAGE
969 014066 004537 015622 JSR R5,BSFOK ;FIND A SECTOR TO USE IN FACTORY AREA
970 014072 005737 015346 TST BSFOKF ;SEE IF ERROR DETECTED
971 014076 001437 BEQ 10$ ;JUMP IF OK
972 014100 PRINTF #FMT18,#NHWSEC
(8) 014100 012746 003562 MOV #NHWSEC,-(SP)
(7) 014104 012746 007624 MOV #FMT18,-(SP)
(6) 014110 012746 000002 MOV #2,-(SP)
(3) 014114 010600 MOV SP,R0
(4) 014116 104417 TRAP C$PNTF
(4) 014120 062706 000006 ADD #6,SP
973 014124 004537 022570 JSR R5,NEWBSF ;BUILD A NEW FILE
974 014130 005737 002414 TST TEMPO ;DID I?
975 014134 001405 BEQ 1$ ;NO
976 014136 013737 002414 002300 MOV TEMPO,NEWFAC ;SET THE FLAG
977 014144 004537 016770 JSR R5,WRITBSF ;WRITE UPDATED 'FIELD' BAD SECTOR FILE
978 ;/ON THE PACK IF REQUESTED
979 014150 1$: PRINTF #FMT18,#HYPHEN
(8) 014150 012746 002675 MOV #HYPHEN,-(SP)
(7) 014154 012746 007624 MOV #FMT18,-(SP)
(6) 014160 012746 000002 MOV #2,-(SP)
(3) 014164 010600 MOV SP,R0
(4) 014166 104417 TRAP C$PNTF
(4) 014170 062706 000006 ADD #6,SP
980 014174 000544 BR BSRFLD ;DO THE FIELD REPORT
981
982 ;START PROCESSING THE ENTRIES
983 014176 10$:
984 014176 PRINTF #FMTSN,#CART,SERNM2,SERNM1
(10) 014176 013746 002274 MOV SERNM1,-(SP)
(9) 014202 013746 002276 MOV SERNM2,-(SP)
(8) 014206 012746 002526 MOV #CART,-(SP)
(7) 014212 012746 007707 MOV #FMTSN,-(SP)
(6) 014216 012746 000004 MOV #4,-(SP)
(3) 014222 010600 MOV SP,R0
(4) 014224 104417 TRAP C$PNTF
(4) 014226 062706 000012 ADD #12,SP
985 014232 005237 015350 INC PSNFG ;SET THE FLAG
986 014236 005037 002416 CLR TEMP1
987 014242 016203 030530 11$: MOV BSFILE(R2),R3 ;GET THE CYLINDER # FROM ENTRY
988 014246 005703 TST R3 ;SEE IF ITS OK TO USE
989 014250 100002 BPL 2$ ;OK
990 014252 000137 015352 JMP NOFACT ;WHOOOPS...ERROR
991 014256 005237 015330 2$: INC FACNUM ;COUNT THIS ENTRY
992 014262 022737 000176 015330 CMP #126.,FACNUM ;END OF FILE LIMIT?
993 014270 001506 BEQ BSRFLD ;YUP
994 014272 022737 000062 015330 CMP #50.,FACNUM ;TIME TO QUIT PRINTING?
995 014300 001040 BNE 21$ ;NO
996 014302 005737 002416 TST TEMP1 ;PRINTED ERROR MESSAGE YET?
997 014306 001035 BNE 21$ ;YUP
998 014310 PRINTF #FMT19,#OVRMAX ;TELL OPR OVER LIMIT
(8) 014310 012746 006251 MOV #OVRMAX,-(SP)
(7) 014314 012746 007631 MOV #FMT19,-(SP)
(6) 014320 012746 000002 MOV #2,-(SP)
```

```
(3) 014324 010600      MOV      SP,R0
(4) 014326 104417      TRAP     C$PNTF
(4) 014330 062706 000006  ADD      #6,SP
999 014334      PRINTF    #MCRLF
(7) 014334 012746 010041  MOV      #MCRLF,-(SP)
(6) 014340 012746 000001  MOV      #1,-(SP)
(3) 014344 010600      MOV      SP,R0
(4) 014346 104417      TRAP     C$PNTF
(4) 014350 062706 000004  ADD      #4,SP
1000 014354      GMANIL   TILLEND,TEMPO,177777,NO
(3) 014354 104443      TRAP     CSGMAN
(3) 014356 000404      BR       10002$
(4) 014360 002414      .WORD   TEMPO
(5) 014362 000120      .WORD   T$CODE
(5) 014364 006114      .WORD   TILLEND
(5) 014366 177777      .WORD   177777
(3) 014370      10002$:
1001 014370 005737 002414  TST      TEMPO          ;NO?
1002 014374 001444      BEQ      BSRFLD      ;QUIT PRINTING ENTRIES
1003 014376 005237 002416  INC      TEMP1          ;SET THE PRINT ERROR FLAG
1004 014402 010337 015332 21$: MOV     R3,BSFCYL      ;SAVE THE CYLINDER NUMBER
1005 014406 005722      TST      (R2)+        ;POINT TO HEAD & SECTOR ENTRY
1006 014410 016203 030530  MOV     BSFILE(R2),R3    ;GET IT
1007 014414 110337 015334  MOV     R3,BSFSEC        ;SAVE THE SECTOR NUMBER
1008 014420 000303      SWAB     R3          ;PUT THE HEAD # IN LOW BYTE
1009 014422 110337 015336  MOV     R3,BSFHD        ;SAVE THE HEAD NUMBER
1010 014426 005722      TST      (R2)+        ;POINT TO THE NEXT ENTRY
1011 014430      PRINTF    #FMTCSH,FACNUM,#CM$SG,BSFCYL,#SMS$G,BSFSEC,#HMSG,BSFHD
(14) 014430 013746 015336  MOV     BSFHD,-(SP)
(13) 014434 012746 002563  MOV     #HMSG,-(SP)
(12) 014440 013746 015334  MOV     BSFSEC,-(SP)
(11) 014444 012746 003243  MOV     #SMS$G,-(SP)
(10) 014450 013746 015332  MOV     BSFCYL,-(SP)
(9) 014454 012746 002550  MOV     #CM$SG,-(SP)
(8) 014460 013746 015330  MOV     FACNUM,-(SP)
(7) 014464 012746 007737  MOV     #FMTCSH,-(SP)
(6) 014470 012746 000010  MOV     #10,-(SP)
(3) 014474 010600      MOV     SP,R0
(4) 014476 104417      TRAP     C$PNTF
(4) 014500 062706 000022  ADD      #22,SP
1012 014504 000656      BR       11$          ;PROCESS THE NEXT ENTRY
1013
1014      ;HERE TO REPORT THE CONTENTS OF THE 'FIELD' FILE
1015 014506 004537 025076  BSRFLD: JSR    R5,RDFIELD ;GET THE FIELD BD SEC FILE
1016 014512 005002      CLR      R2          ;POINT TO THE 1ST SECTOR OF THE 'FIELD' FILE
1017 014514 012737 000020  MOV     #16.,SECMAX      ;SET THE LAST USABLE SECTOR NUMBER
1018 014522 005037 015342  CLR      SECNUM          ;POINT TO THE 1ST SECTOR IN FIELD FILE
1019 014526 005037 015326  CLR      FLDNUM          ;CLEAR THE FIELD ENTRY COUNTER
1020 014532 005037 015350  CLR      PSNFG          ;CLEAR THE PRINT FLAG FOR SERIAL #
1021 014536      PRINTF    #FMT18,#BSRF
(8) 014536 012746 005057  MOV     #BSRF,-(SP)
(7) 014542 012746 007624  MOV     #FMT18,-(SP)
(6) 014546 012746 000002  MOV     #2,-(SP)
(3) 014552 010600      MOV     SP,R0
(4) 014554 104417      TRAP     C$PNTF
(4) 014556 062706 000006  ADD      #6,SP
```

```
1022 014562 004537 015622 JSR R5,BSFOK ;FIND A SECTOR TO USE IN THE FIELD AREA
1023 014566 005737 015346 TST BSFOK ;ANY ERROR DETECTED?
1024 014572 001434 BEQ 10$ ;JUMP IF ...
1025 014574 PRINTF #FMT18,#NSWSEC
(8) 014574 012746 003636 MOV #NSWSEC,-(SP)
(7) 014600 012746 007624 MOV #FMT18,-(SP)
(6) 014604 012746 000002 MOV #2,-(SP)
(3) 014610 010600 MOV SP,R0
(4) 014612 104417 TRAP C$PNTF
(4) 014614 062706 000006 ADD #6,SP
1026 014620 004537 022570 JSR R5,NEWBSF ;BUILD A NEW FILE
1027 014624 005737 002414 TST TEMPO ;DID I?
1028 014630 001402 BEQ 1$ ;NO
1029 014632 004537 016770 JSR R5,WRTBSF ;WRITE UPDATED 'FIELD' BAD SECTOR FILE
1030 ;/ON THE PACK IF REQUESTED
1031 014636 1$: PRINTF #FMT18,#HYPHEN
(8) 014636 012746 002675 MOV #HYPHEN,-(SP)
(7) 014642 012746 007624 MOV #FMT18,-(SP)
(6) 014646 012746 000002 MOV #2,-(SP)
(3) 014652 010600 MOV SP,R0
(4) 014654 104417 TRAP C$PNTF
(4) 014656 062706 000006 ADD #6,SP
1032 014662 000544 BR BSRTOT ;PRINT THE TOTALS FOUND
1033
1034 ;HERE TO PROCESS ENTRIES FROM THE FIELD FILE
1035 014664 10$: PRINTF #FMTSN,#CART,SERNM2,SERNM1
1036 014664 MOV SERNM1,-(SP)
(10) 014664 013746 002274 MOV SERNM2,-(SP)
(9) 014670 013746 002276 MOV #CART,-(SP)
(8) 014674 012746 002526 MOV #FMTSN,-(SP)
(7) 014700 012746 007707 MOV #4,-(SP)
(6) 014704 012746 000004 MOV SP,R0
(3) 014710 010600 TRAP C$PNTF
(4) 014712 104417 ADD #12,SP
(4) 014714 062706 000012 INC PSNFG ;SET THE PRINT FLAG
1037 014720 005237 015350 CLR TEMP1
1038 014724 005037 002416 11$: MOV BSFILE(R2),R3 ;GET THE CYLINDER # FROM ENTRY
1039 014730 016203 030530 TST R3 ;SEE IF ITS OK TO USE
1040 014734 005703 BPL 2$ ;OK
1041 014736 100002 JMP NOFIELD ;ERROR!
1042 014740 000137 015440 2$: INC FLDNUM ;COUNT THIS ENTRY
1043 014744 005237 015326 CMP #126,FLDNUM ;END OF FIELD ENTRY LIMIT?
1044 014750 022737 000176 015326 BEQ BSRTOT ;YES
1045 014756 001506 015326 CMP #50,FLDNUM ;TIME TO QUIT PRINTING?
1046 014760 022737 000062 015326 BNE 21$ ;NO
1047 014766 001040 TST TEMP1 ;PRINT THE ERROR MESSAGE?
1048 014770 005737 002416 BNE 21$ ;NO
1049 014774 001035 PRINTF #FMT19,#OVRMAX ;YES - TELL OPR
1050 014776 (8) 014776 012746 006251 MOV #OVRMAX,-(SP)
(7) 015002 012746 007631 MOV #FMT19,-(SP)
(6) 015006 012746 000002 MOV #2,-(SP)
(3) 015012 010600 MOV SP,R0
(4) 015014 104417 TRAP C$PNTF
(4) 015016 062706 000006 ADD #6,SP
1051 015022 PRINTF #MCRLF
```



```

(7) 015022 012746 010041      MOV      #MCRLF,-(SP)
(6) 015026 012746 000001      MOV      #1,-(SP)
(3) 015032 010600              MOV      SP,R0
(4) 015034 104417              TRAP     C$PNTF
(4) 015036 062706 000004      ADD       #4,SP
1052 015042              GMANIL    TILLEND,TEMPO,177777,NO
(3) 015042 104443              TRAP     C$GMAN
(3) 015044 000404              BR       10003$
(4) 015046 002414              .WORD    TEMPO
(5) 015050 000120              .WORD    T$CODE
(5) 015052 006114              .WORD    TILLEND
(5) 015054 177777              .WORD    177777
(3) 015056              10003$:
1053 015056 005737 002414      TST      TEMPO              ;QUIT?
1054 015062 001444              BEQ      BSRTOT            ;YUP
1055 015064 005237 002416      INC      TEMP1            ;SET THE PRINT FLAG
1056 015070 010337 015332      21$:  MOV      R3,BSFCYL    ;SAVE THE CYLINDER NUMBER
1057 015074 005722              TST      (R2)+              ;POINT TO HEAD & SECTOR ENTRY
1058 015076 016203 030530      MOV      BSFILE(R2),R3    ;GET IT
1059 015102 110337 015334      MOVB     R3,BSFSEC        ;SAVE THE SECTOR NUMBER
1060 015106 000303              SWAB     R3                ;PUT THE HEAD # IN LOW BYTE
1061 015110 110337 015336      MOVB     R3,BSFHD         ;SAVE THE HEAD NUMBER
1062 015114 005722              TST      (R2)+              ;POINT TO THE NEXT ENTRY
1063 015116              PRINTF   #FMTC$H,FLDNUM,#CM$G,BSFCYL,#SM$G,BSFSEC,#HM$G,BSFHD
(14) 015116 013746 015336      MOV      BSFHD,-(SP)
(13) 015122 012746 002563      MOV      #HM$G,-(SP)
(12) 015126 013746 015334      MOV      BSFSEC,-(SP)
(11) 015132 012746 003243      MOV      #SM$G,-(SP)
(10) 015136 013746 015332      MOV      BSFCYL,-(SP)
(9) 015142 012746 002550      MOV      #CM$G,-(SP)
(8) 015146 013746 015326      MOV      FLDNUM,-(SP)
(7) 015152 012746 007737      MOV      #FMTC$H,-(SP)
(6) 015156 012746 000010      MOV      #10,-(SP)
(3) 015162 010600              MOV      SP,R0
(4) 015164 104417              TRAP     C$PNTF
(4) 015166 062706 000022      ADD       #22,SP
1064 015172 000656              BR       11$              ;PROCESS THE NEXT ENTRY
1065
1066
1067
1068 015174              ;PRINT THE TOTAL: FROM EACH SECTION
(9) 015174 013746 015330      BSRTOT: PRINTF   #FMITB,#TMMSG,FACNUM
(8) 015200 012746 003022      MOV      FACNUM,-(SP)
(7) 015204 012746 007724      MOV      #TMMSG,-(SP)
(6) 015210 012746 000003      MOV      #FMITB,-(SP)
(3) 015214 010600              MOV      #3,-(SP)
(4) 015216 104417              MOV      SP,R0
(4) 015220 062706 000010      TRAP     C$PNTF
1069 015224              ADD       #10,SP
(9) 015224 013746 015326      PRINTF   #FMITB,#TFMSG,FLDNUM
(8) 015230 012746 002777      MOV      FLDNUM,-(SP)
(7) 015234 012746 007724      MOV      #TFMSG,-(SP)
(6) 015240 012746 000003      MOV      #FMITB,-(SP)
(3) 015244 010600              MOV      #3,-(SP)
(4) 015246 104417              MOV      SP,R0
(4) 015250 062706 000010      TRAP     C$PNTF
                          ADD       #10,SP

```

1070 015254
(8) 015254 012746 002573
(7) 015260 012746 007624
(6) 015264 012746 000002
(3) 015270 010600
(4) 015272 104417
(4) 015274 062706 000006
1071 015300
(7) 015300 012746 010041
(6) 015304 012746 000001
(3) 015310 010600
(4) 015312 104417
(4) 015314 062706 000004
1072 015320 000137 013664
1073
1074
1075
1076 015324 000000
1077 015326 000000
1078 015330 000000
1079 015332 000000
1080 015334 000000
1081 015336 000000
1082 015340 000000
1083 015342 000000
1084 015344 000000
1085 015346 000000
1086 015350 000000
1087
1088
1089
1090 015352 005737 015330
1091 015356 001014
1092 015360 005037 015330
1093 015364
(8) 015364 012746 003532
(7) 015370 012746 007624
(6) 015374 012746 000002
(3) 015400 010600
(4) 015402 104417
(4) 015404 062706 000006
1094 015410
(8) 015410 012746 002675
(7) 015414 012746 007624
(6) 015420 012746 000002
(3) 015424 010600
(4) 015426 104417
(4) 015430 062706 000006
1095 015434 000137 014506
1096
1097
1098
1099 015440 005737 015326
1100 015444 001014
1101 015446 005037 015326
1102 015452

PRINTF #FMT18,#STARMMSG
MOV #STARMMSG,-(SP)
MOV #FMT18,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #6,SP
PRINTF #MCRLF
MOV #MCRLF,-(SP)
MOV #1,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #4,SP
JMP BSRPTS

;SELECT NEXT UNIT

;HERE IS THE STORAGE FOR THIS ROUTINE

NOSNUM: .WORD 0 ;HAVE SERIAL # FLAG
FLDNUM: .WORD 0 ;NUMBER OF CURRENT FIELD ENTRY
FACNUM: .WORD 0 ;NUMBER OF THE CURRENT FACTORY ENTRY
BSFCYL: .WORD 0 ;CURRENT CYLINDER FROM ENTRY IN PROCESS
BSFSEC: .WORD 0 ;CURRENT SECTOR FROM ENTRY
BSFHD: .WORD 0 ;CURRENT SURFACE (HEAD) FROM ENTRY IN PROCESS
SECMAX: .WORD 0 ;LAST USABLE SECTOR NUMBER IN SELECTED SECTION
SECNUM: .WORD 0 ;CURRENT SECTOR BEING USED TO EXTRACT ENTRYS
SECOLD: .WORD 0 ;START ADDR OF THE 'FOUND' SECTOR IN BAD SEC FILE
BSFOKF: .WORD 0 ;ERROR DETECT FLAG
PSNFG: .WORD 0 ;PRINT FLAG FOR SERIAL #

;HERE IF AT THE END OF THE FACTORY FILE

NOFACT: TST FACNUM ;WAS ANY ENTRY DETECTED?
BNE 1\$;YES
CLR FACNUM ;CLEAR THE ENTRY COUNTER FOR FACTORY SECTORS
PRINTF #FMT18,#HWSEC
MOV #HWSEC,-(SP)
MOV #FMT18,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #6,SP
1\$: PRINTF #FMT18,#HYPHEN
MOV #HYPHEN,-(SP)
MOV #FMT18,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #6,SP
JMP BSRFLD ;DO THE FIELD SECTION

;HERE IF AT THE END OF THE FIELD FILE

NOFIELD: TST FLDNUM ;ANY FIELD ENTRYS?
BNE 1\$;YES
CLR FLDNUM ;NO - CLEAR THE ENTRY COUNTER
PRINTF #FMT18,#SWSEC

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-36
GLOBAL SUBROUTINES

M 5

SEQ 0059

```

(8) 015452 012746 003610      MOV      #SWSEC,-(SP)
(7) 015456 012746 007624      MOV      #FMT18,-(SP)
(6) 015462 012746 000002      MOV      #2,-(SP)
(3) 015466 010600              MOV      SP,R0
(4) 015470 104417              TRAP     C$PNTF
(4) 015472 062706 000006      ADD       #6,SP
1103 015476                    1$: PRINTF  #FMT18,#HYPHEN
(8) 015476 012746 002675      MOV      #HYPHEN,-(SP)
(7) 015502 012746 007624      MOV      #FMT18,-(SP)
(6) 015506 012746 000002      MOV      #2,-(SP)
(3) 015512 010600              MOV      SP,R0
(4) 015514 104417              TRAP     C$PNTF
(4) 015516 062706 000006      ADD       #6,SP
1104 015522 000137 015174      JMP      BSRTOT          ;DO THE TOTALS
1105
1106                          ;HERE IF NO SERIAL NUMBER OR 2 0'S NOT DETECTED IN 1ST 4 WORDS OF SECTOR
1107
1108 015526 062737 000004 015342 NOMSEC: ADD      #4,SECNUM          ;UPDATE THE SECTOR NUMBER TO ACCESS NEXT BSF COPY
1109 015534 023737 015342 015340 CMP      SECNUM,SECMAX      ;AT THE END OF SECTION?
1110 015542 101416          BLOS      1$              ;BRANCH IF OK
1111 015544          PRINTF  #FMT18,#BSEND
(8) 015544 012746 003255      MOV      #BSEND,-(SP)
(7) 015550 012746 007624      MOV      #FMT18,-(SP)
(6) 015554 012746 000002      MOV      #2,-(SP)
(3) 015560 010600              MOV      SP,R0
(4) 015562 104417              TRAP     C$PNTF
(4) 015564 062706 000006      ADD       #6,SP
1112 015570 052737 177777 015346 BIS      #177777,BSFOKF      ;SET THE ERROR FLAG
1113 015576 000465          BR       BSFOKX          ;EXIT THE SECTOR FIND ROUTINE WITH ERROR SET
1114 015600 005737 002476      1$: TST      BSFFLG          ;IS BAD SECTOR FILE WRITTEN BY FIELD?
1115 015604 001003          BNE      2$              ;YES - BRANCH IF FIELD BAD SECTOR FILE
1116 015606 004537 025032      JSR      R5,RDFACT          ;ELSE, READ FACTORY BAD SECTOR FILE
1117 015612 000403          BR       BSFOK          ;CHECK IF THIS SECTOR IS O.K.
1118 015614 004537 025076      2$: JSR      R5,RDFIELD          ;READ FIELD BAD SECTOR FILE
1119 015620 000400          BR       BSFOK          ;CHECK IF THIS SECTOR IS O.K.

```

1121				
1122				
1123	015622	005037	015346	
1124	015626	012737	030530	015344
1125	015634	060237	015344	
1126	015640	005762	030530	
1127	015644	100730		
1128	015646	001006		
1129	015650	005762	030532	
1130	015654	001003		
1131	015656	052737	177777	015324
1132	015664	022762	177777	031126
1133	015672	001315		
1134	015674	022762	177777	031130
1135	015702	001311		
1136	015704	016237	030530	002274
1137	015712	005722		
1138	015714	005762	030530	
1139	015720	100702		
1140	015722	016237	030530	002276
1141	015730	005722		
1142	015732	005762	030530	
1143	015736	001273		
1144	015740	005722		
1145	015742	005762	030530	
1146	015746	001267		
1147	015750	005722		
1148	015752	000205		
1149				

```

BSFOK: CLR BSFOKF ;CLEAR THE ERROR FLAG
MOV #BSFILE,SECOLD ;GET BASIC ADDRESS
ADD R2,SECOLD ;ADD IN THE OFFSET
TST BSFILE(R2) ;SEE IF ANY SERIAL NUMBER
BMI NOMSEC ;IF -1 JUMP TO ERROR SERVICE
BNE 1$ ;IF >0 THEN HAVE A NUMBER
TST BSFILE+2(R2) ;ANY SER. NUM IN WORD 2?
BNE 1$ ;BR IF OK
BIS #177777,NOSNUM ;SET THE NO SERIAL NUMBER FLAG
1$: CMP #-1,BSFILE+254.(R2) ;END OF SECTOR OK ALSO?
BNE NOMSEC ;NO - NO MATCH HERE!
CMP #-1,BSFILE+256.(R2) ;END OK HERE TOO?
BNE NOMSEC ;NO - DON'T HAVE A BAD SECT FILE YET!
MOV BSFILE(R2),SERNM1 ;SAVE LOW ORDER OF SERIAL #
TST (R2)+ ;POINT TO HIGH ORDER OF SERIAL #
TST BSFILE(R2) ;SEE IF LEGAL
BMI NOMSEC ;NO - ERROR
MOV BSFILE(R2),SERNM2 ;SAVE HIGH ORDER OF SERIAL #
TST (R2)+ ;POINT TO A BLANK ENTRY
TST BSFILE(R2) ;SEE IF LEGAL (=0)
BNE NOMSEC ;NO - ERROR
TST (R2)+ ;POINT TO LAST CHECK ENTRY SPOT
TST BSFILE(R2) ;SEE IF LEGAL (=0)
BNE NOMSEC ;NO - ERROR
TST (R2)+ ;POINT TO 1ST VALID ENTRY IN SECTOR
BSFOKX: RTS R5 ;EXIT - R2 POINTS TO THE OFFSET VALUE
;AND SECNUM = CURRENT SECTOR IN FILE

```

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-38
GLOBAL SUBROUTINES

SEQ 0061

1151 015754
(2)
1152
1153 015754
(2)
1154
1155 015754
(8) 015754 012746 005164
(7) 015760 012746 007631
(6) 015764 012746 000002
(3) 015770 010600
(4) 015772 104417
(4) 015774 062706 000006
1156 016000 004537 012370
1157 016004 000137 013546
1158 016010 000404
1159 016012 004537 012400
1160 016016 000137 013546
1161 016022 004537 025246
1162 016026 005737 002414
1163 016032 001403
1164 016034 004537 012642
1165 016040 000764
1166
1167 016042 004537 012546
1168 016046 004537 023656
1169 016052 005737 002464
1170 016056 001414
1171 016060
(8) 016060 012746 004125
(7) 016064 012746 007624
(6) 016070 012746 000002
(3) 016074 010600
(4) 016076 104417
(4) 016100 062706 000006
1172 016104 000137 013546
1173
1174 016110
(3) 016110 104443
(3) 016112 000404
(4) 016114 002414
(5) 016116 000120
(5) 016120 006750
(5) 016122 000001
(3) 016124
1175 016124 005737 002414
1176 016130 001730
1177
1178 016132 005737 015324
1179 016136 001470
1180 016140
(7) 016140 012746 010041
(6) 016144 012746 000001
(3) 016150 010600
(4) 016152 104417
(4) 016154 062706 000004

STARS
:*****
:HERE IS THE ROUTINE TO ADD AN ENTRY INTO THE 'FIELD' BAD SECTOR FILE
STARS
:*****
BSADD: PRINTF #FMT19,#ABSMMSG
MOV #ABSMMSG,-(SP)
MOV #FMT19,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #6,SP
JSR R5,FIRST ;SELECT 1ST UNIT
JMP NXTCMD ;NONE AVAIL.!
BR BSADDL
BSADDS: JSR R5,SELDRV ;SELECT THE NEXT UNIT
JMP NXTCMD ;ALL DONE
BSADDL: JSR R5,LOADED ;DRV READY?
TST TEMPO ;WELL?
BEQ 1\$;YES
JSR R5,DRNRDY
BR BSADDS ;SELECT THE NEXT UNIT
1\$: JSR R5,DRVID ;TELL OPR WHAT DRIVE
JSR R5,RDBDSC ;GET A FRESH COPY OF THE BAD SECTOR FILE
TST ACCESS ;ALLOWED TO DO IT?
BEQ BSATD ;YES
PRINTF #FMT18,#DENIED
MOV #DENIED,-(SP)
MOV #FMT18,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #6,SP
JMP NXTCMD ;TELL OPR NOT ALLOWED & EXIT
BSATD: GMANIL THISDRV,TEMPO,1,NO
TRAP C\$GMAN
BR 10004\$
.WORD TEMPO
.WORD T\$CODE
.WORD THISDRV
.WORD 1
10004\$: TST TEMPO
BEQ BSADDS ;BRANCH IF NOT TO USE THIS DRIVE
BSASN: TST NOSNUM ;SEE IF NEED A SERIAL NUMBER
BEQ GETCYL ;JUMP IF HAVE A NUMBER
PRINTF #MCRLF
MOV #MCRLF,-(SP)
MOV #1,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #4,SP

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 K 5
GLOBAL SUBROUTINES PAGE 1-39

1181 016160
(3) 016160 104443
(3) 016162 000404
(4) 016164 002414
(5) 016166 000120
(5) 016170 005352
(5) 016172 000001
(3) 016174
1182 016174 005737 002414
1183 016200 001447
1184 016202
(3) 016202 104443
(3) 016204 000406
(4) 016206 002456
(5) 016210 000022
(5) 016212 005415
(5) 016214 077777
(5) 016216 000001
(5) 016220 077777
(3) 016222
1185 016222
(3) 016222 104443
(3) 016224 000406
(4) 016226 002460
(5) 016230 000022
(5) 016232 005471
(5) 016234 077777
(5) 016236 000000
(5) 016240 077777
(3) 016242
1186 016242
(10) 016242 013746 002456
(9) 016246 013746 002460
(8) 016252 012746 002526
(7) 016256 012746 007707
(6) 016262 012746 000904
(3) 016266 010600
(4) 016270 104417
(4) 016272 062706 000012
1187 016276
(3) 016276 104443
(3) 016300 000404
(4) 016302 002414
(5) 016304 000120
(5) 016306 006007
(5) 016310 177777
(3) 016312
1188 016312 005737 002414
1189 016316 001720
1190
1191

GETSN: GMANIL ABSSER,TEMPO,1,NO
TRAP C\$GMAN
BR 10005\$
.WORD TEMPO
.WORD T\$CODE
.WORD ABSSER
.WORD 1
10005\$: TST TEMPO ;SEE IF YES (=1)
BEQ GETCYL ;BRANCH IF NO
GMANID ABSSNL,SN1,0,77777,1,77777,NO
TRAP C\$GMAN
BR 10006\$
.WORD SN1
.WORD T\$CODE
.WORD ABSSNL
.WORD 77777
.WORD T\$LOLIM
.WORD T\$HILIM
10006\$: GMANID ABSSNH,SN2,0,77777,0,77777,NO
TRAP C\$GMAN
BR 10007\$
.WORD SN2
.WORD T\$CODE
.WORD ABSSNH
.WORD 77777
.WORD T\$LOLIM
.WORD T\$HILIM
10007\$: PRINTF #FMTSN,#CART,SN2,SN1
MOV SN1,-(SP)
MOV SN2,-(SP)
MOV #CART,-(SP)
MOV #FMTSN,-(SP)
MOV #4,-(SP)
MOV SP,R0
TRAP C\$PNTF
ADD #12,SP
GMANIL VALSN,TEMPO,177777,NO
TRAP C\$GMAN
BR 10010\$
.WORD TEMPO
.WORD T\$CODE
.WORD VALSN
.WORD 177777
10010\$: TST TEMPO ;JMP IF NO
BEQ GETSN ;NO VALID SERIAL NUMBER - ASK AGAIN

```

1193
1194 016320
(3) 016320 104443
(3) 016322 000406
(4) 016324 015332
(5) 016326 000042
(5) 016330 005254
(5) 016332 000777
(5) 016334 000000
(5) 016336 000777
(3) 016340
1195
1196
1197 016340 022737 000001 0023'6
1198 016346 001017
1199 016350 022737 000377 015332
1200 016356 103013
1201 016360
(8) 016360 012746 005756
(7) 016364 012746 007631
(6) 016370 012746 000002
(3) 016374 010600
(4) 016376 104417
(4) 016400 062706 000006
1202 016404 000745
1203 016406
(3) 016406 104443
(3) 016410 000406
(4) 016412 015334
(5) 016414 000042
(5) 016416 005304
(5) 016420 000077
(5) 016422 000000
(5) 016424 000047
(3) 016426
1204 016426
(3) 016426 104443
(3) 016430 000406
(4) 016432 015336
(5) 016434 000042
(5) 016436 005331
(5) 016440 000003
(5) 016442 000000
(5) 016444 000001
(3) 016446
1205
1206
1207
1208 016446 013700 015332
1209 016452 000300
1210 016454 000241
1211 016456 006000
1212 016460 103002
1213 016462 052700 100000
1214 016466 053700 015334
1215 016472 005737 015336

```

```

GETCYL: GMANID ABSCYL,BSFCYL,D,777,0,511.,NO
TRAP CS$GMAN
BR 10011$
.WORD BSFCYL
.WORD T$CODE
.WORD ABSCYL
.WORD 777
.WORD T$LOLIM
.WORD T$HILIM

```

10011\$:
;CHECK FOR A VALID RL01 CYL IF DRIVE=RL01

```

CMP #1,TDR ;RL01=1
BNE GETSEC ;SKIP CHECK IF RL02
CMP #255.,BSFCYL ;VALID RL01 CYLINDER?
BHS GETSEC ;YES
PRINTF #FMT19,RL1CLM ;NO - TELL OPR
MOV #RL1CLM,-(SP)
MOV #FMT19,-(SP)
MOV #2,-(SP)
MOV SP,RO
TRAP CS$PNTF
ADD #6,SP
BR GETCYL ;GET CYL AGAIN

```

```

GETSEC: GMANID ABSSEC,BSFSEC,D,77,0,39.,NO
TRAP CS$GMAN
BR 10012$
.WORD BSFSEC
.WORD T$CODE
.WORD ABSSEC
.WORD 77
.WORD T$LOLIM
.WORD T$HILIM

```

```

10012$: GMANID ABSHD,BSFHD,D,3,0,1,NO
TRAP CS$GMAN
BR 10013$
.WORD BSFHD
.WORD T$CODE
.WORD ABSHD
.WORD 3
.WORD T$LOLIM
.WORD T$HILIM

```

10013\$:
;CHECK TO SEE IF THE NEW ENTRY ALREADY EXISTS IN THE FILE

```

MOV BSFCYL,RO ;GET THE CYL TYPED
SWAB RO
CLC ;CLEAR THE 'C' BIT
ROR RO
BCC 1$ ;BR IF DON'T NEED THE EXTRA BIT
BIS #BIT15,RO ;ADD HIGH ORDER BIT IN CYL #
BIS BSFSEC,RO ;ADD IN THE SECTOR NUMBER
TST BSFHD ;ON HEAD ??

```

1216 016476 001402
1217 016500 052700 000100
1218 016504 010037 002410
1219 016510 004537 027340
1220 016514 005737 002406
1221 016520 001414
1222 016522
(8) 016522 012746 004171
(7) 016526 012746 007624
(6) 016532 012746 000002
(3) 016536 010600
(4) 016540 104417
(4) 016542 062706 000006
1223 016546 000137 016012

ACKENT: BEQ ACKENT ;BR IF HEAD 0
BIS #100,RO ;MAKE IT HEAD #1
MOV RO,CHKSEC ;SAVE FOR THE CHECK
JSR R5,CKBDS ;CHECK TO SEE IF ALREADY IN BAD SECT FILE
TST HDRFND ;HEADER IN FILE?
BEQ 1\$;BR IF NOT IN FILE
PRINTF #FMT18,#EXISTS ;TELL OPR ENTRY IN FILE NOW
MOV #EXISTS,-(SP)
MOV #FMT18,-(SP)
MOV #2,-(SP)
MOV SP,RO
TRAP C\$PNTF
ADD #6,SP
JMP BSADDS ;SELECT THE NEXT UNIT

;WE NOW HAVE THE NEW ENTRY DATA NEEDED TO GENERATE A BAD SECTOR FILE
;ENTRY...FIND A FREE SPOT IN THE BAD SECTOR FILE 'FIELD' AREA FOR THE
;ADDITION AND THEN UPDATE THE BAD SECTOR FILE ITSELF (MEDIA).

1229 016552
(8) 016552 012746 006200
(7) 016556 012746 007624
(6) 016562 012746 000002
(3) 016566 010600
(4) 016570 104417
(4) 016572 062706 000006
1230 016576 005037 015342
1231 016602 005002
1232 016604 012737 000020 015340
1233 016612 005037 015326
1234 016616 004537 015622
1235 016622 005737 015346
1236 016626 001421
1237 016630
(8) 016630 012746 003636
(7) 016634 012746 007624
(6) 016640 012746 000002
(3) 016644 010600
(4) 016646 104417
(4) 016650 062706 000006
1238 016654 004537 022570
1239 016660 005737 002414
1240 016664 001002
1241 016666 000137 016012

1\$: PRINTF #FMT18,#NEWENT ;TELL OPR IT IS A NEW ENTRY
MOV #NEWENT,-(SP)
MOV #FMT18,-(SP)
MOV #2,-(SP)
MOV SP,RO
TRAP C\$PNTF
ADD #6,SP
CLR SECNUM ;START THE SEARCH AT SECTOR 20.
CLR R2 ;POINT TO THE STARTING AREA IN BSFILE
MOV #16,SECNUM ;THIS IS THE LAST AVAIL. SECTOR PAIR
CLR FLDNUM ;START AT ENTRY #1
JSR R5,BSFOK ;FIND A 'FIELD' SECTOR AREA
TST BSFOK ;ON A SECTOR?
BEQ 2\$;YES
PRINTF #FMT18,#NSWSEC ;NO - TELL OPR
MOV #NSWSEC,-(SP)
MOV #FMT18,-(SP)
MOV #2,-(SP)
MOV SP,RO
TRAP C\$PNTF
ADD #6,SP
JSR R5,NEWBSF ;ASK OPR IF TIME TO MAKE A 'FIELD' BSF
TST TEMPO ;WAS A FILE BUILT?
BNE 2\$;YES - CONTINUE
JMP BSADDS ;SELECT THE NEXT UNIT

1242
1243 016672 005737 015324
1244 016676 001406
1245 016700 013777 002456 176436
1246 016706 013777 002460 176432
1247 016714 005237 015326
1248 016720 005762 030530
1249 016724 100403
1250 016726 062702 000004
1251 016732 000757

2\$: TST NOSNUM ;PACK HAVE A SERIAL # ??
BEQ 21\$;YUP
MOV SN1,@SECOLD ;NO - SAVE LOW 5 #
MOV SN2,@SECOLD+2 ;SAVE HIGH 5 #
21\$: INC FLDNUM ;COUNT THIS ENTRY TO BE TESTED
TST BSFILE(R2) ;SEE IF A FREE SLOT
BMI 3\$;I FOUND IT...
ADD #4,R2 ;POINT TO THE NEXT ENTRY
BR 2\$;AND TRY THE NEXT SLOT

1252
1253 016734 013762 015332 030530

3\$: MOV BSFCYL,BSFILE(R2) ;INSERT THE CYLINDER NUMBER

CZRLMB0 RL01/02 BD SEC FIL TL MACV11 30A(1052) 17-DEC-79 10:53 N 5
CZRLMB.MAC 12-DEC-79 14:06 GLOBAL SUBROUTINES PAGE 1-42

1254 016742 013703 015336
1255 016746 000303
1256 016750 063703 015334
1257 016754 010362 030532
1258
1259
1260
1261 016760 004537 016770
1262
1263
1264 016764 000137 016012

MOV BSFHD,R3 ;GET THE SELECTED HEAD
SWAB R3 ;SWAP BYTES TO POSITION THE HD BIT
ADD BSFSEC,R3 ;R3 NOW HAS COMPLETE HD & SEC ENTRY
MOV R3,BSFILE+2(R2) ;INSERT 2ND HALF OF ENTRY

;INSERT THE ENTRY INTO REST OF THE 'FIELD' FILE

48: JSR R5,WRTBSF ;WRITE UPDATED 'FIELD' BAD SECTOR FILE
;ON THE PACK IF REQUESTED

JMP BSADDS ;SELECT THE NEXT UNIT

```

1266 016770 STARS
(2) :*****
1267 :HERE IS WHERE THE 'FIELD' FILE IS WRITTEN ON THE PACK.
1268 :THE OPERATOR IS ASKED IF IT IS TIME TO UPDATE THE PACK...IF NOT, THEN
1269 :THIS CODE IS ABORTED.
1270 016770 STARS
(2) :*****
1271 :*****
1272 016770 010146 WRTBSF: MOV R1,-(SP) ;SAVE R1
1273 016772 PRINTF #MCRLF
(7) 016772 012746 010041 MOV #MCRLF,-(SP)
(6) 016776 012746 000001 MOV #1,-(SP)
(3) 017002 010600 MOV SP,R0
(4) 017004 104417 TRAP CSPNTR
(4) 017006 062706 000004 ADD #4,SP
1274 017012 GMANIL DOWRT,TEMPO,177777,NO
(3) 017012 177777 TRAP CSGMAN
(3) 017014 000004 BR 10014$
(4) 017016 002414 .WORD TEMPO
(5) 017020 000120 .WORD T$CODE
(5) 017022 005546 .WORD DOWRT
(5) 017024 177777 .WORD 177777
(3) 017026 10014$: TST TEMPO ;YES? (=1)
1275 017026 005737 002414 BEQ 3$ ;EXIT IF 'NO'
1276 017032 001545 JSR R5,LOADED ;READY?
1277 017034 004537 025246 TST TEMPO ;WELL?
1278 017040 005737 002414 BEQ 11$ ;YES
1279 017044 001413 PRINTF #FMT18,#NOTRDY ;NO
1280 017046 (8) 017046 012746 006505 MOV #NOTRDY,-(SP)
(7) 017052 012746 007624 MOV #FMT18,-(SP)
(6) 017056 012746 000002 MOV #2,-(SP)
(3) 017062 010600 MOV SP,R0
(4) 017064 104417 TRAP CSPNTR
(4) 017066 062706 000006 ADD #6,SP
1281 017072 000525 BR 3$
1282 017074 004537 025422 11$: JSR R5,GETDST
1283 017100 032701 020000 BIT #WL,R1 ;DRIVE WRITE LOCKED?
1284 017104 001413 BEQ 5$ ;NO
1285 017106 PRINTF #FMT18,#WRTLCK ;YES
(8) 017106 012746 003460 MOV #WRTLCK,-(SP)
(7) 017112 012746 007624 MOV #FMT18,-(SP)
(6) 017116 012746 000002 MOV #2,-(SP)
(3) 017122 010600 MOV SP,R0
(4) 017124 104417 TRAP CSPNTR
(4) 017126 062706 000006 ADD #6,SP
1286 017132 000505 BR 3$
1287 017134 012737 000005 002500 5$: MOV #5,CPYCNT ;INITIALIZE COPY COUNT FOR DUPLICATION OF
1288 :/THE 'FIELD' BAD SECTOR FILE ON THE PACK
1289 017142 012737 177000 002246 12$: MOV #-512,.BMP ;SET UP THE WORD COUNT
1290 017150 012737 077724 002244 MC/ #77724,BDA ;START THE WRITE AT SECTOR 20. (RL01)
1291 017156 022737 000001 002316 CMP #1,TDR ;RL02?
1292 017164 001403 BEQ 1$ ;JUMP IF RL01
1293 017166 012737 177724 002244 MOV #177724,BDA ;START AT SECTOR 20. FOR RL02
1294 017174 012737 000012 002260 1$: MOV #WRT,'E,FUNC ;LOAD THE FUNCTION
1295 017202 005737 002300 TST NEWFAC ;MAKING A DUMMY 'FACTORY' FILE?

```

```

1296 017206 001405      BEQ      13$      ;NO
1297 017210 042737 000077 002244      BIC      #77,BDA      ;YES - START AT SECTOR 00
1298 017216 005037 002300      CLR      NEWFAC      ;CLEAR THE FLAG ALSO
1299 017222 005237 002320      13$: INC      WRIPG      ;SET THE WRITE IN PROGRESS FLAG
1300 017226 004537 023534      JSR      R5,LDFUNC      ;DO THE WRITE OF THE UPDATED 'FIELD'
1301      ;/BAD SECTOR FILE
1302 017232 004537 025310      JSR      R5,WTRDY      ;WAIT FOR READY
1303 017236 005337 002500      DEC      CPYCNT      ;DECREMENT COPY COUNT
1304 017242 005777 163002      TST      @DCS      ;WAS THE TRANSFER GOOD?
1305 017246 100407      BMI      4$      ;BRANCH TO REPORT 'CANNOT UPDATE BAD SECTOR'
1306      ;/FILE ON PACK''
1307 017250 005737 002500      TST      CPYCNT      ;IS ENTIRE 'FIELD' BAD SECTOR FILE
1308      ;/WRITTEN ON THE PACK?
1309 017254 001420      BEQ      2$      ;BRANCH TO PRINT TIME AND REPORT
1310      ;/OPERATION IS COMPLETED
1311 017256 062737 000004 002244      ADD      #4,BDA      ;ELSE, ADD OFFSET TO DISK ADDRESS REGISTER TO
1312      ;/ACCESS THE NEXT SECTOR GROUP IN WHICH TO
1313      ;/DUPLICATE THE BAD SECTOR FILE
1314 017264 000726      BR      12$      ;BRANCH TO REPEAT WRITE OPERATION
1315
1316      ;HERE IF AN ERROR DETECTED WHILE UPDATING THE MEDIA
1317
1318 017266      4$: PRINTF #FMT18,#BADWRT      ;REPORT 'CANNOT UPDATE BAD SECTOR FILE ON PACK''
      (8) 017266 012746 005610      MOV      #BADWRT,-(SP)
      (7) 017272 012746 007624      MOV      #FMT18,-(SP)
      (6) 017276 012746 000002      MOV      #2,-(SP)
      (3) 017302 010600      MOV      SP,R0
      (4) 017304 104417      TRAP     C$PNTF
      (4) 017306 062706 000006      ADD      #6,SP
1319 017312 000137 013546      JMP      NXTCMD      ;BACK TO THE QUERY LOOP
1320 017316 004537 012502      2$: JSR      R5,PTIME      ;PRINT THE SYS RUN TIME
1321 017322      PRINTF #FMT18,#MDONE      ;TELL OPR - DONE
      (8) 017322 012746 003720      MOV      #MDONE,-(SP)
      (7) 017326 012746 007624      MOV      #FMT18,-(SP)
      (6) 017332 012746 000002      MOV      #2,-(SP)
      (3) 017336 010600      MOV      SP,R0
      (4) 017340 104417      TRAP     C$PNTF
      (4) 017342 062706 000006      ADD      #6,SP
1322 017346 012601      3$: MOV      (SP)+,R1      ;RESET R1
1323 017350 000205      RTS      R5      ;EXIT ROUTINE

```

```
1325 017352      STARS
(2)              ;*****
1326              ;HERE IS THE CODE TO SERVICE REMOVING AN ENTRY FROM THE 'FIELD' BAD
1327              ;SECTOR FILE
1328 017352      STARS
(2)              ;*****
1329
1330 017352      BSDEL: PRINTF #FMT19,#DELMMSG          ;TELL OPR ABOUT TO DELETE...
(8) 017352 012746 005656      MOV #DELMMSG,-(SP)
(7) 017356 012746 007631      MOV #FMT19,-(SP)
(6) 017362 012746 000002      MOV #2,-(SP)
(3) 017366 010600      MOV SP,R0
(4) 017370 104417      TRAP C$PNTF
(4) 0173 2 062706 000006      ADD #6,SP
1331 017376 004537 012370      JSR R5,FIRST          ;SELECT THE 1ST UNIT
1332 017402 000137 013546      JMP NXTCMD          ;NONE AVAIL.!
1333 017406 000404      BR BSDELL
1334 017410 004537 012400      BSDELS: JSR R5,SELDRV      ;SELECT NEXT UNIT
1335 017414 000137 013546      JMP NXTCMD          ;ALL DONE
1336 017420 004537 025246      BSDELL: JSR R5,LOADED      ;READY?
1337 017424 005737 002414      TST TEMPO
1338 017430 001403      BEQ 1$          ;YES
1339 017432 004537 012642      JSR R5,DRNRDY
1340 017436 000764      BR BSDELS          ;SELECT THE NEXT UNIT
1341
1342 017440 004537 012546      1$: JSR R5,DR1D          ;TELL OPR WHAT DRIVE SELECTED
1343 017444 004537 023656      JSR R5,RL1SC          ;GET A FRESH COPY OF THE BAD SEC FILE
1344 017450 005737 002464      TST ACCESS          ;ALLOWED TO PROCEED?
1345 017454 001414      BEQ BSDELLD          ;YES
1346 017456      PRINTF #FMT18,#DENIED          ;NO - TELL OPR
(8) 017456 012746 004125      MOV #DENIED,-(SP)
(7) 017462 012746 007624      MOV #FMT18,-(SP)
(6) 017466 012746 000002      MOV #2,-(SP)
(3) 017472 010600      MOV SP,R0
(4) 017474 104417      TRAP C$PNTF
(4) 017476 062706 000006      ADD #6,SP
1347 017502 000137 013546      JMP NXTCMD          ;BACK TO THE QUERY LOOP
1348
1349 017506      BSDELLD: GMANIL THISDRV,TEMPO,1,NO
(3) 017506 104443      TRAP C$GMAN
(3) 017510 000404      BR 10015$
(4) 017512 002414      .WORD TEMPO
(5) 017514 000120      .WORD T$CODE
(5) 017516 006750      .WORD THISDRV
(5) 017520 000001      .WORD 1
(3) 017522
1350 017522 005737 002414      10015$: TST TEMPO
1351 017526 001730      BEQ BSDELS          ;RE-SELECT IF NOT THIS DRIVE
1352
1353 017530      BSDEL1: PRINTF #MCRLF
(7) 017530 012746 010041      MOV #MCRLF,-(SP)
(6) 017534 012746 000001      MOV #1,-(SP)
(3) 017540 010600      MOV SP,R0
(4) 017542 104417      TRAP C$PNTF
(4) 017544 062706 000004      ADD #4,SP
1354 017550      GMANID DELCYL,BSFCYL,D,777,0,511.,NO
```

```
(3) 017550 104443      TRAP      C$GMAN
(3) 017552 000406      BR        10016$
(4) 017554 015332      .WORD     BSFCYL
(5) 017556 000042      .WORD     T$CODE
(5) 017560 005254      .WORD     DELCYL
(5) 017562 000777      .WORD     777
(5) 017564 000000      .WORD     T$LOLIM
(5) 017566 000777      .WORD     T$HILIM
(3) 017570
1355 017570      10016$: GMANID   DELSEC,BSFSEC,D,77,0,39.,NO
(3) 017570 104443      TRAP      C$GMAN
(3) 017572 000406      BR        10017$
(4) 017574 015334      .WORD     BSFSEC
(5) 017576 000042      .WORD     T$CODE
(5) 017600 005304      .WORD     DELSEC
(5) 017602 000077      .WORD     77
(5) 017604 000000      .WORD     T$LOLIM
(5) 017606 000047      .WORD     T$HILIM
(3) 017610
1356 017610      10017$: GMANID   DELHD,BSFHD,D,3,0,1,NO
(3) 017610 104443      TRAP      C$GMAN
(3) 017612 000406      BR        10020$
(4) 017614 015336      .WORD     BSFHD
(5) 017616 000042      .WORD     T$CODE
(5) 017620 005331      .WORD     DELHD
(5) 017622 000003      .WORD     3
(5) 017624 000000      .WORD     T$LOLIM
(5) 017626 000001      .WORD     T$HILIM
(3) 017630
1357 017630 013700 015332      10020$: MOV      BSFCYL,R0      ;COPY THE CYL TO REMOVE
1358 017634 000300      SWAB     R0      ;PUT IT IN HIGH BYTE
1359 017636 000241      CLC
1360 017640 006000      ROR      R0
1361 017642 103002      BCC      1$
1362 017644 052700 100000      BIS      #BIT15,R0      ;BR IF DON'T WANT ANOTHER BIT
1363 017650 053700 015334      BIS      BSFSEC,R0      ;ADD IN HIGH ORDER CYL BIT
1364 017654 005737 015336      TST      BSFHD      ;ADD IN THE SECTOR NUMBER
1365 017660 001402      BEQ      2$      ;ON HEAD 0??
1366 017662 052700 000100      BIS      #100,R0      ;YES
1367 017666 010037 002410      MOV      R0,CHKSEC      ;NO - POINT TO HEAD 1
1368 017672 004537 027340      JSR      R5,CKBDSC      ;SAVE THE COMPACTED DISK ADDRESS
1369 017676 005737 002406      TST      HDRFND      ;CHECK TO SEE IF ENTRY EXISTS
1370 017702 001014      BNE      10$      ;FOUND?
1371 017704      PRINTF   #FMT18,#NOENTRY      ;YES
(8) 017704 012746 005725      MOV      #NOENTRY,-(SP)      ;NO
(7) 017710 012746 007624      MOV      #FMT18,-(SP)
(6) 017714 012746 000002      MOV      #2,-(SP)
(3) 017720 010600      MOV      SP,R0
(4) 017722 104417      TRAP      C$PNTF
(4) 017724 062706 000006      ADD      #6,SP
1372 017730 000137 017410      JMP      BSDELS      ;SELECT THE NEXT UNIT
1373
1374 017734 004537 025076      10$: JSR      R5,RDFIELD      ;GET THE FIELD BAD SEC FILE
1375 017740 005002      CLR      R2
1376 017742 005037 015342      CLH      SECNUM
1377 017746 005037 015326      CLR      FLDNUM
```

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 F 6
GLOBAL SUBROUTINES PAGE 1-47

SEQ 0070

```

1378 017752 012737 000020 015340      MOV      #16,,SECMAX
1379 017760 004537 015622      JSR      R5,BSFOK          ;POINT TO A WORK AREA
1380 017764 005737 015346      TST      BSFOKF          ;POINTING TO A VALID AREA?
1381 017770 001421              BEQ      11$              ;YES - PROCEED
1382 017772              PRINTF  #FMT18,#NSWSEC          ;TELL OPR THAT ERROR EXISTS
      (8) 017772 012746 003636      MOV      #NSWSEC,-(SP)
      (7) 017776 012746 007624      MOV      #FMT18,-(SP)
      (6) 020002 012746 000002      MOV      #2,-(SP)
      (3) 020006 010600              MOV      SP,R0
      (4) 020010 104417              TRAP     C$PNTF
      (4) 020012 062706 000006      ADD      #6,SP
1383 020016 004537 022570      JSR      R5,NEWBSF          ;SEE IF OPR WANTS TO MAKE A FILE
1384 020022 005737 002414      TST      TEMPO          ;PROCEED IF A 'FIELD' FILE BUILT
1385 020026 001002              BNE      11$          ;BR - FILE WAS BUILT
1386 020030 000137 017410      JMP      BSDELS          ;SELECT THE NEXT UNIT
1387
1388 020034 023762 015332 030530 11$:  CMP      BSFCYL,BSFILE(R2)      ;AT CORRECT ENTRY?
1389 020042 001027              BNE      20$          ;NOPE! UPDATE POINTER
1390 020044 013737 015336 002416      MOV      BSFHD,TEMP1      ;GET THE HEAD SELECTED
1391 020052 000337 002416              SWAB     TEMP1          ;PUT IT IN HIGH BYTE
1392 020056 053737 015334 002416      BIS      %SFSEC,TEMP1      ;ADD IN THE SECTOR BITS
1393 020064 023762 002416 030532      CMP      TEMP1,BSFILE+2(R2) ;CORRECT SECTOR TOO?
1394 020072 001013              BNE      20$          ;NO - UPDATE POINTER
1395
1396              ;HAVE THE ENTRY SLOT NOW ... KILL THE ENTRY & MOVE ALL OTHERS UP 1
1397
1398 020074 016262 030534 030530 12$:  MOV      BSFILE+4(R2),BSFILE(R2) ;MOVE NEXT CYL ENTRY UP
1399 020102 016262 030536 030532      MOV      BSFILE+6(R2),BSFILE+2(R2) ;MOVE NEXT SECT ENTRY UP
1400 020110 005762 030534              TST      BSFILE+4(R2)      ;END OF ENTRIES YET?
1401 020114 100422              BMI      3$          ;YUP - EXIT
1402 020116 022222              CMP      (R2)+,(R2)+      ;POINT TO THE NEXT SLOT OF ENTRIES
1403 020120 000765              BR       12$          ;AND DO AGAIN
1404
1405              ;UPDATE THE ENTRY SLOT POINTER
1406
1407 020122 022222 030530 20$:  CMP      (R2)+,(R2)+      ;UPDATE POINTER BY 2 LOCATIONS
1408 020124 005762              TST      BSFILE(R2)      ;END OF ENTRIES?
1409 020130 100341              BPL      11$          ;NO - LOOK AT THIS SLOT
1410
1411              ;HERE IF NO 'FIELD' ENTRY DETECTED ON THE PACK
1412
1413 020132              PRINTF  #FMT18,#NOFLDE          ;TELL OPR NO 'FIELD' ENTRY HERE
      (8) 020132 012746 003662      MOV      #NOFLDE,-(SP)
      (7) 020136 012746 007624      MOV      #FMT18,-(SP)
      (6) 020142 012746 000002      MOV      #2,-(SP)
      (3) 020146 010600              MOV      SP,R0
      (4) 020150 104417              TRAP     C$PNTF
      (4) 020152 062706 000006      ADD      #6,SP
1414 020156 000137 017410      JMP      BSDELS          ;SELECT THE NEXT UNIT
1415
1416              ;HERE TO CLEAR THIS ENTRY FROM REST OF FIELD BAD SECTOR FILE
1417              ;WILL COPY THIS MODIFIED SECTOR PAIR INTO THE ENTIRE 'FIELD' BAD SEC FILE
1418
1419 020162 004537 016770 3$:  JSR      R5,WRTBSF          ;WRITE UPDATED 'FIELD' BAD SECTOR FILE
1420
1421 020166 000137 017410      JMP      BSDELS          ;/ON THE PACK IF REQUESTED
                          ;SELECT THE NEXT UNIT

```

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-48
GLOBAL SUBROUTINES

G 6

SEQ 001

```

1423 020172      STARS
(2)              :*****
1424              :BSWRITE -- ROUTINE TO WRITE THE WHOLE PACK WITH THE WORST CASE DATA PATTERN
1425              :      FOR THE RL01/2 THEN ISSUE THE 'VERIFY' (READ PACK) COMMAND. THIS
1426              :      WILL CHECK THE PACK FOR BAD SPOTS AND COMPARE THE FOUND ENTRIES
1427              :      WITH THE EXISTING BAD SECTOR FILE.
1428 020172      STARS
(2)              :*****
1429              :
1430 020172      BSWRITE: PRINTF #FMT19,#MWRITE ;TELL OPR WHAT IS HAPPENING
(8) 020172      MOV      #MWRITE,-(SP)
(7) 020176      MOV      #FMT19,-(SP)
(6) 020202      MOV      #2,-(SP)
(3) 020206      MOV      SP,R0
(4) 020210      TRAP     C$PNTF
(4) 020212      ADD      #6,SP
1431 020216      GMANIL  MSTWRT,TEMPO,177777,NO
(3) 020216      TRAP     C$GMAN
(3) 020220      BR       10021$
(4) 020222      .WORD    TEMPO
(5) 020224      .WORD    T$CODE
(5) 020226      .WORD    MSTWRT
(5) 020230      .WORD    177777
(3) 020232
1432 020232      005737  002414
1433 020236      001402
1434 020240      004537  012370
1435 020244      000137  013546
1436 020250      000404
1437 020252      004537  012400
1438 020256      000137  013546
1439
1440 020262      004537  012546
1441 020266      004537  025246
1442 020272      005737  002414
1443 020276      001403
1444 020300      004537  012642
1445 020304      000762
1446
1447 020306      004537  012502
1448 020312      004537  025422
1449 020316      032701  020000
1450 020322      001416
1451 020324      004537  012546
1452 020330
(8) 020330      012746  003460
(7) 020334      012746  010044
(6) 020340      012746  000002
(3) 020344      010600
(4) 020346      104417
(4) 020350      062706  000006
1453 020354      000137  020252
1454
1455 020360
(7) 020360      012746  010041
(6) 020364      012746  000001

:*****
:BSWRITE: PRINTF #FMT19,#MWRITE ;TELL OPR WHAT IS HAPPENING
MOV      #MWRITE,-(SP)
MOV      #FMT19,-(SP)
MOV      #2,-(SP)
MOV      SP,R0
TRAP     C$PNTF
ADD      #6,SP
GMANIL  MSTWRT,TEMPO,177777,NO
TRAP     C$GMAN
BR       10021$
.WORD    TEMPO
.WORD    T$CODE
.WORD    MSTWRT
.WORD    177777

10021$      TST      TEMPO
BEQ      1$
JSR      R5,FIRST ;QUIT IF CAN'T WRITE ON ALL PACKS
;SELECT THE 1ST UNIT
JMP      NXTCMD ;NONE AVAIL.!
BR       BSWRTL

BSWRTL: JSR      R5,SELDRV ;SELECT THE NEXT UNIT
JMP      NXTCMD ;ALL DONE

BSWRTL: JSR      R5,DRVID ;TELL OPR WHAT DRIVE SELECTED
JSR      R5,LOADED
TST      TEMPO
BEQ      1$ ;DRV READY
JSR      R5,DRNRDY ;TELL OPR NOT READY
BR       BSWRTL ;SELECT THE NEXT UNIT

1$: JSR      R5,PTIME ;PRINT THE RUN TIME
JSR      R5,GETDST ;GET STATUS OF DRV
BIT      #WL,R1 ;WRITE LOCKED?
BEQ      2$ ;NO
JSR      R5,DRVID ;TELL THE DRIVE ID
PRINTF   #MSG,#WRTLCK ;YES
MOV      #WRTLCK,-(SP)
MOV      #MSG,-(SP)
MOV      #2,-(SP)
MOV      SP,R0
TRAP     C$PNTF
ADD      #6,SP

11$: JMP      BSWRTL ;SELECT THE NEXT UNIT

2$: PRINTF   #MCRLF
MOV      #MCRLF,-(SP)
MOV      #1,-(SP)

```

(3)	020370	010600		MOV	SP,R0	
(4)	020372	104417		TRAP	C\$PNTF	
(4)	020374	062706	000004	ADD	#4,SP	
1456	020400	004537	020612	JSR	R5,CLRBSN	;CLEAR THE TEMP STORAGE FOR HARD ERRORS
1457	020404	005037	002232	CLR	SFTCNT	;CLEAR THE SOFT ERROR COUNTER
1458	020410	005037	002230	CLR	ERRCNT	;CLEAR THE HARD ERROR COUNTER
1459						
1460	020414			PRINTF	#FMT18,#WRPKF	;PRINT WRITE PACK FWD
(8)	020414	012746	006674	MOV	#WRPKF,-(SP)	
(7)	020420	012746	007624	MOV	#FMT18,-(SP)	
(6)	020424	012746	000002	MOV	#2,-(SP)	
(3)	020430	010600		MOV	SP,R0	
(4)	020432	104417		TRAP	C\$PNTF	
(4)	020434	062706	000006	ADD	#6,SP	
1461	020440	005737	010130	TST	WRTSAW	;SAWTOOTH WRT?
1462	020444	001412		BEQ	3\$;NO
1463	020446			PRINTF	#MSG,#SAWFWD	;YES - TELL OPR
(8)	020446	012746	006603	MOV	#SAWFWD,-(SP)	
(7)	020452	012746	010044	MOV	#MSG,-(SP)	
(6)	020456	012746	000002	MOV	#2,-(SP)	
(3)	020462	010600		MOV	SP,R0	
(4)	020464	104417		TRAP	C\$PNTF	
(4)	020466	062706	000006	ADD	#6,SP	
1464	020472	005037	002312	CLR	FWDFLG	;SET CONTROL FOR FWD SAWTOOTH WRITE
1465	020476	004537	025514	JSR	R5,WRPACK	;WRITE THE PACK
1466	020502	004537	020636	JSR	R5,CVERIFY	;CALL THE VERIFY ROUTINE
1467						
1468	020506	004537	012502	JSR	R5,PTIME	;TELL THE HALF TIME
1469	020512			PRINTF	#FMT18,#WRPKR	;TELL OPR WRT PACK REVERSE
(8)	020512	012746	006722	MOV	#WRPKR,-(SP)	
(7)	020516	012746	007624	MOV	#FMT18,-(SP)	
(6)	020522	012746	000002	MOV	#2,-(SP)	
(3)	020526	010600		MOV	SP,R0	
(4)	020530	104417		TRAP	C\$PNTF	
(4)	020532	062706	000006	ADD	#6,SP	
1470	020536	005737	010130	TST	WRTSAW	;SAWTOOTH WRT?
1471	020542	001412		BEQ	4\$;NO
1472	020544			PRINTF	#MSG,#SAWREV	;YES
(8)	020544	012746	006636	MOV	#SAWREV,-(SP)	
(7)	020550	012746	010044	MOV	#MSG,-(SP)	
(6)	020554	012746	000002	MOV	#2,-(SP)	
(3)	020560	010600		MOV	SP,R0	
(4)	020562	104417		TRAP	C\$PNTF	
(4)	020564	062706	000006	ADD	#6,SP	
1473	020570	005237	002312	INC	FWDFLG	;SET CONTROL FOR REVERSE SAWTOOTH WRT
1474	020574	004537	025514	JSR	R5,WRPACK	;WRITE THE PACK
1475	020600	004537	020636	JSR	R5,CVERIFY	;CALL THE VERIFY ROUTINE
1476	020604	004537	021110	JSR	R5,ENDRD1	;PRINT THE TOTALS OF ERRORS DETECTED
1477	020610	000620		BR	BSWRTS	;SELECT THE NEXT DRIVE

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 ¹6 PAGE 1-50
GLOBAL SUBROUTINES

SEQ 0073

1479
1480
1481

;HERE TO CLEAR THE TEMP BAD SECTOR FILE STORAGE OF 'HARD' ERROR SPOTS
;ON THE PACK

1482 020612 010146
1483 020614 012701 030014
1484 020620 012721 177777
1485 020624 022701 030410
1486 020630 001373
1487 020632 012601
1488 020634 000205

CLRBSN: MOV R1, -(SP)
MOV #BSECN, R1
1\$: MOV #-1, (R1)+
CMP #BSECNE, R1
BNE 1\$
MOV (SP)+, R1
RTS R5

;SAVE R1
;POINT TO THE 1ST LOCATION IN THE TABLE
;INIT THIS ADDR OF TABLE
;DONE?
;NO - DO THIS ADDR ALSO
;RESET R1

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 J 6
GLOBAL SUBROUTINES PAGE 1-51

SEQ 0074

```

1490 020636      STARS
(2)              :*****
1491              :BSVERIFY -- ROUTINE TO READ THE PACK TO FIND BAD SPOTS. SPOTS THAT
1492              :ARE 'BAD' AFTER 16 RETRYs TO RECOVER THE DATA WILL BE ENTERED
1493              :INTO A TEMPORARY AREA FOR LATER INSERTION INTO THE REAL BAD
1494              :SECTOR FILE (UNDER THE OPERATOR'S CONTROL).
1495 020636      STARS
(2)              :*****
1496              :
1497 020636 005237 002314  CVERIFY: INC      CVFLG      ;SET THE 'CALLED' FLAG
1498 020642 000402              BR      COMVER      ;GO TO THE COMMON VERIFY CODE
1499
1500 020644 005037 002314  BSVERIFY: CLR      CVFLG      ;CLEAR THE 'CALLED' FLAG
1501
1502 020650      COMVER: PRINTF #FMT19,#VERIFY ;MSG. 'READING PACK'
(8) 020650 012746 004241      MOV      #VERIFY,-(SP)
(7) 020654 012746 007631      MOV      #FMT19,-(SP)
(6) 020660 012746 000002      MOV      #2,-(SP)
(3) 020664 010600              MOV      SP,R0
(4) 020666 104417              TRAP     C$PNTF
(4) 020670 062706 000006      ADD      #6,SP
1503 020674 005737 002314      TST      CVFLG      ;'CALLED'?
1504 020700 001011              BNE      BSVERL      ;YES - SKIP SELECT CODE
1505 020702 004537 012370      JSR      R5,FIRST ;NO - SELECT THE 1ST UNIT
1506 020706 000137 013546      JMP      NXTCMD ;NONE AVAIL.!
1507 020712 000404              BR      BSVERL
1508 020714 004537 012400      BSVERS: JSR      R5,SELDRV ;SELECT THE NEXT UNIT
1509 020720 000137 013546      JMP      NXTCMD ;ALL DONE
1510 020724 004537 025246      BSVERL: JSR      R5,LOADED ;DRV RDY?
1511 020730 005737 002414      TST      TEMPO
1512 020734 001410              BEQ      1$ ;YES
1513 020736 004537 012642      JSR      R5,DRNRDY
1514 020742 005737 002314      TST      CVFLG      ;'CALLED'?
1515 020746 001002              BNE      10$ ;YES
1516 020750 000137 020714      JMP      BSVERS ;SELECT THE NEXT UNIT
1517 020754 000205              10$: RTS      R5 ;NO - EXIT NOW
1518
1519 020756      1$: PRINTF #MCRLF
(7) 020756 012746 010041      MOV      #MCRLF,-(SP)
(6) 020762 012746 000001      MOV      #1,-(SP)
(3) 020766 010600              MOV      SP,R0
(4) 020770 104417              TRAP     C$PNTF
(4) 020772 062706 000004      ADD      #4,SP
1520 020776 022737 000005 013650      CMP      #5,INPUT ;HERE FROM 'WRITE' COMMAND?
1521 021004 001406              BEQ      11$ ;YES
1522 021006 004537 020612      JSR      R5,CLRBSN ;NO - INIT HARD ERROR STORAGE AREA
1523 021012 005037 002232      CLR      SFTCNT ;CLEAR THE SOFT ERROR COUNTER
1524 021016 005037 002230      CLR      ERRCNT ;CLEAR THE HARD ERROR COUNT
1525 021022 004537 023656      11$: JSR      R5,RDBDSC ;GET A FRESH COPY OF THE BAD SECTOR FILE
1526 021026 004537 026754      JSR      R5,HDDHME ;PUT THE HEADS OVER CYLINDER 0
1527 021032 012737 002450 002256      MOV      #BUF1,BBA ;POINT TO THE BUFFER FOR READ/WRITE
1528 021040 012737 175400 002246      MOV      #-1280.,BMP ;SAVE THE WC FOR 10 SECTORS
1529 021046 005037 002416      CLR      TEMP1 ;START AT HEAD 0
1530 021052 005001      CLR      R1 ;START AT CYLINDER 0
1531
1532 021054 022737 000001 002316 CONREAD: CMP      #1,TDR ;DRIVE = RL01?

```

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 K 6
GLOBAL SUBROUTINES PAGE 1-52

SEQ 0075

```

1533 021062 001101      BNE      CRD2      :NO - MUST BE AN RL02
1534 021064 022701 077600  CMP      #077600,R1    :AT RL01 LAST CYL?
1535 021070 001101      BNE      STREAD    :NO - READ THIS TRACK
1536
1537 021072 005737 002416  CRD1:  TST      TEMP1      :ON LAST CYL ... IS IT LAST TRACK?
1538 021076 001476      BEQ      STREAD    :NO - DO THE READ
1539
1540 021100 005737 002314  ENDRD:  TST      CVFLG      :'CALLED'?
1541 021104 001401      BEQ      ENDRD1    :NO - PROCEED WITH THE TOTALS PRINTOUT
1542 021106 000205      RTS      R5        :YES - EXIT NOW
1543 021110 004537 012502  ENDRD1:  JSR      R5,PTIME    :PRINT THE DONE READING TIME
1544 021114      PRINTF  #MSG,#MDONE    :TELL OPR ALL DONE
      (8) 021114 012746 003720  MOV      #MDONE,-(SP)
      (7) 021120 012746 010044  MOV      #MSG,-(SP)
      (6) 021124 012746 000002  MOV      #2,-(SP)
      (3) 021130 010600      MOV      SP,R0
      (4) 021132 104417      TRAP     C$PNTF
      (4) 021134 062706 000006  ADD      #6,SP
1545 021140 004537 012546  JSR      R5,DRVID    :TELL OPR WHICH DRIVE
1546 021144      PRINTF  #FMTTB,#TSOFT,SFTCNT ;PRINT TOTAL 'SOFT' ERRORS
      (9) 021144 013746 002232  MOV      SFTCNT,-(SP)
      (8) 021150 012746 003047  MOV      #TSOFT,-(SP)
      (7) 021154 012746 007724  MOV      #FMTTB,-(SP)
      (6) 021160 012746 000003  MOV      #3,-(SP)
      (3) 021164 010600      MOV      SP,R0
      (4) 021166 104417      TRAP     C$PNTF
      (4) 021170 062706 000010  ADD      #10,SP
1547 021174      PRINTF  #FMTTB,#THARD,ERRCNT ;PRINT TOTAL 'HARD' ERRORS
      (9) 021174 013746 002230  MOV      ERRCNT,-(SP)
      (8) 021200 012746 003076  MOV      #THARD,-(SP)
      (7) 021204 012746 007724  MOV      #FMTTB,-(SP)
      (6) 021210 012746 000003  MOV      #3,-(SP)
      (3) 021214 010600      MOV      SP,R0
      (4) 021216 104417      TRAP     C$PNTF
      (4) 021220 062706 000010  ADD      #10,SP
1548 021224      PRINTF  #FMT18,#HYPHEN
      (8) 021224 012746 002675  MOV      #HYPHEN,-(SP)
      (7) 021230 012746 007624  MOV      #FMT18,-(SP)
      (6) 021234 012746 000002  MOV      #2,-(SP)
      (3) 021240 010600      MOV      SP,R0
      (4) 021242 104417      TRAP     C$PNTF
      (4) 021244 062706 000006  ADD      #6,SP
1549 021250 004537 022162  JSR      R5,ADDEND    :SEE IF OPR WANTS TO UPDATE BAD SEC FILE
1550 021254 005737 002314  TST      CVFLG      :'CALLED'?
1551 021260 001001      BNE      1$        :YES
1552 021262 000614      BR       BSVERS    :SELECT THE NEXT UNIT
1553 021264 000205      RTS      R5        :NO - EXIT NOW
1554
1555
1556 021266 022701 177600  :HERE TO CHECK THE END OF AN RL02
1557 021272 001677      CRD2:  CMP      #177600,R1    :RL02 LAST CYL?
      BEQ      CRD1      :YES - CHECK TO SEE IF LAST TRACK OK

```

2RLMB0 RL01/02 BD SEC FIL TL
2RLMB.MAC 12-DEC-79 14:06

MACV11 30A(1052) 17-DEC-79 10:53 L 6
GLOBAL SUBROUTINES PAGE 1-53

```

1559      ;HERE TO READ THE TRACK SELECTED...WILL TRY 10 SECTORS AT A TIME
1560      ;IF AN ERROR IS DETECTED, WILL THEN TRY TO RECOVER BY READING ONE
1561      ;SECTOR AT A TIME. A SECTOR IS DEEMED 'HARD ERROR' AFTER 16 RETRYS.
1562      ;ALL BAD SPOTS WILL ENTER A TEMP BAD SEC FILE STORAGE AREA...TO BE ADDED
1563      ;TO THE REAL BAD SECTOR FILE AFTER WHOLE PACK HAS BEEN READ.
1564
1565      021274 005002      STREAD: CLR      R2      ;START AT SECTOR 0 ON THIS TRACK
1566      021276 005037      CLR      DECNT    ;INITIALIZE ERROR RECOVERY COUNTER
1567      021302 010137      SRD1:  MOV     R1,BDA  ;INSERT THE CYL # INTO DISK ADDR
1568      021306 053737      BIS      TEMP1,BDA  ;ADD THE HEAD NUMBER (0 OR 1)
1569      021314 050237      BIS      R2,BDA    ;ADD THE SECTOR NUMBER
1570      021320 012737      MOV     #READ,FUNC ;GET A READ FUNCTION
1571      021326 004537      JSR      R5,LDFUNC  ;ISSUE THE READ CMD
1572      021332 004537      JSR      R5,WTRDY   ;WAIT FOR READ TO FINISH
1573
1574      021336 005777      TST      @DCS      ;ANY ERROR ON THE READ?
1575      021342 100041      BPL      NXTSEC    ;BR IF OK
1576
1577      ;HERE IF AN ERROR DETECTED ON THE READ ... READ ONE SECTOR AT A TIME
1578      ;TILL WHOLE TRACK HAS BEEN READ
1579
1580      021344      PRINTF  #MCRLF
1581      (7) 021344 012746 010041      MOV     #MCRLF,-(SP)
1582      (6) 021350 012746 000001      MOV     #1,-(SP)
1583      (3) 021354 010600      MOV     SP,R0
1584      (4) 021356 104417      TRAP     C$PNTF
1585      (4) 021360 062706 000004      ADD     #4,SP
1586      021364 017737 160660 002252      MOV     @DCS,E.DCS ;GET THE ERROR DETECTED
1587      021372 013703 002250      MOV     DCS,R3 ;GET THE BASE ADDRESS FOR RLCS
1588      021376 016337 000004 002440      MOV     DA(R3),E.DA ;SAVE THE DISK ADDRESS AT ERROR
1589      021404 005337 002440      DEC     E.DA ;SECTOR IS PREVIOUS FROM INDICATED
1590      021410 013737 002440 002410      MOV     E.DA,CHKSEC
1591      021416 013737 002410 002502      MOV     CHKSEC,FRSTER ;STORE ERROR ADDRESS FOR RECOVERY LOOP
1592      021424      ERRSOFT 400.,MSFER,ERR1 ;TELL OPR ABOUT THE ERROR DETECTED
1593      (4) 021424 104457      TRAP     C$ERSOFT
1594      (5) 021426 000620      .WORD    400
1595      (5) 021430 003310      .WORD    MSFER
1596      (5) 021432 007130      .WORD    ERR1
1597      021434 004537 025436      JSR      R5,ISDRST ;ISSUE A DRIVE RESET TO CLEAR THE ERROR
1598      021440 005237 002232      INC     SFTCNT ;ADD TO SOFT ERROR TALLY
1599      021444 000446      BR        ONESEC ;RECOVER THE TRACK DATA...SLOWLY

```

```

1592 ;HERE TO SELECT THE NEXT SECTOR ADDR TO READ FROM ON THIS TRACK
1593 ;HERE IF NO ERROR DETECTED ON PREV. READ CMD
1594
1595 021446 062702 000012 NXTSEC: ADD #10.,R2 ;POINT TO THE NEXT SPOT ON THE TRACK
1596 021452 022702 000050 CMP #40.,R2 ;END OF THE TRACK?
1597 021456 001311 BNE SRD1 ;NO - DO THE READ
1598
1599 ;HERE TO SELECT THE NEXT TRACK TO READ ... WILL DO A SEEK TO NEXT HEAD
1600 ;OR TO THE NEXT CYLINDER.
1601
1602 021460 005737 002416 NXTTRK: TST TEMP1 ;ON HEAD #1 NOW?
1603 021464 001427 BEQ 5$ ;NO - SEEK TO NEXT TRACK SAME CYL
1604 021466 005037 002416 CLR TEMP1 ;SET FOR NEXT CYL HEAD 0
1605 021472 062701 000200 ADD #200,R1 ;POINT TO THE NEXT CYLINDER
1606 021476 042701 000177 BIC #177,R1 ;CLEAR UNEXPECTED JUNK BITS
1607 021502 012737 000200 002244 MOV #200,BDA
1608
1609 021510 052737 000005 002244 4$: BIS #SIGN!MK,BDA ;SET FOR A SEEK CMD
1610 021516 012737 000006 002260 MOV #SEEK,FUNC ;GET THE SEEK CMD
1611 021524 004537 023534 JSR R5,LDFUNC ;ISSUE THE SEEK
1612 021530 004537 025310 JSR R5,WTRDY ;WAIT TILL READY
1613 021534 010137 002322 MOV R1,PRPOS ;SAVE THE PRESENT POSITION ON DISK
1614 021540 000137 021054 JMP CONREAD ;CONTINUE READING THE PACK
1615
1616 021544 012737 000100 002416 5$: MOV #HEAD,TEMP1 ;SAVE HEAD SELECT STATUS
1617 021552 012737 000020 002244 MOV #SKHS,BDA ;SET FOR SEEK TO NEXT TRACK SAME CYL
1618 021560 000753 BR 4$ ;ISSUE THE SEEK

```

CZRLMBO RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-55
GLOBAL SUBROUTINES

N 6

```

1620 021562
(2)
1621
1622
1623 021562
(2)
1624
1625 021562 005002
1626 021564 012737 177600 002246
1627 021572 013737 002322 002244
1628 021600 050237 002244
1629 021604 053737 002416 002244
1630
1631
1632 021612 012737 000014 002260
1633 021620 004537 023534
1634 021624 004537 025310
1635
1636 021630 005777 160414
1637 021634 100106
1638
1639
1640
1641 021636 017737 160406 002252
1642 021644 023737 002244 002502
1643 021652 001425
1644 021654 005737 002412
1645 021660 001022
1646 021662
(7) 021662 012746 010041
(6) 021666 012746 000001
(3) 021672 010600
(4) 021674 104417
(4) 021676 062706 000004
1647 021702 013737 002244 002410
1648 021710 013737 002244 002440
1649 021716
(4) 021716 104457
(5) 021720 000644
(5) 021722 003310
(5) 021724 007130
1650 021726 005237 002412
1651 021732 013737 002244 002410
1652 021740 004537 027340
1653 021744 005737 002406
1654 021750 001423
1655 021752
(8) 021752 012746 006346
(7) 021756 012746 007624
(6) 021762 012746 000002
(3) 021766 010600
(4) 021770 104417
(4) 021772 062706 000006
1656 021776
(7) 021776 012746 010041
(6) 022002 012746 000001

STARS
:*****
:HERE TO TRY AND RECOVER THE DATA ON SFELECTED TRACK BY READING 1 SECTOR
:AT A TIME. SECTOR WILL BE MARKED 'BAD' AFTER 16 RETRYS AND NO RECOVERY.
STARS
:*****

ONESEC: CLR R2 ;START AT SECTOR 0 ON THIS TRACK
MOV #-128.,BMP ;SET THE WC AT 1 SECTOR'S WORTH
1$: MOV PRPOS,BDA ;GET THE CYL # TO START AT
BIS R2,BDA ;ADD IN THE SECTOR NUMBER
BIS TEMP1,BDA ;AND THE TRACK (HEAD 0 OR 1)

;READ A SECTOR
2$: MOV #READ,FUNC ;GET A READ FUNCTION
JSR R5,LDFUNC ;ISSUE THE READ
JSR R5,WTRDY ;WAIT FOR READY

TST @DCS ;THIS SECTOR READ OK?
BPL 3$ ;BE IF OK - SELECT NEXT SECTOR

;ERROR IN THIS SECTOR - TRY A MAX OF 16 TIMES TO RECOVER

MOV @DCS,E.DCS ;SAVE THE DETECTED ERROR
CMP BDA,FRSTER ;DID WE REPORT THIS IN MAIN PROGRAM?
BEQ 10$ ;YES - SKIP
TST DECN ;DID WE REPORT IT YET IN RECOVERY LOOP?
BNE 10$ ;YES - SKIP
PRINTF #MCRLF ;ELSE REPORT SOFT ERROR NOW
MOV #MCRLF,-(SP)
MOV #1,-(SP)
MOV SP,R0
TRAP C$PNTF
ADD #4,SP
MOV BDA,CHKSEC ;GET ERROR ADDRESS FOR PRINTOUT
MOV BDA,E.DA
ERRSOFT 420.,MSFER,ERR1
TRAP C$ERSOFT
WORD 420
WORD MSFER
WORD ERR1
10$: INC DECN ;COUNT THIS RETRY
MOV BDA,CHKSEC ;SEE IF THIS SECTOR IS ALREADY IN
JSR R5,CKBDSC ;THE BAD SECTOR FILE
TST HDRFND ;IN THE FILE NOW?
BEQ 21$ ;BR IF ERROR
PRINTF #FMT18,#INBSF ;TELL OPR SECT IS IN BSF ALREADY
MOV #INBSF,-(SP)
MOV #FMT18,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTF
ADD #6,SP
PRINTF #MCRLF
MOV #MCRLF,-(SP)
MOV #1,-(SP)

```

```
(3) 022006 010600      MOV    SP,R0
(4) 022010 104417      TRAP   C$PNTF
(4) 022012 062706 000004  ADD    #4,SP
1657 022016 000445      BR      30$      ;DO THE NEXT SECTOR ON THIS TRACK
1658
1659 022020 022737 000020 002412 21$:  CMP    #16.,DECNT      ;TIME TO MARK IT AS A BAD SPOT?
1660 022026 001403      BEQ     22$      ;YES
1661 022030 004537 025436  JSR     R5,ISDRST      ;NO - ISSUE A DRIVE RESET
1662 022034 000666      BR      2$      ;AND CONTINUE
1663 022036 005337 002232 22$:  DEC    SFTCNT      ;DELETE THIS HARD ERROR FROM SOFT ERROR TALLY
1664 022042 004537 026604  JSR     R5,INBAD      ;YES - MAKE A TEMP BAD SPOT ENTRY
1665 022046 004537 025436 23$:  JSR     R5,ISDRST      ;RESET THE DRIVE FOR THE NEXT FUNCTION
1666
1667      ;HERE TO SELECT THE NEXT SECTOR TO RECOVER IN THIS TRACK
1668
1669 022052 005737 002412 3$:  TST     DECNT      ;ANY DETECTED?
1670 022056 001433      BEQ     31$      ;OR IF NONE THIS SECTOR
1671 022060 005037 002412  CLR     DECNT      ;CLEAR LOOP COUNTER FOR NEXT SECTOR
1672 022064      PRINTF  #FMT18,#MSREC ;TELL OPR 'RECOVERED'
(8) 022064 012746 003125  MOV     #MSREC,-(SP)
(7) 022070 012746 007624  MOV     #FMT18,-(SP)
(6) 022074 012746 000002  MOV     #2,-(SP)
(3) 022100 010600      MOV     SP,R0
(4) 022102 104417      TRAP   C$PNTF
(4) 022104 062706 000006  ADD    #6,SP
1673 022110      PRINTF  #MCRLF
(7) 022110 012746 010041  MOV     #MCRLF,-(SP)
(6) 022114 012746 000001  MOV     #1,-(SP)
(3) 022120 010600      MOV     SP,R0
(4) 022122 104417      TRAP   C$PNTF
(4) 022124 062706 000004  ADD    #4,SP
1674 022130 000406      BR      31$
1675 022132 005337 002232 30$:  DEC    SFTCNT      ;ADJUST COUNTERS BECAUSE SECTOR-
1676 022136 005037 002412  CLR     DECNT      ;IN-ERROR ALREADY IN BSF
1677 022142 004537 025436  JSR     R5,ISDRST      ;RESET THE DRIVE
1678
1679 022146 005202 31$:  INC     R2      ;POINT TO THE NEXT SECTOR
1680 022150 022702 000050  CMP     #40.,R2      ;END OF THIS TRACK?
1681 022154 001206      BNE     1$      ;NO - READ THIS SECTOR
1682 022156 000137 021460  JMP     NXTTRK      ;ELSE BACK TO NORMAL 10 SECTOR READS
1683
1684 022162      STARS
(2) ;*****
1685 ;ADDFND -- ROUTINE TO ASK OPR IF THE NEW BAD SPOTS FOUND BY THE
1686 ;      'WRITE' COMMAND OR THE 'VERIFY' COMMAND IS TO BE ADDED TO THE
1687 ;      BAD SECTOR FILE ON THE PACK.
1688 022162      STARS
(2) ;*****
1689
1690 022162 005737 002464  ADDFND: TST    ACCESS      ;ALLOWED TO UPDATE THE PACK?
1691 022166 001177      BNE     ADDFEX      ;NO - EXIT NOW
1692 022170 004537 023656  JSR     R5,RDBDSC      ;GET A FRESH COPY OF THE BAD SECTOR FILE
1693 022174 004537 025076  JSR     R5,RDFIELD      ;GET A CORE COPY OF THE 'FIELD' FILE
1694 022200 012701 030014  MOV     #BSECN,R1      ;POINT TO THE NEW ENTRY TABLE
1695 022204 005737 002230  TST     ERRCNT      ;SEE IF ANY NEW BAD SPOTS
1696 022210 001566      BEQ     ADDFEX      ;EXIT IF NONE DETECTED
```

```
1697 022212 005002          CLR      R2          ;CLEAR AN INDEX INTO BAD SECTOR FILE
1698 022214 005037 015342    CLR      SECNUM        ;START AT THE 1ST SECTOR IN 'FIELD'
1699 022220 012737 000020    015340    MOV      #16,SECMAX    ;SETUP THE LIMIT
1700 022226 004537 015622    JSR      R5,BSFOK        ;SET R2 TO POINT INTO THE FILE
1701 022232 005737 015346    TST      BSFOK        ;SEE IF FIELD FILE EXISTS
1702 022236 001420          BEQ      1$          ;BR IF OK
1703 022240          PRINTF  #FMT18,#NSWSEC    ;TELL OPR THAT NO 'FIELD' FILE EXISTS
(8) 022240 012746 003636    MOV      #NSWSEC,-(SP)
(7) 022244 012746 007624    MOV      #FMT18,-(SP)
(6) 022250 012746 000002    MOV      #2,-(SP)
(3) 022254 010600          MOV      SP,R0
(4) 022256 104417          TRAP     C$PNTF
(4) 022260 062706 000006    ADD      #6,SP
1704 022264 004537 022570    JSR      R5,NEWSBF        ;ASK IF TIME TO MAKE A 'FIELD' FILE
1705 022270 005737 002414    TST      TEMPO        ;WAS A 'FIELD' FILE BUILT?
1706 022274 001001          BNE      1$          ;BR IF YES
1707 022276 000533          BR       ADDFEX        ;NO - EXIT
1708 022300 011137 002410    1$:      MOV      (R1),CHKSEC    ;GET AN ENTRY
1709 022304 023727 002410    177777    CMP      CHKSEC,#-1    ;DONE?
1710 022312 001523          BEQ      4$          ;YES - UPDATE REST OF 'FIELD' FILE
1711
1712          ;HERE TO SEE IF ENTRY ALREADY EXISTS...SHOULDN'T
1713
1714 022314 004537 027340          JSR      R5,CKBDSC        ;WELL...
1715 022320 005737 002406          TST      HDRFND        ;FIND IN LIST ALREADY?
1716 022324 001114          BNE      3$          ;YES - LOOK AT THE NEXT ENTRY
1717
1718          ;HERE TO ASK OPR IF THIS ENTRY TO BE ADDED TO BAD SEC FILE
1719
1720 022326 011137 015332          MOV      (R1),BSFCYL    ;GET DA FOR CYL #
1721 022332 042737 000177    015332    BIC      #177,BSFCYL    ;CLEAR HEAD & SECTOR #
1722 022340 000337 015332          SWAB     BSFCYL
1723 022344 000241          CLC
1724 022346 006137 015332          ROL      BSFCYL
1725 022352 103002          BCC      11$
1726 022354 005237 015332          INC      BSFCYL    ;ADD IN LOW ORDER CYL #
1727 022360 011137 015334    11$:      MOV      (R1),BSFSEC    ;GET DA FOR SEC VALUE
1728 022364 042737 177700    015334    BIC      #177700,BSFSEC    ;CLEAR CYLINDER # & HEAD
1729 022372 005037 015336          CLR      BSFHD        ;START AT HEAD 0
1730 022376 032711 000100          BIT      #100,(R1)    ;HEAD 1?
1731 022402 001402          BEQ      2$          ;NO - ITS HEAD 0
1732 022404 005237 ^15336          INC      BSFHD        ;POINT TO HEAD 1
1733 022410          2$:      PRINTF  #FMT16,#NEWENT,#CMMSG,BSFCYL,#SMSG,BSFSEC,#HMSG,BSFHD
(14) 022410 013746 015336          MOV      BSFHD,-(SP)
(13) 022414 012746 002563          MOV      #HMSG,-(SP)
(12) 022420 013746 015334          MOV      BSFSEC,-(SP)
(11) 022424 012746 003243          MOV      #SMSG,-(SP)
(10) 022430 013746 015332          MOV      BSFCYL,-(SP)
(9) 022434 012746 002550          MOV      #CMMSG,-(SP)
(8) 022440 012746 006200          MOV      #NEWENT,-(SP)
(7) 022444 012746 007503          MOV      #FMT16,-(SP)
(6) 022450 012746 000010          MOV      #10,-(SP)
(3) 022454 010600          MOV      SP,R0
(4) 022456 104417          TRAP     C$PNTF
(4) 022460 062706 000022          ADD      #22,SP
1734 022464          GMANIL  ABSMSG,TEMPO,177777,NO ;ASK OPR IF OK TO ENTER
```



```

(3) 022464 104443      TRAP      C$GMAN
(3) 022466 000404      BR        10022$
(4) 022470 002414      .WORD     TEMPO
(5) 022472 000120      .WORD     T$CODE
(5) 022474 005164      .WORD     ABSMSG
(5) 022476 177777      .WORD     177777
(3) 022500
1735 022500 005737 002414      10022$: TST      TEMPO      ;BR IF NO
1736 022504 001424      BEQ      3$        ;NO - GET THE NEXT ENTRY
1737
1738
1739      ;HERE TO INSERT THIS SPOT IN THE BAD SECTOR FILE
1740
1741 022506 005762 030530      21$:  TST      BSFILE(R2) ;SEE IF A FREE SPOT
1742 022512 100403      BMI      22$      ;BR IF FOUND A FREE ENTRY
1743 022514 062702 000004      ADD      #4,R2      ;POINT TO THE NEXT ENTRY SLOT
1744 022520 000772      BR        21$      ;AND TRY AGAIN
1745
1746 022522 013762 015332 030530      22$:  MOV      BSFCYL,BSFILE(R2) ;INSERT THE CYL # INTO FILE
1747 022530 011162 030532      MOV      (R1),BSFILE+2(R2) ;ADD THE SECTOR NUM & HEAD
1748 022534 042762 177700 030532      BIC      #177700,BSFILE+2(R2) ;CLEAR CYL # AND HEAD
1749 022542 005737 015336      TST      BSFHD      ;IS IT HEAD ONE?
1750 022546 001403      BEQ      3$        ;NO - SKIP
1751 022550 052762 000400 030532      BIS      #400,BSFILE+2(R2) ;YES - SET BIT 8 FOR HEAD ONE
1752
1753      ;HERE TO UPDATE THE POINTER INTO THE TEMP BAD SEC TABLE
1754 022556 005721      3$:  TST      (R1)+      ;UPDATE THE POINTER
1755 022560 000647      BR        1$        ;PROCESS THIS ENTRY
1756
1757 022562 004537 016770      4$:  JSR      R5,WRTBSF      ;WRITE UPDATED 'FIELD' BAD SECTOR FILE
1758      ;/ON THE PACK IF REQUESTED
1759
1760      ;HERE TO EXIT THIS PHASE
1761 022566 000205      ADDFEX: RTS      R5      ;EXIT
1762
1763

```

1765 022570
(2)
1766
1767
1768 022570
(2)
1769
1770 022570 010146
1771 022572
(3) 022572 104443
(3) 022574 000404
(4) 022576 002414
(5) 022600 000120
(5) 022602 003155
(5) 022604 177777
(3) 022606
1772 022606 005737 002414
1773 022612 001502
1774
1775
1776 022614 012701 030530
1777 022620 010137 015344
1778 022624 012721 177, 7
1779 022630 022701 033130
1780 022634 001373
1781 022636 012701 030530
1782 022642 005021
1783 022644 005021
1784 022646 005021
1785 022650 005011
1786 022652 005737 002456
1787 022656 001020
1788
1789 022660
(3) 022660 104443
(3) 022662 000406
(4) 022664 002456
(5) 022666 000022
(5) 022670 005415
(5) 022672 077777
(5) 022674 000001
(5) 022676 077777
(3) 022700
1790 022700
(3) 022700 104443
(3) 022702 000406
(4) 022704 002460
(5) 022706 000022
(5) 022710 005471
(5) 022712 077777
(5) 022714 000000
(5) 022716 077777
(3) 022720
1791
1792 022720
(10) 022720 013746 002456

```

STARTS
*****
:NEWBSF -- ROUTINE TO ASK OPR IF TIME TO CREATE A BAD SECTOR
:         FILE IF THE AREA CAN'T BE RECOGNIZED AS A BAD SECTOR FILE.
STARTS
*****
NEWBSF: MOV     R1,-(SP)      ;SAVE R1
        GMANIL  MBLD,TEMPO,177777,NO
        TRAP    C$GMAN
        BR      10023$
        .WORD   TEMPO
        .WORD   T$CODE
        .WORD   MBLD
        .WORD   177777

10023$: TST     TEMPO          ;BR IF NO
        BEQ     2$            ;EXIT

;HERE TO INIT THE BSFILE STORAGE FOR BUILDING A FILE
1$: MOV     #BSFILE,R1      ;SETUP A POINTER
        MOV     R1,SECD     ;POINT TO THE START OF THE 'UPDATE' AREA
11$: MOV     #-1,(R1)+      ;INIT A LOCATION
        CMP     #BSFILE+1280.,R1 ;DONE??
        BNE     11$         ;NO - PROCEED TO INIT
        MOV     #BSFILE,R1  ;GET START AGAIN
        CLR     (R1)+       ;CLEAR
        CLR     (R1)+
        CLR     (R1)+
        CLR     (R1)
        TST     SN1         ;ALREADY HAVE A SERIAL NUMBER?
        BNE     13$         ;YES - TELL OPR WHAT IT IS

12$: GMANID   ABSSNL,SN1,0,77777,1,77777,NO ;GET SERIAL # LOW 5
        TRAP    C$GMAN
        BR      10024$
        .WORD   SN1
        .WORD   T$CODE
        .WORD   ABSSNL
        .WORD   77777
        .WORD   T$LOLIM
        .WORD   T$HILIM

10024$: GMANID   ABSSNH,SN2,0,77777,0,77777,NO ;GET SERIAL # HIGH 5
        TRAP    C$GMAN
        BR      10025$
        .WORD   SN2
        .WORD   T$CODE
        .WORD   ABSSNH
        .WORD   77777
        .WORD   T$LOLIM
        .WORD   T$HILIM

10025$:
13$: PRINTF   #FMTSN,#CART,SN2,SN1
        MOV     SN1,-(SP)

```

(9)	022724	013746	002460		MOV	SN2,-(SP)	
(8)	022730	012746	002526		MOV	#CART,-(SP)	
(7)	022734	012746	007707		MOV	#FMTSN,-(SP)	
(6)	022740	012746	000004		MOV	#4,-(SP)	
(3)	022744	010600			MOV	SP,R0	
(4)	022746	104417			TRAP	C\$PNTF	
(4)	022750	062706	000012		ADD	#12,SP	
1793	022754				G\$MANIL	VALSN,TEMPO,177777,NO	
(3)	022754	104443			TRAP	C\$G\$MAN	
(3)	022756	000404			BR	10026\$	
(4)	022760	002414			.WORD	TEMPO	
(5)	022762	000120			.WORD	T\$CODE	
(5)	022764	006007			.WORD	VALSN	
(5)	022766	177777			.WORD	177777	
(3)	022770			10026\$:			
1794	022770	005737	002414		TST	TEMPO	;SEE IF TYPED IN SERIAL NUMBER IS OK
1795	022774	001731			BEQ	12\$;NO - GET A NEW SERIAL NUMBER
1796	022776	013737	002456	030530	MOV	SN1,BSFILE	;SAVE THE SERIAL NUMBER LOW 5
1797	023004	013737	002460	030532	MOV	SN2,BSFILE+2	;AND SERIAL NUMBER HIGH 5
1798	023012	005237	002414		INC	TEMPO	;INDICATE FILE BUILT - 1 SECTOR
1799	023016	000205			RTS	R5	
1800							
1801	023020	005037	002414	2\$:	CLR	TEMPO	;INDICATE NO FILE BUILT
1802	023024	012601			MOV	(SP)+,R1	
1803	023026	000205			RTS	R5	

```
1805 023030 STARS
(2) :*****
1806 BSMKE -- ROUTINE TO CREATE A 'FACTORY' OR 'FIELD' BAD SECTOR FILE.
1807 THIS ROUTINE ABORTS IF 'UPDATE' ACCESS TO THE PACK IS DENIED.
1808 THE 'FACTORY' FILE WILL CONTAIN ONLY THE DUMMY HEADERS...NO
1809 ENTRIES CAN BE PUT IN THIS AREA!
1810 023030 STARS
(2) :*****
1811
1812 023030 BSMKE: PRINTF #FMT19,#BUILD ;TELL OPR WHAT IS HAPPENING
(8) 023030 012746 003213 MOV #BUILD,-(SP)
(7) 023034 012746 007631 MOV #FMT19,-(SP)
(6) 023040 012746 000002 MOV #2,-(SP)
(3) 023044 010600 MOV SP,R0
(4) 023046 104417 TRAP C$PNTF
(4) 023050 062706 000006 ADD #6,SP
1813 023054 004537 012370 JSR R5,FIRST ;SELECT THE 1ST UNIT
1814 023060 000137 013546 JMP NXTCMD ;NONE AVAIL.!
1815 023064 000404 BR BSMKL
1816 023066 004537 012400 BSMKS: JSR R5,SELDLV ;SELECT THE NEXT UNIT
1817 023072 000137 013546 JMP NXTCMD ;ALL DONE
1818 023076 004537 025246 BSMKL: JSR R5,LOADED ;DRV RDY?
1819 023102 005737 002414 TST TEMPO
1820 023106 001403 BEQ 1$ ;YES
1821 023110 004537 012642 JSR R5,DRNRDY
1822 023114 000764 BR BSMKS ;SELECT THE NEXT UNIT
1823
1824 023116 004537 012546 1$: JSR R5,DRVID ;TELL OPR WHAT DRIVE SELECTED
1825 023122 005737 002464 TST ACCESS ;ALLOWED TO UPDATE PACK?
1826 023126 001414 BEQ 10$ ;YES - PROCEED
1827 023130 PRINTF #FMT18,#DENIED ;NO - TELL OPR
(8) 023130 012746 004125 MOV #DENIED,-(SP)
(7) 023134 012746 007624 MOV #FMT18,-(SP)
(6) 023140 012746 000002 MOV #2,-(SP)
(3) 023144 010600 MOV SP,R0
(4) 023146 104417 TRAP C$PNTF
(4) 023150 062706 000006 ADD #6,SP
1828 023154 000137 013546 JMP NXTCMD ;QUIT NOW
1829
1830 023160 10$: GMANIL THISDRV,TEMPO,1,NO
(3) 023160 104443 TRAP C$GMAN
(3) 023162 000404 BR 10027$
(4) 023164 002414 .WORD TEMPO
(5) 023166 000120 .WORD T$CODE
(5) 023170 006750 .WORD THISDRV
(5) 023172 000001 .WORD 1
(3) 023174
1831 023174 005737 002414 10027$: TST TEMPO
1832 023200 001732 BEQ BSMKS ;RE-SELECT IF NOT THIS DRIVE
1833
1834 023202 004537 023656 11$: JSR R5,RBDSC ;GET A FRESH COPY OF THE 'BAD SEC FILE'
1835 023206 004537 025032 JSR R5,RDFACT ;THEN A CORE IMAGE OF THE FACTORY FILE
1836 023212 PRINTF #FMT19,#CKFACT ;TELL OPR CHECKING FACT FILE
(8) 023212 012746 006411 MOV #CKFACT,-(SP)
(7) 023216 012746 007631 MOV #FMT19,-(SP)
(6) 023222 012746 000002 MOV #2,-(SP)
```

(3)	023226	010600		MOV	SP,R0	
(4)	023230	104417		TRAP	C\$PNTF	
(4)	023232	062706	000006	ADD	#6,SP	
1837	023236	005002		CLR	R2	;POINT TO 1ST WORD IN CORE IMAGE
1838	023240	005037	015342	CLR	SECTUM	;START AT 1ST SECTOR PAIR IN FILE
1839	023244	012737	000020	MOV	#16,SECTMAX	;STOP AT THIS SECT PAIR
1840	023252	004537	015622	JSR	R5,BSFOK	;SEE IF ANY RECOGNIZED 'FACTORY' FILE
1841	023256	005737	015346	TST	BSFOK	;WELL???
1842	023262	001013		BNE	12\$;NO - ASK IF TIME TO MAKE ONE
1843	023264			PRINTF	#MSG,#OK	;MSG TO OPR 'FOUND'
(8)	023264	012746	006340	MOV	#OK,-(SP)	
(7)	023270	012746	010044	MOV	#MSG,-(SP)	
(6)	023274	012746	000002	MOV	#2,-(SP)	
(3)	023300	010600		MOV	SP,R0	
(4)	023302	104417		TRAP	C\$PNTF	
(4)	023304	062706	000006	ADD	#6,SP	
1844	023310	000424		BR	2\$;JUMP OVER BUILD CODE
1845						
1846						;HERE TO BUILD A DUMMY 'FACTORY' FILE SO AT LEAST ONE EXISTS...WILL NOT
1847						;CONTAIN ANY ENTRIES!
1848						
1849	023312			12\$: PRINTF	#MSG,#NHWSEC	;TELL OPR THAT NO 'FACTORY' EXISTS
(8)	023312	012746	003562	MOV	#NHWSEC,-(SP)	
(7)	023316	012746	010044	MOV	#MSG,-(SP)	
(6)	023322	012746	000002	MOV	#2,-(SP)	
(3)	023326	010600		MOV	SP,R0	
(4)	023330	104417		TRAP	C\$PNTF	
(4)	023332	062706	000006	ADD	#6,SP	
1850	023336	004537	022570	JSR	R5,NEWBSF	;ASK IF TIME TO BUILD ONE
1851	023342	005737	002414	TST	TEMP0	;DID I MAKE A DUMMY FILE?
1852	023346	001405		BEQ	2\$;NO - CHECK ON THE 'FIELD' FILE
1853	023350	013737	002414	MOV	TEMP0,NEWFAC	;SET FACTORY FLAG
1854	023356	004537	016770	JSR	R5,WRTBSF	;WRITE UPDATED 'FIELD' BAD SECTOR FILE
1855						;ON THE PACK IF REQUESTED
1856						

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-63
GLOBAL SUBROUTINES

1 7

```

1858                                     ;HERE TO SEE IF A 'FIELD' FILE HAS TO BE BUILT
1859
1860 023362 004537 025076                2$: JSR R5,RDFIELD ;GET A CORE IMAGE OF THE 'FIELD' FILE
1861 023366                                PRINTF #FMT19,#CKFLD ;TELL OPR CHECKING FOR FIELD FILE
      (8) 023366 012746 006450          MOV #CKFLD,-(SP)
      (7) 023372 012746 007631          MOV #FMT19,-(SP)
      (6) 023376 012746 000002          MOV #2,-(SP)
      (3) 023402 010600                MOV SP,R0
      (4) 023404 104417                TRAP C$PNTF
      (4) 023406 062706 000006          ADD #6,SP
1862 023412 005002                    CLR R2 ;START AT 1ST WORD IN BUFFER
1863 023414 005037 015342                CLR SECNUM ;AND 1ST SECTOR PAIR OF FILE
1864 023420 012737 000020 015340        MOV #16.,SECMAX ;SETUP THE LIMIT FOR SEARCH
1865 023426 004537 015622                JSR R5,BSFOK ;POINT TO A VALID AREA
1866 023432 005737 015346                TST BSFOK ;FIND THE 'FIELD' AREA?
1867 023436 001013                    BNE 21$ ;NO - ASK IF TIME TO MAKE ONE
1868 023440                                PRINTF #MSG,#OK ;TELL OPR 'FOUND' FILE
      (8) 023440 012746 006340          MOV #OK,-(SP)
      (7) 023444 012746 010044          MOV #MSG,-(SP)
      (6) 023450 012746 000002          MOV #2,-(SP)
      (3) 023454 010600                MOV SP,R0
      (4) 023456 104417                TRAP C$PNTF
      (4) 023460 062706 000006          ADD #6,SP
1869 023464 000421                    BR 4$ ;PROCEED
1870
1871 023466                                21$: PRINTF #MSG,#NSWSEC ;TELL OPR NO 'FIELD' FILE
      (8) 023466 012746 003636          MOV #NSWSEC,-(SP)
      (7) 023472 012746 010044          MOV #MSG,-(SP)
      (6) 023476 012746 000002          MOV #2,-(SP)
      (3) 023502 010600                MOV SP,R0
      (4) 023504 104417                TRAP C$PNTF
      (4) 023506 062706 000006          ADD #6,SP
1872 023512 004537 022570                JSR R5,NEWBSF ;ASK OPR IF TIME TO BUILD A FILE
1873 023516 005737 002414                TST TEMPO ;BUILT A FILE?
1874 023522 001402                    BEQ 4$ ;BR IF NO
1875 023524 004537 016770                3$: JSR R5,WRTBSF ;WRITE UPDATED 'FIELD' BAD SECTOR FILE
1876                                     ;/ON THE PACK IF REQUESTED
1877
1878 023530 000137 023066                4$: JMP BSMKS ;SELECT THE NEXT UNIT

```

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 J 7 PAGE 2
ROUTINE TO LOAD FUNCTION

SFO 0087

```

1880 .SBTTL ROUTINE TO LOAD FUNCTION
1881 ;CALL JSR R5,LDFUNC
1882 ;ALL INFORMATION MUST BE SET UP IN DRIVE BUFFER
1883 ;R4 HAS POINTER TO BUFFER
1884
1885 023534 013703 002250 LDFUNC: MOV DCS,R3 ;GET CSR FOR DRIVE
1886 023540 032713 000200 BIT #BIT7,(R3) ;CAN WE ISSUE COMMAND?
1887 023544 001004 BNE 1$ ;YES, GO ISSUE COMMAND
1888
1889 023546 ERRSF 200,PRGER ;THIS ERROR SHOULD NEVER PRINT
(4) 023546 TRAP CSERSF
(5) 023550 000310 .WORD 200
(5) 023552 003735 .WORD PRGER
(5) 023554 000000 .WORD 0
1890
1891 023556 017763 156474 000002 1$: MOV @BBA,BA(R3) ;LOAD BUS ADDRESS REGISTER
1892 023564 013763 002244 000004 MOV BDA,DA(R3) ;LOAD DISK ADDRESS REGISTER
1893 023572 013763 002246 000006 MOV BMP,MP(R3) ;LOAD MULTI-PURPOSE REGISTER
1894 023600 013737 002260 002262 MOV FUNC,BCSADR ;GET FUNCTION
1895 023606 053737 002302 002262 BIS DRSEL,BCSADR ;SET DRIVE SELECT BITS
1896 023614 052737 000201 002262 BIS #CRDY!DRDY,BCSADR ;SET CRDY & DRDY IN IMAGE
1897 023622 042737 002000 002262 BIC #OPI,BCSADR ;WE'RE CLEAR BIT 10 FOR DRIVE 7-4 (OKAY?)
1898 023630 013763 002262 000000 MOV BCSADR,CS(R3) ;LOAD CSR
1899 023636 042763 000200 000000 BIC #CRDY,CS(R3) ;ISSUE FUNCTION
1900 023644 000205 RTS ;EXIT
1901
1902 .SBTTL INTERRUPT SERVICE ROUTINE
1903 023646 BGNSRV !INTR1
1904
1905 023646 042777 000100 156374 INTR1: BIC #INTEN,@DCS
1906 023654 ENDSRV
(3) 023654 L10016:
(2) 023654 000002 RTI

```

CZRLMBO RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 K 7
BAD SECTOR FILE ROUTINE

SE0 0088

```

1908
1909
1910 023656
1911 (2)
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921 023656
1922 (2)
1923 023656 010046
1924 023660 010146
1925 023662 010246
1926 023664 010346
1927 023666 004537 025436
1928 023672 012737 000010 002260
1929 023700 004537 023534
1930 023704 004537 025310
1931 023710 005777 156334
1932 023714 100016
1933 023716 017737 156326 002252
1934 023724 013703 002250
1935 023730 016337 000004 002440
1936 023736
1937 023746 000137 025020
1938
1939 023752 016300 000006
1940 023756 022737 000001 002316
1941 023764 001005
1942 023766 043700 002334
1943 023772 012701 077600
1944 023776 000404
1945 024000 043700 002340
1946 024004 012701 177600
1947 024010 160001
1948 024012 010137 002244
1949 024016 052737 000025 002244
1950 024024 012737 000006 002260
1951 024032 004537 023534
1952 024036 004537 025310
1953 024042 005777 156202
1954 024046 100016
1955 024050 017737 156174 002252
1956 024056 013703 002250
1957 024062 016337 000004 002440

.SBTTL BAD SECTOR FILE ROUTINE

STARS
:*****
:ROUTINE TO RECOVER BAD SECTOR FILE AND SAVE IT FOR
:COMPARISON UPON ERROR ON READS/Writes. WE WILL ONLY
:RESERVE SPACE FOR 16 BAD SECTORS PER DRIVE.
:WE WILL ISSUE A DRIVE RESET FIRST, READ HEADER, POSITION
:TO LAST TRACK (CYLINDER 255, SURFACE 1) AND READ IN
:THE FIRST SECTOR FOR FACTORY BAD, AND THE 20TH FOR
:FIELD BAD SECTORS. R4 WILL CONTAIN THE BUFFER POINTER
:TO THE DRIVE WE WANT TO READ
:
:CALL JSR R5,RDBDSC
STARS
:*****
RDBDSC: MOV R0,-(SP) ;SAVE REGISTERS
        MOV R1,-(SP) ;
        MOV R2,-(SP) ;
        MOV R3,-(SP) ;
21$: JSR R5,ISDRST ;RESET THE DRIVE - GET STATUS AND CLEAR ERROR REG.
      MOV #RDHDR,FUNC ;READ HEADER TO FIND POSITION
      JSR R5,LDFUNC ;ON DISK
      JSR R5,WTRDY
      TST @DCS ;ERROR DETECTED?
      BPL 22$ ;NO
      MOV @DCS,E.DCS ;YES - SAVE THE RLCS STATUS
      MOV DCS,R3 ;GET THE BASE ADDRESS FOR RLCS
      MOV DA(R3),E.DA ;SAVE THE DISK ADDRESS AT ERROR
      ERRHRD 500.,MHDR,ERR2
      TRAP C$ERHRD
      .WORD 500
      .WORD MHDR
      .WORD ERR2
      JMP 9$ ;FORCED EXIT

22$: MOV MP(R3),R0 ;GET HEADER AND CALCULATE
      CMP #1,TDR ;RL02 TYPE DRIVE?
      BNE 23$ ;JUMP IF RL02
      BIC CYLSK,R0 ;HERE FOR RL01 - GET CYL ADDRESS (BITS 7-14)
      MOV #77600,R1 ;INITIALIZE FOR CYL 255
      BR 25$
23$: BIC CMSK,R0 ;HERE FOR RL02
      MOV #177600,R1 ;INITIALIZE FOR CYL 510
25$: SUB R0,R1 ;GET DIFFERENCE FROM PRESENT CYL ADDRESS TO CYL 255
      MOV R1,BDA ;INITIALIZE DAR WITH DISK ADDRESS DIFFERENCE
      BIS #SKHS!SIGN!MK,BDA
      MOV #SEEK,FUNC
      JSR R5,LDFUNC ;SEEK TO THE BAD SEC FILE CYLINDER
      JSR R5,WTRDY ;WAIT FOR DONE
      TST @DCS ;ERROR DETECTED?
      BPL 26$ ;NO
      MOV @DCS,E.DCS ;YES - SAVE THE RLCS STATUS
      MOV DCS,R3 ;GET THE BASE ADDRESS FOR RLCS
      MOV DA(R3),E.DA ;SAVE THE DISK ADDRESS AT ERROR

```


1958	024070				ERRHRD	510.,MHDER,ERR2	
(4)	024070	104456			TRAP	C\$ERHRD	
(5)	024072	000776			.WORD	510	
(5)	024074	003420			.WORD	MHDER	
(5)	024076	007376			.WORD	ERR2	
1959	024100	000137	025020		JMP	9\$:FORCED EXIT
1960							
1961	024104	012737	000010	002260	26\$:	MOV	#RDHDR,FUNC
1962	024112	004537	023534			JSR	R5,LDFUNC
1963	024116	004537	025310			JSR	R5,WTRDY
1964	024122	005777	156122			TST	@DCS
1965	024126	100016				BPL	27\$
1966	024130	017737	156114	002252		MOV	@DCS,E.DCS
1967	024136	013703	002250			MOV	DCS,R3
1968	024142	016337	000004	002440		MOV	DA(R3),E.DA
1969	024150					ERRHRD	520.,MHDER,ERR2
(4)	024150	104456				TRAP	C\$ERHRD
(5)	024152	001010				.WORD	520
(5)	024154	003420				.WORD	MHDER
(5)	024156	007376				.WORD	ERR2
1970	024160	000137	025020			JMP	9\$
1971							:FORCED EXIT
1972	024164	016300	000006		27\$:	MOV	MP(R3),R0
1973	024170	042700	000077			BIC	#77,R0
1974	024174	022737	000001	002316		CMF	#1,TDR
1975	024202	001007				BNE	300\$
1976	024204	022700	077700			CMF	#77700,R0
1977	024210	001226				BNE	21\$
1978	024212	012737	077700	002244		MOV	#77700,BDA
1979	024220	000406				BR	555\$
1980	024222	022700	177700		300\$:	CMF	#177700,R0
1981	024226	001217				BNE	21\$
1982	024230	012737	177700	002244		MOV	#177700,BDA
1983	024236	012737	177400	002246	555\$:	MOV	#-256.,BMP
1984	024244	012737	000014	002260		MOV	#READ,FUNC
1985							:DO A 1 SECTOR PAIR READ
1986	024252	005037	002422			CLR	TEMP3
1987	024256	005037	002414			CLR	TEMPO
1988	024262	005037	002412			CLR	DECNT
1989	024266	013702	002304			MOV	BSECT,R2
1990	024272	012700	000176			MOV	#126.,R0
1991	024276	012722	177777		11\$:	MOV	#-1,(R2)+
1992	024302	005300				DEC	R0
1993	024304	001374				BNE	11\$
1994							:EXIT IF STORAGE INITED
1995	024306	013702	002304			MOV	BSECT,R2
1996	024312	012700	000031			MOV	#25.,R0
1997	024316	004537	023534		4\$:	JSR	R5,LDFUNC
1998	024322	004537	025310			JSR	R5,WTRDY
1999							:ISSUE THE READ CMD
2000	024326	005777	155716			TST	@DCS
2001	024332	100065				BPL	3\$
2002							:WAS THE READ GOOD?
2003	024334	004537	025436			JSR	R5,ISDRST
2004	024340	062737	000004	002244		ADD	#4,BDA
2005	024346	005737	002422			TST	TEMP3
							:NEXT SECTOR
							:MANUFACTURING OR FIELD BAD

2006	024352	001424				BEQ	5\$:MANUFACTURING
2007	024354	022737	000001	002316		CMP	#1,TDR	:RL01=1
2008	024362	001024				BNE	400\$:MUST BE AN RL02
2009	024364	022737	077750	002244		CMP	#77750,BDA	:END OF FACTORY FILE
2010	024372	001351				BNE	4\$:NO - READ NEXT SECTOR
2011	024374				41\$:	PRINTF	#FMT18,#SWSEC	:TELL OPR NO 'FIELD' FILE ON PACK
(8)	024374	012746	003610			MOV	#SWSEC,-(SP)	
(7)	024400	012746	007524			MOV	#FMT18,-(SP)	
(6)	024404	012746	000002			MOV	#2,-(SP)	
(3)	024410	010600				MOV	SP,R0	
(4)	024412	104417				TRAP	C\$PNTF	
(4)	024414	062706	000006			ADD	#6,SP	
2012	024420	000137	024766			JMP	7\$:EXIT
2013								
2014	024424	023727	002244	077724	5\$:	CMP	BDA,#77724	:AT END OF MANUFACTURING BAD
2015	024432	000410				BR	55\$	
2016	024434	022737	177750	002244	400\$:	CMP	#177750,BDA	:AT END OF FIELD BAD FOR RL02
2017	024442	001325				BNE	4\$:NO GO BACK FOR NEXT
2018	024444	000753				BR	41\$:PRINT 'FIELD' ERROR
2019	024446	023727	002244	177724		CMP	BDA,#177724	:AT END OF MANUFACTURING BAD
2020	024454	001320			55\$:	BNE	4\$:NO, GET THE NEXT SECTOR PAIR
2021	024456				56\$:	PRINTF	#FMT18,#HWSEC	:TELL OPR NO 'FACTORY' FILE ON PACK
(8)	024456	012746	003532			MOV	#HWSEC,-(SP)	
(7)	024462	012746	007624			MOV	#FMT18,-(SP)	
(6)	024466	012746	000002			MOV	#2,-(SP)	
(3)	024472	010600				MOV	SP,R0	
(4)	024474	104417				TRAP	C\$PNTF	
(4)	024476	062706	000006			ADD	#6,SP	
2022	024502	000137	024766			JMP	7\$:EXIT & HEADS HOME
2023								
2024	024506	017701	155544		3\$:	MOV	#BDA,R1	:START OF LIST
2025	024512	005037	015324			CLR	NOSNUM	:CLEAR THE FOUND SERIAL NUMBER FLAG
2026	024516	005721				TST	(R1)+	:SEE IF A SERIAL NUMBER PRESENT
2027	024520	001005				BNE	31\$:YUP - SN WORD 0 >0
2028	024522	005721				TST	(R1)+	:NO ... SEE IF SN WORD 1 =0
2029	024524	001004				BNF	32\$:OK - SOME SERIAL NUM PRESENT
2030	024526	005237	015324			INC	NOSNUM	:NO - SET THE 'NO SERIAL NUMBER' FLAG
2031	024532	000401				BR	32\$	
2032	024534	005721			31\$:	TST	(R1)+	:SKIP OVER THE 2ND SERIAL NUM WORD
2033	024536	022121			32\$:	CMP	(R1)+,(R1)+	:SKIP PAST THE 'BLANK' WORDS
2034	024540	012137	002416		1\$:	MOV	(R1)+,TEMP1	:GET CYLINDER ENTRY WORD
2035	024544	100446				BMI	2\$:IF MINUS - END OF BAD SECTORS
2036	024546	005237	002412			INC	DECNT	:COUNT THIS ENTRY IN THE FILE
2037	024552	012137	002420			MOV	(R1)+,TEMP2	:GET HEAD AND SECTOR
2038	024556	000337	002416			SWAB	TEMP1	:PUT CYLINDER IN HIGH BYTE
2039	024562	000241				CLC		
2040	024564	006037	002416			ROR	TEMP1	:ALIGN THE BITS
2041	024570	103003				BCC	111\$:NEED ANOTHER BIT?
2042	024572	052737	100000	002416		BIS	#BIT15,TEMP1	:YES
2043	024600	013712	002416		111\$:	MOV	TEMP1,(R2)	:STORE OFF CYLINDER PART
2044	024604	013737	002420	002416		MOV	TEMP2,TEMP1	:GET SECTOR
2045	024612	042737	177700	002416		BIC	#177700,TEMP1	:LEAVE ONLY SECTOR
2046	024620	053712	002416			BIS	TEMP1,(R2)	:SET IN SECTOR BITS
2047	024624	042737	177377	002420		BIC	#177377,TEMP2	:CLEAR ALL EXCEPT HEAD BIT
2048	024632	006237	002420			ASR	TEMP2	
2049	024636	006237	002420			ASR	TEMP2	

CZRLMB0 RL01/02 BD SEC FIL TL MACV11 30A(1052) 17-DEC-79 10:53 N 7
 CZRLMB.MAC 12-DEC-79 14:06 BAD SECTOR FILE ROUTINE PAGE 3-3

```

2050 024642 053722 002420      BIS      TEMP2,(R2)+      ;SET IN HEAD
2051 024646 005300              DEC      R0
2052 024650 001333              BNE      1$
2053 024652 005737 002414      TST      TEMPO              ;PRINT A MESSAGE?
2054 024656 001330              BNE      1$              ;NO
2055 024660 000423              BR       6$
2056
2057 024662 005737 002422      2$:      TST      TEMP3              ;SWITCH TO FIELD BAD OR QUI
2058 024666 001037              BNE      7$              ;QUIT, 7$
2059 024670 022737 000001 002316      CMP      #1,TDR              ;RL01=1
2060 024676 001004              BNE      350$              ;MUST BE RL02
2061 024700 012737 077724 002214      MOV      #77724,BDA      ;START AT FIELD SECTOR
2062 024706 000403              BR       36$
2063 024710 012737 177724 002244 350$:      MOV      #177724,BDA      ;START OF FIELD AREA FOR RL02
2064 024716 012737 000001 002422 36$:      MOV      #1,TEMP3
2065 024724 000137 024316      JMP      4$
2066 024730              6$:      PRINTF    #FMT18,#TBLFUL
      (8) 024730 012746 006040      MOV      #TBLFUL,-(SP)
      (7) 024734 012746 007624      MOV      #FMT18,-(SP)
      (6) 024740 012746 000002      MOV      #2,-(SP)
      (3) 024744 010600      MOV      SP,R0
      (4) 024746 104417      TRAP     C$PNTF
      (4) 024750 062706 000006      ADD      #6,SP
2067 024754 005237 002414      INC      TEMPO              ;SET THE PRINT FLAG
2068 024760 012700 000170      MOV      #120.,R0      ;RESET THE COUNTER
2069 024764 000665              BR       1$              ;AND CONTINUE
2070
2071 024766 005737 002414      7$:      TST      TEMPO              ;OVER 25. ENTRIES?
2072 024772 001412              BEQ      9$              ;NO
2073 024774              PRINTF    #FMT20,DECNT      ;PRINT # ENTRIES IN FILE
      (8) 024774 013746 002412      MOV      DECNT,-(SP)
      (7) 025000 012746 007640      MOV      #FMT20,-(SP)
      (6) 025004 012746 000002      MOV      #2,-(SP)
      (3) 025010 010600      MOV      SP,R0
      (4) 025012 104417      TRAP     C$PNTF
      (4) 025014 062706 000006      ADD      #6,SP
2074 025020 012603              9$:      MOV      (SP)+,R3
2075 025022 012602      MOV      (SP)+,R2
2076 025024 012601      MOV      (SP)+,R1
2077 025026 012600      MOV      (SP)+,R0
2078 025030 000205              RTS      R5
2079
2080      ;ROUTINE TO READ THE 'FACTORY' FILE FROM THE BAD SECTOR FILE
2081
2082 025032 005037 002476      RDFACT: CLR      BSFFLG      ;CLEAR BSF FLAG TO DENOTE 'FACTORY' ENTRIES
2083 025036 004537 025222      JSR      R5,CLRBSF      ;CLEAR THE BSFILE STORAGE AREA
2084 025042 012737 177000 002246      MOV      #-512.,BMP      ;SAVE THE WORD COUNT
2085 025050 012737 077700 002244      MOV      #77700,BDA      ;AND THE DISK ADDR FOR FACTORY FILE
2086 025056 022737 000001 002316      CMP      #1,TDR              ;IS IT AN RL02?
2087 025064 001426              BEQ      RDBSFILE      ;NO - READ THE FILE
2088 025066 012737 177700 002244      MOV      #177700,BDA      ;HERE FOR RL02
2089 025074 000422              BR       RDBSFILE      ;THEN READ THEE FILE
2090
2091      ;ROUTINE TO READ THE 'FIELD' FILE FROM THE BAD SECTOR FILE
2092 025076 012737 000001 002476      RDFIELD: MOV     #1,BSFFLG      ;MAKE BSF FLAG EQUAL TO 1 TO DENOTE 'FIELD' ENTRIES
2093 025104 004537 025222      JSR      R5,CLRBSF      ;CLEAR THE BSFILE STORAGE AREA

```

```
2094 025110 012737 177000 002246      MOV      #-512,BMP      ;SAVE THE WORD COUNT
2095 025116 012737 077724 002246      MOV      #77724,BDA    ;AND THE DISK ADDR FOR 'FIELD' FILE
2096 025124 022737 000001 002316      CMP      #1,TDR       ;IS DRIVE A RL02?
2097 025132 001403          BEQ      RDBSFIL    ;NO - READ THE FILE
2098 025134 012737 177724 002244      MOV      #177724,BDA    ;HERE FOR RL02
2099
2100 025142 063737 015342 002244 RDBSFIL: ADD    SECNUM,BDA    ;ADD OFFSET TO DAR TO ACCESS APPROPRIATE SECTORS
2101 025150 012737 000014 002260      MOV      #READ,FUNC    ;SAVE THE COMMAND
2102 025156 004537 023534          JSR      R5,LDFUNC    ;AND ISSUE IT
2103 025162 004537 025310          JSR      R5,WTRDY    ;THEN WAIT FOR READY
2104 025166 005777 155056          TST      @DCS       ;WAS THERE ANY ERROR?
2105 025172 100012          BPL      RDBSEX    ;NO - EXIT
2106
2107 025174          PRINTF    #FMT19,#BADBSF ;TELL THE OPR AN ERROR OCCURRED
(8) 025174 012746 005130      MOV      #BADBSF,-(SP)
(7) 025200 012746 007631      MOV      #FMT19,-(SP)
(6) 025204 012746 000002      MOV      #2,-(SP)
(3) 025210 010600          MOV      SP,R0
(4) 025212 104417          TRAP     C$PNTF
(4) 025214 062706 000006      ADD      #6,SP
2108
2109 025220 000205          RDBSEX: RTS      R5      ;EXIT
2110
2111 025222 010146          CLRBSF: MOV     R1,-(SP)      ;SAVE R1
2112 025224 012701 030530      MOV      #BSFILE,R1    ;SET UP A POINTER
2113 025230 012721 177777      1$:      MOV      #-1,(R1)+    ;SET BUFFER & POINT TO NEXT
2114 025234 022701 033130      CMP      #BSFILE+1280,,R1 ;DONE?
2115 025240 001373          BNE      1$      ;NO - INIT THE NEXT ADDR
2116 025242 012601          MOV      (SP)+,R1    ;RESET R1
2117 025244 000205          RTS      R5      ;EXIT
2118
2119 025246          STARS
(2) ;:*****
2120 ;:LOADED -- CHECK FOR DRV READY
2121 025246          STARS
(2) ;:*****
2122
2123 025246 010146          LOADED: MOV     R1,-(SP)      ;SAVE R1
2124 025250 004537 025422      JSR      R5,GETDST    ;GET DRV STATUS
2125 025254 005037 002414      CLR      TEMPO      ;CLEAR THE FLAG
2126 025260 032701 000020      BIT      #HOP,R1    ;HEADS OVER PACK?
2127 025264 001002          BNE      1$      ;YES
2128 025266 005237 002414      INC      TEMPO      ;NO
2129 025272 032701 000010      1$:      BIT      #BRHM,R1    ;BRUSHES HOME?
2130 025276 001002          BNE      2$      ;YES
2131 025300 005237 002414      INC      TEMPO
2132 025304 012601          2$:      MOV      (SP)+,R1
2133 025306 000205          RTS      R5      ;EXIT
```

```

2135 .SBTTL ROUTINE TO WAIT FOR CONTROLLER READY
2136
2137 ;ROUTINE TO WAIT FOR CONTROLLER READY UNDER FLAG
2138 ;MODE. USED IN INITIALIZE PORTION OF PROGRAM,I.E.,
2139 ;GETTING BAD SECTOR FILE, WRITING PACK INITIALLY.
2140
2141 025310 010046 WTRDY: MOV R0,-(SP) ;SAVE REGISTERS
2142 025312 010146 MOV R1,-(SP)
2143 025314 012701 001750 MOV #1000.,R1 ;WAIT A WHILE
2144 025320 1$: WAITUS #2
(3) 025320 012727 000002 MOV ##2.,(PC)+
(3) 025324 000000 .WORD 0
(3) 025326 013727 002116 MOV L$DLY,(PC)+
(3) 025332 000000 .WORD 0
(3) 025334 005367 177772 DEC -6(PC)
(3) 025340 001375 BNE -.4
(3) 025342 005367 177756 DEC -22(PC)
(3) 025346 001367 BNE -.20
2145 025350 032777 000200 154672 BIT #CRDY,ADCS ;READY SET?
2146 025356 001016 BNE 2$ ;YES, EXIT
2147 025360 005301 DEC R1 ;TIMED OUT?
2148 025362 001356 BNE 1$ ;NO GO BACK
2149 025364 017737 154660 002252 MOV ADCS,E.DCS ;SAVE THE STATUS FOR ERROR REPORT
2150 025372 013703 002250 MOV DCS,R3 ;GET THE BASE ADDRESS FOR RLCS
2151 025376 016337 000004 002440 MOV DA(R3),E.DA ;SAVE THE DISK ADDRESS AT ERROR
2152 025404 ERRDF 110.,NOCRDY,ERR2
(4) 025404 104455 TRAP C$ERDF
(5) 025406 000156 .WORD 110
(5) 025410 003775 .WORD NOCRDY
(5) 025412 007376 .WORD ERR2
2153 025414 012601 2$: MOV (SP)+,R1 ;RESTORE REGISTERS
2154 025416 012600 MOV (SP)+,R0
2155 025420 000205 RTS R5
2156
2157 .SBTTL GET STATUS/DRIVE RESET ROUTINE
2158
2159 ;ROUTINE TO ISSUE DRIVE RESET
2160 ;ALSO GET STATUS, R1 HAS STATUS IF GS
2161 ;USES R3, DOES NOT SAVE IT
2162
2163 025422 013703 002250 GETDST: MOV DCS,R3 ;GET CSR ADDRESS
2164 025426 012763 000003 000004 MOV #GSBIT,DA(R3) ;INITIALIZE DAR FOR GET STATUS COMMAND
2165 025434 000405 BR CSTUFF
2166 025436 013703 002250 ISDRST: MOV DCS,R3 ;GET CSR ADDRESS
2167 025442 012763 000013 000004 MOV #DRST,DA(R3) ;INIT DAR FOR GET STATUS COMMAND AND CLEAR ERR REG
2168 025450 012763 000204 000000 CSTUFF: MOV #CRDY!GSTAT,CS(R3) ;SET CONTROLLER READY AND GET STATUS FUNCTION
2169 025456 053763 002302 000000 BIS DRSEL,CS(R3) ;SELECT THE DRIVE
2170 025464 042763 000200 000000 BIC #CRDY,CS(R3) ;PERFORM THE GET STATUS COMMAND
2171 025472 004537 025310 JSR R5,WTRDY ;WAIT FOR CONTROLLER READY
2172 025476 022763 000013 000004 CMP #DRST,DA(R3) ;RESET THE DRIVE?
2173 025504 001402 BEQ 1$ ;NO - EXIT
2174 025506 016301 000006 MOV MP(R3),R1 ;ELSE, GET THE STATUS WORD
2175 025512 000205 1$: RTS R5
2176

```

```

2178 .SBTTL ROUTINE TO WRITE PACKS INITIALLY
2179
2180 ;ROUTINE TO WRITE PACK WITH PATTERN, ALL TRACKS WILL BE
2181 ;WRITTEN (EXCEPT BAD SECTOR TRACK)
2182 ;FORMAT IS # OF WORDS (WORD 1), PATTERN ADDRESS (WORD 2)
2183 ;PATTERN (WORDS 3 - 128)
2184 ;WE WILL ATTEMPT TO WRITE MULTIPLE SECTORS AT A TIME
2185 ; (10 SECTORS). IF AN ERROR OCCURS WE WILL THEN
2186 ;WRITE INDIVIDUAL SECTORS FOR THAT TRACK. WE DO WRITES,
2187 ;READS AND INCORE COMPARISONS TO VERIFY.
2188
2189 ;
2190 ;CALL JSR R5,WRPACK
2191
2192 025514 010046 WRPACK: MOV R0,-(SP) ;SAVE REGISTERS
2193 025516 010146 MOV R1,-(SP)
2194 025520 010246 MOV R2,-(SP)
2195 025522 010346 MOV R3,-(SP)
2196 025524 010446 MOV R4,-(SP)
2197 025526 013746 002256 MOV BBA,-(SP)
2198 025532 004537 026754 1$: JSR R5,HDHOME ;HEADS HOME
2199 025536 012737 002450 002256 MOV #BUF1,BBA
2200 025544 012737 175400 002246 MOV #-1280,BMP ;INITIALIZE TO WRITE 10 SECTORS
2201 025552 004537 030412 JSR R5,WRBUF ;GENERATE THE WC DATA PATTERN
2202
2203 ;NOW ACTUALLY WRITE DATA OUT ON PACK, WILL NOT WRITE LAST
2204 ;TRACK
2205
2206 025556 005001 CLR R1 ;R1=CYL 000
2207 025560 005004 CLR R4 ;START AT 1ST CYLINDER
2208 025562 005737 002312 TST FWDFLG ;FORWARD DIRECTION?
2209 025566 001410 BEQ 2$ ;YES
2210 025570 012704 000776 MOV #510,R4 ;SET FOR THE LAST CYL (RL02)
2211 025574 022737 000001 002316 CMP #1,TDR ;DRIVE = RL01?
2212 025602 001002 BNE 2$ ;NO - DA IS OK
2213 025604 042704 177400 BIC #177400,R4 ;YES - MAX CYL IS 255.
2214 025610 000137 026152 2$: JMP SKWRT ;SEEK TO THE START CYLINDER
2215
2216 025614 022737 000001 002316 CONWR: CMP #1,TDR ;RL01=1
2217 025622 001007 BNE 13$ ;MUST BE AN RL02
2218 025624 022701 077600 CMP #077600,R1 ;RL01 LAST CYLINDER?
2219 025630 001020 BNE STWRT ;NO - PROCEED TO WRITE TRACK
2220 025632 005737 002416 12$: TST TEMP1 ;ON HEAD 1 LAST TRACK?
2221 025636 001415 BEQ STWRT ;NO - WRITE HEAD 0 LAST TRACK
2222 025640 000404 BR ENDWR
2223 025642 022701 177600 13$: CMP #177600,R1 ;LAST CYL FOR RL02?
2224 025646 001011 BNE STWRT ;NO - GO WRITE TRACK
2225 025650 00077J BR 12$ ;YES - TEST FOR LAST TRACK ON LAST CYL
2226
2227 ;HERE WHEN ALL DONE WRITING THE PACK
2228
2229 025652 012637 002256 ENDWR: MOV (SP)+,BBA
2230 025656 012604 MOV (SP)+,R4
2231 025660 012603 MOV (SP)+,R3
2232 025662 012602 MOV (SP)+,R2
2233 025664 012601 MOV (SP)+,R1

```

```

2234 025666 012600      MOV      (SP)+,R0
2235 025670 000205      RTS      R5              ;END EXIT
2236
2237      ;THIS PORTION WILL WRITE THE PACK USING MULTIPLE SECTORS. IF AN
2238      ;ERROR OCCURS WE WILL GO TO 2$ AND INDIVIDUAL SECTORS.
2239      ;IF AFTER 3 RETRYS ON A SECTOR NO RECOVERY CAN BE MADE, THEN THE SECTOR WILL
2240      ;BE MARKED 'BAD' IN THE TEMP BAD SEC FILE STORAGE AREA.
2241
2242 025672 005002      STWRT:  CLR      R2              ;INITIAL SECTOR 0
2243 025674 005037 002412      CLR      DECN      ;INITIALIZE ERROR LOOP COUNTER
2244 025700 010137 002244      SWRT1: MOV     R1,BDA      ;SET UP CYLINDER
2245 025704 053737 002416 002244      BIS     TEMP1,BDA    ;INSERT THE HEAD NUMBER (0 OR 1)
2246 025712 050237 002244      BIS     R2,BDA      ;ADD IN THE SECTOR NUMBER
2247 025716 012737 000012 002260      MOV     #WRITE,FUNC  ;WRITE CMD
2248 025724 004537 023534      JSR      R5,LDFUNC   ;ISSUE THE WRITE
2249 025730 004537 025310      JSR      R5,WTRDY    ;WAIT FOR READY
2250
2251 025734 005777 154310      TST      @DCS      ;ERROR DETECTED?
2252 025740 100041      BPL      WNXSEC      ;BR IF NO ERROR - GET NEXT SECTOR
2253
2254      ;HERE IF AN ERROR WAS DETECTED - GOING TO WRITE THE TRACK ONE SECTOR
2255      ;AT A TIME ... >3 RETRYS = 'BAD' SECTOR
2256
2257 025742      PRINTF  #MCRLF
(7) 025742 012746 010041      MOV     #MCRLF,-(SP)
(6) 025746 012746 000001      MOV     #1,-(SP)
(3) 025752 010600      MOV     SP,R0
(4) 025754 104417      TRAP     C$PNTF
(4) 025756 062706 000004      ADD     #4,SP
2258 025762 017737 154262 002252      MOV     @DCS,E.DCS    ;SAVE THE ERROR DETECTED
2259 025770 013703 002250      MOV     DCS,R3      ;GET THE BASE ADDRESS FOR RLCS
2260 025774 016337 000004 002440      MOV     DA(R3),E.DA    ;SAVE THE DISK ADDRESS AT ERROR
2261 026002 005337 002440      DEC      E.DA      ;SECTOR IS PREVIOUS FROM INDICATED
2262 026006 013737 002440 002410      MOV     E.DA,CHKSEC
2263 026014 013737 002410 002502      MOV     CHKSEC,FRSTER  ;STORE ERROR ADDRESS FOR ERROR LOOP
2264 026022      ERRSOFT 410.,MSFER,ERR1
(4) 026022 104457      TRAP     C$ERSOFT
(5) 026024 000632      .WORD    410
(5) 026026 003310      .WORD    MSFER
(5) 026030 007130      .WORD    ERR1
2265 026032 004537 025436      JSR      R5,ISDRST    ;RESET THE DRIVE
2266 026036 005237 002232      INC      SFTCNT    ;ADD TO SOFT ERROR TALLY
2267 026042 000471      BR       W1SEC      ;WRITE 1 SECTOR AT A TIME
2268
2269      ;HERE TO SELECT THE NEXT SECTOR GROUP ON THIS TRACK
2270
2271 026044 062702 000012      WNXSEC: ADD     #10.,R2      ;NEXT GROUP
2272 026050 022702 000050      CMP      #40.,R2      ;DONE?
2273 026054 001311      BNE      SWRT1      ;NO, GO BACK
2274 026056 005237 002240      INC      WRTCNT    ;COUNT THIS WRITE PASS ON SELECTED TRK
2275 026062 023737 002240 010132      CMP      WRTCNT,WRTLIM ;AT LIMIT FOR THIS TRACK?
2276 026070 001300      BNE      STWRT      ;NO - DO THIS TRACK AGAIN
2277 026072 005037 002240      CLR      WRTCNT    ;YES - CLEAR THE PASS COUNTER
2278
2279      ;HERE TO SELECT THE NEXT TRACK WITH A SEEK CMD
2280

```



```

2281 026076 005737 010130      WNXTRK: TST      WRTSAW      :DOING A SAWTOOTH WRITE CYCLE?
2282 026102 001410              BEQ      3$          :NO - DO INCREMENTAL
2283 026104 005737 002312      TST      FWDFLG      :SAWTOOTH FWD WRT?
2284 026110 001003              BNE      2$          :NO - DOING REVERSE WRT
2285
2286 026112 004537 026754      1$:      JSR      R5,HDHOME      :YES - SET THE HEADS OVER CYL #000
2287 026116 000402              BR        3$
2288
2289 026120 004537 027052      2$:      JSR      R5,HDLAST      :SET THE HEADS OVER THE LAST CYL
2290
2291 026124 005737 002416      3$:      TST      TEMP1          :DOING HEAD 0 ??
2292 026130 001432              BEQ      5$          :YES - SET FOR HEAD #1
2293 026132 005737 002312      TST      FWDFLG      :FWD WRITE?
2294 026136 001404              BEQ      31$         :YES - R4 IS AN UPCOUNTER?
2295 026140 005304              DEC      R4          :NO - DOWNCOUNT R4 (CYL COUNTER)
2296 026142 002003              BGE      32$         :PROCEED IF STILL HAVE SOME TO DO
2297 026144 000137 025652      JMP      ENDWR      :JUST COMPLETED THE PACK
2298
2299 026150 005204              31$:      INC      R4          :POINT TO THE NEXT CYLINDER (FWD DIRECTION)
2300
2301 026152 026152              SKWRT=.
2302 026152 005037 002416      32$:      CLR      TEMP1          :SET POINTER BACK TO HEAD #0
2303
2304 026156 010401              4$:      MOV      R4,R1          :GET THE CYLINDER #
2305 026160 000301              SWAB      R1          :POSITION THE BITS FOR DIRECT LOADING
2306 026162 000241              CLC          :INTO THE DA REGISTER
2307 026164 006001              ROR      R1          :FOR THE SEEK TO THE PROPER
2308 026166 103002              BCC      41$         :CYLINDER
2309 026170 052701 100000      BIS      #BIT15,R1
2310 026174 010137 002324      41$:      MOV      R1,NEWPOS      :SET THE DESIRED DISK ADDRESS
2311 026200 053737 002416      BIS      TEMP1,NEWPOS    :ADD IN THE SELECTED HEAD BIT
2312 026206 004537 027136      JSR      R5,SKFNC      :ISSUE THE SEEK TO THE DESIRED CYLINDER/HEAD
2313 026212 000137 025614      JMP      CONWR      :AND CONTINUE WRITING THE PACK
2314
2315 026216 012737 000100 002416 5$:      MOV      #HEAD,TEMP1    :POINT TO HEAD #1
2316 026224 000754              BR        4$          :AND SEEK THERE
2317
2318              :IF AN ERROR OCCURS THEN WE COME HERE AND DO THE TRACK SECTOR
2319              :BY SECTOR.
2320
2321 026226 005002              WISEC:  CLR      R2          :R2 = SECTOR
2322 026230 012737 177600 002246      MOV      #-128.,BMP      :LOAD WORD COUNT
2323 026236 013737 002322 002244      1$:      MOV      PRPOS,BDA      :SETUP DISK ADDRESS
2324 026244 053737 002416 002244      BIS      TEMP1,BDA      :ADD IN THE HEAD NUMBER (0 OR 1)
2325 026252 050237 002244      BIS      R2,BDA      :ADD IN THE SECTOR NUMBER
2326
2327              :HERE TO WRITE A SECTOR
2328
2329 026256 012737 000012 002260 2$:      MOV      #WRITE,FUNC    :WRITE FUNCTION
2330 026264 004537 023534      JSR      R5,LDFUNC      :ISSUE THE WRITE
2331 026270 004537 025310      JSR      R5,WTRDY      :WAIT FOR WRITE TO FINISH
2332
2333 026274 005777 153750      TST      @DCC          :ERROR ON WRITE?
2334 026300 100114              BPL      3$          :NO - SETUP FOR NEXT SECTOR
2335
2336              :HERE IF ERROR ON 1 SECTOR WRITE

```


CZRLMBO RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 4-4
 CZRLMB.MAC 12-DEC-79 14:06 ROUTINE TO WRITE PACKS INITIALLY

```

2337
2338 026302 017737 153742 002252      MOV      @DCS,E.DCS      ;SAVE THE DETECTED ERROR
2339 026310 023737 002244 002502      CMP      BDA,FRSTER    ;DID WE REPORT ERROR IN MAIN PROGRAM?
2340 026316 001425                      BEQ      10$            ;YES - SKIP
2341 026320 005737 002412              TST      DECNT          ;DID WE REPORT IT ONCE IN ERROR LOOP?
2342 026324 001022                      BNE      10$            ;YES - SKIP
2343 026326                      PRINTF   #MCRLF                    ;ELSE REPORT IT NOW
      (7) 026326 012746 010041          MOV      #MCRLF,-(SP)
      (6) 026332 012746 000001          MOV      #1,-(SP)
      (3) 026336 010600                      MOV      SP,R0
      (4) 026340 104417                      TRAP     C$PNTF
      (4) 026342 062706 000004          ADD      #4,SP
2344 026346 013737 002244 002410      MOV      BDA,CHKSEC
2345 026354 013737 002244 002440      MOV      BDA,E.DA
2346 026362                      ERRSOFT 430,MSFER,ERR1
      (4) 026362 104457                      TRAP     C$ERSOFT
      (5) 026364 000656                      .WORD   430
      (5) 026366 003310                      .WORD   MSFER
      (5) 026370 007130                      .WORD   ERR1
2347 026372 005237 002412 002410 10$: INC      DECNT          ;NO, GIVE IT ONE MORE TRY
2348 026376 013737 002244 002410      MOV      BDA,CHKSEC    ;CHECK IF SECTOR IS IN
2349 026404 004537 027340              JSR      R5,CKBDSC      ;BAD SECTOR FILE
2350 026410 005737 002406              TST      HDRFND        ;IF SET, IT WAS
2351 026414 001431                      BEQ      21$            ;NO MATCH
2352 026416                      PRINTF   #FMT18,#INBSF
      (8) 026416 012746 006346          MOV      #INBSF,-(SP)
      (7) 026422 012746 007624          MOV      #FMT18,-(SP)
      (6) 026426 012746 000002          MOV      #2,-(SP)
      (3) 026432 010600                      MOV      SP,R0
      (4) 026434 104417                      TRAP     C$PNTF
      (4) 026436 062706 000006          ADD      #6,SP
2353 026442                      PRINTF   #MCRLF
      (7) 026442 012746 010041          MOV      #MCRLF,-(SP)
      (6) 026446 012746 000001          MOV      #1,-(SP)
      (3) 026452 010600                      MOV      SP,R0
      (4) 026454 104417                      TRAP     C$PNTF
      (4) 026456 062706 000004          ADD      #4,SP
2354 026462 005337 002232              DEC      SFTCNT
2355 026466 005037 002412              CLR      DECNT
2356 026472 004537 025436              JSR      R5,ISDRST
2357 026476 000434                      BR       31$            ;WORK ON NEXT SECTOR
2358
2359 026500 022737 000004 002412 21$: CMP      #4,DECNT        ;IT MAY HAVE BEEN NOISE.
2360 026506 001403                      BEQ      22$            ;HARD ERROR?
2361 026510 004537 025436              JSR      R5,ISDRST
2362 026514 000660                      BR       2$            ;NO - ISSUE A DRIVE RESET
2363                                     ;AND TRY AGAIN
2364 026516 005337 002232 22$: DEC      SFTCNT        ;DELETE THIS HARD ERROR FROM SOFT ERROR TALLY
2365 026522 004537 026604              JSR      R5,INBAD
2366 026526 004537 025436              JSR      R5,ISDRST
2367 026532 005737 002412 3$: TST      DECNT          ;TELL OPR & PUT IT IN TEMP STORAGE
2368 026536 001414                      BEQ      31$            ;RESET THE DRIVE
2369 026540                      PRINTF   #FMT18,#MSREC    ;ANY RECOVERY HERE?
      (8) 026540 012746 003125          MOV      #MSREC,-(SP) ;NO
      (7) 026544 012746 007624          MOV      #FMT18,-(SP) ;YES - TELL OPR 'RECOVERED'
      (6) 026550 012746 000002          MOV      #2,-(SP)

```

CZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 H 8
CZRLMB.MAC 12-DEC-79 14:06 ROUTINE TO WRITE PACKS INITIALLY PAGE 4-5

SEQ 0098

(3)	026554	010600		MOV	SP,R0	
(4)	026556	104417		TRAP	C\$PNTF	
(4)	026560	062706	000006	ADD	#6,SP	
2370	026564	005037	002412	CLR	DECT	;CLEAR LOOP COUNTER FOR NEXT SECTOR
2371						
2372						
2373						
2374	026570	005202				
2375	026572	020227	000050	31\$: INC	R2	;POINT TO THE NEXT SECTOR
2376	026576	002617		CMP	R2,#40.	;END OF THE TRACK?
2377	026600	000137	026076	BLT	1\$;NO - DO THIS SECTOR
				JMP	WNXTRK	;YES - DO NEXT TRACK

CZRLMB0 RL01/02 BD SEC FIL TL MACV11 30A(1052) 17-DEC-79 10:53 I 8 PAGE 4-6
 CZRLMB.MAC 12-DEC-79 14:06 ROUTINE TO WRITE PACKS INITIALLY

```

2379 026604 STARS
(2) :*****
2380 :INBAD -- ROUTINE TO INSERT THE BAD SECTOR FOUND INTO A TEMP
2381 :      BAD SECTOR FILE AND TELL OPR THAT A BAD SECTOR (HARD ERR)
2382 :      WAS DETECTED.
2383 026604 STARS
(2) :*****
2384 :*****
2385 026604 010146 INBAD: MOV R1,-(SP) ;SAVE R1
2386 026606 016337 000000 002434 MOV CS(R3),E.CS
2387 026614 016337 000002 002436 MOV BA(R3),E.BA
2388 026622 016337 000004 002440 MOV DA(R3),E.DA
2389 026630 016337 000006 002442 MOV MP(R3),E.MP
2390 026636 016337 000006 002444 MOV MP(R3),E.MP1
2391 026644 016337 000006 002446 MOV MP(R3),E.MP2
2392 026652 005037 002412 CLR DECNT ;CLEAR CURRENT SOFT ERROR COUNT
2393 026656 005337 002410 DEC CHKSEC ;SECTOR IS PREVIOUS FROM INDICATED
2394 026662 ERRHRD 300.,MHDER,ERR1
(4) 026662 104456 TRAP C$ERHRD
(5) 026664 000454 .WORD 300
(5) 026666 003420 .WORD MHDER
(5) 026670 007130 .WORD ERR1
2395 026672 005237 002230 INC ERRCNT ;UPDATE THE HARD ERROR COUNT
2396 026676 012701 030014 MOV #BSECN,R1 ;POINT TO THE BAD SECTOR TEMP STORAGE
2397 026702 005711 IBDN: TST (R1) ;LOOK FOR A SPOT TO INSERT ENTRY
2398 026704 100417 BMI IBDN1 ;BR IF FOUND ONE
2399 026706 005721 TST (R1)+ ;POINT TO NEXT ENTRY ADDR
2400 026710 022701 030076 CMP #BSECN+50.,R1 ;END OF TABLE?
2401 026714 001372 BNE IBDN ;NO - TRY THIS ENTRY SLOT
2402 026716 PRINTF #FMT18,#TBLFUL ;YES - TELL OPR END OF TABLE (25. ENTRYS FOUND)
(8) 026716 012746 006040 MOV #TBLFUL,-(SP)
(7) 026722 012746 007624 MOV #FMT18,-(SP)
(6) 026726 012746 000002 MOV #2,-(SP)
(3) 026732 010600 MOV SP,R0
(4) 026734 104417 TRAP C$PNTF
(4) 026736 062706 000006 ADD #6,SP
2403 026742 000402 BR IBDN2 ;EXIT
2404 026744 013711 002410 IBDN1: MOV CHKSEC,(R1) ;SAVE THE ENTRY IN TABLE
2405 026750 012601 IBDN2: MOV (SP)+,R1 ;RESET R1
2406 026752 000205 RTS R5

```

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 J 8 PAGE 4-7
HEADS HOME ROUTINE

SEG 01

```

2409          .SBTTL  HEADS HOME ROUTINE
2410
2411          ;ROUTINE TO BRING HEADS OVER TRACK 0
2412
2413          HDHOME: MOV    R0,-(SP)          ;SAVE R0
2414          026754 010046      MOV    #RDHDR,FUNC      ;READ HEADER
2415          026756 012737 000010 002260      JSR    R5,LDFUNC      ;GO DO IT.
2416          026764 004537 023534      JSR    R5,WTRDY
2417          026770 004537 025310
2418          026774 016300 000006      MOV    MP(R3),R0      ;GET HEADER
2419          027000 042700 000177      BIC    #177,R0      ;ONLY CYLINDER
2420          027004 010037 002244      MOV    R0,BDA      ;MOVE IT TO BUFFERED DA
2421          027010 052737 000001 002244      BIS    #MK,BDA      ;SET MARKER
2422          027016 012737 000006 002260      MOV    #SEEK,FUNC      ;LOAD SEEK
2423          027024 004537 023534      JSR    R5,LDFUNC      ;SEEK.
2424          027030 004537 025310      JSR    R5,WTRDY      ;WAIT.
2425          027034 013737 002322 002264      MOV    PRPOS,LSTHDR
2426          027042 005037 002322      CLR    PRPOS      ;SET BUFFER TO HOME
2427          027046 012600      MOV    (SP)+,R0
2428          027050 000205      RTS    R5
2429
2430          ;ROUTINE TO SET THE HEADS OVER THE LAST CYLINDER
2431
2432          HDLAST: MOV    #RDHDR,FUNC      ;SET TO READ THE CURRENT POSITION
2433          027052 012737 000010 002260      JSR    R5,LDFUNC      ;READ HEADERS
2434          027060 004537 023534      JSR    R5,WTRDY      ;WAIT TILL DONE
2435          027064 004537 025310
2436          027070 016337 000006 002322      MOV    MP(R3),PRPOS      ;GET THE CURRENT POSITION
2437          027076 042737 000177 002322      BIC    #177,PRPOS      ;SAVE ONLY THE CYL BITS
2438          027104 012737 177600 002322      MOV    #177600,NEWPOS      ;SET LAST CYL FOR RL02
2439          027112 022737 000001 002316      CMP    #1,TDR      ;DRIVE = RL01?
2440          027120 001003      BNE    1$      ;NO - MUST BE RL02
2441          027122 012737 077600 002324      MOV    #77600,NEWPOS      ;YES - SET RL01 LAST TRACK ADDRESS
2442          027130 004537 027136      JSR    R5,JKFNC      ;SEEK TO THE LAST TRACK
2443          027134 000205      RTS    R5

```

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 4-8
SEEK ROUTINE

K 8

SEQ 0101

```

2445 .SBTTL SEEK ROUTINE
2446 :ROUTINE TO SEEK TO A CYLINDER POINTED TO BY 'NEWPOS' FROM A CYLINDER
2447 :POINTED TO BY 'PRPOS'
2448 :EXITS WITH PRPOS CONTAINING THE NEW CYLINDER ADDRESS
2449
2450 027136 010146 SKFNC: MOV R1,-(SP) ;SAVE R1
2451 027140 010246 MOV R2,-(SP) ;SAVE R2
2452 027142 013702 002324 MOV NEWPOS,R2 ;SET THE DESIRED CYL
2453 027146 013701 002322 MOV PRPOS,R1 ;GET THE CURRENT POSITION
2454 027152 042701 000177 BIC #177,R1 ;CLEAR THE HEAD/SECTOR BITS
2455 027156 042702 000177 BIC #177,R2
2456 027162 160102 SUB R1,R2 ;CALC THE DIFFERENCE
2457 027164 103002 BCC 1$
2458 027166 005402 NEG R2 ;MAKE DIFFERENCE A POSITIVE NUMBER
2459 027170 000402 BR 2$
2460 027172 052702 000004 1$: BIS #4,R2 ;SET THE DIRECTION BIT
2461 027176 052702 000001 2$: BIS #MM,R2 ;SET THE SEEK MARKER BIT
2462 027202 032737 000100 002324 BIT #HEAD,NEWPOS ;GO TO HEAD #1?
2463 027210 001402 BEQ 3$ ;NO
2464 027212 052702 000020 BIS #SKHS,R2 ;YES - SELECT THE HEAD BIT
2465 027216 010237 002244 3$: MOV R2,BDA ;SAVE THE DA
2466 027222 010237 002272 MOV R2,DIFWD ;ALSO AS DIFFERENCE WORD
2467 027226 012737 000006 002260 MOV #SEEK,FUNC ;SET TO DO A SEEK FUNCTION
2468 027234 004537 023534 JSR R5,LDFUNC ;ISSUE THE SEEK
2469 027240 004537 025310 JSR R5,WTRDY ;WAIT TILL READY SET
2470 027244 005777 153000 TST @DCS ;SEEK ERROR DETECTED?
2471 027250 100014 BPL 31$ ;NO
2472 027252 017737 152772 002252 MOV @DCS,E.DCS ;YES - SAVE THE ERROR STATUS
2473 027260 013703 002250 MOV DCS,R3 ;GET THE BASE ADDRESS FOR RLCS
2474 027264 016337 000004 002440 MOV DA(R3),E.DA ;SAVE THE DISK ADDRESS AT ERROR
2475 027272 ERRHRD 530,MSKER,ERR2
2476 (4) 027272 104456 TRAP C$ERRHD
2477 (5) 027274 001022 .WORD 530
2478 (5) 027276 003275 .WORD MSKER
2479 (5) 027300 007376 .WORD ERR2
2480
2481 027302 013737 002324 002322 31$: MOV NEWPOS,PRPOS ;UPDATE THE CURRENT POSITION WORD
2482 027310 012602 4$: MOV (SP)+,R2 ;RESET R2
2483 027312 012601 MOV (SP)+,R1 ;RESET R1
2484 027314 000205 RTS R5 ;EXIT
2485
2486 :ROUTINE TO CLEAR ALL DRIVE INFORMATION USED ON START OR
2487 :RESTART IF CALLED. CAN BE USED TO CLEAR INDIVIDUAL DRIVE
2488 :INFORMATION BY BITMAP FOLLOWING CALL.
2489 :CALL JSR R5,CLEAR
2490
2491 027316 010446 CLEAR: MOV R4,-(SP) ;SAVE R4
2492 027320 012704 002230 MOV #ERRCNT,R4 ;POINT TO THE 1ST TO CLEAR
2493 027324 005024 2$: CLR (R4)+ ;CLEAR
2494 027326 020427 002326 CMP R4,#RECNL ;AT END OF BUFFER
2495 027332 001374 BNE 2$ ;NO, GO TO 2$
2496 027334 012604 4$: MOV (SP)+,R4 ;RESTORE CURRENT BUFFER POINTER
2497 027336 000205 RTS R5 ;EXIT

```

C2RLMB0 RL01/02 BC SEC FIL TL
C2RLMB.MAC 12-DEC-79 14:06

MACV11 30A(1052) 17-DEC-79 10:53 L 8
PAGE 4-9
ROUTINE TO CHECK FOR BAD SECTOR

2497
2498
2499
2500
2501
2502
2503 027340 005037 002406
2504 027344 010046
2505 027346 010146
2506 027350 012700 000177
2507 027354 013701 002304
2508 027360 022711 177777
2509 027364 001411
2510 027366 023711 002410
2511 027372 001404
2512 027374 005721
2513 027376 005300
2514 027400 001367
2515 027402 000402
2516
2517 027404 005237 002406
2518
2519 027410 012601
2520 027412 012600
2521 027414 000205
2522
2523 027416
(2)
2524 027416
(2)
2525
2526
2527 027416 000176
2528 030012 177777
2529
2530 030014 000176
2531 030410 177777
2532 030412
(2)
2533 030412
(2)
2534
2535 030412
(2)
2536
2537
2538 030412
(2)
2539
2540 030412 010146
2541 030414 010246
2542 030416 010346
2543
2544 030420 013701 002246
2545 030424 013702 002450
2546 030430 012703 030462

.SBTTL ROUTINE TO CHECK FOR BAD SECTOR

:ROUTINE TO MATCH BAD SECTOR.....BDA IS SECTOR WE ARE LOOKING
:FOR IN LIST POINTED TO BY BSECT.....HDRFND IS SET IF WE FIND IT.
:

CKBDS: CLR HDRFND ;CLEAR FLAG
MOV R0,-(SP) ;SAVE R0
MOV R1,-(SP) ;SAVE R1
MOV #127,R0 ;127 ENTRIES
1\$: MOV BSECT,R1 ;GET WHERE WE'RE LOOKING
2\$: CMP #-1,(R1) ;END OF ENTRIES?
BEQ 4\$;BRANCH IF AT END
CMP CHKSEC,(R1) ;HAVE WE GOT A MATCH
BEQ 3\$;THEN GO SET INDICATOR, ELSE
TST (R1)+
DEC R0
BNE 2\$
BR 4\$

3\$: INC HDRFND ;SET FLAG FOUND

4\$: MOV (SP)+,R1
MOV (SP)+,R0
RTS R5

STARS

::*****

STARS

::*****

:BUFFER TO STORE BAD SECTOR LISTS

BSECO: .BLKW 126. ;STORAGE FOR BAD SPOTS IN BAD SECTOR FILE
.WORD -1 ;FORCED TERMINATOR

BSECN: .BLKW 126. ;STORAGE FOR 'FOUND' BAD SPOTS
BSECNE: .WORD -1 ;FORCED TERMINATOR

STARS

::*****

STARS

::*****

STARS

::*****
:SUBROUTINE TO LOAD A MEMORY BUFFER WITH THE WORST CASE DATA PATTERN
:TO WRITE ON THE PACK.

STARS

::*****

WRBUF: MOV R1,-(SP) ;SAVE R1
MOV R2,-(SP) ;SAVE R2
MOV R3,-(SP) ;AND R3

MOV BMP,R1 ;GET THE WORD COUNT FOR THE WRITE CMD
MOV BUF,R2 ;GET THE BUFFER ADDRESS
1\$: MOV #WCPAT,R3 ;GET THE STARTING ADDRESS OF THE DATA PATTERN

2547 030434 012322
 2548 030436 005201
 2549 030440 001404
 2550 030442 022703 030522
 2551 030446 001372
 2552 030450 000767
 2553 030452 012603
 2554 030454 012602
 2555 030456 012601
 2556 030460 000205

2\$: MOV (R3)+,(R2)+ ;PUT THE DATA IN MEMORY BUFFER
 INC R1 ;DOWNCOUNT THE WC (MINUS WC TO START WITH)
 BEQ 3\$;EXIT IF ALL DONE BUILDING THE BUFFER
 CMP #WCPAT+32.,R3 ;AT THE END OF THE DATA PATTERN TABLE?
 BNE 2\$;NO - STORE THE NEXT FROM DATA TABLE
 BR 1\$;YES - RESET THE DATA TABLE POINTER
 3\$: MOV (SP)+,R3 ;RESET R3
 MOV (SP)+,R2
 MOV (SP)+,R1
 RTS R5 ;EXIT

;WORST CASE PATTERN USED IN WRITING

2561 030462 155555
 2562 030464 066666
 2563 030466 133333
 2564 030470 155555
 2565 030472 066666
 2566 030474 133333
 2567 030476 155555
 2568 030500 066666
 2569 030502 133333
 2570 030504 155555
 2571 030506 066666
 2572 030510 133333
 2573 030512 155555
 2574 030514 066666
 2575 030516 133333
 2576 030520 155555

WCPAT: .WORD 155555
 .WORD 066666
 .WORD 133333
 .WORD 155555
 .WORD 066666
 .WORD 133333
 .WORD 155555
 .WORD 066666
 .WORD 133333
 .WORD 155555
 .WORD 066666
 .WORD 133333
 .WORD 155555
 .WORD 066666
 .WORD 133333
 .WORD 155555

2577
 2578 030522 000240
 2579 030524
 (3) 030524
 (3) 030524 104401
 2580 030526 000000

ENDOF PROGRAM: NOP
 ENDTST
 L10015: TRAP C\$ETST
 HALT

2581
 2582 030530
 (2)
 2583 030530
 (2)
 2584 030530 002400
 2585
 2586 035530 177777
 2587

STARS
 ;*****
 STARS
 ;*****
 BSFILE: .BLKW 1280. ;STORAGE FOR BAD SECTOR FILE DATA
 ;/1280. WORDS - 10 SECTORS - 1/4 TRACK,
 .WORD -1 ;END OF STORAGE

2588 035532
 (2)
 2589 035532
 (2)
 2590
 2591 035532
 2592 035532
 (3) 035532 000011
 2593 035534
 (4) 035534 000031
 (4) 035536 035556

STARS
 ;*****
 STARS
 ;*****
 BGNMOD HRDPRM
 BGNHRD
 .WORD L10017-L\$HARD/2
 GPRMA CSRMMSG,CSR,0,160000,177776,YES
 .WORD T\$CODE
 .WORD CSRMMSG

```

(4) 035540 160000 .WORD T$LOLIM
(4) 035542 177776 .WORD T$HILIM
2594 035544 GPRMD DRMSG,DRBT,0,03400,0,7,YES
(4) 035544 001032 .WORD T$CODE
(4) 035546 035572 .WORD DRMSG
(4) 035550 003400 .WORD 03400
(4) 035552 000000 .WORD T$LOLIM
(4) 035554 000007 .WORD T$HILIM
2595 035556 ENDMOD
(2) .EVEN
(3) 035556 L10017:
2596
2600
2601 035556 052502 020123 042101 CSRMSG: .ASCIZ /BUS ADDRESS/
2602 035572 051104 053111 000105 DRMSG: .ASCIZ /DRIVE/
2603
2607
2608 .EVEN
2609
2610 035600 ENDMOD
2611
2612 035600 BGNMOD SFTPRM
2613 035600 BGNSFT
(3) 035600 000010 .WORD L10020-L$SOFT/2
2614 035602 GPRML DSWRT,0,1,YES
(4) 035602 000130 .WORD T$CODE
(4) 035604 035622 .WORD DSWRT
(4) 035606 000001 .WORD 1
2615 035610 GPRMD DW/CNT,2,D,177777,1,177777,YES
(4) 035610 001052 .WORD T$CODE
(4) 035612 035650 .WORD DW/CNT
(4) 035614 177777 .WORD 177777
(4) 035616 000001 .WORD T$LOLIM
(4) 035620 177777 .WORD T$HILIM
2616 035622 ENDSFT
(2) .EVEN
(3) 035622 L10020:
2620 .EVEN
2621 035622 040523 052127 047517 DSWRT: .ASCIZ /SAWTOOTH WRITE CYCLE?/
2622 035650 051127 052111 020105 DW/CNT: .ASCIZ /WRITE CYCLES PER TRACK?/
2623 .EVEN
2627 035700 ENDMOD
2628 035700 LASTAD
(2) .EVEN
(4) 035700 000000 .WORD 0
(4) 035702 000000 .WORD 0
(3) 035704 L$LAST::
2629
2630 000001 .END
  
```


ABSCYL	005254		282#	1194																
ABSHD	005331		286#	1204																
ABSMSG	005164		280#	1155	1734															
ABSSEC	005304		284#	1203																
ABSSER	005352		287#	1181																
ABSSNH	005471		289#	1185	1790															
ABSSNL	005415		288#	1184	1789															
ACCESS	002464		202#	902*	1169	1344	1690	1825												
ACKENT	016504		1216	1218#																
ADDCOD	011726	G	642#																	
ADDFEX	022566		1691	1696	1707	1761#														
ADDEND	022162		1549	1690#																
ADR =	000020	G	29#																	
ASSEMB=	00CJ10		7																	
BA =	00G002		32#	1891*	2387															
BADBSF	005130		279#	2107																
BADWRT	005610		291#	1318																
BA16 =	000020		51#																	
BA17 =	000040		50#																	
BBA	002256		130#	549*	1527*	1891	2024	2197	2199*	2229*										
BCSADR	002262		132#	1894*	1895*	1896*	1897*	1898												
BCSR	002402		177#																	
BDA	002244		125#	1290*	1293*	1297*	1311*	1567*	1568*	1569*	1607*	1609*	1617*	1627*	1628*					
			1629*	1642	1647	1648	1651	1892	1948*	1949*	1978*	1982*	2004*	2009	2014					
			2016	2019	2061*	2063*	2085*	2088*	2095*	2098*	2100*	2244*	2245*	2246*	2323*					
			2324*	2325*	2339	2344	2345	2348	2420*	2421*	2465*									
BURSEL	002404		178#																	
BIT0 =	000001	G	29#	38	39	75	76	77												
BIT00 =	000001	G	29#																	
BIT01 =	000002	G	29#																	
BIT02 =	000004	G	29#																	
BIT03 =	000010	G	29#																	
BIT04 =	000020	G	29#																	
BIT05 =	000040	G	29#																	
BIT06 =	000100	G	29#																	
BIT07 =	000200	G	29#																	

[illegible]

CLKADR	002360		163#	439*	444*	733													
CLKBFR	002370		167#	694*	696*	763*													
CLKCNT	002366		166#	696	736*	739*	763												
CLKFLD	002376		170#	449*	456	709*													
CLKFRQ	002354		161#	673	737*	740*													
CLKINI	012132		498	554	725#														
CLKSON	002364		165#	755*	762*														
CLKST	012304		498	554	752#														
CLKTIK	012124	G	450	707#															
CLKTYP	002356		162#	441*	458*	665	698	726	730	752	757								
CLNCOD	011644	G	627#																
CLRBSF	025222		2083	2093	2111#														
CLRBSN	020612		1456	1482#	1522														
CLRDAT	010744		511#	513															
CLRSTB	010760		516#	518															
CMDDO	004753		276#	916															
CMD1	004326		269#	905															
CMD2	004401		270#	906															
CMD3	004461		271#	907															
CMD4	004546		272#	908															
CMD5	004602		273#	909															
CMD6	004671		274#	910															
CMD7	004724		275#	911															
MSG	002550		233#	347	1011	1063	1733												
MSK	002340		155#	1945															
CNTFLG	002472		205#	436*	505*	551													
CONVER	020650		1498	1502#															
CONREA	021054		1532#	1614															
CONWR	025614		2216#	2313															
COP =	000040		63#																
CPYCNT	002500		208#	1287*	1303*	1307													
CRDY =	000200		49#	1896	1899	2145	2168	2170											
CRD1	021072		1537#	1557															
CRD2	021266		1533	1556#															
CRLCS	002515		231#	350	359														
CS =	000000		31#	1898*	1899*	2168*	2169*	2170*	2386										
CSR =	000000		83#	2593															
CSRMSG	035556		2593	2601#															

CSDU = 000053	7#	649												
CSEDIT= 000003	7#	15												
C\$ERDF= 000055	7#	881	2152											
C\$ERHR= 000056	7#	1936	1958	1969	2394	2475								
C\$ERRO= 000060	7#													
C\$ERSF= 000054	7#	1889												
C\$ERSO= 000057	7#	1587	1649	2264	2346									
C\$ESCA= 000010	7#													
C\$SEEG= 000005	7#													
C\$ESUB= 000003	7#													
C\$ETST= 000001	7#	2579												
C\$EXIT= 000032	7#													
C\$GETB= 000026	7#													
C\$GETW= 000027	7#													
C\$GMAN= 000043	7#	899	916	1000	1052	1174	1181	1184	1185	1187	1194	1203	1204	
	1274	1349	1354	1355	1356	1431	1734	1771	1789	1790	1793	1830		
C\$GPHR= 000042	7#	524												
C\$GPLO= 000030	7#													
C\$GPRI= 000040	7#													
C\$INIT= 000011	7#	558												
C\$INLP= 000020	7#													
C\$MANI= 000050	7#													
C\$MEM = 000031	7#													
C\$MSG = 000023	7#	353	362											
C\$OPEN= 000034	7#													
C\$PNTB= 000014	7#	347	350	351	359	360	805							
C\$PNTF= 000017	7#	461	462	591	593	607	609	811	812	820	862	867	872	
	876	898	903	905	906	907	908	909	910	911	915	955	957	
	959	964	972	979	984	998	999	1011	1021	1025	1031	1036	1050	
	1051	1063	1068	1069	1070	1071	1093	1094	1102	1103	1111	1155	1171	
	1180	1186	1201	1222	1229	1237	1273	1280	1285	1318	1321	1330	1346	
	1353	1371	1382	1413	1430	1452	1455	1460	1463	1469	1472	1502	1519	
	1544	1546	1547	1548	1580	1646	1655	1656	1672	1673	1703	1733	1792	
	1812	1827	1836	1843	1849	1861	1868	1871	2011	2021	2066	2073	2107	
	2257	2343	2352	2353	2369	2402								
C\$PNTS= 000016	7#													
C\$PNTX= 000015	7#													
C\$QIO = 000377	7#													
C\$RDBU= 000007	7#	447												
C\$REFG= 000047	7#	464	502	540										
C\$RESE= 000033	7#	434	637											
C\$REVI= 000003	7#	15												
C\$RFLA= 000021	7#													
C\$RPT = 000025	7#	412												
C\$SEFG= 000046	7#													
C\$SPRI= 000041	7#	432	452	454	631	883								
C\$SVEC= 000037	7#	450	545	583	630	728	732							
C\$TPRI= 000013	7#													
DA = 000004	33#	1583	1892*	1935	1957	1968	2151	2164*	2167*	2172	2260	2388	2474	
DCRC = 004000	45#													
DCS 002250	127#	472*	475*	477	585*	587	591	600*	602	607	779*	780	811	
	855*	856*	879	1304	1574	1581	1582	1636	1641	1885	1905*	1931	1933	
	1934	1953	1955	1956	1964	1966	1967	2000	2104	2145	2149	2150	2163	
	2166	2251	2258	2259	2333	2338	2470	2472	2473					
DECNT 002412	181#	1566*	1644	1650*	1659	1669	1671*	1676*	1988*	2036*	2073	2243*	2341	
	2347*	2355*	2359	2367	2370*	2392*								

[illegible]

195#	2391*											
129#	349*	350	358*	359								
913*	965*	991*	992	994	1011	1068	1078#	1090	1092*			
380#	812											
547#												
770#	850	944	1156	1331	1434	1505	1813					
914*	1019*	1043*	1044	1046	1063	1069	1077#	1099	1101*	1233*	1247*	1377*
375#	1011	1063										
376#	905											
373#	984	1036	1186	1792								
374#	1068	1069	1546	1547								
366#	461	462	593	609								
347	367#	1733										
368#	591	607	811									
350	359	369#										
370#	867	872	876	903	906	907	908	909	910	911	964	972
979	1021	1025	1031	1070	1093	1094	1102	1103	1111	1171	1222	1229
1237	1280	1285	1318	1321	1346	1371	1382	1413	1460	1469	1548	1655
1672	1703	1827	2011	2021	2066	2352	2369	2402				
371#	955	998	1050	1155	1201	1330	1430	1502	1812	1836	1861	2107
372#	2073											
729	733#											
735	739#											
210#	1586*	1642	2263*	2339								
131#	1294*	1570*	1610*	1632*	1894	1928*	1950*	1961*	1984*	2101*	2247*	2329*
2414*	2422*	2432*	2467*									
144#	1464*	1473*	2208	2283	2293							
7#	643	644										
7#	575	624										
7#	14	16	27	86	118	216	221	321	327	329	355	387
389	394	395	400	402	406	410	411	413	418	428	430	564
575	627	628	640	642	643	645	647	648	650	661	707	717
836	843	1903	2579	2591	2592	2610	2612	2613	2627			
7#	628	638										
7#	648	649										
7#	14	16	27	86	118	216	221	321	327	353	362	387
389	394	395	400	402	406	410	412	413	428	558	564	624
627	638	640	642	644	645	647	649	650	704	712	717	836
843	1906	2579	2591	2595	2610	2612	2616	2627				
7#	2592	2595										
7#	390	393										
7#	430	558										
7#												
7#	14	16	27	86	118	216	221	321	327	387	389	394
395	400	402	406	410	413	428	564	627	640	642	645	647
650	717	836	2591	2610	2612	2627						
7#	329	353	355	362								
7#	418	422										

[illegible]

194

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

J 9
MACY11 30A(1052) 17-DEC-79 10:53 PAGE 5-8
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 1

L\$DESP	002076	G	15#				
L\$DEVP	002060	G	15#				
L\$DISP	010136	G	15	4C#			
L\$DLY	002116	G	15#	453	480	604	2144
L\$DTP	002040	G	15#				
L\$DTYP	002034	G	15#				
L\$DU	011730	G	15	648#			
L\$DUT	002072	G	15#				
L\$DVTY	002216	G	15	21#			
L\$EF	002052	G	15#				
L\$ENVI	002044	G	15#				
L\$ETP	002102	G	15#				
L\$EXP1	002046	G	15#				
L\$EXP4	002064	G	15#				
L\$EXP5	002066	G	15#				
L\$HARD	035534	G	15	2592#			
L\$HIME	002120	G	15#				
L\$HPCP	002016	G	15#				
L\$HPTP	002022	G	15#				
L\$HW	010122	G	15	390#			
L\$ICP	002104	G	15#				
L\$INIT	010150	G	15	430#			
L\$LADP	002026	G	15#				
L\$LAST	035704	G	15	2628#			
L\$LOAD	002100	G	15#				
L\$LUN	002074	G	15#				
L\$MREV	002050	G	15#				
L\$NAME	002000	G	15#				
L\$PRIO	002042	G	15#				
L\$PROT	010142	G	15	418#			
L\$PRT	002112	G	15#				
L\$REPP	002062	G	15#				
L\$REV	002010	G	15#				
L\$RPT	010140	G	15	411#			
L\$SOFT	035602	G	15	2613#			
L\$SPC	002056	G	15#				
L\$SPCP	002020	G	15#				
L\$SPTP	002024	G	15#				
L\$STA	002030	G	15#				
L\$SW	010130	G	15	396#			
L\$TEST	002114	G	15#				
L\$TIML	002014	G	15#				
L\$UNIT	002012	G	15#	520	579		
L10000	007374		353#				
L10001	007472		362#				
L10002	010126		390	393#			
L10003	010134		396	399#			
L10004	010140		412#				
L10006	011160		558#				
L10007	011642		624#				
L10010	011724		638#				
L10011	011726		644#				
L10012	011730		649#				
L10013	012122		704#				
L10014	012130		712#				
L10015	030524		2579#				

CZRLMBO RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 K 9 PAGE 5-9
CZRLMB MAC 12-DEC-79 14:06 CROSS REFERENCE TABLE -- USER SYMBOLS

L10016	023654		1906#													
L10017	035556		2592	2595#												
L10020	035622		2613	2616#												
MAXWC	002452		197#	548*												
MBLD	003155		242#	1771												
MCRLF	010041		351	360	377#	862	898	915	957	959	999	1051	1071	1180	1273	
			1353	1455	1519	1580	1646	1656	1673	2257	2343	2353				
MDERS	003337		248#	881												
MDHEDR	002000 G		14#													
MDONE	003720		259#	1321	1544											
MDRTYP	006562		307#	812												
MHDR	003420		250#	1936	1958	1969	2394									
MINUTE	002430		188#	805												
MPK =	000001		771	1609	1949	2421	2461									
MP =	000006		34#	1893*	1939	1972	2174	2389	2390	2391	2418	2436				
MRDER	003372		249#													
MRLCS	002506		230#	591	607	811										
MSFER	003310		247#	1587	1649	2264	2346									
MSG	010044		378#	820	1452	1463	1472	1544	1843	1849	1868	1871				
MSKER	003275		246#	2475												
MSREC	003125		241#	1672	2369											
MSTWRT	006144		298#	1431												
MTEST	012716		849#													
MWRITE	004256		268#	1430												
NEWSBF	022570		973	1026	1238	1383	1704	1770#	1850	1872						
NEWENT	006200		299#	1229	1733											
NEWFAC	002300		139#	976*	1295	1298*	1853*									
NEWLD	003505		253#	876												
NEWPOS	002324		149#	2310*	2311*	2438*	2441*	2452	2462	2477						
NHWSEC	003562		255#	972	1849											
NILCLK	010420		446	457	461#											
NOCLK	006777		313#	461												
NOCRDY	003775		261#	2152												
NOCTLR	007072		315#	593												
NODRIV	004021		262#													
NOENTR	005725		293#	1371												
NOFACT	015352		990	1090#												
NOFIEL	015440		1042	1099#												
NOFLDE	003662		258#	1413												
NOLoad	003433		251#	867												
NOMSEC	015526		1108#	1127	1133	1135	1139	1143								

19

[illegible]

[illegible]

CZRLMBO RL01/02 BC SEC FIL TL MACV11 30A(1052) 17-DEC-79 10:53 N 9
 CZRLMB.MAC 12-DEC-79 14:06 CROSS REFERENCE TABLE -- USER SYMBOLS

TBLFUL	006040	2595#	2616#	2402										
TDR	002316	296#	2066	789*	812	1197	1291	1532	1940	1974	2007	2059	2086	2096
TEMPO	002414	146#	786*	2439										
		2211	2216	865	870	874	899	900	950	974	976	1000	1001	1027
		182#	861*	1162	1174	1175	1181	1182	1187	1188	1239	1274	1275	1278
		1052	1053	1350	1384	1431	1432	1442	1511	1705	1734	1735	1771	1772
		1337	1349	1798*	1801*	1819	1830	1831	1851	1853	1873	1987*	2053	2067*
		1793	1794	2128*	2131*									
		2071	2125*	996	1003*	1038*	1048	1055*	1390*	1391*	1392*	1393	1529*	1537
TEMP1	002416	183#	986*	1604*	1616*	1629	2034*	2038*	2040*	2042*	2043	2044*	2045*	2046
		1568	1602	2291	2302*	2311	2315*	2324						
		2220	2245	2044	2047*	2048*	2049*	2050						
TEMP2	002420	184#	2037*	2005	2057	2064*								
TEMP3	002422	185#	1986*											
TFMSG	002777	237#	1069											
THARD	003076	240#	1547											
THISDR	006750	312#	1174	1349	1830									
TICK	002424	186#	671											
TILLEN	006114	297#	1000	1052										
TIME	010047	379#	805											
TFMSG	003022	238#	1068											
TRPFLG	002470	204#	582*	588	795*									
TRPHAN	012474	583	630	795#										
TSOFT	003047	239#	1546											
TSARGC=	000002	15#	347#	350#	351#	359#	360#	461#	462#	591#	593#	607#	609#	805#
		811#	812#	820#	862#	867#	872#	876#	898#	903#	905#	906#	907#	908#
		909#	910#	911#	915#	955#	957#	959#	964#	972#	979#	984#	998#	999#
		1011#	1021#	1025#	1031#	1036#	1050#	1051#	1063#	1068#	1069#	1070*	1071#	1093#
		1094#	1102#	1103#	1111#	1155#	1171#	1180#	1186#	1201#	1222#	1229#	1237#	1273#
		1280#	1285#	1318#	1321#	1330#	1346#	1353#	1371#	1382#	1413#	1430#	1452#	1455#
		1460#	1463#	1469#	1472#	1502#	1519#	1544#	1546#	1547#	1548#	1580#	1646#	1655#
		1656#	1672#	1673#	1703#	1733#	1792#	1812#	1827#	1836#	1843#	1849#	1861#	1868#
		1871#	2011#	2021#	2066#	2073#	2107#	2257#	2343#	2352#	2353#	2369#	2402#	
TS CODE=	001052	899#	916#	1000#	1052#	1174#	1181#	1184#	1185#	1187#	1194#	1203#	1204#	1274#
		1349#	1354#	1355#	1356#	1431#	1734#	1771#	1789#	1790#	1793#	1830#	2593#	2594#
		2614#	2615#											
TSERRN=	001022	7#	881#	1587#	1649#	1889#	1936#	1958#	1969#	2152#	2264#	2346#	2394#	2475#
TS EXCP=	000000	899#	916#	1184#	1185#	1194#	1203#	1204#	1354#	1355#	1356#	1789#	1790#	2593#
		2594#	2615#											
TS GMAN=	000000	7#	899#	916#	1184#	1185#	1194#	1203#	1204#	1354#	1355#	1356#	1789#	1790#
TS HILI=	177777	899#	916#	1184#	1185#	1194#	1203#	1204#	1354#	1355#	1356#	1789#	1790#	2593#
		2594#	2615#											
TS LAST=	000001	7#	2628#											
TS LOLI=	000001	899#	916#	1184#	1185#	1194#	1203#	1204#	1354#	1355#	1356#	1789#	1790#	2593#
		2594#	2615#											
TS LSYM=	010000	7#	353	362	393	399	412	558	624	638	644	649	704	712
		1906	2579	2595	2616									
TS LTNO=	000001	2628#												
TS NEST=	177777	7#	14#	16#	27#	86#	118#	216#	221#	321#	327#	329#	353#	355#
		362#	387#	389#	390#	393#	394#	395#	396#	399#	400#	402#	406#	410#
		411#	412#	413#	418#	422#	428#	430#	558#	564#	575#	624#	627#	628#
		638#	640#	642#	643#	644#	645#	647#	648#	649#	650#	661#	704#	707#
		712#	717#	836#	843#	1903#	1906#	2579#	2591#	2592#	2595#	2610#	2612#	2613#
		2616#	2627#											
TS NSO =	000000	14#	16	27#	86	118#	216	221#	321	327#	387	389#	394	395#
		400	402#	406	410#	413	418#	422	428#	564	575#	624	627#	640

SEO 0118

	642#	645	647#	650	661#	704	707#	712	717#	836	843#	2579	2591#
TINS1 = 000005	2610	2612#	2627										
	329#	353	355#	362	390#	393	396#	399	411#	412	430#	558	628#
	638	643#	644	648#	649	1903#	1906	2592#	2595	2613#	2616		
TSPINU= 000000	7#												
TSSAVL= 177777	7#												
T\$SEGL= 177777	7#												
TSSUBN= 000000	7#	843#											
T\$TAGL= 177777	7#												
T\$TAGN= 010021	7#	329#	355#	390#	39#	411#	418#	430#	575#	628#	643#	648#	661#
	707#	843#	1903#	2592#	2613#								
T\$TEMP= 000000	16#	86#	216#	321#	353#	362#	387#	393#	394#	399#	400#	404#	406#
	412#	413#	422#	558#	564#	624#	638#	640#	644#	645#	649#	650#	656#
	659#	704#	712#	720#	723#	748#	750#	766#	768#	799#	801#	807#	809#
	815#	817#	824#	827#	836#	844#	847#	890#	892#	899#	916#	936#	942#
	1000#	1052#	1151#	1153#	1174#	1181#	1184#	1185#	1187#	1194#	1203#	1204#	1266#
	1270#	1274#	1325#	1328#	1349#	1354#	1355#	1356#	1423#	1428#	1431#	1490#	1495#
	1620#	1623#	1684#	1688#	1734#	1765#	1768#	1771#	1789#	1790#	1793#	1805#	1810#
	1830#	1906#	1910#	1921#	2119#	2121#	2379#	2383#	2523#	2524#	2532#	2533#	2535#
	2538#	2579#	2582#	2583#	2588#	2589#	2593#	2594#	2595#	2610#	2614#	2615#	2616#
	2627#												
T\$TEST= 000001	7#	843#	2628										
T\$TSTM= 177777	7#	347	350	351	353	359	360	362	412	432	434	439	444
	447	450	452	454	455	461	462	464	502	524	540	545	558
	583	591	593	594	607	609	611	620	624	630	631	632	634
	637	638	644	649	728	732	805	811	812	820	862	867	872
	876	881	883	898	899	903	905	906	907	908	909	910	911
	915	916	955	957	959	964	972	979	984	998	999	1000	1011
	1021	1025	1031	1036	1050	1051	1052	1063	1068	1069	1070	1071	1093
	1094	1102	1103	1111	1155	1171	1174	1180	1181	1184	1185	1186	1187
	1194	1201	1203	1204	1222	1229	1237	1273	1274	1280	1285	1318	1321
	1330	1346	1349	1353	1354	1355	1356	1371	1382	1413	1430	1431	1452
	1455	1460	1463	1469	1472	1502	1519	1544	1546	1547	1548	1580	1587
	1646	1649	1655	1656	1672	1673	1703	1733	1734	1771	1789	1790	1792
	1793	1812	1827	1830	1836	1843	1849	1861	1868	1871	1889	1936	1958
	1969	2011	2021	2066	2073	210							

VALSN	006007	295#	1187	1793														
VC	= 001000	61#	874															
VERIFY	004241	267#	1502															
WCPAT	030462	2546	2550	2561#														
WDE	= 100000	55#																
WGE	= 002000	60#																
WHATCM	013216	851	854	894#														
WL	- 020000	57#	870	1283	1449													
WNXSEC	026044	2252	2271#															
WNXTRK	026076	2281#	2377															
WRBUF	030412	2201	2540#															
WRCHK	= 000002	69#																
WRINIT	002346	158#																
WRIPG	002320	147#	1299*															
WRITE	= 000012	73#	1294	2247	2329													
WRFACK	025514	1465	1474	2192#														
WRPKF	006674	310#	1460															
WRPKR	006722	311#	1469															
WRTBSF	016770	977	1029	1261	1272#	1419	1757	1854	1875									
WRTCNT	002240	123#	2274*	2275	2277*													
WRTLCK	003460	252#	872	1285	1452													
WRTLIM	010132	398#	2275															
WRTLOK	002462	201#	873*															
WRTSAW	010130	397#	1461	1470	2281													
WTRDY	025310	1302	1572	1612	1634	1930	1952	1963	1998	2103	2141#	2171	2249	2331				
		2416	2424	2434	2469													
W1SEC	026226	2267	2321#															
XSALWA	= 000000	7#																
XSFALS	= 000040	7#																
XSOFFS	= 000400	7#																
XSTRUE	= 000020	7#																
.	= 035704	4#	19#	386#	453	480	561#	604	2144	2301	2527#	2530#	2584#					

MSBYTE	15#														
MSCNTO	899#	916#	1000#	1052#	1174#	1181#	1184#	1185#	1187#	1194#	1203#	1204#	1274#	1349#	1354#
	1355#	1356#	1431#	1734#	1771#	1789#	1790#	1793#	1830#	2593#	2594#	2614#	2615#		
MSCOUN	347#	350#	351#	359#	360#	461#	462#	591#	593#	607#	609#	805#	811#	812#	820#
	862#	867#	872#	876#	898#	903#	905#	906#	907#	908#	909#	910#	911#	915#	955#
	957#	959#	964#	972#	979#	984#	998#	999#	1011#	1021#	1025#	1031#	1036#	1050#	1051#
	1063#	1068#	1069#	1070#	1071#	1093#	1094#	1102#	1103#	1111#	1155#	1171#	1180#	1186#	1201#
	1222#	1229#	1237#	1273#	1280#	1285#	1318#	1321#	1330#	1346#	1353#	1371#	1382#	1413#	1430#
	1452#	1455#	1460#	1463#	1469#	1472#	1502#	1519#	1544#	1546#	1547#	1548#	1580#	1646#	1655#
	1656#	1672#	1673#	1703#	1733#	1792#	1812#	1827#	1836#	1843#	1849#	1861#	1868#	1871#	2011#
	2021#	2066#	2073#	2107#	2257#	2343#	2352#	2353#	2369#	2402#					
MSDATA	15#	19#	21#												
MSDECR	16#	86#	216#	321#	353#	362#	387#	393#	394#	399#	400#	406#	412#	413#	422#
	558#	564#	624#	638#	640#	644#	645#	649#	650#	704#	712#	836#	1906#	2579#	2595#
	2610#	2616#	2627#												
MSDEFA	899#	916#	1000#	1052#	1174#	1181#	1184#	1185#	1187#	1194#	1203#	1204#	1274#	1349#	1354#
	1355#	1356#	1431#	1734#	1771#	1789#	1790#	1793#	1830#	2593#	2594#	2614#	2615#		
MSENDE	16#	86#	216#	321#	353#	362#	387#	393#	394#	399#	400#	406#	412#	413#	558#
	564#	624#	638#	640#	644#	645#	649#	650#	704#	712#	836#	1906#	2579#	2595#	2610#
	2616#	2627#													
MSERRI	881#	1587#	1649#	1889#	1936#	1958#	1969#	2152#	2264#	2346#	2394#	2475#			
MSEXCP	899#	916#	1184#	1185#	1194#	1203#	1204#	1354#	1355#	1356#	1789#	1790#	2593#	2594#	2615#
MSGEN	14#	15#	19#	21#	27#	118#	221#	327#	329#	353#	355#	362#	389#	390#	393#
	395#	396#	399#	402#	404#	410#	411#	412#	418#	428#	430#	558#	575#	624#	627#
	628#	638#	642#	643#	644#	647#	648#	649#	661#	704#	707#	712#	717#	843#	899#
	916#	1000#	1052#	1174#	1181#	1184#	1185#	1187#	1194#	1203#	1204#	1274#	1349#	1354#	1355#
	1356#	1431#	1734#	1771#	1789#	1790#	1793#	1830#	1903#	1906#	2579#	2591#	2592#	2595#	2612#
	2613#	2616#	2628#												
MSGENB	899#	916#	1000#	1052#	1174#	1181#	1184#	1185#	1187#	1194#	1203#	1204#	1274#	1349#	1354#
	1355#	1356#	1431#	1734#	1771#	1789#	1790#	1793#	1830#						
MSGETS	16#	86#	216#	321#	353#	362#	387#	393#	394#	399#	400#	406#	412#	413#	422#
	558#	564#	624#	638#	640#	644#	645#	649#	650#	704#	712#	836#	1906#	2579#	2595#
	2610#	2616#	2627#												
MSGNGB	14#	15#	19#	21#	27#	118#	221#	327#	329#	355#	389#	390#	395#	396#	402#
	404#	410#	411#	418#	428#	430#	575#	627#	628#	642#	643#	647#	648#	661#	707#
	717#	1903#	2591#	2592#	2612#	2613#	2628#								
MSGNIN	15#	19#	21#	347#	350#	351#	353#	359#	360#	362#	390#	396#	404#	412#	432#
	434#	439#	440#	444#	445#	447#	448#	450#	452#	453#	454#	455#	461#	462#	464#
	465#	480#	502#	503#	524#	525#	540#	541#	545#	558#	583#	591#	593#	594#	604#
	607#	609#	611#	620#	624#	630#	631#	632#	634#	637#	638#	644#	649#	704#	712#
	728#	732#	805#	811#	812#	820#	862#	867#	872#	876#	881#	883#	898#	899#	903#
	905#	906#	907#	908#	909#	910#	911#	915#	916#	955#	957#	959#	964#	972#	979#
	984#	998#	999#	1000#	1011#	1021#	1025#	1031#	1036#	1050#	1051#	1052#	1063#	1068#	1069#
	1070#	1071#	1093#	1094#	1102#	1103#	1111#	1155#	1171#	1174#	1180#	1181#	1184#	1185#	1186#
	1187#	1194#	1201#	1203#	1204#	1222#	1229#	1237#	1273#	1274#	1280#	1285#	1318#	1321#	1330#
	1346#	1349#	1353#	1354#	1355#	1356#	1371#	1382#	1413#	1430#	1431#	1452#	1455#	1460#	1463#
	1469#	1472#	1502#	1519#	1544#	1546#	1547#	1548#	1580#	1587#	1646#	1649#	1655#	1656#	1672#
	1673#	1703#	1733#	1734#	1771#	1789#	1790#	1792#	1793#	1812#	1827#	1830#	1836#	1843#	1849#
	1861#	1868#	1871#	1889#	1906#	1936#	1958#	1969#	2011#	2021#	2066#	2073#	2107#	2144#	2152#
	2257#	2264#	2343#	2346#	2352#	2353#	2369#	2394#	2402#	2475#	2579#	2592#	2593#	2594#	2595#
	2613#	2614#	2615#	2616#	2628#										
MSGNLS	899#	916#	1000#	1052#	1174#	1181#	1184#	1185#	1187#	1194#	1203#	1204#	1274#	1349#	1354#
	1355#	1356#	1431#	1734#	1771#	1789#	1790#	1793#	1830#						
MSGNTA	353#	362#	393#	399#	412#	558#	624#	638#	644#	649#	704#	712#	1906#	2579#	2595#
	2616#														
MSGNTE	843#														

MSHAPT	15#														
MSHNP	15#														
MSINCR	14#	27#	118#	221#	327#	329#	347#	350#	351#	353#	355#	359#	360#	362#	389#
	390#	395#	396#	402#	410#	411#	412#	418#	428#	430#	432#	434#	439#	444#	447#
	450#	452#	454#	455#	461#	462#	464#	502#	524#	540#	545#	558#	575#	583#	591#
	593#	594#	607#	609#	611#	620#	624#	627#	628#	630#	631#	632#	634#	637#	638#
	642#	643#	644#	647#	648#	649#	661#	707#	717#	728#	732#	805#	811#	812#	820#
	847#	862#	867#	872#	876#	881#	883#	898#	899#	903#	905#	906#	907#	908#	909#
	910#	911#	915#	916#	955#	957#	959#	964#	972#	979#	984#	998#	999#	1000#	1011#
	1021#	1025#	1031#	1036#	1050#	1051#	1052#	1063#	1068#	1069#	1070#	1071#	1093#	1094#	1102#
	1103#	1111#	1155#	1171#	1174#	1180#	1181#	1184#	1185#	1186#	1187#	1194#	1201#	1203#	1204#
	1222#	1229#	1237#	1273#	1274#	1280#	1285#	1318#	1321#	1330#	1346#	1349#	1353#	1354#	1355#
	1356#	1371#	1382#	1413#	1430#	1431#	1452#	1455#	1460#	1463#	1469#	1472#	1502#	1519#	1544#
	1546#	1547#	1548#	1580#	1587#	1646#	1649#	1655#	1656#	1672#	1673#	1703#	1733#	1734#	1771#
	1789#	1790#	1792#	1793#	1812#	1827#	1830#	1836#	1843#	1849#	1861#	1868#	1871#	1889#	1903#
	1936#	1958#	1969#	2011#	2021#	2066#	2073#	2107#	2152#	2257#	2264#	2343#	2346#	2352#	2353#
	2369#	2394#	2402#	2475#	2579#	2591#	2592#	2612#	2613#						
MSLDRO	432#	439#	444#	452#	454#	455#	464#	502#	524#	540#	594#	611#	620#	631#	632#
	634#	883#													
MSMCHI	7#														
MSMCLO	7#														
MSPOP	16#	86#	216#	321#	353#	362#	387#	393#	394#	399#	400#	406#	412#	413#	422#
	558#	564#	624#	638#	640#	644#	645#	649#	650#	704#	712#	836#	1906#	2579#	2595#
	2610#	2616#	2627#												
MSPRIN	347#	350#	351#	359#	360#	461#	462#	591#	593#	607#	609#	805#	811#	812#	820#
	862#	867#	872#	876#	898#	903#	905#	906#	907#	908#	909#	910#	911#	915#	955#
	957#	959#	964#	972#	979#	984#	998#	999#	1011#	1021#	1025#	1031#	1036#	1050#	1051#
	1063#	1068#	1069#	1070#	1071#	1093#	1094#	1102#	1103#	1111#	1155#	1171#	1180#	1186#	1201#
	1222#	1229#	1237#	1273#	1280#	1285#	1318#	1321#	1330#	1346#	1353#	1371#	1382#	1413#	1430#
	1452#	1455#	1460#	1463#	1469#	1472#	1502#	1519#	1544#	1546#	1547#	1548#	1580#	1646#	1655#
	1656#	1672#	1673#	1703#	1733#	1792#	1812#	1827#	1836#	1843#	1849#	1861#	1868#	1871#	2011#
	2021#	2066#	2073#	2107#	2257#	2343#	2352#	2353#	2369#	2402#					
MSPUSH	14#	27#	118#	221#	327#	329#	355#	389#	390#	395#	396#	402#	410#	411#	418#
	428#	430#	575#	627#	628#	642#	643#	647#	648#	661#	707#	717#	843#	1903#	2591#
	2592#	2612#	2613#												
MSPUT	347#	350#	351#	359#	360#	450#	461#	462#	545#	583#	591#	593#	607#	609#	630#
	728#	732#	805#	811#	812#	820#	862#	867#	872#	876#	898#	903#	905#	906#	907#
	908#	909#	910#	911#	915#	955#	957#	959#	964#	972#	979#	984#	998#	999#	1011#
	1021#	1025#	1031#	1036#	1050#	1051#	1063#	1068#	1069#	1070#	1071#	1093#	1094#	1102#	1103#
	1111#	1155#	1171#	1180#	1186#	1201#	1222#	1229#	1237#	1273#	1280#	1285#	1318#	1321#	1330#
	1346#	1353#	1371#	1382#	1413#	1430#	1452#	1455#	1460#	1463#	1469#	1472#	1502#	1519#	1544#
	1546#	1547#	1548#	1580#	1646#	1655#	1656#	1672#	1673#	1703#	1733#	1792#	1812#	1827#	1836#
	1843#	1849#	1861#	1868#	1871#	2011#	2021#	2066#	2073#	2107#	2257#	2343#	2352#	2353#	2369#
	2402#														
MSPUT1	347#	350#	351#	359#	360#	450#	461#	462#	545#	583#	591#	593#	607#	609#	630#
	728#	732#	805#	811#	812#	820#	862#	867#	872#	876#	898#	903#	905#	906#	907#
	908#	909#	910#	911#	915#	955#	957#	959#	964#	972#	979#	984#	998#	999#	1011#
	1021#	1025#	1031#	1036#	1050#	1051#	1063#	1068#	1069#	1070#	1071#	1093#	1094#	1102#	1103#
	1111#	1155#	1171#	1180#	1186#	1201#	1222#	1229#	1237#	1273#	1280#	1285#	1318#	1321#	1330#
	1346#	1353#	1371#	1382#	1413#	1430#	1452#	1455#	1460#	1463#	1469#	1472#	1502#	1519#	1544#
	1546#	1547#	1548#	1580#	1646#	1655#	1656#	1672#	1673#	1703#	1733#	1792#	1812#	1827#	1836#
	1843#	1849#	1861#	1868#	1871#	2011#	2021#	2066#	2073#	2107#	2257#	2343#	2352#	2353#	2369#
	2402#														
MSRADI	899#	916#	1000#	1052#	1174#	1181#	1184#	1185#	1187#	1194#	1203#	1204#	1274#	1349#	1354#
	1355#	1356#	1431#	1734#	1771#	1789#	1790#	1793#	1830#	2593#	2594#	2614#	2615#		
MSRNRO	439#	444#	524#												

MSSETS	14#	27#	118#	221#	327#	329#	355#	382#	390#	395#	396#	402#	410#	411#	418#
	428#	430#	575#	627#	628#	642#	643#	647#	648#	661#	707#	717#	843#	1903#	2591#
	2592#	2612#	2613#												
	347#	350#	351#	353#	359#	360#	362#	412#	432#	434#	439#	444#	447#	450#	452#
	454#	455#	461#	462#	464#	502#	524#	540#	545#	558#	583#	591#	593#	594#	607#
	609#	611#	620#	624#	630#	631#	632#	634#	637#	638#	644#	649#	728#	732#	805#
	811#	812#	820#	862#	867#	872#	876#	881#	883#	898#	899#	903#	905#	906#	907#
	908#	909#	910#	911#	915#	916#	955#	957#	959#	964#	972#	979#	984#	998#	999#
	1000#	1011#	1021#	1025#	1031#	1036#	1050#	1051#	1052#	1063#	1068#	1069#	1070#	1071#	1093#
	1094#	1102#	1103#	1111#	1155#	1171#	1174#	1180#	1181#	1184#	1185#	1186#	1187#	1194#	1201#
	1203#	1204#	1222#	1229#	1237#	1273#	1274#	1280#	1285#	1318#	1321#	1330#	1346#	1349#	1353#
	1354#	1355#	1356#	1371#	1382#	1413#	1430#	1431#	1452#	1455#	1460#	1463#	1469#	1472#	1502#
	1519#	1544#	1546#	1547#	1548#	1580#	1587#	1646#	1649#	1655#	1656#	1672#	1673#	1703#	1733#
	1734#	1771#	1789#	1790#	1792#	1793#	1812#	1827#	1830#	1836#	1843#	1849#	1861#	1868#	1871#
1889#	1936#	1958#	1969#	2011#	2021#	2066#	2073#	2107#	2152#	2257#	2264#	2343#	2346#	2352#	
MSTLAB	347#	350#	351#	353#	359#	360#	362#	412#	432#	434#	439#	444#	447#	450#	452#
	454#	455#	461#	462#	464#	502#	524#	540#	545#	558#	583#	591#	593#	594#	607#
	609#	611#	620#	624#	630#	631#	632#	634#	637#	638#	644#	649#	728#	732#	805#
	811#	812#	820#	862#	867#	872#	876#	881#	883#	898#	899#	903#	905#	906#	907#
	908#	909#	910#	911#	915#	916#	955#	957#	959#	964#	972#	979#	984#	998#	999#
	1000#	1011#	1021#	1025#	1031#	1036#	1050#	1051#	1052#	1063#	1068#	1069#	1070#	1071#	1093#
	1094#	1102#	1103#	1111#	1155#	1171#	1174#	1180#	1181#	1184#	1185#	1186#	1187#	1194#	1201#
	1203#	1204#	1222#	1229#	1237#	1273#	1274#	1280#	1285#	1318#	1321#	1330#	1346#	1349#	1353#
	1354#	1355#	1356#	1371#	1382#	1413#	1430#	1431#	1452#	1455#	1460#	1463#	1469#	1472#	1502#
	1519#	1544#	1546#	1547#	1548#	1580#	1587#	1646#	1649#	1655#	1656#	1672#	1673#	1703#	1733#
	1734#	1771#	1789#	1790#	1792#	1793#	1812#	1827#	1830#	1836#	1843#	1849#	1861#	1868#	1871#
	1889#	1936#	1958#	1969#	2011#	2021#	2066#	2073#	2107#	2152#	2257#	2264#	2343#	2346#	2352#
	2353#	2369#	2394#	2402#	2475#	2579#									
	MSTSTL	347#	350#	351#	353#	359#	360#	362#	412#	432#	434#	439#	444#	447#	450#
454#		455#	461#	462#	464#	502#	524#	540#	545#	558#	583#	591#	593#	594#	607#
609#		611#	620#	624#	630#	631#	632#	634#	637#	638#	644#	649#	728#	732#	805#
811#		812#	820#	862#	867#	872#	876#	881#	883#	898#	899#	903#	905#	906#	907#
908#		909#	910#	911#	915#	916#	955#	957#	959#	964#	972#	979#	984#	998#	999#
1000#		1011#	1021#	1025#	1031#	1036#	1050#	1051#	1052#	1063#	1068#	1069#	1070#	1071#	1093#
1094#		1102#	1103#	1111#	1155#	1171#	1174#	1180#	1181#	1184#	1185#	1186#	1187#	1194#	1201#
1203#		1204#	1222#	1229#	1237#	1273#	1274#	1280#	1285#	1318#	1321#	1330#	1346#	1349#	1353#
1354#		1355#	1356#	1371#	1382#	1413#	1430#	1431#	1452#	1455#	1460#	1463#	1469#	1472#	1502#
1519#		1544#	1546#	1547#	1548#	1580#	1587#	1646#	1649#	1655#	1656#	1672#	1673#	1703#	1733#
1734#		1771#	1789#	1790#	1792#	1793#	1812#	1827#	1830#	1836#	1843#	1849#	1861#	1868#	1871#
1889#		1936#	1958#	1969#	2011#	2021#	2066#	2073#	2107#	2152#	2257#	2264#	2343#	2346#	2352#
2353#		2369#	2394#	2402#	2475#	2579#									
MSWORD		15#	404#	881#	899#	916#	1000#	1052#	1174#	1181#	1184#	1185#	1187#	1194#	1203#
	1274#	1349#	1354#	1355#	1356#	1431#	1587#	1649#	1734#	1771#	1789#	1790#	1793#	1830#	1889#
	1936#	1958#	1969#	2152#	2264#	2346#	2394#	2475#	2593#	2594#	2614#	2615#	2628		
POINTE PRINTB PRINTF	11														
	347	350	351	359	360	805									
	461	462	591	593	607	609	811	812	820	862	867	872	876	898	903
	905	906	907	908	909	910	911	915	955	957	959	964	972	979	984
	998	999	1011	1021	1025	1031	1036	1050	1051	1063	1068	1069	1070	1071	1093
	1094	1102	1103	1111	1155	1171	1180	1186	1201	1222	1229	1237	1273	1280	285
	1318	1321	1330	1346	1353	1371	1382	1413	1430	1452	1455	1460	1463	1469	1472
	1502	1519	1544	1546	1547	1548	1580	1646	1655	1656	1672	1673	1703	1733	1792
	1812	1827	1836	1843	1849	1861	1868	1871	2011	2021	2066	2073	2107	2257	2343
	2352	2353	2369	2402											
READBU	447														

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACV11 30A(1052) 17-DEC-79 10:53 PAGE 6-4
CROSS REFERENCE TABLE -- MACRO NAMES

H 10

SEQ 0124

READER	464	502	540												
SETPRI	432	452	454	631	883										
SETVER	450	545	583	630	728	732									
STARS	656	659	720	723	748	750	766	768	799	801	807	809	815	817	824
	827	844	847	890	892	936	942	1151	1153	1266	1270	1325	1328	1423	1428
	1490	1495	1620	1623	1684	1688	1765	1768	1805	1810	1910	1921	2119	2121	2379
	2383	2523	2524	2532	2533	2535	2538	2582	2583	2588	2589				
SVC	5#	7													
WAITMS	93#	453	480												
WAITUS	103#	604	2144												

. ABS. 035704 000

ERRORS DETECTED: 0

.CZRLMB.LST/CRF=SVC33/ML.CZRLMB.MAC
RUN-TIME: 121 116 10 SECONDS
RUN-TIME RATIO: 502/248=2.0
CORE USED: 16K (31 PAGES)