



ROMWBW

User Guide

Version 3.1 Pre-release
10 Feb 2023

RetroBrew Computers Group
www.retrobrewcomputers.org

Wayne Warthen
wwarthen@gmail.com

Contents

1 Overview	2
2 Getting Started	4
2.1 Acquiring RomWBW	4
2.2 Installation	5
2.3 System Startup	7
2.4 Core System Information	9
2.5 Hardware Discovery	9
2.6 Device Unit Assignments	10
3 Boot Loader Operation	12
3.1 Starting Applications from ROM	13
3.2 Starting Operating Systems from Disk	14
3.3 System Management	17
3.3.1 Listing Disk Device Inventory	17
3.3.2 Rebooting the System	17
3.3.3 Changing Console and Console speed	17
3.3.4 HBIOS Diagnostic Verbosity	18
4 Disk Management	19
4.1 Drive Letter Assignment	20
4.2 ROM & RAM Disks	22
4.3 Floppy Disks	23
4.4 Hard Disks	25
4.5 Slices	26
4.6 Hard Disk Layouts	28
4.6.1 Checking Hard Disk Layout	29
5 Disk Content Preparation	31
5.1 Disk Images	31

5.1.1	Floppy Disk Images	32
5.1.2	Hard Disk Images	33
5.2	In-situ Disk Preparation	35
6	Operating Systems	39
6.1	Digital Research CP/M 2.2	39
6.2	Z-System	40
6.3	NZCOM Automatic Z-System	42
6.4	Digital Research CP/M 3	43
6.5	Simeon Cran's ZPM3	44
6.6	QP/M	45
6.7	UCSD p-System	45
6.8	FreeRTOS	46
7	Custom Applications	48
8	FAT Filesystem	50
8.1	FAT Filesystem Preparation	50
8.2	FAT Application Usage	52
9	CP/NET Networking	54
9.1	CP/NET Client Setup	55
9.2	CP/NET Sever Setup	56
9.3	CP/NET Usage	56
9.4	Network Boot	58
10	Transferring Files	61
10.1	Serial Port Transfers	61
10.2	Disk Image Transfers	62
10.3	FAT Filesystem Transfers	62
11	Customizing RomWBW	64
11.1	Startup Command Processing	64
11.2	ROM Customization	65
12	UNA Hardware BIOS	66
13	Upgrading	67
13.1	Upgrading via Flash Utility	67
13.2	Upgrading via XModem Flash Updater	68
13.3	Post Upgrade System Image and Application Update Process	69
13.4	System Update	70

14 Acknowledgments	71
15 Licensing	73
16 Getting Assistance	75
17 Appendixes	76
17.1 Appendix A - Pre-built ROM Images	77
17.2 Appendix B - Device Summary	82

Preface

This document is a general usage guide for the RomWBW software and is generally the best place to start with RomWBW. There are several companion documents you should refer to as appropriate:

- [RomWBW System Guide](#) discusses much of the internal design and construction of RomWBW. It includes a reference for the RomWBW HBIOS API functions.
- [RomWBW Applications](#) is a reference for the OS-hosted proprietary command line applications that were created to enhance RomWBW.
- [RomWBW ROM Applications](#) is a reference for the ROM-hosted applications provided with RomWBW including the monitor, programming languages, etc.
- [RomWBW Disk Catalog](#) is a reference for the contents of the disk images provided with RomWBW. It is somewhat out of date at this time.
- [RomWBW Errata](#) is updated as needed to document issues or anomalies discovered in the current software distribution.

Since RomWBW is purely a software product for many different platforms, the documentation does **not** cover hardware construction, configuration, or troubleshooting – please see your hardware provider for this information.

Each of the operating systems and ROM applications included with RomWBW are sophisticated tools in their own right. It is not reasonable to fully document their usage here. However, you will find complete manuals in PDF format in the Doc directory of the distribution. The intention of this document is to describe the operation of RomWBW and the ways in which it enhances the operation of the included applications and operating systems.

On a personal note, I found this document very difficult to write. Members of the retro-computing community have dramatically different experiences, skill levels, and desires. I realize some readers will find this document far too basic. Others will find it lacking in many areas. I am doing my best and encourage you to provide constructive feedback.

Chapter 1

Overview

RomWBW software provides a complete, commercial quality implementation of CP/M (and workalike) operating systems and applications for modern Z80/180/280 retro-computing hardware systems. A wide variety of platforms are supported including those produced by these developer communities:

- [RetroBrew Computers](#)
- [RC2014, RC2014-Z80](#)
- [retro-comp](#)
- [Small Computer Central](#)

General features include:

- Banked memory services for several banking designs
- Disk drivers for RAM, ROM, Floppy, IDE, CF, and SD
- Serial drivers including UART (16550-like), ASCI, ACIA, SIO
- Video drivers including TMS9918, SY6545, MOS8563, HD6445
- Keyboard (PS/2) drivers via VT8242 or PPI interfaces
- Real time clock drivers including DS1302, BQ4845
- OSes: CP/M 2.2, ZSDOS, CP/M 3, NZ-COM, ZPM3, QPM, p-System, and FreeRTOS
- Built-in VT-100 terminal emulation support

RomWBW is distributed as both source code and pre-built ROM and disk images. Some of the provided software can be launched directly from the ROM firmware itself:

- System Monitor
- Operating Systems (CP/M 2.2, ZSDOS)
- ROM BASIC (Nascom BASIC and Tasty BASIC)
- ROM Forth

A dynamic disk drive letter assignment mechanism allows mapping operating system drive letters to any available disk media. Additionally, mass storage devices (IDE Disk, CF Card, SD Card) support the use of multiple slices (up to 256 per device). Each slice contains a complete CP/M filesystem and can be mapped independently to any drive letter. This overcomes the inherent size limitations in legacy OSes and allows up to 2GB of accessible storage on a single device.

The pre-built ROM firmware images are generally suitable for most users. However, it is also very easy to modify and build custom ROM images that fully tailor the firmware to your specific preferences. All tools required to build custom ROM firmware under Windows are included – no need to install assemblers, etc. The firmware can also be built using Linux or MacOS after confirming a few standard tools have been installed.

Multiple disk images are provided in the distribution. Most disk images contain a complete, bootable, ready-to-run implementation of a specific operating system. A “combo” disk image contains multiple slices, each with a full operating system implementation. If you use this disk image, you can easily pick whichever operating system you want to boot without changing media.

By design, RomWBW isolates all of the hardware specific functions in the ROM chip itself. The ROM provides a hardware abstraction layer such that all of the operating systems and applications on a disk will run on any RomWBW-based system. To put it simply, you can take a disk (or CF/SD Card) and move it between systems transparently.

A tool is provided that allows you to access a FAT-12/16/32 filesystem. The FAT filesystem may be coresident on the same disk media as RomWBW slices or on stand-alone media. This makes exchanging files with modern OSes such as Windows, MacOS, and Linux very easy.

Chapter 2

Getting Started

2.1 Acquiring RomWBW

The [RomWBW Repository](#) on GitHub is the official distribution location for all project source and documentation. The fully-built distribution releases are available on the [RomWBW Releases Page](#) of the repository. On this page, you will normally see a Development Snapshot as well as recent stable releases. Unless you have a specific reason, I suggest you stick to the most recent stable release. Expand the “Assets” drop-down for the release you want to download, then select the asset named RomWBW-vX.X.X-Package.zip. The Package asset includes all pre-built ROM and Disk images as well as full source code. The other assets contain only source code and do not have the pre-built ROM or disk images.

All source code and distributions are maintained on GitHub. Code contributions are very welcome.

Distribution Directory Layout

The RomWBW distribution is a compressed zip archive file organized in a set of directories. Each of these directories has it’s own ReadMe.txt file describing the contents in detail. In summary, these directories are:

Direc- tory	Description
Binary	The final output files of the build process are placed here. Most importantly, the ROM images with the file names ending in “.rom” and disk images ending in .img.
Doc	Contains various detailed documentation, both RomWBW specifically as well as the operating systems and applications.

Direc- tory	Description
Source	Contains the source code files used to build the software and ROM images.
Tools	Contains the programs that are used by the build process or that may be useful in setting up your system.

2.2 Installation

In general, installation of RomWBW on your platform is very simple. You just need to program your ROM with the correct ROM image from the RomWBW distribution. Subsequently, you can write disk images on your disk drives (IDE disk, CF Card, SD Card, etc.) which then provides even more functionality.

The pre-built ROM images will automatically detect and support typical devices for their corresponding platform including serial ports, video adapters, on-board disk interfaces, and PropIO/ParPortProp boards without building a custom ROM. The distribution is a .zip archive. After downloading it to a working directory on your modern computer (Windows/Linux/Mac) use any zip tool to extract the contents of the archive.

Depending on how you got your hardware, you may have already been provided with a pre-programmed ROM chip. If so, use that initially. Otherwise, you will need to use a ROM programmer to initially program your ROM chip. Please refer to the documentation that came with your ROM programmer for more information. Once you have a running RomWBW system, you can generally update your ROM to a newer version in-situ with the included ROM Flashing tool (Will Sowerbutts' FLASH application) as described in the Upgrading section of this document.

The Binary directory of the distribution contains the pre-built ROM and disk images. The ROM image files all end in ".rom". Based on the table below, **carefully** pick the appropriate ROM image for your hardware.

Description	ROM Image File	Baud Rate
RetroBrew Z80 SBC ¹ for ECB Bus	SBC_std.rom	38400
RetroBrew Zeta V1 Z80 SBC ² , ParPortProp	ZETA_std.rom	38400
RetroBrew Zeta V2 Z80 SBC ² , ParPortProp	ZETA2_std.rom	38400
RetroBrew N8 Z180 ¹ (date code >= 2312)	N8_std.rom	38400
RetroBrew Mark IV ³ Z180 for ECB Bus	MK4_std.rom	38400
RCBus Z80 CPU Module ⁴ , 512K RAM/ROM	RCZ80_std.rom	115200
RCBus Z80 CPU Module ⁴ , 512K RAM/ROM, DUART	RCZ80_duart.rom	115200

Description	ROM Image File	Baud Rate
RCBus Z80 CPU Module ⁴ , 512K RAM/ROM, MT011	RCZ80_mt.rom	115200
RCBus Z80 CPU Module ⁴ , 512K RAM/ROM, KIO	RCZ80_kio.rom	115200
RCBus Z180 CPU Module ⁴ w/ external banking	RCZ180_ext.rom	115200
RCBus Z180 CPU Module ⁴ w/ native banking	RCZ180_nat.rom	115200
RCBus Z280 CPU Module ⁴ w/ external banking	RCZ180_ext.rom	115200
RCBus Z280 CPU Module ⁴ w/ native banking	RCZ180_nat.rom	115200
Easy Z80 SBC ² w/ RCBus	EZZ80_std.rom	115200
Tiny EIPC Z80 SBC ² w/ RCBus	EZZ80_tz80.rom	115200
Z80-512K CPU/RAM/ROM Module ² for RCBus	EZZ80_skz.rom	115200
SC126 Z180 SBC ⁵ w/ BP80 Bus	SCZ180_126.rom	115200
SC130 Z180 SBC ⁵ w/ RCBus	SCZ180_130.rom	115200
SC131 Z180 Pocket Computer ⁵	SCZ180_131.rom	115200
SC140 Z180 CPU Module ⁵ for Z50Bus	SCZ180_140.rom	115200
Dyno Z180 SBC ⁶ w/ Dyno Bus	DYNO_std.rom	38400
Nhyodyne Z80 MBC ¹	MBC_std.rom	38400
Rhyophyre Z180 SBC ¹	RPH_std.rom	38400
Z80 ZRC ⁷ for RCBus	RCZ80_zrc.rom	115200
Z280 ZZRCC ⁷ for RCBus	RCZ280_nat_zzr.rom	115200
Z280 ZZ80MB SBC ⁷ w/ RCBus	RCZ280_nat_zz.rom	115200

¹Designed by Andrew Lynch

²Designed by Sergey Kiselev

³Designed by John Coffman

⁴RCBus compliant (multiple products/designers)

⁵Designed by Stephen Cousins

⁶Designed by Steve Garcia

⁷Designed by Bill Shen

RCBus refers to Spencer Owen's RC2014 bus specification and derivatives including RC26, RC40, RC80, and BP80.

The RCBus Z180 & Z280 require a separate RAM/ROM memory module. There are two types of these modules and you must pick the correct ROM for your type of memory module. The first option is the same as the 512K RAM/ROM module for RC/BP80 Bus. This is called external ("ext") because the bank switching is performed externally from the CPU. The second type of RAM/ROM module has no bank switching logic – this is called native ("nat") because the CPU itself provides the bank switching logic. Only Z180 and Z280 CPUs have the ability to do bank switching in the CPU, so the ext/nat selection only applies to them. Z80 CPUs have no built-in

bank switching logic, so they are always configured for external bank switching.

All pre-built ROM images are pure binary files (they are not “hex” files). They are intended to be programmed starting at the very start of the ROM chip (address 0). Most of the pre-built images are 512KB in size. If your system utilizes a larger ROM, you can just program the image into the first 512KB of the ROM for now.

Initially, don't worry about trying to write a disk image to any disk (or CF/SD) devices you have. This will be covered later. You will be able to boot and check out your system with just the ROM.

Connect a serial terminal or computer with terminal emulation software to the primary serial port of your CPU board. You may need to refer to your hardware provider's documentation for details. A null-modem connection may be required. Set the baud rate as indicated in the table above. Set the line characteristics to 8 data bits, 1 stop bit, no parity, and no flow control. If possible, select ANSI or VT-100 terminal emulation.

RomWBW will automatically attempt to detect and support typical add-on components for each of the systems supported. More information on the required system configuration and optional supported components for each ROM is found in the file called “RomList.txt” in the Binary directory.

2.3 System Startup

Upon power-up, your terminal should display a sign-on banner within 2 seconds followed by hardware inventory and discovery information. When hardware initialization is completed, a boot loader prompt allows you to choose a ROM-based operating system, system monitor, application, or boot from a disk device.

Here is an example of a fairly typical startup. Your system will have different devices and configuration, but the startup should look similar.

```
RomWBW HBIOS v3.1.1-pre.183, 2022-10-04
```

```
RC2014 [RCZ80_kio] Z80 @ 7.372MHz  
0 MEM W/S, 1 I/O W/S, INT MODE 2, Z2 MMU  
512KB ROM, 512KB RAM  
ROM VERIFY: 00 00 00 00 PASS
```

```
KIO: IO=0x80 ENABLED  
CTC: IO=0x84 TIMER MODE=TIM16  
AY: MODE=RCZ80 IO=0xD8 NOT PRESENT
```

```

SI00: IO=0x89 SI0 MODE=115200,8,N,1
SI01: IO=0x8B SI0 MODE=115200,8,N,1
DSRTC: MODE=STD IO=0xC0 NOT PRESENT
MD: UNITS=2 ROMDISK=384KB RAMDISK=256KB
FD: MODE=RCWDC IO=0x50 NOT PRESENT
IDE: IO=0x10 MODE=RC
IDE0: NO MEDIA
IDE1: NO MEDIA
PPIDE: IO=0x20
PPIDE0: LBA BLOCKS=0x00773800 SIZE=3815MB
PPIDE1: NO MEDIA

```

Unit	Device	Type	Capacity/Mode
-----	-----	-----	-----
Char 0	SI00:	RS-232	115200,8,N,1
Char 1	SI01:	RS-232	115200,8,N,1
Disk 0	MD0:	RAM Disk	256KB,LBA
Disk 1	MD1:	ROM Disk	384KB,LBA
Disk 2	IDE0:	Hard Disk	--
Disk 3	IDE1:	Hard Disk	--
Disk 4	PPIDE0:	CompactFlash	3815MB,LBA
Disk 5	PPIDE1:	Hard Disk	--

If your system completes the ROM-based boot process successfully, you should see the RomWBW Boot Loader prompt. For example:

```
RC2014 [RCZ80_kio] Boot Loader
```

```
Boot [H=Help]:
```

If you get to this prompt, your system has completed the boot process and is ready to accept commands. Note that the Boot Loader is not an operating system or application. It is essentially the point where you choose which operating system or application you want RomWBW to execute.

The Boot Loader is explained in detail in the next section. For now, you can try a few simple commands to confirm that you can interact with the system.

At the Boot Loader prompt, you can type `H` <enter> for help. You can type `L` <enter> to list the available built-in ROM applications. If your terminal supports ANSI escape sequences, you can try the 'G' command to play a simple on-screen game.

If all of this seems fine, your ROM has been successfully programmed. See the [Boot Loader](#)

Operation section of this document for further instructions on use of the Boot Loader.

2.4 Core System Information

During startup, the first few lines of information displayed provide the most basic information on your system. In the example above, these lines are the Core System Information:

```
RomWBW HBIOS v3.1.1-pre.183, 2022-10-04
```

```
RC2014 [RCZ80_kio] Z80 @ 7.372MHz  
0 MEM W/S, 1 I/O W/S, INT MODE 2, Z2 MMU  
512KB ROM, 512KB RAM  
ROM VERIFY: 00 00 00 00 PASS
```

The first line is a version identification banner for RomWBW. After that you see a group of 4 lines describing the basic system. In this example, the platform is the RC2014 running a configuration named "RCZ80_kio". The CPU is a Z80 with a current clock speed of 7.372 MHz. There are 0 memory wait states and 1 I/O wait state. Z80 interrupt mode 2 is active and the bank memory manager is type "Z2" which is standard for RC2014. The system has 512KB of ROM total and 512KB of RAM total. Finally, a verification of the checksum of the critical ROM banks is shown (all 4 should be 00).

RomWBW attempts to detect the running configuration of the system at startup. Depending on your hardware, there may be inaccuracies in this section. For example, in some cases the CPU clock speed is assumed rather than actually measured. This does not generally affect the operation of your system. If you want to correct any of the information displayed, you can create a custom ROM which is described later.

2.5 Hardware Discovery

The next set of messages during boot show the hardware devices as they are probed and initially configured. In the example above, these lines are:

```
KIO: IO=0x80 ENABLED  
CTC: IO=0x84 TIMER MODE=TIM16  
AY: MODE=RCZ80 IO=0xD8 NOT PRESENT  
SI00: IO=0x89 SIO MODE=115200,8,N,1  
SI01: IO=0x8B SIO MODE=115200,8,N,1  
DSRTC: MODE=STD IO=0xC0 NOT PRESENT  
MD: UNITS=2 ROMDISK=384KB RAMDISK=256KB
```

```
FD: MODE=RCWDC IO=0x50 NOT PRESENT
IDE: IO=0x10 MODE=RC
IDE0: NO MEDIA
IDE1: NO MEDIA
PPIDE: IO=0x20
PPIDE0: LBA BLOCKS=0x00773800 SIZE=3815MB
PPIDE1: NO MEDIA
```

What you see will depend on your specific system and ROM, but should match the hardware present in your system. Each device has a tag that precedes the colon. This tag identifies the driver and instance of each device. For example, the tag "SIO0:" refers to the SIO serial port driver and specifically the first channel. The "SIO1:" tag refers to the second channel.

In many cases you will see IO=0xNN in the data following the tag. This identifies the base I/O port address of the hardware device and is useful for identifying hardware conflicts.

Note that you may see some lines indicating that the associated hardware is not present. Above, you can see that the FD driver did not find a floppy interface. Lines such as these are completely normal when your system does not have the associated hardware.

Finally, be aware that all ROMs are configured to identify specific hardware devices at specific port addresses. If you add hardware to your system that is not automatically identified, you may need to build a custom ROM to add support for it. Building a custom ROM is covered later.

[Appendix A - Device Summary] contains a list of the RomWBW hardware devices which may help you identify the hardware discovered in your system.

2.6 Device Unit Assignments

In order to support a wide variety of hardware, RomWBW HBIOS uses a modular approach to implementing device drivers and presenting devices to an operating system. In general, all devices are classified as one of the following:

- Disk (RAM/ROM Disk, Floppy Disk, Hard Disk, CF Card, SD Card, etc.)
- Character (Serial Ports, Parallel Ports, etc.)
- Video (Video Display/Keyboard Interfaces)
- Sound (Audio Playback Devices)
- RTC/NVRAM (Real Time Clock, Non-volatile RAM)
- System (Internal Services, e.g. Timer, DMA, etc.)

HBIOS uses the concept of unit numbers to present a generic set of hardware devices to the operating system. As an example, a typical system might have a ROM Disk, RAM Disk, Floppy

Drives, and Disk Drives. All of these are considered disk devices and are presented to the operating system as generic block devices. This means that each operating system does not need to embed code to interact directly with all of the different hardware devices – RomWBW takes care of that.

In the final group of startup messages, a device unit summary table is displayed so that you can see how the actual hardware devices have been mapped to unit numbers during startup.

Unit	Device	Type	Capacity/Mode
-----	-----	-----	-----
Char 0	UART0:	RS-232	38400, 8, N, 1
Char 1	UART1:	RS-232	38400, 8, N, 1
Disk 0	MD1:	RAM Disk	384KB, LBA
Disk 1	MD0:	ROM Disk	384KB, LBA
Disk 2	FD0:	Floppy Disk	3.5", DS/HD, CHS
Disk 3	FD1:	Floppy Disk	3.5", DS/HD, CHS
Disk 4	IDE0:	CompactFlash	3815MB, LBA
Disk 5	IDE1:	Hard Disk	--
Disk 6	PRPSD0:	SD Card	1886MB, LBA
Video 0	CVDU0:	CRT	Text, 80x25

In this example, you can see that the system has a total of 7 Disk Units numbered 0-6. There are also 2 Character Units and 1 Video Unit. The table shows the unit numbers assigned to each of the devices. Notice how the unit numbers are assigned sequentially regardless of the specific device.

There may or may not be media in the disk devices listed. For example, the floppy disk devices (Disk Units 2 & 3) may not have a floppy in the drive. Also note that Disk Unit 4 shows a disk capacity, but Disk Unit 5 does not. This is because the PPIDE interface of the system supports up to two drives, but there is only one actual drive attached. A unit number is assigned to all available devices regardless of whether they have actual media installed at boot time.

Note that Character Unit 0 is normally the initial system console.

If your system has an RTC/NVRAM device, it will not be listed in the unit summary table. Since only a single RTC/NVRAM device can exist in one system, unit numbers are not required nor used for this type of device. Also, System devices are not listed because they are entirely internal to RomWBW.

Chapter 3

Boot Loader Operation

Once your system has completed the startup process, it presents a Boot Loader command prompt. The purpose of the Boot Loader is to select and launch a desired application or operating system. It also has the ability to configure some aspects of system operation.

After starting your system, following the hardware initialization, you will see the RomWBW Boot Loader prompt. Below is an example:

```
Mark IV [MK4_wbw] Boot Loader
```

```
Boot [H=Help]:
```

From the Boot Loader prompt, you can enter commands to select and launch any of the RomWBW operating systems or ROM applications. It also allows you to manage some basic settings of the system. To enter a command, just enter the command followed by **<enter>**.

For example, typing H<enter> will display a short command summary:

```
Boot [H=Help]: h
```

```
L          - List ROM Applications
D          - Disk Device Inventory
R          - Reboot System
I <u> [<c>] - Set Console Interface/Baud code
V [<n>]    - View/Set HBIOS Diagnostic Verbosity
<u>[.<s>]  - Boot Disk Unit/Slice
```

Likewise the L command will display the list of ROM Applications that you can launch right from the Boot Loader:


```
Boot [H=Help]: L
```

```
ROM Applications:
```

```
M: Monitor
Z: Z-System
C: CP/M 2.2
F: Forth
B: BASIC
T: Tasty BASIC
P: Play a Game
N: Network Boot
X: XModem Flash Updater
U: User App
```

3.1 Starting Applications from ROM

To start a ROM application you just enter the corresponding letter at the Boot Loader prompt. In the following example, we launch the built-in Microsoft BASIC interpreter. From within BASIC, we use the BYE command to return to the Boot Loader:

```
Boot [H=Help]: b
```

```
Loading BASIC...
Memory top?
Z80 BASIC Ver 4.7b
Copyright (C) 1978 by Microsoft
55603 Bytes free
Ok
bye
```

```
Mark IV [MK4_wbw] Boot Loader
```

```
Boot [H=Help]:
```

The following ROM applications and OSes are available at the boot loader prompt:

Application	Description
Monitor	Z80 system debug monitor w/ Intel Hex loader
CP/M 2.2	Digital Research CP/M 2.2 OS
Z-System	ZSDOS 1.1 w/ ZCPR 1 (Enhanced CP/M compatible OS)
Forth	Brad Rodriguez's ANSI compatible Forth language
Tasty BASIC	Dimitri Theuling's Tiny BASIC implementation
Play	A simple video game (requires ANSI terminal emulation)
Network Boot	Boot system via Wiznet MT011 device
Flash Update	Upload and flash a new ROMWBW image using xmodem

Each of the ROM Applications is documented in [RomWBW ROM Applications](#). Some of the applications (such as BASIC) also have their own independent manual in the Doc directory of the distribution. The OSes included in the ROM (CP/M 2.2 & Z-System) are described in the Operating Systems section of this document.

In general, the command to exit any of these applications and restart the system is BYE. The exceptions are the Monitor which uses B and Play which uses Q.

Two of the ROM Applications are, in fact, complete operating systems. Specifically, "CP/M 2.2" and "Z-System" are provided so that you can actually start either operating system directly from your ROM. This technique is useful when:

- You don't yet have any real disk drives in your system
- You want to setup real disk drives for the first time
- You are upgrading your system and need to upgrade your real disk drives

The RAM disk and ROM disk drives will be available even if you have no physical disk devices attached to your system.

3.2 Starting Operating Systems from Disk

In order to make use of the more sophisticated operating systems available with RomWBW, you will need to boot an operating system from a disk. Setting up disks is described in detail later. For now, we will just go over the command line for performing this type of boot.

From the Boot Loader prompt, you can enter a number (**<diskunit>**) and optionally a dot followed by a second number (**<slice>**). The **<disk unit>** unit number refers to a disk unit that was displayed when the system was booted – essentially it specifies the specific physical disk drive you want to boot. The **<slice>** numbers refers to a portion of the disk unit to boot. If no

slice is specified, then it is equivalent to booting from the first slice (slice 0). Disk units and slices are described in more detail later.

Following this, you should see the operating system startup messages. Your operating system prompt will typically be A> and when you look at the drive letter assignments, you should see that A: has been assigned to the disk and slice you selected to boot.

If you receive the error message "Disk not bootable!", you have either failed to properly initialize the disk and slice requested or you have selected the wrong disk/slice.

The following example shows a disk boot into the first slice of disk unit 4 which happens to be the CP/M 2.2 operating system on this disk. This is accomplished by entering just the number '4' and pressing **<enter>**.

```
Boot [H=Help]: 4
```

```
Booting Disk Unit 4, Slice 0, Sector 0x00000800...
```

```
Volume "Unlabeled" [0xD000-0xFE00, entry @ 0xE600]...
```

```
CBIOS v3.1.1-pre.194 [WBW]
```

```
Formatting RAMDISK...
```

```
Configuring Drives...
```

```
A:=IDE0:0
B:=MD0:0
C:=MD1:0
D:=FD0:0
E:=FD1:0
F:=IDE0:1
G:=IDE0:2
H:=IDE0:3
I:=PRPSD0:0
J:=PRPSD0:1
K:=PRPSD0:2
L:=PRPSD0:3
```

```
1081 Disk Buffer Bytes Free
```

```
CP/M-80 v2.2, 54.0K TPA
```

A>

Notice that a list of drive letters and their assignments to RomWBW devices and slices is displayed during the initialization of the operating system.

Here is another example where we are booting disk unit 4, slice 3 which is the CP/M 3 operating system on this disk:

```
Boot [H=Help]: 4.3
```

```
Booting Disk Unit 4, Slice 3, Sector 0x0000C800...
```

```
Volume "Unlabeled" [0x0100-0x1000, entry @ 0x0100]...
```

```
CP/M V3.0 Loader
```

```
Copyright (C) 1998, Caldera Inc.
```

```
BNKBIOS3 SPR F600 0800
```

```
BNKBIOS3 SPR 4500 3B00
```

```
RESBDOS3 SPR F000 0600
```

```
BNKBDOS3 SPR 1700 2E00
```

```
60K TPA
```

```
CP/M v3.0 [BANKED] for HBIOS v3.1.1-pre.194
```

A>

Some operating systems (such as CP/M 3 shown above) do not list the drive assignments during initialization. In this case, you can use the ASSIGN command to display the current assignments.

The Boot Loader simply launches whatever is in the disk unit/slice you have specified. It does not know what operating system is at that location. The layout of operating systems on disk media is described in the Using Disks section of this document.

3.3 System Management

3.3.1 Listing Disk Device Inventory

The disk device units available in your system are listed in the boot messages. However, if that list has scrolled off of your screen, you can use the 'D' command to display a list of them at any time from the Boot Loader prompt.

```
Boot [H=Help]: d
```

```
Disk Devices:
```

```
Disk Unit 0 on MD0:
Disk Unit 1 on MD1:
Disk Unit 2 on FD0:
Disk Unit 3 on FD1:
Disk Unit 4 on IDE0:
Disk Unit 5 on IDE1:
Disk Unit 6 on IDE2:
Disk Unit 7 on IDE3:
Disk Unit 8 on IDE4:
Disk Unit 9 on IDE5:
Disk Unit 10 on SD0:
Disk Unit 11 on PRPSD0:
```

3.3.2 Rebooting the System

The 'R' command within the Boot Loader performs a software reset of the system. It is the software equivalent of pressing the reset button.

There is generally no need to do this, but it can be convenient when you want to see the boot messages again or ensure your system is in a clean state.

```
Boot [H=Help]: r
```

```
Restarting System...
```

3.3.3 Changing Console and Console speed

Your system can support a number of devices for the console. They may be VDU type devices or serial devices. If you want to change which device is the console, the *I* menu option can be used to choose the unit and its speed.

The command format is I <unit> [<baudrate>]

where **<unit>** is the character unit to select and **<baudrate>** is the optional baud rate.

Supported baud rates are:

75	450	1800	7200	38400	115200	460800	1843200
150	600	2400	9600	28800	153600	614400	2457600
225	900	3600	14400	57600	230400	921600	3686400
300	1200	4800	19200	76800	307200	1228800	7372800

Here is an example of changing the console to unit #1 (the second serial port) and switching the port to 9600 baud:

```
Boot [H=Help]: i 1 9600
```

```
Change speed now. Press a key to resume.
```

```
Console on Unit #1
```

At this point, the Boot Loader prompt will be displayed on character unit #1.

Note that not all character devices support changing baud rates and some only support a limited subset of the baud rates listed. If you attempt to select an invalid baud rate for your system, you will get an error message.

3.3.4 HBIOS Diagnostic Verbosity

The 'V' command of the Boot Loader allows you to view and optionally change the level of diagnostic messages that RomWBW will produce. The normal verbosity level is 4, which means to display only fatal errors. You can increase this level to see more warnings when function calls to RomWBW HBIOS detect problems.

The use of diagnostic levels above 4 are really intended only for software developers. I do not recommend changing this under normal circumstances.

Chapter 4

Disk Management

The systems supported by RomWBW all have the ability to use persistent disk media. A wide variety of disk devices are supported including floppy drives, hard disks, CF Cards, and SD Cards. RomWBW also supports the use of extra RAM and ROM memory as pseudo-disk devices.

RomWBW supports a variety of storage devices which will be discussed in more detail later.

- ROM Disk
- RAM Disk
- Floppy Disk
- Hard Disk (includes CF Cards and SD Cards)

We will start by discussing each of these types of storage devices and how to prepare them so files can be stored on them. Subsequently, we will describe how to install the pre-built disk images with bootable operating systems and ready-to-run content.

Some systems have disk interfaces built-in, while others will require add-in cards. You will need to refer to the documentation for your system for your specific options.

In the RomWBW boot messages, you will see hardware discovery messages. If you have a disk drive interface, you should see messages listing device types like FD:, IDE:, PPIDE:, SD:. Additionally, you will see messages indicating the media that has been found on the interfaces. As an example, here are the messages you might see if you have an IDE interface in your system with a single CF Card inserted in the primary side of the interface:

```
IDE: IO=0x80 MODE=MK4
IDE0: 8-BIT LBA BLOCKS=0x00773800 SIZE=3815MB
IDE1: NO MEDIA
```

The messages you see will vary depending on your hardware and the media you have installed. But, they will all have the same general format as the example above.

Once your system has working disk devices, they will be accessible from any operating system you choose to run. Disk storage is available whether you boot your OS from ROM or from the disk media itself.

Referring back to the Boot Loader section on “Launching from ROM”, you could start CP/M 2.2 using the ‘C’ command. As the operating system starts up, you should see a list of drive letters assigned to the disk media you have installed. Here is an example of this:

Configuring Drives...

```
A:=MD1:0
B:=MD0:0
C:=IDE0:0
D:=IDE0:1
```

You will probably see more drive letters than this. The drive letter assignment process is described below in the Drive Letter Assignment section. Be aware that RomWBW will only assign drive letters to disk interfaces that actually have media in them. If you do not see drive letters assigned as expected, refer to the prior system boot messages to ensure media has been detected in the interface. Actually, there is one exception to this rule: floppy drives will be assigned a drive letter regardless of whether there is any media inserted at boot.

Notice how each drive letter refers back to a specific disk hardware interface like IDE0. This is important as it is telling you what each drive letter refers to. Also notice that mass storage disks (like IDE) will normally have multiple drive letters assigned. The extra drive letters refer to additional “slices” on the disk. The concept of slices is described below in the Slices section.

4.1 Drive Letter Assignment

In legacy CP/M-type operating systems, drive letters were generally mapped to disk drives in a completely fixed way. For example, drive A: would **always** refer to the first floppy drive. Since RomWBW supports a wide variety of hardware configurations, it implements a much more flexible drive letter assignment mechanism so that any drive letter can be assigned to any disk device.

At boot, you will notice that RomWBW automatically assigns drive letters to the available disk devices. These assignments are displayed during the startup of the selected operating system. Additionally, you can review the current drive assignments at any time using the ASSIGN command. CP/M 3 and ZPM3 do not automatically display the assignments at startup,

but you can use ASSIGN to display them. Refer to [RomWBW Applications](#) for more information on use of the ASSIGN command.

Here is an example of the list of drive letter assignments made during the startup of Z-System:

Loading Z-System...

CBIOS v3.1.1-pre.194 [WBW]

Formatting RAMDISK...

Configuring Drives...

```
A:=MD0:0
B:=MD1:0
C:=FD0:0
D:=FD1:0
E:=IDE0:0
F:=IDE0:1
G:=IDE0:2
H:=IDE0:3
```

1081 Disk Buffer Bytes Free

ZSDOS v1.1, 54.0K TPA

Above you can see that drive A: has been assigned to MD0 which is the RAM Disk device. Drives C: and D: have been assigned to floppy drives. Drives E: thru L: have been assigned to the IDE0 hard disk device. The 4 entries for IDE0 are referring to 4 slices on that disk. Slices are discussed later.

The drive letter assignments **do not** change during an OS session unless you use the ASSIGN command yourself to do it. Additionally, the assignments at boot will stay the same on each boot as long as you do not make changes to your hardware configuration. Note that the assignments **are** dependent on the media currently inserted in hard disk drives. So, notice that if you insert or remove an SD Card or CF Card, the drive assignments will change. Since drive letter assignments can change, you must be careful when doing destructive things like using CLRDIR to make sure the drive letter you use is referring to the desired media.

When performing a ROM boot of an operating system, note that A: will be your RAM disk and B: will be your ROM disk. When performing a disk boot, the disk you are booting from will be assigned to A: and the rest of the drive letters will be offset to accommodate this. This is done

because most legacy operating systems expect that A: will be the boot drive.

4.2 ROM & RAM Disks

A typical RomWBW system has 512KB of ROM and 512KB of RAM. Some portions of each are dedicated to loading and running applications and operating system. The space left over is available for an operating system to use as a pseudo-disk device.

The RAM disk provides a small CP/M filesystem that you can use for the temporary storage of files. Unless your system has a battery backed mechanism for persisting your RAM contents, the RAM disk contents will be lost at each power-off. However, the RAM disk is an excellent choice for storing temporary files because it is very fast. You will notice that the first time an operating system is started after the power was turned off, you will see a message indicating that the RAM disk is being formatted. If you reset your system without turning off power, the RAM disk will not be reformatted and it's contents will still be intact.

Like the RAM disk, the ROM disk also provides a small CP/M filesystem, but it's contents are static – they are part of the ROM. As such, you cannot save files to the ROM disk. Any attempt to do this will result in a disk I/O error. The contents of the ROM disk have been chosen to provide a core set of tools and applications that are helpful for either CP/M 2.2 or ZSDOS. Since ZSDOS is CP/M 2.2 compatible, this works fairly well. However, you will find some files on the ROM disk that will work with ZSDOS, but will not work on CP/M 2.2. For example, LDDS, which loads the ZSDOS date/time stamper will only run under ZSDOS.

Unlike other types of disk devices, ROM and RAM Disks do not contain an actual operating system and are not “bootable”. However, they are accessible to any operating system (whether the operating system is loaded from ROM or a different disk device).

Neither RAM nor ROM disks require explicit formatting or initialization. ROM disks are pre-formatted and RAM disks are formatted automatically with an empty directory when first used.

Flash ROM Disks

The limitation of ROM disks being read only can be overcome on some platforms with the appropriate selection of Flash ROM chip and system configuration. In this case the flash-file system can be enabled which will allow the ROM disk to be read and written to. Flash devices have a limited write lifespan and continual usage will eventually wear out the device. It is not suited for high usage applications. Enabling ROM disk writing requires building a custom ROM.

4.3 Floppy Disks

If your system has the appropriate hardware, RomWBW will support the use of floppy disks. The supported floppy disk formats are generally derived from the IBM PC floppy disk formats:

- 5.25" 360K Double-sided, Double-density
- 5.25" 1.2M Double-sided, High-density
- 3.5" 720K Double-sided, Double-density
- 3.5" 1.44M Double-sided, High-density

When supported, RomWBW is normally configured for 2 3.5" floppy drives. If a high-density drive is used, then RomWBW automatically detects and adapts to double-density or high-density media. It cannot automatically detect 3.5" vs. 5.25" drive types – the ROM must be pre-configured for the drive type.

Floppy media must be physically formatted before it can be used. This is normally accomplished by using the supplied Floppy Disk Utility (FDU) application. This application interacts directly with your hardware and therefore you must specify your floppy interface hardware at startup. Additionally, you need to specify the floppy drive and media format to use for formatting.

Below is a sample session using FDU to format a 1.44M floppy disk in the first (primary) floppy disk drive:

```
B>fdu
```

```
Floppy Disk Utility (FDU) v5.8, 26-Jul-2021 [HBIOS]  
Copyright (C) 2021, Wayne Warthen, GNU GPL v3
```

```
SELECT FLOPPY DISK CONTROLLER:
```

- (A) Disk IO ECB Board
- (B) Disk IO 3 ECB Board
- (C) Zeta SBC Onboard FDC
- (D) Zeta 2 SBC Onboard FDC
- (E) Dual IDE ECB Board
- (F) N8 Onboard FDC
- (G) RC2014 SMC (SMB)
- (H) RC2014 WDC (SMB)
- (I) SmallZ80 Expansion
- (J) Dyno-Card FDC, D1030
- (K) RC2014 EPFDC
- (L) Multi-Board Computer FDC

```

(X) Exit
=== OPTION ===> D-IDE

===== D-IDE =====<< FDU MAIN MENU >>=====
(S)ETUP: UNIT=00  MEDIA=720KB DS/DD  MODE=POLL  TRACE=00
-----
(R)EAD          (W)RITE          (F)ORMAT          (V)ERIFY
(I)NIT BUFFER  (D)UMP BUFFER  FDC (C)MDS  E(X)IT
=== OPTION ===> SETUP
ENTER UNIT [00-03] (00):
00: 3.5" 720KB - 9 SECTORS, 2 SIDES, 80 TRACKS, DOUBLE DENSITY
01: 3.5" 1.44MB - 18 SECTORS, 2 SIDES, 80 TRACKS, HIGH DENSITY
02: 5.25" 320KB - 8 SECTORS, 2 SIDES, 40 TRACKS, DOUBLE DENSITY
03: 5.25" 360KB - 9 SECTORS, 2 SIDES, 40 TRACKS, DOUBLE DENSITY
04: 5.25" 1.2MB - 15 SECTORS, 2 SIDES, 80 TRACKS, HIGH DENSITY
05: 8" 1.11MB - 15 SECTORS, 2 SIDES, 77 TRACKS, DOUBLE DENSITY
06: 5.25" 160KB - 8 SECTORS, 1 SIDE, 40 TRACKS, DOUBLE DENSITY
07: 5.25" 180KB - 9 SECTORS, 1 SIDE, 40 TRACKS, DOUBLE DENSITY
08: 5.25" 320KB - 8 SECTORS, 1 SIDE, 80 TRACKS, DOUBLE DENSITY
09: 5.25" 360KB - 9 SECTORS, 1 SIDE, 80 TRACKS, DOUBLE DENSITY
ENTER MEDIA [00-09] (00): 01
00: POLLING (RECOMMENDED)
01: INTERRUPT (!!! READ MANUAL !!!)
02: FAST INTERRUPT (!!! READ MANUAL !!!)
03: INT/WAIT (!!! READ MANUAL !!!)
04: DRQ/WAIT (!!! NOT YET IMPLEMENTED!!!)
ENTER MODE [00-04] (00):
ENTER TRACE LEVEL [00-01] (00):

===== D-IDE =====<< FDU MAIN MENU >>=====
(S)ETUP: UNIT=00  MEDIA=1.44MB DS/HD  MODE=POLL  TRACE=00
-----
(R)EAD          (W)RITE          (F)ORMAT          (V)ERIFY
(I)NIT BUFFER  (D)UMP BUFFER  FDC (C)MDS  E(X)IT
=== OPTION ===> FORMAT (T)RACK, (D)ISK ===> DISK
ENTER INTERLEAVE [01-12] (02):

```

RESET DRIVE...

PROGRESS: TRACK=4F HEAD=01 SECTOR=01

```
===== D-IDE =====<< FDU MAIN MENU >>=====
(S)ETUP: UNIT=00  MEDIA=1.44MB DS/HD  MODE=POLL  TRACE=00
-----
(R)EAD          (W)RITE          (F)ORMAT          (V)ERIFY
(I)NIT BUFFER  (D)UMP BUFFER  FDC (C)MDS          E(X)IT
=== OPTION ===> EXIT
```

Since the physical format of floppy media is the same as that used in a standard MS-DOS/Windows computer, you can also physically format floppy media in a modern computer. However, the directory format itself will not be compatible with CP/M OSes. In this case, you can use the CLRDIR application supplied with RomWBW to reformat the directory area.

Once a floppy disk is formatted, you can read/write files on it using any of the RomWBW operating systems. The specific commands will depend on the operating system or application in use – refer to the appropriate OS/application documentation as needed.

WARNING: Some of the operating systems provided with RomWBW require that a soft-reset be performed when swapping floppy disk media. For example, under CP/M 2.2, you must press control-C at the CP/M prompt after inserting a new floppy disk.

4.4 Hard Disks

Under RomWBW, a hard disk is similar to a floppy disk in that it is considered a disk unit. However, RomWBW has multiple features that allow its legacy operating systems to take advantage of modern mass storage media.

To start with, the concept of a hard disk in RomWBW applies to any storage device that provides at least 8MB of space. The actual media can be a real spinning hard disk, a CompactFlash Card, a SD Card, etc. In this document, the term hard disk will apply equally to all of these.

RomWBW uses Logical Block Addressing (LBA) to interact with all hard disks. The RomWBW operating systems use older Cylinder/Head/Sector (CHS) addressing. To accommodate the operating systems, RomWBW emulates CHS addressing. Specifically, it makes all hard disks look like they have 16 sectors and 16 heads. The number of tracks varies with the size of the physical hard disk.

It is recommended that hard disk media used with RomWBW be 1GB or greater in capacity. The reasons for this are discussed later, but it allows you to use the recommended disk layout for RomWBW that accommodates 64 CP/M filesystem slices and a 384KB FAT filesystem.

Although we have not yet discussed how to get content on your disk units, it is necessary to have a basic understanding of how RomWBW handles disk devices as background. The following sections explain how disk units are managed within the operating systems. We will subsequently discuss how to actually setup disk devices with usable content.

4.5 Slices

The vintage operating systems included with RomWBW were produced at a time when mass storage devices were quite small. CP/M 2.2 could only handle filesystems up to 8MB. In order to achieve compatibility across all of the operating systems supported by RomWBW, the hard disk filesystem format used is 8MB. This ensures any filesystem will be accessible to any of the operating systems.

Since storage devices today are quite large, RomWBW implements a mechanism called slicing to allow up to 256 8MB filesystems on a single large storage device. This allows up to 2GB of usable space on one media. You can think of slices as a way to refer to any of the first 256 8MB chunks of space on a single media.

Note that although you can use up to 256 slices per physical disk, this large number of slices is rarely used. The recommended RomWBW disk layout provides for 64 slices which is more than enough for most use cases.

Of course, the problem is that CP/M-like operating systems have only 16 drive letters (A:-P:) available. Under the covers, RomWBW allows you to use any drive letter to refer to any slice of any media. The ASSIGN command is used to view or change the current drive letter mappings at any time. At startup, the operating system will automatically allocate a reasonable number of drive letters to the available storage devices. The allocation will depend on the number of mass storage devices available at boot. For example, if you have only one hard disk type media, you will see that 8 drive letters are assigned to the first 8 slices of that media. If you have two large storage devices, you will see that each device is allocated four drive letters.

Referring to slices within a storage device is done by appending a : where is the device relative slice number from 0-255. For example, if you have an IDE device, it will show up as IDE0: in the boot messages meaning the first IDE device. To refer to the fourth slice of IDE0, you would type "IDE0:3". Here are some examples:

```
IDE0:0   First slice of disk in IDE0
IDE0:    First slice of disk in IDE0
```

IDE0:3 Fourth slice of disk in IDE0

So, if you wanted to use drive letter L: to refer to the fourth slice of IDE0, you could use the command `ASSIGN L:=IDE0:3`. There are a couple of rules to be aware of when assigning drive letters. First, you may only refer to a specific device/slice with one drive letter at a time. Said another way, you cannot have multiple drive letters referring to a the same device/slice at the same time. Second, there must always be a drive assigned to A:. Any attempt to violate these rules will be blocked by the `ASSIGN` command.

In case this wasn't already clear, you **cannot** refer directly to slices using CP/M. CP/M only understands drive letters, so to access a given slice, you must assign a drive letter to it first.

While it may be obvious, you cannot use slices on any media less than 8MB in size. Specifically, you cannot slice RAM disks, ROM disks, floppy disks, etc. All of these are considered to have a single slice and any attempt to `ASSIGN` a drive letter to a slice beyond that will result in an error message.

It is very important to understand that RomWBW slices are not individually created or allocated on your hard disk. RomWBW uses a single, large chunk of space on your hard disk to contain the slices. You should think of slices as just an index into a sequential set of 8MB areas that exist in this large chunk of space. The next section will go into more detail on how slices are located on your hard disk.

Although you do not need to allocate slices individually, you do need to initialize each slice for CP/M to use it. This is somewhat analogous to doing a `FORMAT` operation on other systems. With RomWBW you use the `CLRDIR` command to do this. This command is merely "clearing out" the directory space of the slice referred to by a drive letter and setting up the new empty directory. Since `CLRDIR` works on drive letters, make absolutely sure you know what media and slice are assigned to that drive letter before using `CLRDIR` because `CLRDIR` will wipe out any pre-existing contents of the slice.

Here is an example of using `CLRDIR`. In this example, the `ASSIGN` command is used to show the current drive letter assignments. Then the `CLRDIR` command is used to initialize the directory of drive 'G' which is slice 2 of hard disk device IDE0 ("IDE0:2").

```
B>assign
```

```
A:=MD0:0
B:=MD1:0
C:=FD0:0
D:=FD1:0
```

```
E:=IDE0:0  
F:=IDE0:1  
G:=IDE0:2  
H:=IDE0:3
```

```
B>clrdi G:
```

```
CLRDIR Version 1.2 April 2020 by Max Scane
```

```
Warning - this utility will overwrite the directory sectors of Drive: G  
Type Y to proceed, any key other key to exit. Y  
Directory cleared.  
B>
```

4.6 Hard Disk Layouts

As previously discussed, when RomWBW uses a hard disk, it utilizes a chunk of space for a sequential series of slices that contain the actual CP/M filesystems referred to by drive letters.

Originally, RomWBW always used the very start of the hard disk media for the location of the slices. In this layout, slice 0 referred to the first chunk of ~8MB on the disk, slice 1 referred to the second chunk of ~8MB on the disk, and so on. The number of slices is limited to the size of the disk media – if you attempted to read/write to a slice that would exceed the disk size, you would see I/O errors. This is considered the “legacy” disk layout for RomWBW.

RomWBW has subsequently been enhanced to support the concept of partitioning. The partition mechanism is entirely compliant with Master Boot Record (MBR) Partition Tables introduced by IBM for the PC. The Wikipedia article on the [Master Boot Record](#) is excellent if you are not familiar with them. This is considered the “modern” disk layout for RomWBW. RomWBW uses the partition type id 0x2E. RomWBW does not support extended partitions – only a single primary partition can be used.

Both the legacy and modern disk layouts continue to be fully supported by RomWBW. There are no plans to deprecate the legacy layout. In fact, the legacy format takes steps to allow a partition table to still be used for other types of filesystems such as DOS/FAT. It just does not use a partition table entry to determine the start of the RomWBW slices.

There is one more difference between the legacy and modern disk layouts that should be highlighted. The CP/M filesystem in the slices of the legacy disk layout contain 512 directory entries. The modern disk layout filesystems provide 1024 directory entries. In fact, you will subsequently see that the prefixes “hd512” and “hd1k” are used to identify disk images appropriate for the legacy and modern format.

You **cannot** mix disk layouts on a single disk device. To say it another way, the existence of a partition table entry for RomWBW on a hard disk makes it behave in the modern mode. The lack of a RomWBW partition table entry will cause legacy behavior. Adding a partition table entry on an existing legacy RomWBW hard disk will cause the existing data to be unavailable and/or corrupted. Likewise, removing the RomWBW partition entry from a modern hard disk layout will cause the same problems. It is perfectly fine for one system to have multiple hard disks with different layouts – each physical disk device is handled separately.

If you are setting up a new disk, the modern (hd1k) layout is recommended for the following reasons:

- Larger number of directory entries per filesystem
- Simplifies creation of coresident FAT filesystem
- Reduces chances of data corruption

4.6.1 Checking Hard Disk Layout

If you are not sure which hard disk layout was used for your existing media, you can use the CP/M STAT command to determine this. This command displays the number of directory entries on a filesystem. If it indicates 512, your disk layout is legacy (hd512). If it indicates 1024, your disk layout is modern (hd1k).

Here is an example of checking the disk layout. We want to check the CompactFlash Card inserted in IDE interface 0. We start the system and boot to Z-System in ROM by using the 'Z' command at the Boot Loader. As Z-System starts, we see the following disk assignments:

```
Boot [H=Help]: z
```

```
Loading Z-System...
```

```
CBIOS v3.1.1-pre.194 [WBW]
```

```
Configuring Drives...
```

```
A:=MD0:0
B:=MD1:0
C:=FD0:0
D:=FD1:0
E:=IDE0:0
F:=IDE0:1
G:=IDE0:2
H:=IDE0:3
```

```
I:=PRPSD0:0  
J:=PRPSD0:1  
K:=PRPSD0:2  
L:=PRPSD0:3
```

```
1081 Disk Buffer Bytes Free
```

```
ZSDOS v1.1, 54.0K TPA
```

You can see that the IDE0 interface (which contains the CF Card) has been assigned to drive letters E: to H:. We can use the STAT command on any of these drive letters. So, for example:

```
B>stat e:dsk:
```

```
    E: Drive Characteristics  
65408: 128 Byte Record Capacity  
    8176: Kilobyte Drive Capacity  
    1024: 32 Byte Directory Entries  
        0: Checked Directory Entries  
    256: Records/ Extent  
     32: Records/ Block  
    64: Sectors/ Track  
     2: Reserved Tracks
```

It is critical that you include "dsk:" after the drive letter in the STAT command line. The important line to look at is labeled "32 Byte Directory Entries". In this case, the value is 1024 which implies that this drive is located on a modern (hd1k) disk layout. If the value was 512, it would indicate a legacy (hd512) disk layout.

Chapter 5

Disk Content Preparation

With some understanding of how RomWBW presents disk space to the operating systems, we need to go over the options for actually setting up your disk(s) with content.

Since it would be quite a bit of work to transfer over all the files you might want initially to your disk(s), RomWBW provides a much easier way to get initial contents on your disks. You can use your modern Windows, Linux, or Mac computer to copy a disk image onto the disk media, then just move the media over to your RomWBW computer. RomWBW comes with a variety of disk images that are ready to use and have a much more complete set of files than you will find on the ROM disk. This process is covered below under [Disk Images](#).

If you do not want to start with pre-built disk images, you can alternatively initialize the media in-place using your RomWBW system. Essentially, this means you are creating a set of blank directories on your disk so that files can be saved there. This process is described below under Disk Initialization. In this scenario, you will need to subsequently copy any files you want to use onto the newly initialized disk (see Transferring Files).

You will notice that in the following instructions there is no mention of specific hardware. Because the RomWBW firmware provides a hardware abstraction layer, all disk images will work on all hardware variations. Yes, this means you can remove an CF/SD Card from one RomWBW system and put it in a different RomWBW system. The only constraint is that the applications on the disk media must be up to date with the firmware on the system being used.

5.1 Disk Images

As mentioned previously, RomWBW includes a variety of disk images that contain a full set of applications for the operating systems supported. It is generally easier to use these disk

images than transferring your files over individually. You use your modern computer (Windows, Linux, MacOS) to write the disk image onto the disk media, then just move the media over to your system.

The disk image files are found in the Binary directory of the distribution. Floppy disk images are prefixed with “fd_” and hard disk images are prefixed with either “hd512_” or “hd1k_” depending on the hard disk layout they are for.

Each disk image has the complete set of normal applications and tools distributed with the associated operating system or application suite. The following table shows the disk images available.

Disk Image	Description	Boot
xxx_cpm22.img	DRI CP/M 2.2 Operating System	Yes
xxx_zsdos.img	ZCPR-DJ & ZSDOS 1.1 Operating System	Yes
xxx_nzcom.img	NZCOM ZCPR 3.4 Operating System	Yes
xxx_cpm3.img	DRI CP/M 3 Operating System	Yes
xxx_zpm3.img	ZPM3 Operating System	Yes
xxx_qpm.img	QPM Operating System	Yes
xxx_ws4.img	WordStar v4 & ZDE Applications	No

You will find 3 sets of these .img files in the distribution. The “xxx” portion of the filename will be “fd_” for a floppy image, “hd512” for a legacy layout hard disk image, and “hd1K” for a modern layout hard disk image.

There is also an image file called “psys.img” which contains a bootable p-System hard disk image. It contains 6 p-System filesystem slices, but these are not interoperable with the CP/M slices described above. This file is discussed separately under p-System in the Operating Systems section.

5.1.1 Floppy Disk Images

The floppy disk images are all intended to be used with 3.5” high-density, double-sided 1.44 MB floppy disk media. This is ideal for the default floppy drive support included in RomWBW standard ROMs.

For floppy disks, the .img file is written directly to the floppy media as is. The floppy .img files are 1.44 MB which is the exact size of a single 3.5” high density floppy disk. You will need a floppy disk drive of the same type connected to your modern computer to write this image. Although modern computers do not come equipped with a floppy drive, you can still find USB floppy drives that work well for this.

The floppy disk must be physically formatted **before** writing the image onto it. You can do this with RomWBW using FDU as described in the [Floppy Disks](#) section of this document. You can also format the floppy using your modern computer, but using FDU on RomWBW is preferable because it will allow you to use optimal physical sector interleaving.

RomWBW includes a Windows application called RawWriteWin in the Tools directory of the distribution. This simple application will let you choose a file and write it to an attached floppy drive. For Linux/MacOS, I think you can use the dd command (but I have not actually tried this). It is probably obvious, but writing an image to a floppy disk will overwrite and destroy all previous contents.

Once the image has been written to the floppy disk, you can insert the floppy disk in your RomWBW floppy disk and read/write files on it according to the specific operating system instructions. If the image is bootable, then you will be able to boot from it by entering the floppy drive's corresponding unit number at the RomWBW Boot Loader command prompt.

5.1.2 Hard Disk Images

Keeping in mind that a RomWBW hard disk (including CF /SD Cards) allows you to have multiple slices (CP/M filesystems), there are a couple ways to image hard disk media. The easiest approach is to use the "combo" disk image. This image is already prepared with 6 slices containing 5 ready-to-run OSes and a slice with the WordStar application. Alternatively, you can create your own hard disk image with the specific slice contents you choose.

Combo Hard Disk Image

The combo disk image is essentially just a single image that has several of the individual filesystem images already concatenated together. The combo disk image contains the following 6 slices in the positions indicated:

Slice	Description
Slice 0	DRI CP/M 2.2 Operating System
Slice 1	ZCPR-DJ & ZSDOS 1.1 Operating System
Slice 2	NZCOM ZCPR 3.4 Operating System
Slice 3	DRI CP/M 3 Operating System
Slice 4	ZPM3 Operating System
Slice 5	WordStar v4 & ZDE Applications

You will notice that there are actually 2 combo disk images in the distribution. One for an hd512 disk layout (hd512_combo.img) and one for an hd1k disk layout (hd1k_combo.img).

Simply use the image file that corresponds to your desired hard disk layout.

Custom Hard Disk Image

If you want to use specific slices in a specific order, you can easily generate a custom hard disk image file.

For hard disks, each .img file represents a single slice (CP/M filesystem). Since a hard disk can contain many slices, you can just concatenate the slices (.img files) together to create your desired hard disk image. For example, if you want to create a hard disk image that has slices for CP/M 2.2, CP/M 3, and WordStar in the hd512 format, you would use the command line of your modern computer to create the final image:

Windows:

```
COPY /B hd512_cpm22.img + hd512_cpm3.img + hd512_ws hd.img
```

Linux/MacOS:

```
cat hd512_cpm22.img hd512_cpm3.img hd512_ws >hd.img
```

NOTE: For the hd1k disk layout, you **must** prepend the prefix file called hd1k_prefix.dat which contains the required partition table. So, for an hd1k layout you would use the following:

Windows:

```
COPY /B hd1k_prefix.dat + hd1k_cpm22.img + hd1k_cpm3.img + hd1k_ws hd.img
```

Linux/MacOS:

```
cat hd1k_prefix.dat hd1k_cpm22.img hd1k_cpm3.img hd1k_ws >hd.img
```

In all of the examples above, the resulting file (hd.img) would now be written to your hard disk media and would be ready to use in a RomWBW system.

Writing Hard Disk Images

Once you have chosen a combo hard disk image file or prepared your own custom hard disk image file, it will need to be written to the media using your modern computer. Note that you **do not** run CLRDIR or SYSCOPY on the slices that contain the data. When using this method, the disk will be partitioned and setup with 1 or more slices containing ready-to-run bootable operating systems.

To write a hard disk image file onto your actual media (actual hard disk or CF/SD Card), you need to use an image writing utility on your modern computer. Your modern computer will need to have an appropriate interface or slot that accepts the media. To actually copy the

image, you can use the `dd` command on Linux or MacOS. On Windows, in the “Tools” directory of the distribution, there is an application called Win32DiskImager. In all cases, the image file should be written to the media starting at the very first block or sector of the media.

You are not limited to the number of slices that are contained in the image that you write to your hard disk media. You can use additional slices as long your media has room for them. However, writing the disk image will not initialize the additional slices. If these additional slices were previously initialized, they will not be corrupted when you write the new image and will still contain their previous contents. If the additional slices were not previously initialized, you can use `CLRDIR` to do so and optionally `SYSCOPY` if you want them to be bootable.

To be entirely clear, writing a disk image file to your hard disk media will overwrite an pre-existing partition table and the number of slices that your image file contains. It will not overwrite or corrupt slices beyond those in the image file. As a result, you can use additional slices as a place to maintain your personal data because these slices will survive re-imaging of the media. If you setup a FAT partition on your media, it will also survive the imaging process.

WARNING: In order for your additional slices and/or FAT partition to survive re-imaging, you **must** follow these rules:

- Do not modify the partition table of the media using `FDISK80` or any other partition management tools.
- Ensure that your hard disk image file uses the same disk layout approach (`hd512` or `hd1k`) as previously used on the media.

Once you have copied the image onto the hard disk media, you can move the media over to your RomWBW system. You can then boot to the operating system slices by specifying “.” at the RomWBW Boot Loader command prompt.

5.2 In-situ Disk Preparation

If you do not wish to use the pre-built disk images, it is entirely possible to setup your disks manually and transfer contents to them.

In this scenario, you will initialize the disk media entirely from your RomWBW system. So, you need to start by inserting the disk media, booting RomWBW, and confirming that the media is being recognized. If RomWBW recognizes the media, it will indicate this in the boot messages even though the media has not yet been prepared for use.

The following instructions are one way to proceed. This does not mean to imply it is the only possible way. Also, note that RAM/ROM disk media is prepared automatically. ROM disks are part of the ROM image and RAM disks are initialized when an operating system is started.

Start by booting RomWBW and launching either CP/M 2.2 or Z-System from ROM using the Boot Loader 'C' or 'Z' commands respectively. You can now use the tools on the ROM disk to prepare your disks. Note that you will see the operating system assign disks/slices to drives even though the disks/slices are not yet initialized. This is normal and does not mean the disks/slices are ready to use.

Preparation of floppy disk media is very simple. The floppy disk must be physically formatted as discussed in [Floppy Disks](#) previously using FDU. If a floppy is already physically formatted, you can wipe out it's contents (make it empty again) by running CLRDIR on it. You can confirm a floppy disk is ready for content by simply running a DIR command on it. The DIR command should complete without error and should list no files. At this point, you can proceed to copy files to the floppy disk and (optionally) make the floppy bootable using SYSCOPY.

The rest of this section will cover preparation of hard disk media. To start, it is critical that you decide which disk layout approach to use (either hd512 or hd1k). Review the [Hard Disk Layouts](#) section if you are not sure.

Partition Setup

Since the disk layout is determined by the existence (or lack) of a RomWBW partition, you must start by running FDISK80. When FDISK80 starts, enter the disk unit number of the new media. At this point, use the 'I' command to initialize (reset) the partition table to an empty state. If you are going to use the hd512 layout, then use 'W' to write the empty table to the disk and exit. Remember that the lack of a partition for RomWBW implies the legacy (hd512) layout.

If you are going to use an hd1k layout, then you must create a partition for the RomWBW CP/M slices. The partition can be placed anywhere you want and can be any size ≥ 8 MB. Keeping the size of the partition to increments of 8MB makes sense. The partition type **must** be set to '2e'. The typical location for the RomWBW partition is at 1MB with a size of 512MB (64 slices). Below is an example of creating a RomWBW partition following these guidelines.

```
FDISK80 for RomWBW, UNA, Mini-M68k, KISS-68030, SBC-188  ----
Version 1.1-22 created 7-May-2020
(Running under RomWBW HBIOS)
```

```
HBIOS unit number [0..11]: 4
Capacity of disk 4: ( 4G) 7813120      Geom 77381010
Nr  ---Type-  A  --      Start          End      LBA start  LBA count  Size
 1          00      *** empty ***
 2          00      *** empty ***
 3          00      *** empty ***
```



```

4          00          *** empty ***
>>i
>>n
New partition number: 1
Starting Cylinder (default 0): 1Mb
Ending Cylinder (or Size= "+nnn"): +512Mb
>>t
Change type of partition number: 1
New type (in hex), "L" lists types: 2e
>>p
Nr  ---Type-  A  --      Start          End      LBA start  LBA count  Size
1   RomWBW   2e      8:0:1  1023:15:16      2048      1048576  512M
2           00      *** empty ***
3           00      *** empty ***
4           00      *** empty ***
>>w
Do you really want to write to disk? [N/y]: y
Okay
FDISK exit.

```

At this point, it is best to restart your system to make sure that the operating system is aware of the partition table updates. Start CP/M 2.2 or Z-System from ROM again.

You are now ready to initialize the individual slices of your hard disk media. On RomWBW, slice initialization is done using the CLRDIR application. Since the CLRDIR application works on OS drive letters, you must pay attention to how the OS drive letters are mapped to your disk devices which is listed when the OS starts. Let's assume that C: has been assigned to slice 0 of the disk you are initializing. You would use CLRDIR C: to initialize C: and prepare it hold files. Note that CLRDIR will prompt you for confirmation and you must respond with a **capital 'Y'** to confirm.

After CLRDIR completes, the slice should be ready to use by the operating system via the drive letter assigned. Start by using the DIR command on the drive (DIR C:). This should return without error, but list no files. Next, use the STAT command to confirm that the disk is using the layout you intended. For example, use STAT C:DSK: and look at the number of "32 Byte Directory Entries". It should say 512 for a legacy (hd512) disk layout and 1024 for a modern (hd1024) disk layout.

Assuming you want to use additional slices, you should initialize them using the same process. You may need to reassign OS drive letters to access some slices that are beyond the ones automatically assigned. You can use the ASSIGN command to handle this.

Once you have your slice(s) initialized, you can begin transferring files to the associated drive letters. Refer to the [Transferring Files](#) section for options to do this. If you want to make a slice bootable, you will need to use SYSCOPY to setup the system track(s) of the slice. The use of SYSCOPY depends on the operating system and is described in the [Operating Systems](#) section of this document.

As an example, let's assume you want to setup C: as a bootable Z-System disk and add to it all the files from the ROM disk. To setup the system track you would use:

```
B>SYSCOPY C:=B:ZSYS.SYS
```

```
SYSCOPY v2.0 for RomWBW CP/M, 17-Feb-2020 (CP/M 2 Mode)
Copyright 2020, Wayne Warthen, GNU GPL v3
```

```
Transfer system image from B:ZSYS.SYS to C: (Y/N)? Y
Reading image... Writing image... Done
```

Then, to copy all of the files from the ROM disk to C:, you could use the COPY command as shown below. In this example, the list of files being copied has been truncated.

```
B>copy *.* m:
COPY Version 1.73 (for ZSDOS) 2 Jul 2001
Copying B0:?????????.??? to M0:
-> ASM      .COM..0k  Verify..0k
-> ASSIGN   .COM..0k  Verify..0k
-> CLRDIR   .COM..0k  Verify..0k
-> COMPARE  .COM..0k  Verify..0k
-> COPY     .COM..0k  Verify..0k
-> CPM      .SYS..0k  Verify..0k
0 Errors
```

Once this process succeeds, you will be able to boot directly to the disk slice from the boot loader prompt. See the instructions in [Starting Operating Systems from Disk](#) for details on this.

Chapter 6

Operating Systems

One of the primary goals of RomWBW is to expose a set of generic hardware functions that make it easy to adapt operating systems to any hardware supported by RomWBW. As a result, there are now 8 operating systems that have been adapted to run under RomWBW. The adaptations are identical for all hardware supported by RomWBW because RomWBW hides all hardware specifics from the operating system.

By design, the operating systems provided with RomWBW are original and unmodified from their original distribution. Patches published by the authors are generally included or applied. The various enhancements RomWBW provides (such as hard disk slices) are implemented entirely within the system adaptation component of each operating system (e.g., CP/M CBIOS). As a result, each operating system should function exactly as documented by the authors and retain maximum compatibility with original applications.

Note that all of the operating systems included with RomWBW support the same basic filesystem format from DRI CP/M 2.2 (except for p-System). As a result, a formatted filesystem will be accessible to any operating system. The only possible issue is that if you turn on date/time stamping using the newer OSes, the older OSes will not understand this. Files will not be corrupted, but the date/time stamps will not be maintained.

The following sections briefly describe the operating system options currently available and brief operating notes.

6.1 Digital Research CP/M 2.2

This is the most widely used variant of the Digital Research operating systems. It has the most basic feature set, but is essentially the compatibility metric for all other CP/M-like operating

systems including those listed below.

If you are new to the CP/M world, I would recommend using this CP/M variant to start with simply because it is the most stable and you are less likely to encounter compatibility issues.

Documentation

- [CPM Manual](#)

Boot Disk

To make make a bootable CP/M disk, use the RomWBW SYSCOPY tool to place a copy of the operating system on the boot track of the disk. The RomWBW ROM disk has a copy of the boot track call "CPM.SYS". For example:

```
SYSCOPY C:=B:CPM.SYS
```

Notes

- You can change media, but it must be done while at the OS command prompt and you **must** warm start CP/M by pressing ctrl-C. This is a CP/M 2.2 constraint and is well documented in the DRI manual.
- SUBMIT.COM has been patched per DRI to always place submit files on A:. This ensures the submitted file will always be properly executed.
- The original versions of DDT, DDTZ, and ZSID used the RST 38 vector which conflicts with interrupt mode 1 use of this vector. The DDT, DDTZ, and ZSID applications in RomWBW have been modified to use RST 30 to avoid this issue.
- Z-System applications will not run under CP/M 2.2. For example, the LDDS date stamper will not work.

6.2 Z-System

Z-System is the most popular non-DRI CP/M workalike "clone" which is generally referred to as Z-System. Z-System is intended to be an enhanced version of CP/M and should run all CP/M 2.2 applications. It is optimized for the Z80 CPU (as opposed to 8080 for CP/M) and has some significant improvements such as date/time stamping of files.

Z-System is a somewhat ambiguous term because there are multiple generations of this software. RomWBW Z-System is a combination of both ZCPR-DJ (the CCP) and ZSDOS 1.1 (the BDOS) when referring to Z-System.

The latest version of Z-System (ZCPR 3.4) is also provided with RomWBW via the NZ-COM adaptation (see below).

Documentation

- [ZCPR Manual](#)
- [ZCPR-DJ](#)
- [ZSDOS Manual](#)

Boot Disk

To make make a bootable Z-System disk, use the RomWBW SYSCOPY tool to place a copy of the operating system on the boot track of the disk. The RomWBW ROM disk has a copy of the boot track call "ZSYS.SYS". For example:

```
SYSCOPY C:=B:ZSYS.SYS
```

Notes

- Although most CP/M 2.2 applications will run under Z-System, some may not work as expected. The best example is PIP which is not aware of the ZSDOS paths and will fail in some scenarios (use COPY instead).
- Although ZSDOS can recognize a media change in some cases, it will not always work. You should only change media at a command prompt and be sure to warm start the OS with a ctrl-C.
- ZSDOS has a concept of fast relog of drives. This means that after a warm start, it avoids the overhead of relogging all the disk drives. There are times when this causes issues. After using tools like CLRDIRE or MAP, you may need to run "RELOG" to get the drive properly recognized by ZSDOS.
- RomWBW fully supports both DateStamper and P2DOS file date/time stamping. You must load the desired stamping module (LDDS for DateStamper or LDP2D for P2DOS). This could be automated using a PROFILE.SUB file. Follow the ZSDOS documentation to initialize a disk for stamping.
- ZSVSTAMP expects to be running under the ZCPR 3.X command processor. By default, RomWBW uses ZCPR 1.0 (intentionally, to reduce space usage) and ZSVSTAMP will just abort in this case. It will work fine if you implement NZCOM. ZSVSTAMP is included solely to facilitate usage if/when you install NZCOM.
- FILEDATE only works with DateStamper style date stamping. If you run it on a drive that is not initialized for DateStamper, it will complain FILEDATE, !!!TIME&.DAT missing.

This is normal and just means that you have not initialized that drive for DateStamper (using PUTDS).

- ZXD will handle either DateStamper or P2DOS type date stamping. However, it **must** be configured appropriately. As distributed, it will look for P2DOS date stamps. Use ZCNFG to reconfigure it for P2DOS if that is what you are using.
- Many of the tools can be configured (using either ZCNFG or DSCONFIG). The configuration process modifies the actual application file itself. This will fail if you try to modify one that is on the ROM disk because it will not be able to update the image.
- DATSWEEP can be configured using DSCONFIG. However, DSCONFIG itself needs to be configured first for proper terminal emulation by using SETTERM. So, run SETTERM on DSCONFIG before using DSCONFIG to configure DATSWEEP!
- After using PUTDS to initialize a directory for ZDS date stamping, I am finding that it is necessary to run RELOG before the stamping routines will actually start working.
- Generic CP/M PIP and ZSDOS path searching do not mix well if you use PIP to copy to or from a directory in the ZSDOS search path. Best to use COPY from the ZSDOS distribution.

6.3 NZCOM Automatic Z-System

NZCOM is a much further refined version of Z-System (ZCPR 3.4). NZCOM was sold as an enhancement for existing users of CP/M 2.2 or ZSDOS. For this reason, (by design) NZCOM does not provide a way to boot directly from disk. Rather, it is loaded after the system boots into a host OS. On the RomWBW NZCOM disk images, the boot OS is ZSDOS 1.1. A PROFILE.SUB file is included which automatically launches NZCOM as soon as ZSDOS loads.

NZCOM is highly configurable. The RomWBW distribution has been configured in the most basic way possible. You should refer to the documentation and use MKZCM as desired to customize your system.

NZCOM has substantially more functionality than CP/M or basic Z-System. It is important to read the the "NZCOM Users Manual.pdf" document in order to use this operating system effectively.

Documentation

- [NZCOM Users Manual](#)

Boot Disk

Since NZ-COM boots via Z-System, you can make a bootable NZ-COM disk using ZSYS.SYS as described in [Z-System](#) above. You will need to add a PROFILE.SUB file to auto-start NZ-COM itself.

Notes

- All of the notes for [Z-System](#) above generally apply to NZCOM.
- There is no DIR command, you must use SDZ instead. If you don't like this, look into the ALIAS facility.

6.4 Digital Research CP/M 3

This is the Digital Research follow-up product to their very popular CP/M 2.2 operating system. While highly compatible with CP/M 2.2, it features many enhancements and is not 100% compatible. It makes direct use of banked memory to increase the user program space (TPA). It also has a new suite of support tools and help system.

Documentation

- [CPM3 Users Guide](#)
- [CPM3 Command Summary](#)
- [CPM3 Programmers Guide](#)
- [CPM3 System Guide](#)

Boot Disk

To make a CP/M 3 boot disk, you actually place CPMLDR.SYS on the system tracks of the disk. You do not place CPM3.SYS on the system tracks. CPMLDR.SYS chain loads CPM3.SYS which must exist as a file on the disk.

CP/M 3 uses a multi-step boot process involving multiple files. The CP/M 3 boot files are not included on the ROM disk due to space constraints. You will need to transfer the files to your system from the RomWBW distribution directory Binary\CPM3.

After this is done, you will need to use SYSCOPY to place the CP/M 3 loader image on the boot tracks of all CP/M 3 boot disks/slices. The loader image is called CPMLDR.SYS. You must then copy (at a minimum) CPM3.SYS and CCP.COM onto the disk/slice. Assuming you copied the CP/M 3 boot files onto your RAM disk at A:, you would use:

```
SYSCOPY C:=CPMLDR.SYS  
PIP C:=CPM3.SYS  
PIP C:=CCP.COM
```

Notes

- The COPYSYS command described in the DRI CP/M 3 documentation is not provided with RomWBW. The RomWBW SYSCOPY command is used instead.
- Although CP/M 3 is generally able to run CP/M 2.2 programs, this is not universally true. This is especially true of the utility programs included with the operating system. For example, the SUBMIT program of CP/M 3 is completely different/incompatible from the SUBMIT program of CP/M 2.2.
- RomWBW fully supports CP/M 3 file date/time stamping, but this requires that the disk be properly initialized for it. This process has not been performed on the CP/M 3 disk image. Follow the CP/M 3 documentation to complete this process.

6.5 Simeon Cran's ZPM3

ZPM3 is an interesting combination of the features of both CP/M 3 and ZCPR 3. Essentially, it has the features of and compatibility with both.

Documentation

ZPM3 has no real documentation. You are expected to understand both CP/M 3 and ZCPR 3.

Boot Disk

ZPM3 uses a multi-step boot process involving multiple files. The ZPM3 boot files are not included on the ROM disk due to space constraints.

You will need to transfer the files to your system from the RomWBW distribution directory Binary\ZPM3.

After this is done, you will need to use SYSCOPY to place the ZPM3 loader image on the boot tracks of the disk. The loader image is called ZPMLDR.SYS. You must then copy (at a minimum) CPM3.SYS, ZCCP.COM, ZINSTAL.ZPM, and STARTZPM.COM onto the disk/slice. Assuming you copied the ZPM3 boot files onto your RAM disk at A:, you would use:

```
A>B:SYSCOPY C:=ZPMLDR.SYS  
A>B:COPY CPM3.SYS C:  
A>B:COPY ZCCP.COM C:
```



```
A>B: COPY ZINSTALL.ZPM C:
A>B: COPY STARTZPM.COM C:
```

Notes

- The ZPM operating system is contained in the file called CPM3.SYS which is confusing, but this is as intended by the ZPM3 distribution. I believe it was done this way to make it easier for users to transition from CP/M 3 to ZPM3.

6.6 QP/M

QP/M is another OS providing compatibility with and enhancements to CP/M 2.2. It is provided as a bootable disk image for RomWBW.

Refer to the ReadMe.txt file in Source/Images/d_qpm for more details regarding the RomWBW adaptation and customizations.

Documentation

- [QP/M 2.7 Installation Guide and Supplements](#)
- [QP/M 2.7 Interface Guide](#)
- [QP/M 2.7 Features and Facilities](#)

Boot Disk

There is no RomWBW-specific boot disk creation procedure. QP/M comes with a QINSTALL tool for this purpose. You can use the tool if you want to perform a fresh installation.

Notes

- QPM is not available as source. This implementation was based on the QPM binary distribution and has been minimally customized for RomWBW.
- QINSTALL is used to customize QPM. It is included on the disk image. You should review the notes in the ReadMe.txt file in Source/Image/d_qpm before making changes.

6.7 UCSD p-System

This is a full implementation of the UCSD p-System IV.0 for Z80 running under RomWBW. Unlike the OSes above, p-System uses its own unique filesystem and is not interoperable with other OSes.

It was derived from the p-System Adaptable Z80 System. Unlike some other distributions, this implements a native p-System Z80 Extended BIOS, it does not rely on a CP/M BIOS layer.

The p-System is provided on a hard disk image file called `psys.img`. This must be copied to its own dedicated hard disk media (CF Card, SD Card, etc.). It is booted by selecting slice 0 of the corresponding hard disk unit at the RomWBW Boot Loader prompt. Do not attempt to use CP/M slices on the same disk.

Refer to the `ReadMe.txt` file in `Source/pSys` for more details.

Documentation

- [UCSD p-System Users Manual](#)

Boot Disk

There is no mechanism provided to create a p-System boot disk from scratch under RomWBW. This has already been done as part of the porting process. You must use the provided p-System hard disk image file which is bootable.

Notes

- There is no floppy support at this time.
- The hard disk image contains 6 p-System slices which are assigned to p-System unit numbers 4, 5, 9, 10, 11, and 12 which is standard for p-System. Slices 0-5 are assigned sequentially to these p-System unit numbers and it is not possible to reassign them. Unit #4 (slice 0) is bootable and contains all of the p-System distribution files. Unit #5 (slice 1) is just a blank p-System filesystem. The other units (9-12) have not been initialized, but this can be done from Filer using the Zero command.
- p-System relies heavily on the use of a full screen terminal. This implementation has been setup to expect an ANSI or DEC VT-100 terminal or emulator. The screen output will be garbled if no such terminal or emulator is used for console output.
- There is no straightforward mechanism to move files in and out of p-System. However, the `.vol` files in `Source/pSys` can be read and modified by CiderPress. CiderPress is able to add and remove individual files.

6.8 FreeRTOS

Phillip Stevens has ported FreeRTOS to run under RomWBW. FreeRTOS is not provided in the RomWBW distribution. FreeRTOS is available under the [MIT licence](#) and further general

information is available at [FreeRTOS](#).

You can also contact Phillip for detailed information on the Z180 implementation of FreeRTOS for RomWBW. [feilipu](#)

Chapter 7

Custom Applications

The operation of the RomWBW hosted operating systems is enhanced through several custom applications. You have already read about one of these – the ASSIGN command. These applications are functional on all of the OS variants included with RomWBW.

The applications discussed here are **not** the same as the built-in ROM applications mentioned previously. These applications run as commands within the operating systems provided by RomWBW. So, these commands are only available at an operating system prompt after an operating system has been loaded.

All of the RomWBW Custom Applications are built to function under all of the RomWBW Operating Systems (except for p-System). In general, the applications will automatically adapt as needed to the currently running operating system. One exception is FDU – the Floppy Disk Utility. This application requires that you pick the floppy disk interface you want to interact with.

There is more complete documentation of all of these applications in the related RomWBW manual “[RomWBW Applications](#)” found in the Doc directory of the distribution.

The following custom applications are found on the ROM disk and are, therefore, globally available.

Application	**Description
ASSIGN	Add, change, and delete drive letter assignments. Use ASSIGN /? for usage instructions.
SYSCOPY	Copy system image to a device to make it bootable. Use SYSCOPY with no parms for usage instructions.
MODE	Reconfigures serial ports dynamically.

Application	**Description
FDU	Format and test floppy disks. Menu driven interface.
FORMAT	Will someday be a command line tool to format floppy disks. Currently does nothing!
XM	XModem file transfer program adapted to hardware. Automatically uses primary serial port on system.
FLASH	Will Sowerbutts' in-situ ROM programming utility.
FDISK80	John Coffman's Z80 hard disk partitioning tool. See documentation in Doc directory.
TALK	Direct console I/O to a specified character device.
RTC	Manage and test the Real Time Clock hardware.
TIMER	Display value of running periodic system timer.
CPUSPD	Change the running CPU speed and wait states of the system.

Some custom applications do not fit on the ROM disk. They are found on the disk image files or the individual files can be found in the Binary\Apps directory of the distribution.

Application	Description
TUNE	Play .PT2, .PT3, .MYM audio files.
FAT	Access MS-DOS FAT filesystems from RomWBW (based on FatFs).
INTTEST	Test interrupt vector hooking.

Chapter 8

FAT Filesystem

The FAT filesystem format that originated with MS-DOS has been almost ubiquitous across modern computers. Virtually all operating systems now support reading and writing files to a FAT filesystem. For this reason, RomWBW now has the ability to read and write files on FAT filesystems.

This is accomplished by running a RomWBW custom application called FAT. This application understands both FAT filesystems as well as CP/M filesystems.

- Files can be copied between a FAT filesystem and a CP/M filesystem, but you cannot execute files directly from a FAT filesystem.
- FAT12, FAT16, and FAT32 formats are supported.
- Long filenames are not supported. Files with long filenames will show up with their names truncated into the older 8.3 convention.
- A FAT filesystem can be located on floppy or hard disk media. For hard disk media, the FAT filesystem must be located within a valid FAT partition.

8.1 FAT Filesystem Preparation

In general, you can create media formatted with a FAT filesystem on your RomWBW computer or on your modern computer. We will only be discussing the RomWBW-based approach here.

In the case of a floppy disk, you can use the FAT application to format the floppy disk. For example, if your floppy disk is on RomWBW disk unit 2, you could use `FAT FORMAT 2 :.` This will overwrite the floppy with a FAT filesystem and all previous contents will be lost. Once formatted this way, the floppy disk can be used in a floppy drive attached to a modern computer or it can be used on RomWBW using the other FAT tool commands.

In the case of hard disk media, it is necessary to have a FAT partition. If you prepared your RomWBW hard disk media using the disk image process, then this partition will already be present and you do not need to recreate it. This default FAT partition is located at approximately 512MB from the start of your disk and it is 384MB in size. So, your hard disk media must be 1GB or greater to use this default FAT partition.

You can confirm the existence of the FAT partition with FDISK80 by using the 'P' command to show the current partition table. Here is an example of a partition table listing from FDISK80 that includes the FAT partition (labeled "FAT16"):

```
Capacity of disk 4: ( 4G) 7813120      Geom 77381010
Nr  ---Type-  A  --      Start          End      LBA start  LBA count  Size
 1   RomWBW   2e      8:0:1  1023:15:16      2048    1048576  512M
 2    FAT16   06    1023:0:1  1023:15:16    1050624    786432  384M
 3                00          *** empty ***
 4                00          *** empty ***
```

If your hard disk media does not have a FAT partition already defined, you will need to define one using FDISK80 by using the 'N' command. Ensure that the location and size of the FAT partition does not overlap any of the CP/M slice area and that it fits within the size of your media.

Once the partition is defined, you will still need to format it. Just as with a floppy disk, you use the FAT tool to do this. If your hard disk media is on RomWBW disk unit 4, you would use FAT FORMAT 4:. This will look something like this:

```
E>fat format 4:
```

```
About to format FAT Filesystem on Disk Unit #4.
All existing FAT partition data will be destroyed!!!
```

```
Continue (y/n)?
```

```
Formatting... Done
```

```
Your FAT filesystem is now ready to use.
```

If your RomWBW system has multiple disk drives/slots, you can also just create a disk with your modern computer that is a dedicated FAT filesystem disk. You can use your modern computer to format the disk (floppy, CF Card, SD Card, etc.), then insert the disk in your RomWBW computer and access it using FAT based on its RomWBW unit number.

8.2 FAT Application Usage

Complete instructions for the FAT application are found in [RomWBW Applications](#). Here, we will just provide a couple of simple examples. Note that the FAT application is not on the ROM disk because it is too large to include there.

The most important thing to understand about the FAT application is how it refers to FAT filesystems vs. CP/M filesystems. It infers this based on the file specification provided. If you use a specification like C:SAMPLE.TXT, it will use the C: drive of your CP/M operating system. If you use a specification like 4:SAMPLE.TXT, it will use the FAT filesystem on the disk in RomWBW disk unit 4. Basically, if you start your file or directory specification with a number followed by a colon, it means FAT filesystem. Anything else will mean CP/M filesystem.

Here are a few examples. This first example shows how to get a FAT directory listing from RomWBW disk unit 4:

```
E>fat dir 4:
```

```
Directory of 4:
```

```
E>
```

As you can see, there are currently no files there. Now let's copy a file from CP/M to the FAT directory:

```
E>fat copy sample.txt 4:
```

```
Copying...
```

```
SAMPLE.TXT ==> 4:/SAMPLE.TXT ... [OK]
```

```
1 File(s) Copied
```

If we list the FAT directory again, you will see the file:

```
E>fat dir 4:
```

```
Directory of 4:
```

```
01/30/2023 17:50:14      29952  ---A  SAMPLE.TXT
```

Now let's copy the file from the FAT filesystem back to CP/M. This time we will get a warning about overwriting the file. For this example, we don't want to do that, so we abort and reissue

the command specifying a new filename to use:

```
E>fat copy 4:sample.txt e:
```

Copying...

```
4:/SAMPLE.TXT ==> E:SAMPLE.TXT Overwrite? (Y/N) [Skipped]
```

```
0 File(s) Copied
```

```
E>fat copy 4:sample.txt e:sample2.txt
```

Copying...

```
4:/SAMPLE.TXT ==> E:SAMPLE2.TXT ... [OK]
```

```
1 File(s) Copied
```

Finally, let's try using wildcards:

```
E>fat copy sample*.* 4:
```

Copying...

```
SAMPLE.TXT ==> 4:/SAMPLE.TXT Overwrite? (Y/N) ... [OK]
```

```
SAMPLE2.TXT ==> 4:/SAMPLE2.TXT ... [OK]
```

```
2 File(s) Copiedd
```

Chapter 9

CP/NET Networking

Digital Research created a simple network file sharing system called CP/NET. This allowed a network server running CP/NOS to host files available to network attached CP/M computers. Essentially, the host becomes a simple file sharing server.

RomWBW disk images include an adaptation of the DRI CP/NET client software provided by Douglas Miller. RomWBW does not support operation as a network server itself. However, Douglas has also developed a Java-based implementation of the DRI network server that can be used to provide host services from a modern computer.

Both CP/NET 1.2 and 3.0 clients are provided. Version 1.2 is for use with CP/M 2.2 and compatible OSes. Version 3.0 is for use with CP/M 3 and compatible OSes.

The CP/NET client software provided with RomWBW is specifically for the MT011 Module developed by Mark T for the RCBus. The client software interacts directly with this hardware. In a future version of RomWBW, I hope to add a generic networking API that will allow a greater range of network hardware to be used.

To use CP/NET effectively, you will want to review the documentation provided by Douglas on his [cpnet-z80 GitHub Project](#). Additionally, you should consult the DRI documentation which is not included with RomWBW, but is available on the [cpnet-z80](#) site.

Below, I will provide the general steps involved in setting up a network using MT011 with RomWBW. The examples are all based on Z-System.

9.1 CP/NET Client Setup

The CP/NET client files are included on the RomWBW disk images, but they are found in user area 4. They are placed there to avoid confusing anyone that is not specifically trying to run a network client.

First, you need to merge the files from user area 4 into user area 0. After booting into Z-System (disk boot), you can copy the files using the following command:

```
COPY 4:*. * 0:
```

You will be asked if you want to overwrite README.TXT. It doesn't really matter, but I suggest you do not overwrite it.

The MT011 Module uses a WizNet network module. At this point, you will need to configure it for your local network. The definitive guide to the use of WIZCFG is on the [cpnet-z80](#) site in the document called "CPNET-WIZ850io.pdf". Here is an example of the commands needed to configure the WizNet:

wizcfg w n F0	set CP/NET node id
wizcfg w i 192.168.1.201	set WizNet IP address
wizcfg w g 192.168.1.1	set local network gateway IP address
wizcfg w s 255.255.255.0	set WizNet subnet mask
wizcfg w 0 00 192.168.1.3 31100	set server node ID, IP address, & port

You will need to use values appropriate for your local network. You can use the command `wiznet w` to display the current values which is useful to confirm they have been set as intended.

```
A>wizcfg w
Node ID:  F0H
IP Addr:  192.168.1.201
Gateway:  192.168.1.1
Subnet:    255.255.255.0
MAC:      98:76:B6:11:00:C4
Socket 0: 00H 192.168.1.3 31100 0
```

You will need to reapply these commands every time you power cycle your RomWBW computer, so I recommend putting them into a SUBMIT file.

After applying these commands, you should be able ping the WizNet from another computer on the local network. If this works, then the client-side is ready.

9.2 CP/NET Sever Setup

These instructions will assume you are using Douglas' CpNetSocketServer as the server on your network. The definitive guide to this software is also on the [cpnet-z80](#) site and is called "CpNetSocketServer.pdf".

The software is a Java application, so it can generally run anywhere there is a Java runtime environment available. I have normally used it on a Linux system and have had good results with that.

You will need to download the application called "CpNetSocketServer.jar" from the [cpnet-z80](#) site. The application uses a configuration file. My configuration file is called "cpnet00.rc" and has these contents:

```
cpnetserver_host = 192.168.1.3
cpnetserver_port = 31100
cpnetserver_temp = P
cpnetserver_sid = 00
cpnetserver_max = 16
cpnetserver_root_dir = /home/wayne/cpnet/root
```

You will also need to setup a directory structure with the drive letters per the documentation.

To start the server, you would use a command like this:

```
java -jar CpNetSocketServer.jar conf=cpnet00.rc
```

At this point, the server should start and you should see the following:

```
CpNetSocketServer v1.3
Using config in cpnet00.rc
Server 00 Listening on 192.168.1.3 port 31100 debug false
```

Your CP/NET server should now be ready to accept client connections.

9.3 CP/NET Usage

With both the client and server configured, you are ready to load and use CP/NET on your RomWBW system. CP/NET documentation is available on the [cpnet-z80](#) site. The document is called "dri-cpnet.pdf".

After booting your computer, you will always need to start CP/NET using the CPNETLDR command. If that works, you can map network drives as local drives using the NETWORK command. The CPNETSTS command is useful for displaying the current status. Here is a sample session:

A>cpnetldr

CP/NET 1.2 Loader

=====

BIOS		E600H	1A00H
BDOS		D800H	0E00H
SNIOS	SPR	D400H	0400H
NDOS	SPR	C800H	0C00H
TPA		0000H	C800H

CP/NET 1.2 loading complete.

A>network k:=c:[0]

A>dir k:

K: TELNET	COM : ZDENST	COM : CLRDIR	COM : RTC	COM
K: DDTZ	COM : MBASIC	COM : XSUBNET	COM : NETWORK	COM
K: WGET	COM : UNCR	COM : FLASH	COM : PIP	COM
K: TIMEZONE	COM : COMPARE	COM : ZAP	COM	

A>cpnetsts

CP/NET 1.2 Status

=====

Requester ID = F0H

Network Status Byte = 10H

Disk device status:

Drive A: = LOCAL

Drive B: = LOCAL

Drive C: = LOCAL

Drive D: = LOCAL

Drive E: = LOCAL

Drive F: = LOCAL

Drive G: = LOCAL

Drive H: = LOCAL

Drive I: = LOCAL

Drive J: = LOCAL

Drive K: = Drive C: on Network Server ID = 00H

```
Drive L: = LOCAL
Drive M: = LOCAL
Drive N: = LOCAL
Drive O: = LOCAL
Drive P: = LOCAL
Console Device = LOCAL
List Device = LOCAL
```

You will see some additional messages on your server when clients connect. Here are the messages issued by the server in the above example:

```
Connection from 192.168.1.201 (31100)
Remote 192.168.1.201 is f0
Creating HostFileBdos 00 device with root dir /home/wayne/cpnet/root
```

At this point CP/NET is ready for general use.

9.4 Network Boot

It is possible to boot your MT011 equipped RomWBW system directly from a network server. This means that the operating system will be loaded directly from the network server and all of your drive letters will be provided by the network server.

It is important to understand that the operating system that is loaded in this case is **not** a RomWBW enhanced operating system. Some commands (such as the ASSIGN command) will not be possible. Also, you will only have access to drives provided by the network server – no local disk drives will be available.

In order to do this, your MT011 Module must be enhanced with an NVRAM SPI FRAM mini-board. The NVRAM is used to store your WizNet configuration values so they do not need to be re-entered every time you cold boot your system.

Using the same values from the previous example, you would issue the WizNet commands:

```
wizcfg n F0
wizcfg i 192.168.1.201
wizcfg g 192.168.1.1
wizcfg s 255.255.255.0
wizcfg 0 00 192.168.1.3 31100
```

Note that the 'w' parameter is now omitted which causes these values to be written to NVRAM.

As before, your network server will need to be running CpnetSocketServer. However, you will need to setup a directory that contains some files that will be sent to your RomWBW system

when the Network boot is performed. By default the directory will be ~/NetBoot. In this directory you need to place the following files:

- `cpnos-wbw.sys` found in the Binary directory of RomWBW
- `ndos.spr` found in the Source/Images/cpnet12 directory of RomWBW
- `snios.spr` found in the Source/Images/cpnet12 directory of RomWBW

You also need to make sure CpNetSocketServer is configured with an 'A' drive and that drive must contain (at an absolute minimum) the following file:

- `ccp.spr` found in the Source/Images/cpnet12 directory of RomWBW

Finally, you need to add the following line to your CpNetSocketServer configuration file:

```
netboot_default = cpnos-wbw.sys
```

To perform the network boot, you start your RomWBW system normally which should leave you at the Boot Loader prompt. The 'N' command will initiate the network boot. Here is an example of what this looks like:

```
RC2014 [RCZ180_nat_wbw] Boot Loader
```

```
Boot [H=Help]: n
```

```
Loading Network Boot...
```

```
MT011 WizNET Network Boot
```

```
WBWBIOS  SPR  FD00 0100
COBDOS   SPR  FA00 0300
SNIOS    SPR  F600 0400
NDOS     SPR  EA00 0C00
```

```
58K TPA
```

```
A>
```

The CP/M operating system and the CP/NET components have been loaded directly from the network server. All of your drive letters are automatically mapped directly to the drive letters configured with CpNetSocketServer.

```
A>cpnetsts
```

```
CP/NET 1.2 Status
=====
```

Requester ID = F0H

Network Status Byte = 10H

Disk device status:

Drive A: = Drive A: on Network Server ID = 00H

Drive B: = Drive B: on Network Server ID = 00H

Drive C: = Drive C: on Network Server ID = 00H

Drive D: = Drive D: on Network Server ID = 00H

Drive E: = Drive E: on Network Server ID = 00H

Drive F: = Drive F: on Network Server ID = 00H

Drive G: = Drive G: on Network Server ID = 00H

Drive H: = Drive H: on Network Server ID = 00H

Drive I: = Drive I: on Network Server ID = 00H

Drive J: = Drive J: on Network Server ID = 00H

Drive K: = Drive K: on Network Server ID = 00H

Drive L: = Drive L: on Network Server ID = 00H

Drive M: = Drive M: on Network Server ID = 00H

Drive N: = Drive N: on Network Server ID = 00H

Drive O: = Drive O: on Network Server ID = 00H

Drive P: = Drive P: on Network Server ID = 00H

Console Device = LOCAL

List Device = LOCAL

At this point you can use CP/M and CP/NET normally, but all disk access will be to/from the network drives.

Chapter 10

Transferring Files

Transferring files between your modern computer and your RomWBW system can be achieved in a variety of ways. The most common of these are described below. All of these have a certain degree of complexity and I encourage new users to use the available community forums to seek assistance as needed.

10.1 Serial Port Transfers

RomWBW provides an serial file transfer program called XModem that has been adapted to run under RomWBW hardware. The program is called XM and is on your ROM disk as well as all of the pre-built disk images.

You can type XM by itself to get usage information. In general, you will run XM with parameters to indicate you want to send or receive a file on your RomWBW system. Then, you will use your modern computers terminal program to complete the process.

The XM application generally tries to detect the hardware you are using and adapt to it. However, you must ensure that you have a reliable serial connection. You must also ensure that the speed of the connection is not too fast for XModem to service. Alternatively, you can ensure that hardware flow control is working properly.

There is an odd interaction between XModem and partner terminal programs that can occur. Essentially, after launching XM, you must start the protocol on your modern computer fairly quickly (usually in about 20 seconds or so). So, if you do not pick a file on your modern computer quickly enough, you will find that the transfer completes about 16K, then hangs. The interaction that causes this is beyond the scope of this document.

10.2 Disk Image Transfers

It is possible to pass disk images between your RomWBW system and your modern computer. This assumes you have an appropriate media slot on your modern computer for the media you want to use (CF Card, SD Card, or floppy drive).

The general process to get files from your modern computer to a RomWBW computer is:

1. Use `cpmtools` on your modern computer to create a RomWBW CP/M filesystem image.
2. Insert your RomWBW media (CF Card, SD Card, or floppy disk) in your modern computer.
3. Use a disk imaging tool to copy the RomWBW filesystem image onto the media.
4. Move the media back to the RomWBW computer.

This process is a little complicated, but it has the benefit of allowing you to get a lot of files over to your RomWBW system quickly and with little chance of corruption.

The process can be run in reverse to get files from your RomWBW computer to a modern computer.

The exact use of these tools is a bit too much for this document, but the tools are all included in the RomWBW distribution along with usage documents.

Note that the build scripts for RomWBW create the default disk images supplied with RomWBW. It is relatively easy to customize the contents of the disk images that are part of RomWBW. This is described in more detail in the `Source\Images` directory of the distribution.

10.3 FAT Filesystem Transfers

The ability to interact with FAT filesystems was covered in [FAT Filesystem](#). This capability means that you can generally use your modern computer to make an SD Card or CF Card with a standard FAT32 filesystem on it, then place that media in your RomWBW computer and access the files.

When formatting the media on your modern computer, be sure to pick the FAT filesystem. NTFS and other filesystems will not work. As previously mentioned, the FAT application does not understand long filenames, only the traditional 8.3 filenames. If you have files on your modern computer with long filenames, it is usually easiest to rename them on the modern computer.

To copy files from your modern computer to your RomWBW computer, start by putting the disk media with the FAT filesystem in your modern computer. The modern computer should recognize it. Then copy the files you want to get to your RomWBW computer onto this media.

Once done, remove the media from your modern computer and insert it in the RomWBW computer. Finally, use the FAT tool to copy the files onto a CP/M drive.

This process works just fine in reverse if you want to copy files from a CP/M filesystem to your modern computer.

WARNING: If you are using media that contains both a FAT partition and a RomWBW partition, your modern computer may be confused by the RomWBW partition. In some cases, it will prompt you to format the RomWBW partition because it doesn't know what it is. You will be prompted before it does this – just be careful not to allow it.

Chapter 11

Customizing RomWBW

11.1 Startup Command Processing

Most of the operating systems supported by RomWBW provide a mechanism to run commands at boot. This is similar to the AUTOEXEC.BAT files from MS-DOS.

With the exception of ZPM3 and p-System, all operating systems will look for a file called PROFILE.SUB on the system drive at boot. If it is found, it will be processed as a standard CP/M submit file. You can read about the use of the SUBMIT facility in the CP/M manuals included in the RomWBW distribution. Note that the boot disk must also have a copy of SUBMIT.EXE.

Note that the automatic startup processing generally requires booting to a disk drive. Since the ROM disk is not writable, there is no simple way to add/edit a PROFILE.SUB file there. If you want to customize your ROM and add a PROFILE.SUB file to the ROM Disk, it will work, but is a lot harder than using a boot disk.

In the case of ZPM3, the file called STARTZPM.COM will be run at boot. To customize this file, you use the ZCPR ALIAS facility. You will need to refer to ZCPR documentation for more information on the ALIAS facility.

p-System has it's own startup command processing mechanism that is covered in the p-System documentation.

11.2 ROM Customization

The pre-built ROM images are configured for the basic capabilities of each platform. Additionally, some of the typical add-on hardware for each platform will be automatically detected and used. If you want to go beyond this, RomWBW provides a very flexible configuration mechanism based on configuration files. Creating a customized ROM requires running a build script, but it is quite easy to do.

Essentially, the creation of a custom ROM is accomplished by updating a small configuration file, then running a script to compile the software and generate the custom ROM and disk images. There are build scripts for Windows, Linux, and MacOS to accommodate virtually all users. All required build tools (compilers, assemblers, etc.) are included in the distribution, so it is not necessary to setup a build environment on your computer.

RomWBW can be built on modern Windows, Linux, or MacOS computers. The process for building a custom ROM is documented in the ReadMe.txt file in the Source directory of the distribution.

For those who are interested in more than basic system customization, note that all source code is provided (including the operating systems). Modification of the source code is considered an expert level task and is left to the reader to pursue.

Note that the ROM customization process does not apply to UNA. All UNA customization is performed within the ROM setup script that is built into the ROM.

Chapter 12

UNA Hardware BIOS

John Coffman has produced a new generation of hardware BIOS called UNA. The standard RomWBW distribution includes it's own hardware BIOS. However, RomWBW can alternatively be constructed with UNA as the hardware BIOS portion of the ROM. If you wish to use the UNA variant of RomWBW, then just program your ROM with the ROM image called "UNA_std.rom" in the Binary directory. This one image is suitable on **all** of the platforms and hardware UNA supports.

UNA is customized dynamically using a ROM based setup routine and the setup is persisted in the system NVRAM of the RTC chip. This means that the single UNA-based ROM image can be used on most of the RetroBrew platforms and is easily customized. UNA also supports FAT file system access that can be used for in-situ ROM programming and loading system images.

While John is likely to enhance UNA over time, there are currently a few things that UNA does not support:

- Floppy Drives
- Terminal Emulation
- Zeta 1, N8, RC2014, Easy Z80, and Dyno Systems
- Some older support boards

The UNA version embedded in RomWBW is the latest production release of UNA. RomWBW will be updated with John's upcoming UNA release with support for VGA3 as soon as it reaches production status.

Please refer to the [UNA BIOS Firmware Page](#) for more information on UNA.

Chapter 13

Upgrading

Upgrading to a newer release of RomWBW is essentially just a matter of updating the ROM chip in your system. If you have spare ROM chips for your system and a ROM programmer, it is always safest to retain your existing, working ROM chip and program a new one with the new firmware. If the new one fails to boot, you can easily return to the known working ROM.

Prior to attempting to reprogram your actual ROM chip, you may wish to “try” the update to ensure it will work on your system. With RomWBW, you can upload a new ROM image executable and load it from the command line. For each ROM image file (.rom) in the Binary directory, you will find a corresponding application file (.com). For example, for SBC_std.rom, there is also an SBC_std.com file. You can upload the .com file to your system using XModem, then simply run the .com file. You will see your system go through the normal startup process just like it was started from ROM. However, your ROM has not been updated and the next time you boot your system, it will revert to the system image contained in ROM.

13.1 Upgrading via Flash Utility

If you do not have easy access to a ROM programmer, it is usually possible to reprogram your system ROM using the FLASH utility from Will Sowerbutts. This application, called FLASH.COM, can be found on the ROM drive of any running system. In this case, you would need to transfer the new ROM image (.rom) over to your system using XModem (or one of the other mechanisms described in the Transferring Files section). The ROM image is too large to fit on your RAM drive, so you will need to transfer it to a larger storage drive. Once the ROM image is on your system, you can use the FLASH application to update your ROM. The following is a typical example of transferring ROM image using XModem and flashing the chip in-situ.

```
E>xm r rom.rom
```

```
XMODEM v12.5 - 07/13/86  
RBC, 28-Aug-2019 [WBW], ASCI
```

```
Receiving: E0:ROM.IMG  
7312k available for uploads  
File open - ready to receive  
To cancel: Ctrl-X, pause, Ctrl-X
```

Thanks for the upload

```
E>flash write rom.rom  
FLASH4 by Will Sowerbutts <will@sowerbutts.com> version 1.2.3
```

```
Using RomWBW (v2.6+) bank switching.  
Flash memory chip ID is 0xBFB7: 39F040  
Flash memory has 128 sectors of 4096 bytes, total 512KB  
Write complete: Reprogrammed 2/128 sectors.  
Verify (128 sectors) complete: OK!
```

Obviously, there is some risk to this approach since any issues with the programming or ROM image could result in a non-functional system.

To confirm your ROM chip has been successfully updated, restart your system and boot an operating system from ROM. Do not boot from a disk device yet. Review the boot messages to see if any issues have occurred.

13.2 Upgrading via XModem Flash Updater

Similar to using the Flash utility, the system ROM can be updated or upgraded through the ROM based updater utility. This works by reprogramming the flash ROM as the file is being transferred.

This has the advantage that secondary storage is not required to hold the new image.

From the Boot Loader menu select X (Xmodem Flash Updater) and then U (Begin Update). Then initiate the Xmodem transfer of the .img or .upd file.

More information can be found in the ROM Applications document.

13.3 Post Upgrade System Image and Application Update Process

Once you are satisfied that the ROM is working well, you will need to update the system images and RomWBW custom applications on your disk drives. The system images and custom applications are matched to the RomWBW ROM firmware in use. If you attempt to boot a disk or run applications that have not been updated to match the current ROM firmware, you are likely to have odd problems.

The simplest way to update your disk media is to just use your modern computer to overwrite the entire media with the latest disk image of your choice. This process is described below in the Disk Images section. If you wish to update existing disk media in your system, you need to perform the following steps.

If the disk is bootable, you need to update the system image on the disk using the procedure described in the [Operating Systems](#) section of this document.

Finally, if you have copies of any of the RomWBW custom applications on your hard disk, you need to update them with the latest copies. The following applications are found on your ROM disk. Use COPY to copy them over any older versions of the app on your disk:

- ASSIGN.COM
- SYSCOPY.COM
- MODE.COM
- FDU.COM (was FDTST.COM)
- FORMAT.COM
- XM.COM
- FLASH.COM
- FDISK80.COM
- TALK.COM
- RTC.COM
- TIMER.COM
- INTTEST.COM

For example: B>COPY ASSIGN.COM C:

Some RomWBW custom applications are too large to fit on the ROM disk. If you are using any of these you will need to transfer them to your system and then update all copies. These applications are found in the Binary\Apps directory of the distribution and in all of the disk images.

- FAT.COM
- TUNE.COM

13.4 System Update

If the system running ROMWBW utilizes the SST39SF040 Flash chip then it is possible to do a System Update in place of a System Upgrade in some cases.

A System Update would involve only updating the BIOS, ROM applications and CP/M system.

A System Update may be more favorable than a System Upgrade in cases such as:

- Overwriting of the ROM drive is not desired.
- Space is unavailable to hold a full ROMWBW ROM.
- To minimize time taken to transfer and flash a full ROM.
- Configuration changes are only minor and do not impact disk applications.

The ROMWBW build process generates a system upgrade file along with the normal ROM image and can be identified by the extension “.upd”. It will be 128Kb in size. In comparison the normal ROM image will have the extension “.rom” and be 512Kb or 1024Kb in size.

Transferring and flashing the System Update is accomplished in the same manner as described above in *Upgrading* with the required difference being that the flash application needs to be directed to complete a partial flash using the /P command line switch.

```
E>FLASH WRITE ROM.UPD /P
```

Chapter 14

Acknowledgments

I want to acknowledge that a great deal of the code and inspiration for RomWBW has been provided by or derived from the work of others in the RetroBrew Computers Community. I sincerely appreciate all of their contributions. The list below is probably missing many names – please let me know if I missed you!

- Andrew Lynch started it all when he created the N8VEM Z80 SBC which became the first platform RomWBW supported. Some of his code can still be found in RomWBW.
- Dan Werner wrote much of the code from which RomWBW was originally derived and he has always been a great source of knowledge and advice.
- Douglas Goodall contributed code, time, testing, and advice in “the early days”. He created an entire suite of application programs to enhance the use of RomWBW. Unfortunately, they have become unusable due to internal changes within RomWBW. As of RomWBW 2.6, these applications are no longer provided.
- David Giles created support for the Z180 CSIO which is now included SD Card driver.
- Ed Brindley contributed some of the code that supports the RC2014 platform.
- Phil Summers contributed the Forth and BASIC adaptations in ROM, the AY-3-8910 sound driver as well as a long list of general code enhancements.
- Spencer Owen created the RC2014 series of hobbyist kit computers which has exponentially increased RomWBW usage.
- Stephen Cousins has likewise created a series of hobbyist kit computers at Small Computer Central and is distributing RomWBW with many of them.
- The CP/NET client files were developed by Douglas Miller.

- Phillip Stevens contributed support for FreeRTOS.
- Curt Mayer contributed the original Linux / MacOS build process.
- UNA BIOS and FDISK80 are the products of John Coffman.
- FLASH4 is a product of Will Sowerbutts.
- CLRDIR is a product of Max Scane.
- Tasty Basic is a product of Dimitri Theulings.
- Dean Netherton contributed the sound driver interface and the SN76489 sound driver.
- The RomWBW Disk Catalog document was produced by Mykl Orders.

Contributions of all kinds to RomWBW are very welcome.

Chapter 15

Licensing

RomWBW is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

RomWBW is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with RomWBW. If not, see <https://www.gnu.org/licenses/>.

Portions of RomWBW were created by, contributed by, or derived from the work of others. It is believed that these works are being used in accordance with the intentions and/or licensing of their creators.

If anyone feels their work is being used outside of it's intended licensing, please notify:

Wayne Warthen wwarthen@gmail.com

RomWBW is an aggregate work. It is composed of many individual, standalone programs that are distributed as a whole to function as a cohesive system. Each program may have it's own licensing which may be different from other programs within the aggregate.

In some cases, a single program (e.g., CP/M Operating System) is composed of multiple components with different licenses. It is believed that in all such cases the licenses are compatible with GPL version 3.

RomWBW encourages code contributions from others. Contributors may assert their own copyright in their contributions by annotating the contributed source code appropriately. Con-

tributors are further encouraged to submit their contributions via the RomWBW source code control system to ensure their contributions are clearly documented.

All contributions to RomWBW are subject to this license.

Chapter 16

Getting Assistance

The best way to get assistance with RomWBW or any aspect of the RetroBrew Computers projects is via one of the community forums:

- [RetroBrew Computers Forum](#)
- [RC2014 Google Group](#)
- [retro-comp Google Group](#)

Submission of issues and bugs are welcome at the [RomWBW GitHub Repository](#).

Also feel free to email Wayne Warthen at wwarthen@gmail.com.

Chapter 17

Appendixes

17.1 Appendix A - Pre-built ROM Images

The standard ROM images will detect and install support for certain devices and peripherals that are on-board or frequently used with each platform as documented below. If the device or peripheral is not detected at boot, the ROM will simply bypass support appropriately.

SBC (SBC_std.rom)

- CPU speed is detected at startup
- Console on onboard UART serial port at 38400 baud
- Includes support for PPIDE/CF Card(s) connected to on-board parallel port.
- Includes support for CVDU and VGA3 boards. If detected at startup, support for video and keyboard is installed including VT-100/ANSI terminal emulation.
- Auto detects DiskIO v3 floppy disk controller and installs support for two attached 3.5" floppy disks if found
- Auto-detects PropIO or PropIO V2 and installs associated video, keyboard and SD Card support if present.
- If PropIO, PropIO V2, CVDU, or VGA hardware is detected, initial console output is determined by JP2. If JP2 is shorted, console will go to on-board serial port, if JP2 is open, console will go to the detected video and keyboard ports.
- SBC V1 has a known race condition in the bank switching circuit which is likely to cause system instability. SBC V2 does not have this issue.

SBC (SBC_simh.rom)

- SBC variant customized to run under SimH
- Implements two emulated SimH hard disk images
- Uses SimH RTC

ZETA (ZETA_std.rom)

- CPU speed is detected at startup
- Console on onboard UART serial port at 38400 baud
- Auto-detects FDC and installs 3.5" disk support if found
- Auto detects on-board floppy disk controller and installs support for one attached 3.5" floppy disk if found
- Auto-detects ParPortProp and includes support for it if it is attached.
- If ParPortProp is installed, initial console output is determined by JP1. If JP1 is shorted, console will go to on-board serial port, if JP1 is open, console will go to ParPortProp video and keyboard ports.

ZETA2 (ZETA2_std.rom)

- CPU speed is detected at startup
- Console on onboard UART serial port at 38400 baud
- Auto detects on-board floppy disk controller and installs support for one attached 3.5" floppy disk if found
- Auto-detects ParPortProp and includes support for it if it is attached.
- Uses CTC to generate periodic timer interrupts.
- If ParPortProp is installed, initial console output is determined by JP1. If JP1 is shorted, console will go to on-board serial port, if JP1 is open, console will go to ParPortProp video and keyboard ports.

N8 (N8_std.rom)

- CPU speed is detected at startup
- Console on Z180 onboard primary ASCII serial port at 38400 baud
- Auto detects onboard floppy disk controller and installs support for two attached 3.5" floppy disks if found
- Includes support for on-board TMS9918 video and keyboard including VT-100/ANSI terminal emulation.
- Includes support for on-board SD Card as hard disk and assumes a production level N8 board (date code >= 2312).

MK4 (MK4_std.rom)

- CPU speed is detected at startup
- Console on Z180 onboard primary ASCII serial port at 38400 baud
- Includes support for on-board IDE port (CF Card via adapter).
- Includes support for on-board SD Card port.
- Auto detects Dual IDE floppy disk controller and installs support for two attached 3.5" floppy disks if found
- Auto-detects PropIO or PropIO V2 and installs associated video, keyboard and SD Card support if present.
- Includes support for CVDU and VGA3 boards. If detected at startup, support for video and keyboard is installed including VT-100/ANSI terminal emulation.

RCZ80 (RCZ80_std.rom)

- Assumes CPU oscillator of 7.3728 MHz
- Requires 512K RAM/ROM module
- Auto detects Serial I/O Module (ACIA), Dual Serial Module (SIO/2), and EP Dual UART.

- Console on whichever serial module is installed, order of priority is UART, SIO, then ACIA.
- Baud rate is determined by hardware, but normally 115200.
- Auto support for RC2014 Compact Flash Module
- Auto support for RC2014 PPIDE Module
- Support for Scott Baker SIO board may be enabled in config
- Auto detects WDC floppy disk controller and installs support for two attached 3.5" floppy disks if found
- Support for SMC floppy controller may be enabled in config
- Support for J.B. Lang TMS9918 video card may be enabled in config
- Support for PropIO V2 may be enabled in config (PRPENABLE). If enabled, will auto-detect and install associated video, keyboard and SD Card support if present.

RCZ80 w/ KIO (RCZ80_kio.rom)

- Same as RCZ80_std
- Requires KIO module
- SIO ports provided by KIO

RCZ180 (RCZ180_nat.rom & RCZ180_ext.rom)

- Assumes CPU oscillator of 18.432 MHz
- Console on Z180 onboard primary ASCII serial port at 115200 baud
- Auto support for RC2014 Compact Flash Module
- Auto support for RC2014 PPIDE Module
- Support for alternative serial modules may be enabled in config
- Auto detects WDC floppy disk controller and installs support for two attached 3.5" floppy disks if found
- Support for SMC floppy controller may be enabled in config
- Support for J.B. Lang TMS9918 video card may be enabled in config
- You must pick the variant (_ext or _nat) depending on which memory module you are using:
 - RCZ180_ext.rom uses external bank management to access memory, such as the 512K RAM/ROM module.
 - RCZ180_nat.rom uses the built-in Z180 memory manager for use with memory modules using direct physical addressing of memory, such as the SC119.
- Support for PropIO V2 may be enabled in config (PRPENABLE). If enabled, will auto-detect and install associated video, keyboard and SD Card support if present.

RCZ280 (RCZ280_ext.rom, RCZ280_nat.rom, RCZ280_nat_zz.rom)

- Assumes CPU oscillator of 24 MHz
- Bus clock will be 6 MHz or 12 MHz, so does not match RC2014 standard!!!
- Requires 512K RAM/ROM module (unless using ZZ80MB)
- Auto detects Serial I/O Module (ACIA), Dual Serial Module (SIO), EP Dual UART (DUART), and built-in Z280 UART (Z2U).
- ACIA module is only supported on _ext variant.
- Built-in Z280 UART (Z2U) is buffered and interrupt driven only on _nat and _nat_zz variants. It uses polling I/O on _ext.
- Console on whichever serial module is installed, order of priority is Z2U, UART, SIO, DUART, ACIA
- Baud rate is determined by hardware, but normally 115200.
- Auto support for RC2014 Compact Flash Module
- Auto support for RC2014 PPIDE Module
- Support for Scott Baker SIO board may be enabled in config
- Auto detects WDC floppy disk controller and installs support for two attached 3.5" floppy disks if found
- Support for SMC floppy controllers may be enabled in config
- Support for J.B. Lang TMS9918 video card may be enabled in config
- You must pick the variant (_ext, _nat, or _nat_zz) depending on which platform or memory module you are using
 - RCZ280_ext.rom uses external bank management to access memory, such as the 512K RAM/ROM module.
 - RCZ280_nat.rom uses the built-in Z280 memory manager for use with memory modules using direct physical addressing of memory, such as the SC119.
 - RCZ280_nat_zz.rom is specifically for the ZZ80MB platform which has both CPU and memory onboard.
- Support for PropIO V2 may be enabled in config (PRPENABLE). If enabled, will auto-detect and install associated video, keyboard and SD Card support if present.

SCZ180 (SCZ180_126.rom, SCZ180_130.rom, SCZ180_131.rom, SCZ140.rom)

- Same as RCZ180
- Adds auto support for onboard SPI SD Card
- The 4 different variants of SCZ180 are provided to match the 4 corresponding systems (SC126, SC130, SC131, and SC140) designed by Stephen Cousins.
- Support for PropIO V2 may be enabled in config (PRPENABLE). If enabled, will auto-detect and install associated video, keyboard and SD Card support if present.

EZZ80 (EZZ80_std.rom)

- Assumes CPU oscillator of 10.000 MHz
- Console on primary SIO serial port at 115200 baud
- Includes support for on-board SIO
- Auto support for RC2014 Compact Flash Module
- Auto support for RC2014 PPIDE Module
- Auto detects WDC floppy disk controller and installs support for two attached 3.5" floppy disks if found
- Support for SMC floppy controllers may be enabled in config
- Support for PropIO V2 may be enabled in config (PRPENABLE). If enabled, will auto-detect and install associated video, keyboard and SD Card support if present.

DYNO (DYNO_std.rom)

- Assumes CPU oscillator of 18.432 MHz
- Console on Z180 onboard serial ports at 38400 baud
- Includes support for BQ4842 RTC
- Auto detects Dyno floppy disk controller and installs support for two attached 3.5" floppy disks if found
- Includes support for onboard PPIDE

17.2 Appendix B - Device Summary

The table below briefly describes each of the possible devices that may be discovered by RomWBW in your system.

ID	Type	Description
ACIA	Char	MC68B50 Asynchronous Communications Interface Adapter
ASCI	Char	Z180 Built-in Serial Ports
AY	Audio	AY-3-8910/YM2149 Programmable Sound Generator
BQRTC	RTC	BQ4845P Real Time Clock
CTC	System	Zilog Clock/Timer
CVDU	Video	MC8563-based Video Display Controller
DMA	System	Zilog DMA Controller
DS1307	RTC	Maxim DS1307 PCF I2C Real-Time Clock w/ NVRAM
DS1501RTC	RTC	Maxim DS1501/DS1511 Watchdog Real-Time Clock
DSKY	System	Keypad & Display
DSRTC	RTC	Maxim DS1302 Real-Time Clock w/ NVRAM
DUART	Char	SCC2681 or compatible Dual UART
FD	Disk	8272 of compatible Floppy Disk Controller
GDC	Video	uPD7220 Video Display Controller
HDSK	Disk	SIMH Simulator Hard Disk
IDE	Disk	IDE/ATA Hard Disk Interface
INTRTC	RTC	Interrupt-based Real Time Clock
KBD	Kbd	8242 PS/2 Keyboard Controller
KIO	System	Zilog Serial/ Parallel Counter/Timer
LPT	Char	Parallel I/O Controller
MD	Disk	ROM/RAM Disk
MSXKYB	Kbd	MSX Compliant Matrix Keyboard
I2C	System	I2C Interface
PIO	Char	Zilog Parallel Interface Controller
PPIDE	Disk	8255 IDE/ATA Hard Disk Interface
PPK	Kbd	Matrix Keyboard
PPPSD	Disk	ParPortProp SD Card Interface
PPPCON	Serial	ParPortProp Serial Console Interface
PRPSD	Disk	PropIO SD Card Interface
PRPCON	Serial	PropIO Serial Console Interface
RF	Disk	RAM Floppy Disk Interface
RP5C01	RTC	Ricoh RPC01A Real-Time Clock w/ NVRAM
SD	Disk	SD Card Interface

ID	Type	Description
SIMRTC	RTC	SIMH Simulator Real-Time Clock
SIO	Char	Zilog Serial Port Interface
SN76489	Sound	SN76489 Programmable Sound Generator
SPK	Sound	Bit-bang Speaker
TMS	Video	TMS9918/38/58 Video Display Controller
UART	Char	16C550 Family Serial Interface
USB-FIFO	Char	FT232H-based ECB USB FIFO
VDU	Video	MC6845 Family Video Display Controller
VGA	Video	HD6445CP4-based Video Display Controller
YM	Audio	YM2612 Programmable Sound Generator
Z2U	Char	Zilog Z280 Built-in Serial Ports