

# QuecPython LED User Guide

**LTE Standard Module Series**

Version: 1.0.0

Date: 2020-11-10

Status: Preliminary

**Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:**

**Quectel Wireless Solutions Co., Ltd.**

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: [info@quectel.com](mailto:info@quectel.com)

**Or our local office. For more information, please visit:** <http://www.quectel.com/support/sales.htm>.

**For technical support, or to report documentation errors, please visit:**

<http://www.quectel.com/support/technical.htm> Or email to [support@quectel.com](mailto:support@quectel.com).

## **General Notes**

Quectel offers the information as a service to its customers. The information provided is based upon customers' requirements. Quectel makes every effort to ensure the quality of the information it makes available. Quectel does not make any warranty as to the information contained herein, and does not accept any liability for any injury, loss or damage of any kind incurred by use of or reliance upon the information. All information supplied herein is subject to change without prior notice.

## **Disclaimer**

While Quectel has made efforts to ensure that the functions and features under development are free from errors, it is possible that these functions and features could contain errors, inaccuracies and omissions. Unless otherwise provided by valid agreement, Quectel makes no warranties of any kind, implied or express, with respect to the use of features and functions under development. To the maximum extent permitted by law, Quectel excludes all liability for any loss or damage suffered in connection with the use of the functions and features under development, regardless of whether such loss or damage may have been foreseeable.

## **Duty of Confidentiality**

The Receiving Party shall keep confidential all documentation and information provided by Quectel, except when the specific permission has been granted by Quectel. The Receiving Party shall not access or use Quectel's documentation and information for any purpose except as expressly provided herein. Furthermore, the Receiving Party shall not disclose any of the Quectel's documentation and information to any third party without the prior written consent by Quectel. For any noncompliance to the above requirements, unauthorized use, or other illegal or malicious use of the documentation and information, Quectel will reserve the right to take legal action.

## **Copyright**

The information contained here is proprietary technical information of Quectel wireless solutions co., ltd. Transmitting, reproducing, disseminating and editing this document as well as using the content without

permission are forbidden. Offenders will be held liable for payment of damages. All rights are reserved in the event of a patent grant or registration of a utility model or design.

***Copyright © Quectel Wireless Solutions Co., Ltd. 2020. All rights reserved.***

# About the Document

## Revision History

Version	Date	Author	Description
-	2020-11-10	Kenney/Rivern	Creation of the document
1.0.0	2020-11-10	Kenney/Rivern	Preliminary

## Contents

About the Document.....	3
Contents.....	4
Figure Index.....	6
1 Introduction .....	7
2 Overview .....	8
3 LED Function Realization.....	8
4 Terms and Abbreviations .....	12



## Figure Index

Figure 1: GPIO Serial Port .....	7
Figure 2: LED Light Flashing .....	10

# 1 Introduction

This document takes EC100Y-CN as an example to introduce how to use the LED function.



## 2 Overview

Before using the LED function, you need to understand the GPIO serial port of the EVB. GPIO is the general I/O port. GPIO is the pin output and input function of the EVB. The output function is to pull the pin high and low; the input function is to detect whether the level on the pin is high or low. When you need to control the high and low of the pin, use the output function of GPIO. For example, when controlling the on and off of the LED lamp, it is necessary to control the high and low level of the output to realize the on and off of the LED lamp.

Take EC100Y-CN module as an example, as shown in the figure is the GPIO serial port:




Figure 1: GPIO Serial Port

## 3 LED Function Realization

To realize the LED function in the EVB, you need to use the Pin function in QuecPython. Take EC100Y-CN module as an example, connect the LED control line of the module to the GPIO1 serial port of the EVB,

and then connect the module V3.3 serial port to the EVB V3.3 serial port to supply power to the module. After the connection is complete, power on the EVB.

**Step1:** First import the machine module and create a GPIO object. The code example is as follows:

```
from machine import Pin
gpio1 = Pin(GPIO1, Pin.OUT, Pin.PULL_DISABLE, 0)
```

<i>GPIO</i>	Integer type. Pin number. The pin correspondence is as follows: GPIO1 – Pin number 22 GPIO2 – Pin number 23 GPIO3 – Pin number 178 GPIO4 – Pin number 199 GPIO5 – Pin number 204
<i>direction</i>	Integer type. IN      Input mode OUT     Output mode
<i>pullMode</i>	Integer type. PULL_DISABLE Floating mode PULL_PU     Pull up mode PULL_PD     Pull down mode
<i>level</i>	Integer type. Pin level. 0    Set the pin to low level 1    Set the pin to high level

**Step2:** Obtain the pin voltage and execute the code as follows:

```
gpio1.read()
```

**Step3:** Set the pin level. The execution code is as follows:

```
gpio1.write(1)
```


**Step4:** Realize the flashing effect of LED lights by setting a string of changing voltages of the pins. The execution code is as follows:

```
import utime
i = 1
while i < 100:
    gpio1.write(0)
    utime.sleep(1)
    gpio1.write(1)
    utime.sleep(1)
    i += 1
```

```
>>> from machine import *
>>>
>>> gpio1 = Pin(Pin.GPIO1,Pin.OUT,Pin.PULL_DISABLE,0)
>>>
>>> gpio1.read()
0
>>> █
```

```
>>> import utime
>>>
>>>
>>> i = 1
>>> while i<100:
...     gpio1.write(0)
...     utime.sleep(1)
...     gpio1.write(1)
...     utime.sleep(1)
...     i += 1
...
0
0
```

After running the above code, you can observe that the LED lights of the EC100Y-CN module flash every 1 second, and more functions can be achieved by modifying the code and connecting multiple sets of peripherals.



**Figure 2: LED Light Flashing**

**NOTE**

The above part of the code can be found in the SDK provided by Quectel, and the path is `modules/gpio/example_pin.py`.

## 4 Terms and Abbreviations

Table 1: Terms and Abbreviations

Abbreviation	Description
GPIO	General-Purpose Input/Output
LED	Light Emitting Diode
SDK	Software Development Kit

