

QuecPython NTP Application Note

LTE Standard Module Series

Version: 1.0.0

Date: 2020-11-10

Status: Preliminary



Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:

Quectel Wireless Solutions Co., Ltd.

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local office. For more information, please visit:

<http://www.quectel.com/support/sales.htm>.

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/technical.htm>

Or email to support@quectel.com.

General Notes

Quectel offers the information as a service to its customers. The information provided is based upon customers' requirements. Quectel makes every effort to ensure the quality of the information it makes available. Quectel does not make any warranty as to the information contained herein, and does not accept any liability for any injury, loss or damage of any kind incurred by use of or reliance upon the information. All information supplied herein is subject to change without prior notice.

Disclaimer

While Quectel has made efforts to ensure that the functions and features under development are free from errors, it is possible that these functions and features could contain errors, inaccuracies and omissions. Unless otherwise provided by valid agreement, Quectel makes no warranties of any kind, implied or express, with respect to the use of features and functions under development. To the maximum extent permitted by law, Quectel excludes all liability for any loss or damage suffered in connection with the use of the functions and features under development, regardless of whether such loss or damage may have been foreseeable.

Duty of Confidentiality

The Receiving Party shall keep confidential all documentation and information provided by Quectel, except when the specific permission has been granted by Quectel. The Receiving Party shall not access or use Quectel's documentation and information for any purpose except as expressly provided herein. Furthermore, the Receiving Party shall not disclose any of the Quectel's documentation and information to any third party without the prior written consent by Quectel. For any noncompliance to the above requirements, unauthorized use, or other illegal or malicious use of the documentation and information, Quectel will reserve the right to take legal action.

Copyright

The information contained here is proprietary technical information of Quectel wireless solutions co., ltd. Transmitting, reproducing, disseminating and editing this document as well as using the content without permission are forbidden. Offenders will be held liable for payment of damages. All rights are reserved in the event of a patent grant or registration of a utility model or design.

Copyright © Quectel Wireless Solutions Co., Ltd. 2020. All rights reserved.

About the Document

Revision History

Version	Date	Author	Description
-	2020-11-10	Rivern/ Kenney	Creation of the document
1.0.0	2020-11-10	Rivern/ Kenney	Preliminary

Contents

About the Document.....	3
Contents.....	4
Figure Index	5
1 Introduction	6
2 NTP Time Synchronization	7
2.1. Overview	7
2.2. Realizing Time Synchronization	7
3 Appendix A References.....	10

Figure Index

Figure 1: Insert a SIM Card.....	8
Figure 2: Check Data Call Result.....	8
Figure 3: Returning Current NTP Server	9
Figure 4: Set NTP Server.....	9
Figure 5: Successful Time Synchronization.....	9

1 Introduction

This document takes EC100Y-CN as an example to show how to synchronize NTP time with ntptime module.

This document is applicable to the following Quectel modules:

- EC100Y-CN
- EC600S-CN

2 NTP Time Synchronization

2.1. Overview

NTP, which stands for Network Time Protocol, is a protocol used for synchronizing computer time over a network. This protocol enables computer to synchronize the time of its server or time source (such as quartz clock, GPS, and etc.) and provides high-accuracy time calibration (the time difference between LAN and standard time is less than 1 ms, and that between WAN and standard time is about tens of milliseconds). It can also prevent malicious protocol attacks by encryption and confirmation. The purpose of NTP is to provide accuracy and strong time service in a disorderly internet environment.

UTC, the correct time source, is needed before NTP can provide correct time. NTP can obtain UTC from atomic clock, astronomical observatory, satellites or internet. The time is transmitted according to the NTP server level. All servers are classified into different strata according to the distance from the external UTC time source. Stratum-1 is on the top floor and has external UTC access; Stratum-2 obtains time from Stratum-1; Stratum-3 obtains time from Stratum-2, ..., and so on. The total number of strata is limited to 15. All the servers are connected to each other on a stepped structure formed logically, and the time server of stratum-1 is the basis of the entire system. The host is generally connected to multiple time servers, and filters the time obtained from different servers with statistical algorithms to select the best path and source to correct the host time. Even if the host cannot be connected to a certain time server for a long time, NTP service still works effectively.

To prevent malicious damage to the time server, NTP adopts an authentication mechanism to check whether the time information is actually from the claimed server and check the data return path. In this way, NTP provides a protection mechanism against interference. The time contained in the NTP time synchronization message is Greenwich Mean Time, which is the number of seconds since 1900.

2.2. Realizing Time Synchronization

To synchronize time, it needs to obtain time from NTP server, so you have to connect to network before realizing time synchronization. This document takes connecting to network with SIM card as an example.

1. Prepare an available Nano SIM card. Slide to open the SIM card slot on EVB and insert the card. Close the SIM card slot and power on the EVB. Then wait for auto dialing. Here takes EC100Y-CN as an example. The SIM card slot is shown as below:




Figure 1: Insert a SIM Card

You can check the data call result as below:

```
>>> import dataCall
>>> dataCall.getInfo(1,0)
(1, 0, [1, 0, '10.22.246.141', '58.242.2.2', '218.104.78.2'])
>>>
```

Figure 2: Check Data Call Result

2. Import ntptime module after the data call is successful.

```
import ntptime
ntptime.host
```

Then the current NTP server is returned, the default is "ntp.aliyun.com".

```
>>>
>>> ntptime.host
'ntp.aliyun.com'
>>> █
```

Figure 3: Returning Current NTP Server

3. Set NTP server. Returning 0 indicates the NTP server is set successfully. Returning 1 indicates failure.

```
ntptime.sethost(host)
```

```
>>> ntptime.sethost('pool.ntp.org')
0
>>> █
```

Figure 4: Set NTP Server

4. Synchronize NTP time. Returning 0 indicates the NTP time is synchronized successfully. Returning 1 indicates failure.

```
ntptime.settime()
```

The time synchronization result can be checked with `utime.localtime()`. Execution of `utime.localtime()` returns current time. The return value is a tuple (**year, month, mday, hour, minute, second, weekday, yearday**). For details, see *Quectel_QuecPython_Class_Library_API_Introduction*.

The returned time of `ntptime.settime()` is UTC time. Beijing time is eight hours ahead of UTC, so after time synchronization, the time is eight hours less than the current time.

```
>>>
>>> import ntptime
>>> import utime
>>>
>>> utime.localtime()
(2020, 10, 28, 11, 14, 55, 2, 302)
>>> ntptime.settime()
0
>>> utime.localtime()
(2020, 10, 28, 3, 15, 11, 2, 302)
>>> █
```

Figure 5: Successful Time Synchronization

3 Appendix A References

Table 1: Terms and Abbreviations

Abbreviation	Description
GPS	Global Positioning System
LAN	Local Area Network
NTP	Network Time Protocol
RTC	Real_Time Clock
SIM	Subscriber Identity Module
UTC	Coordinated Universal Time
WAN	Wide Area Network