



Elektrobit



UDACITY

Technical Safety Concept Lane Assistance

Document Version: [Version]

Template Version 1.0, Released on 2017-06-21



Document history

| Date | Version | Editor | Description |
|-----------------|---------|----------------|-----------------|
| August 29, 2017 | 1.0 | Microsoft Word | Initial Version |
| | | | |
| | | | |
| | | | |
| | | | |

Table of Contents

[Document history](#)

[Table of Contents](#)

[Purpose of the Technical Safety Concept](#)

[Inputs to the Technical Safety Concept](#)

[Functional Safety Requirements](#)

[Refined System Architecture from Functional Safety Concept](#)

[Functional overview of architecture elements](#)

[Technical Safety Concept](#)

[Technical Safety Requirements](#)

[Refinement of the System Architecture](#)

[Allocation of Technical Safety Requirements to Architecture Elements](#)

[Warning and Degradation Concept](#)

Purpose of the Technical Safety Concept


A technical safety concept is similar to a functional safety concept in the sense that it defines requirements and allocates them to subsystems. While a functional safety concept provides a bird's eye view of the system, a technical safety concept goes deeper into the technical details of the system. Technical safety requirements are derived from functional safety requirements.

Inputs to the Technical Safety Concept

Functional Safety Requirements

| ID | Functional Safety Requirement | A S I L | Fault Tolerant Time Interval | Safe State |
|--|---|------------------|---------------------------------------|--|
| Functional Safety Requirement 01-01 | The electronic power steering ECU shall ensure that the lane departure warning oscillating torque amplitude is below Max_Torque_Amplitude | C | 50ms | Lane Departure warning function is not activated |
| Functional Safety Requirement 01-02 | The electronic power steering ECU shall ensure that the lane departure warning oscillating torque frequency is below Max_Torque_Frequency | C | 50ms | Lane Departure warning function is not activated |
| Functional Safety Requirement 02-01 | The electronic power steering ECU shall ensure that the lane keeping assistance torque is applied for only Max_Duration | B | 500ms | Lane Keeping assistance system is not activated |

Refined System Architecture from Functional Safety Concept



Functional overview of architecture elements

| Element | Description |
|---|---|
| Camera Sensor | Perceives the environment through images which are passed to the camera sensor ECU for processing |
| Camera Sensor ECU - Lane Sensing | Determines if the car is leaving the lane and if so, determines the torque to be sent to the torque request generator |
| Camera Sensor ECU - Torque request generator | Sends a vibrational torque request to the power steering ECU |
| Car Display | Displays a number of visual cues that help the driver understand what the car is doing |
| Car Display ECU - Lane Assistance On/Off Status | Receives a signal from the power steering ECU about the status of the lane departure warning function and conveys the same to the display |

| | |
|--|--|
| Car Display ECU - Lane Assistant Active/Inactive | Receives a signal from the power steering ECU about the status of the lane assistance function and conveys the same to the display |
| Car Display ECU - Lane Assistance malfunction warning | Receives a signal from the power steering ECU if there is a malfunction with the lane assistance system and conveys the same to the display |
| Driver Steering Torque Sensor | Senses how much torque is already being applied by the driver |
| Electronic Power Steering (EPS) ECU - Driver Steering Torque | Determines how much torque is already being applied by the driver |
| EPS ECU - Normal Lane Assistance Functionality | Receives the vibrational torque request from the camera ECU |
| EPS ECU - Lane Departure Warning Safety Functionality | Receives the request from the camera subsystem to activate/deactivate the lane departure warning system(i.e. to cause vibrations of the steering wheel) and conveys this request to the steering wheel through the motor |
| EPS ECU - Lane Keeping Assistant Safety Functionality | Receives the request from the camera subsystem to activate/deactivate the lane assistance system(i.e. to apply additional torque to the steering wheel) and conveys this request to the steering wheel through the motor |
| EPS ECU - Final Torque | Computes the final torque needed to be applied to the steering wheel after taking into consideration the torque already being applied by the driver and the torque requested by the camera subsystem and conveys the same to the motor |
| Motor | Applies the final torque to the steering wheel |

Technical Safety Concept

Technical Safety Requirements

Lane Departure Warning (LDW) Requirements:

Functional Safety Requirement 01-01 with its associated system elements

(derived in the functional safety concept)

| ID | Functional Safety Requirement | Electronic Power Steering ECU | Camera ECU | Car Display ECU |
|-------------------------------------|---|-------------------------------|------------|-----------------|
| Functional Safety Requirement 01-01 | The lane keeping item shall ensure that the lane departure oscillating torque amplitude is below Max_Torque_Amplitude | X | | |

Technical Safety Requirements related to Functional Safety Requirement 01-01 are:

| ID | Technical Safety Requirement | ASIL | Fault Tolerant Time Interval | Architecture Allocation | Safe State |
|---------------------------------|---|------|------------------------------|-------------------------------------|--|
| Technical Safety Requirement 01 | LDW safety component shall ensure that the amplitude of the <i>LDW_torque_request</i> sent to the <i>Final Electronic Power Steering Torque</i> component is below Max_torque_amplitude | C | 50ms | LDW Safety Block | The lane departure warning torque request amplitude shall be set to zero |
| Technical Safety Requirement 02 | Validity and Integrity of the data transmission for the <i>LDW_Torque_Request</i> signal shall be ensured | C | 50ms | Data Transmission Integrity Check | |
| Technical Safety Requirement 03 | As soon as a failure is detected by the LDW function, it shall deactivate the LDW feature and the LDW_Torque_Request shall be set to zero. | C | 50ms | LDW Safety Block | |
| Technical Safety Requirement 04 | As soon as the LDW function deactivates the LDW feature, the LDW safety software block shall send a signal to the car display ECU to turn on a warning light. | C | 50ms | LDW Safety Block | |
| Technical Safety Requirement | Memory test shall be conducted at the startup of EPS ECU to | A | Ignition cycle | Separate External block with Memory | |

| | | | | | |
|-----------|---------------------------------|--|--|-----------|--|
| ent 05 | check for any faults in memory. | | | test code | |
|-----------|---------------------------------|--|--|-----------|--|

Functional Safety Requirement 01-2 with its associated system elements
(derived in the functional safety concept)

| ID | Functional Safety Requirement | Electronic Power Steering ECU | Camera ECU | Car Display ECU |
|-------------------------------------|---|-------------------------------|------------|-----------------|
| Functional Safety Requirement 01-02 | The lane keeping item shall ensure that the lane departure oscillating torque frequency is below Max_Torque_Frequency | X | | |

Technical Safety Requirements related to Functional Safety Requirement 01-02 are:

| ID | Technical Safety Requirement | ASIL | Fault Tolerant Time Interval | Architecture Allocation | Safe State |
|---------------------------------|---|------|------------------------------|-----------------------------------|--|
| Technical Safety Requirement 01 | LDW safety component shall ensure that the frequency of the <i>LDW_torque_request</i> sent to the <i>Final Electronic Power Steering Torque</i> component is below Max_torque_frequency | C | 50ms | LDW Safety Component | The lane departure warning torque request amplitude shall be set to zero |
| Technical Safety Requirement 02 | Validity and Integrity of the data transmission for the <i>LDW_Torque_Request</i> signal shall be ensured | C | 50ms | Data Transmission Integrity Check | |
| Technical Safety Requirement 03 | As soon as a failure is detected by the LDW function, it shall deactivate the LDW feature and the LDW_Torque_Request shall be set to zero. | C | 50ms | LDW Safety Component | |
| Technical | As soon as the LDW function | C | 50ms | LDW Safety | |

| | | | | | |
|---------------------------------|---|---|----------------|---|--|
| Safety Requirement 04 | deactivates the LDW feature, the LDW safety software block shall send a signal to the car display ECU to turn on a warning light. | | | Component | |
| Technical Safety Requirement 05 | Memory test shall be conducted at the startup of EPS ECU to check for any faults in memory. | A | Ignition Cycle | Separate External block with Memory test code | |

Lane Keeping Assistance (LKA) Requirements:

Functional Safety Requirement 02-1 with its associated system elements
(derived in the functional safety concept)


| ID | Functional Safety Requirement | Electronic Power Steering ECU | Camera ECU | Car Display ECU |
|-------------------------------------|---|-------------------------------|------------|-----------------|
| Functional Safety Requirement 02-01 | The lane keeping item shall ensure that the lane keeping assistance torque is applied for only Max_Duration | X | | |

Technical Safety Requirements related to Functional Safety Requirement 02-01 are:

| ID | Technical Safety Requirement | ASIL | Fault Tolerant Time Interval | Allocation to Architecture | Safe State |
|---------------------------------|---|------|------------------------------|-----------------------------------|------------|
| Technical Safety Requirement 01 | LKA safety component shall ensure that the duration of the <i>LKA_torque_request</i> sent to the <i>Final Electronic Power Steering Torque</i> component is below Max_torque_duration | B | 500ms | LKA safety component | The lane |
| Technical Safety Requirement 02 | Validity and Integrity of the data transmission for the <i>LKA_Torque_Request</i> signal shall be ensured | B | 500ms | Data Transmission Integrity Check | |

| | | | | | |
|---------------------------------|---|---|----------------|---|---|
| Technical Safety Requirement 03 | As soon as a failure is detected by the LKA function, it shall deactivate the LKA feature and the <i>LKA_Torque_Request</i> shall be set to zero. | B | 500ms | LKA safety component | departure warning torque request amplitude shall be set to zero |
| Technical Safety Requirement 04 | As soon as the LKA function deactivates the LKA feature, the LKA safety software block shall send a signal to the car display ECU to turn on a warning light. | B | 500ms | LKA safety component | |
| Technical Safety Requirement 05 | Memory test shall be conducted at the startup of EPS ECU to check for any faults in memory. | A | Ignition Cycle | Separate External block with Memory test code | |

Refinement of the System Architecture



Allocation of Technical Safety Requirements to Architecture Elements

For this particular item, all technical safety requirements are allocated to the Electronic Power Steering ECU

Warning and Degradation Concept

The warning and degradation concept is the same for the technical safety requirements as for the functional safety requirements.

In both the cases(Lane Departure Warning and Lane Keeping Assistance):

| | |
|-------------|--|
| Warning | Warning light displayed to the driver on the dashboard |
| Degradation | Turn off functionality |