

Copyright © 2018 Dell Inc. or its subsidiaries. All rights reserved.

# **Dell EMC RackManager and RackManager Toolkit Documentation Bundle**

**Version 1.1.0**

**September, 2018**

## Table of Contents

Table of Contents	2
DSS9000 RackManager and RackManager Toolkit Docs	4
About RackManager	4
About RackManager Boot Firmware	5
About RackManager Toolkit	5
RackManager Toolkit MAN Pages	6
RackManager Users Guides	7
RackManager Development Docs	7
RM_LinuxInstall -- RackManager OS Installation Guide	8
About	8
Required Operating System -- CentOS 7.1/7.5	8
Serial Console Connection	8
Drivers	8
Physical Connection	9
Terminal Emulator	9
CentOS 7.1/7.5 Installation	9
Installing via USB	9
CentOS 7.1 Only	10
CentOS 7.5 Only	11
Both Centos 7.1 and CentOS 7.5	12
rackmanager-toolkit -- a compressed tarball of the rackmanager toolkit repository	13
About	13
Usage	13
To INSTALL the RackManager Toolkit	13
To UPDATE the RackManager Toolkit	14
To install the RackManager Toolkit CentOS updates via a local directory	14
Run RMconfig and Reboot	14
To REMOVE the RackManager Toolkit	15
Installation, Path, and Dependencies	15
See Also	15
Limitations	15
Known Issues	15
RMconfig -- RackManager Configuration Utility	16
About	16
Usage:	16
Installation, Path, and Dependencies:	17
Examples:	17
Subsystems managed by RMconfig	17
High level description of what lower-level config does for each subsystem (by subsystem)	18
Limitations:	19
Known Issues:	19
RMg5cli -- Legacy G5 Commandline Utility	20
About	20
Usage	20
To run:	20
Options:	20
Installation, Path, and Dependencies:	20
Examples:	20
Limitations:	21
Known Issues:	21
RMg5update -- a BASH utility used to update the G5 infrastructure firmware	22
About	22
Usage	22

To run:	23
Examples:	23
Updating with Generic G5 Firmware Packages	23
Updating with Custom G5 Firmware Packages	24
Updating with Switch Firmware Directly	24
Installation, Path, and Dependencies:	24
See Also:	24
Known Issues:	24
<b>RMredfishtool</b>	<b>26</b>
About	26
Why redfishtool?	27
Usage	27
Common OPTIONS:	27
Options used by "raw" subcommand:	27
Options to specify top-level collection members: eg: Systems -I <sysld>	28
Options to specify 2nd-level collection members: eg: Systems -l<sysld> Processors -l<procl>	28
Additional OPTIONS:	28
Subcommands:	28
Subcommand Operations and Addl Args	28
Systems Operations	28
Chassis Operations	29
Managers Operations	29
AccountService Operations	30
SessionService Operations	30
raw Operations	30
<b>Example Usage</b>	<b>31</b>
System subcommand Examples	31
Chassis subcommand Examples	31
Managers subcommand Examples	31
AccountService subcommand Examples	32
SessionService subcommand Examples	32
<b>Known Issues, and ToDo Enhancements</b>	<b>32</b>

# DSS9000 RackManager and RackManager Toolkit Docs

This is a **Public Dell ESI Github repo** containing published documentation for the DSS9000 RackManager.

- This doc is the top-level MAN page for the DSS9000 RackManager and RackManager Toolkit.
  - The ***Redfish-API-Users-Guide-for-DSS9000-Rackmanager.md*** contains a general description of Redfish plus details regarding the Redfish service running on DSS9000 RackManager.
  - Two sub-folders contain detail man pages referenced herein
    - `./man_pages` -- contains all of the user utility command MAN pages
    - `./service_man_pages` -- contains MAN pages for RMTK services managed by systemd--being updated and not published yet
  - All documents are natively in Github Markdown format (except concept deck)
    - These are easy to browse on Github natively --- it renders Markdown fast and good
    - Or after opening the Markdown doc in Chrome, you can Print to a pdf to get a PDF version of a doc
    - you can download the markdown files and get a free markdown reader from: [www.markdownpad.com](http://www.markdownpad.com),
    - you can also download the entire repo to zip or with a git clone
- 

## About RackManager

The DSS9000 ***RackManager*** is an embedded CentOS server in the DSS9000 rack that provides enhanced rack-level management functions.

- The ***RackManager*** hardware platform can be implemented by:
  - For the DSS9000, the *default* platform is an Atom Server that is embedded in the IM (Infrastructure Module) of the DSS9000 rack
    - this may also be referred to as the "Stark RackManager (SRM)" or the "SilverShadow" card
- ***RackManager*** interfaces with other controllers in the DSS9000 rack only via the internal rack "Management Network"
  - The DSS9000 with RackManager has an enhanced GbE internal Management Network that interconnects RackManager directly with all of the sled BMCs, as well as the other infrastructure controllers (e.g. the MCs, IMs, BCs)
  - RackManager uses the management network to:
    - communicate with internal rack infrastructure management controllers -- primarily the managed MC
    - communicate directly with node BMCs
      - This allows RackManager software to use any network-based API supported by the BMC (e.g., ipmitool, WSMangement, racadm, redfish, etc.) over the high-speed GbE internal management network
- ***RackManager*** has the following external interfaces
  - Two external RJ45 Ethernet Interfaces to connect to customer networks:
    - for the DSS9000 integrated Stark RM, these ports are labeled Mgmt1 and Mgmt2 on the IM module in the first PowerBay
    - for external 1U RMs, these two ports are most likely LOM2 and LOM3 of the external server
      - LOM1 will be used to connect to the DSS9000's IM module
  - A serial console to the RM is also supported:
    - for the DSS9000 integrated Stark RM, a USB-Serial interface on the IM module can be used to connect to either the Stark RM's serial port.
    - for external 1U RMs, the serial console connects to the BMC via the serial MUX -- see the server hardware guide.

- **RackManager** runs the off-the-shelf CentOS 7 Minimal Operating System:
  - will pre-installed at the factory on the Stark RackManager along with the RackManager Toolkit
  - can be re-installed or updated using normal CentOS yum update facilities
- **RackManager** does not replace the DSS9000's MC, but rather provides a more flexible and higher function management infrastructure for rack-level management
  - The MC is still present in each PowerBay in order to manage the PowerBay.
  - The Managed-MC in PowerBay-1 still consolidates rack-level power and the cooling status, and provides an internal network API that RackManager uses to get the rack-level infrastructure status, or to power-on/off/reset sleds, etc.

## About RackManager Boot Firmware

The embedded RackManager in the IM has boot firmware that runs at power-on or reset and boots the CentOS OS.

- This is not a full ACPI-capable BIOS
- Generally no configuration is required
- Details for configuring and updating the boot firmware is contained in the Rmbiosupdate\_MAN.md man page:
  - Link: [man\\_pages/Rmbiosupdate\\_MAN.md](#)

## About RackManager Toolkit

The **RackManager Toolkit** (RMTK) is a set of utilities and services written by Dell ESI specifically to run on RackManager providing enhanced management.

- It is installed on top of a CentOS 7 image as a yum groupinstall named "Dell RackManager Toolkit Local Repository":
  - Link: [man\\_pages/rackmanager-toolkit-install\\_MAN.md](#)
- RMTK includes several Linux Services used by the other utilities and Dell added services:
  - OpenSSH sshd -- so that customers can ssh to the RackManager
    - a customer can ssh to the RackManager through the mgmt ports, and then run other utilities from the RM's bash command-line shell
  - Apache httpd -- The RMTK's RMRedfishService is front-ended with this Apache httpd
    - Future releases will include additional web GUI APIs
  - dhcpd -- used to give IP address to the sled BMCs, utility nodes, and internal switches on the "Internal Management Network"
    - This is only for the internal management network and therefore not visible outside the rack
    - These devices are on isolated VLANs and dhcp will not serve any device connected to the base untagged management network
- RMTK includes several other pre-installed open-source / Dell utilities that a customer can run from the RM command shell:
  - `ipmitool` -- the open-source utility for IPMI-based computer hardware management
  - `wsmancli` -- the open source CLI utility based on OpenWSMAN for communicating with computers that implement the WSMAN Web Service Interface
  - `racadm` -- the Dell PowerEdge iDrac CLI utility
  - `redfishtool` -- the open-source DMTF python-based program that runs intelligent redfish commands from a CLI
- RMTK also provides several additional utilities developed for RackManager:
  - `RMconfig` -- a basic utility to setup and configure the RackManager Toolkit:

- includes creating default RM Users: rackmanager\_adm, rackmanager\_oper, rackmanager\_readonly
    - includes creating default RM permission groups: RM\_ADMIN, RM\_OPER, RM\_READONLY
    - sets-up default RMTK config files for sshd, dhcpd, httpd, etc., and puts the path to the RMTK utilities in the standard shell path
    - creates the network stack that allows the RM to communicate with the internal management network isolated from the external Ethernet interfaces.
  - RMg5update -- a utility to update DSS9000 infrastructure firmware: MCs, IM, BC, and G5 Switches
  - RMg5cli -- a utility to connect to the DSS9000 MC
  - RMredfishtool -- a version of redfishtool CLI that is optimized for the RackManager toolkit on DSS9000
  - RMbiosupdate -- a utility to update the Stark RackManager's BIOS ROM boot firmware
  - RMadm -- provides several helpful debug and admin subcommands
  - RMversion -- displays the RM Toolkit version
- RMTK includes several key "Services":
    - RMRedfishService -- a rack-level implementation of the industry standard Redfish RESTful hardware management API. The RMRedfishService runs behind the Apache httpd (as either a reverse proxy or using the Apache mod-wsgi). The service provides:
      - a rack-level Redfish service implementation from which one can manage the entire rack
      - caches that select data for speed
      - node-specific data from the sled BMCs directly over the internal management network
      - chassis, fan and power data from the managed MC over the internal management network
    - RMNodeDiscoveryService -- discovers BMC nodes and creates hosts entries with names that map to block.slot
    - RMMgmtPortMonitor -- an internal service that monitors the state of ports on the internal management network as required based on the network topology
      - The key feature is monitoring the status of the Mgmt1 and Mgmt2 external links that connect to RM via VLANs, so if the link ever drops, the RM will know to re-bringup the link
    - RMTIMEService -- used to get localtime from the DSS9000 MC if RM has lost its localtime due to a poweroff.
      - When RM starts if it has lost localtime, it re-initializes its localtime from the MC
      - it routinely syncs its RM localtim to the MC so that the MC localtime is valid
      - Note that timezone is not synced, but timezone on the MC is not generally visible to a user
    - RMMgtNetworkStart -- is a script used to startup the namespaced network stacks on the RM. It is not a full service.
      - this subsystem is called by systemd as part of normal network start so that the namespaced network stacks on RM used to implement the vlan tunnel from RM to the physical Mgmt1 and Mgmt2 ports on the DSS9000 IM switch is configured correctly.

## RackManager Toolkit MAN Pages

For additional details on the RackManager Toolkit (RMTK) utilities and services see the following detailed MAN Pages:

- Pre-installed Open-Source/Dell Standard Utilities:
  - ipmitool -- the ipmitool man page can be found by typing 'man ipmitool'
  - wsmancli -- see wsmancli man page at <link>
  - racadm -- the racadm man page can be found by typing 'racadm help'
  - redfishtool -- see redfishtool man page at <https://github.com/DMTF/Redfishtool/blob/master/README.md>
- RackManager Toolkit specific Utilities:
  - RMversion -- see /man\_pages/RMversion\_MAN.md
  - RMconfig -- see /man\_pages/RMconfig\_MAN.md

- RMg5cli -- see /man\_pages/RMg5cli\_MAN.md
- RMredfishtool -- see /man\_pages/RMredfishtool.md
- RMg5update -- see /man\_pages/RMg5update\_MAN.md
- RMBiosupdate -- see /man\_pages/RMBiosupdate\_MAN.md
- RMAadmin -- see /man\_pages/RMAadmin\_MAN.md
- RackManager Toolkit **Services** MAN Pages:
  - RMRedfishService -- see /service\_man\_pages/RMRedfishService\_MAN.md
  - RMNodeDiscoveryService -- see /service\_man\_pages/RMNodeDiscoveryService\_MAN.md
  - RMMgmtPortMonitor -- see /service\_man\_pages/RMMgmtPortMonitor\_MAN.md
  - RMMgtNetworkStart -- see service\_man\_pages/RMMgtNetworkStart\_MAN.md
  - RMTIMEService --see /service\_man\_pages/RMTIMEService\_MAN.md

## RackManager Users Guides

The following additional User Guides and API definitions for RackManager interfaces are available:

- **Redfish-Users-Guide** -- see ./Redfish-Users-Guide.md
  - this describes the Redfish Service implementation on RackManager and lists supported APIs

## RackManager Development Docs

Additional detailed development documentation for each included RackManager Toolkit utility is located in the DEV\_SPECS folder of the rackmanager-docs repo.

---

# RM\_LinuxInstall -- RackManager OS Installation Guide

---

## About

This document explains the step-by-step process of installing **CentOS 7.1** or **CentOS 7.5** onto the DSS 9000 RackManager.

Because the DSS 9000 RackManager does not contain any interface to connect a monitor, a serial console connection must be established beforehand in order to configure the installation.

With a serial console connection in place, the DSS 9000 RackManager supports OS installation through USB.

## Required Operating System -- CentOS 7.1/7.5

- The RackManager Toolkit version 1.2 and newer requires the DSS 9000 RackManager hardware to be running **CentOS 7.1** or **CentOS 7.5**.

Note that older versions of the toolkit require **CentOS 7.1**

- Only the **minimal** software installation package of CentOS 7.1 or CentOS 7.5 should be selected and installed during installation configuration.
- In order to install the OS, you will need to download the .iso image from a mirror site. An example mirror site is listed for each version of CentOS, although others may be available and may have the same versions.
  - You can download either the DVD .iso or the Minimal .iso:
    - CentOS 7.1
      - Mirror: [http://archive.kernel.org/centos-vault/7.1.1503/isos/x86\\_64/](http://archive.kernel.org/centos-vault/7.1.1503/isos/x86_64/)
      - DVD: [http://archive.kernel.org/centos-vault/7.1.1503/isos/x86\\_64/CentOS-7-x86\\_64-DVD-1503-01.iso](http://archive.kernel.org/centos-vault/7.1.1503/isos/x86_64/CentOS-7-x86_64-DVD-1503-01.iso)
      - Minimal: [http://archive.kernel.org/centos-vault/7.1.1503/isos/x86\\_64/CentOS-7-x86\\_64-Minimal-1503-01.iso](http://archive.kernel.org/centos-vault/7.1.1503/isos/x86_64/CentOS-7-x86_64-Minimal-1503-01.iso)
    - CentOS 7.5
      - Mirror: [http://mirrors.rit.edu/centos/7/isos/x86\\_64/](http://mirrors.rit.edu/centos/7/isos/x86_64/)
      - DVD: [http://mirrors.rit.edu/centos/7/isos/x86\\_64/CentOS-7-x86\\_64-DVD-1804.iso](http://mirrors.rit.edu/centos/7/isos/x86_64/CentOS-7-x86_64-DVD-1804.iso)
      - Minimal: [http://mirrors.rit.edu/centos/7/isos/x86\\_64/CentOS-7-x86\\_64-Minimal-1804.iso](http://mirrors.rit.edu/centos/7/isos/x86_64/CentOS-7-x86_64-Minimal-1804.iso)

## Serial Console Connection

In order to configure installation options, you must first establish a serial console connection between the DSS 9000 RackManager's host and a separate PC. If this is the first time connecting the PC in use to the DSS 9000 RackManager, you may need to first download and install the appropriate drivers.

## Drivers

- Download and install USB-to-UART drivers for Silicon Labs CP210x to the host PC using the following process:
  1. Go to: <http://www.silabs.com/products/mcu/Pages/USBtoUARTBridgeVCPDrivers.aspx>
  2. Select and download the appropriate set of drivers based on your OS version.
  3. Extract the contents of the zip file.
  4. Run the included installer.



## Physical Connection

- Using a standard USB Mini-B cable, connect the DSS 9000 RackManager's console port to the host computer.

### NOTE:

- The DSS 9000 RackManager must be powered (+5V LED lit) in order to connect and establish a serial console connection.
- To connect the host's serial console to the mini USB connector, the Console Select Jumper (J13) on the DSS 9000 RackManager must be in position 1-2.
- Verify the host computer can see two additional serial ports in the Device Manager.

### NOTE:

- The two additional serial ports should look similar to:
  - Silicon Labs Dual CP210x USB to UART Bridge: Enhanced COM Port (COMxx)
  - Silicon Labs Dual CP210x USB to UART Bridge: Standard COM Port (COMxx)
- The port marked **Standard** above is the host port. The standard port provides access to the RackManager's Linux shell.
- The port marked **Enhanced** provides access to a micro-BMC (uBMC) interface for remotely managing/power cycling the RackManager's motherboard.

## Terminal Emulator

- Connect to the **standard** host port of the DSS 9000 RackManager using a terminal emulator (e.g. TeraTerm, Hyperterminal, PuTTY) and the following settings:

Parameter	Value
Speed	115,200
Data Bits	8
Parity	None
Stop Bits	1
Flow Control	None

**NOTE:** The preferred emulation mode is **ANSI**

## CentOS 7.1/7.5 Installation

The DSS 9000 RackManager currently only supports OS installation via USB with a bootable USB drive.

### Installing via USB

The following detailed steps walk you through the installation process via USB:

1. Create a bootable CentOS 7.1 or CentOS 7.5 USB drive using your favorite method, and insert the drive into one of the two USB ports on the DSS 9000 RackManager hardware, or in the USB port on the IM module if inside a powerbay.

**NOTE:** This does not work if using a USB hub, the bootable USB drive must be directly inserted

2. Confirm the DSS 9000 RackManager has power, and then connect to the serial console of DSS 9000 RackManager via your favorite serial terminal emulator.

**NOTE:** Follow the steps in the Establishing a Serial Console Connection section to establish a serial console connection.

3. Reboot/Reset the DSS 9000 RackManager by pressing the physical reboot button next to the Mini USB-B serial port with a pen, or the physical reset switch on the board itself

**NOTE:** If your setup is correct and functioning, you should see activity on your serial console

4. Before the existing OS begins to boot, press F12 to go to the boot menu.
5. Press the number corresponding to the inserted USB drive. You should then be prompted with install options.
6. Move the cursor next to the Install CentOS 7 option, and press tab so that you can configure the install to use the serial console. You should then be presented with the following line of text:

- For **CentOS 7.1**

```
vmlinux initrd=initrd.img inst.stage2=hd:LABEL=CENTOS\x207\x20X8 rd.live.check quiet
```

- For **CentOS 7.5**

```
vmlinux initrd=initrd.img inst.stage2=hd:LABEL=CENTOS\x207_5 quiet
```

7. Edit the line by adding **console=ttyS1,115200** to the end of the line so that it looks like so:

- For **CentOS 7.1**

```
vmlinux initrd=initrd.img inst.stage2=hd:LABEL=CENTOS\x207\x20X8 rd.live.check quiet console=ttyS1,115200
```

- For **CentOS 7.5**

```
vmlinux initrd=initrd.img inst.stage2=hd:LABEL=CENTOS\x207_5 quiet console=ttyS1,115200
```

8. After editing the line, press enter to start the installation process. After some activity, you should eventually be provided with a menu of selections for installation settings. This is the base installation settings menu.
9. Language settings are English (United States) by default. You can skip selection 1 if you are okay with this selection, or you can press 1 and hit enter to set a different language setting.
10. Press 2 and hit enter to configure Timezone settings, then press 1 and hit enter to set timezone. You should then be prompted to select your timezone region.
11. Select the options for your time zone region. For the US, press 11 and hit enter. You should then be prompted to select your specific timezone.
12. Select your specific timezone. For the US Central Standard Time, press 3 and hit enter. After this step, the base installation settings menu should then be displayed again.
13. The installation source has already been specified on local media, thus selection 3 can be skipped.
14. As the minimal software installation is set by default, and meets our needs, you can skip selection 4.

**NOTE** After the installation selection, the CentOS 7.1 and CentOS 7.5 install steps differ. Choose the appropriate section below.

### CentOS 7.1 Only

15. Press 5 and hit enter to configure network settings.
16. Press 1 and hit enter to set the host name.
17. Type your desired host name (e.g. RackManager) and press enter.
18. Press 2 and hit enter to configure device enp1s0.
19. The default values for selections 1-6 are acceptable, thus those selections can be skipped. To change the default if desired, press the corresponding selection number and hit enter.
20. If selection 7 is not enabled by default, press 7 and press enter to connect automatically after reboot.
21. If DSS 9000 RackManager is connected to a network via a network cable, you can press 8 and hit enter to apply this configuration in the installer, otherwise you can skip this selection.

**NOTE:** If DSS 9000 RackManager is not connected to a network and you try to apply configuration in installer, you will see an error message that says **Can't apply configuration, device activation failed.**

22. If you are satisfied with the network settings, press `c` and hit `enter` to continue back to the first network settings menu.
23. Press `c` and hit `enter` again to return to the base installation settings menu.
24. Press `6` and hit `enter` to configure the install destination settings.
25. Select the disk that corresponds to `sda` by pressing the associated number and hitting `enter`.
26. Press `c` and hit `enter` to proceed to the partitioning options.
27. Use all space is selected by default, which meets our needs. Press `c` and hit `enter` to continue to the partitioning scheme options.
28. LVM is selected by default, which also meets our needs. Press `c` and hit `enter` to continue back to the base installation settings menu.
29. Kdump is enabled by default which meets our needs, so selection 7 can be skipped.
30. Users can be created after the installation, so selection 8 can be skipped.
31. Press `9` and hit `enter` to provide a password for root.
32. Type the password (e.g. `password`) and press `enter`. You will then have to retype it to confirm.

**NOTE:** Skip to section "Both Centos 7.1 and Centos 7.5".

### CentOS 7.5 Only

15. Press `5` and hit `enter` to configure the install destination settings.
16. Select the disk that corresponds to the SSD or HDD by pressing the associated number and hitting `enter`.

**NOTE:** Be careful to select the option for the SSD or HDD, and not the USB being used to install the OS

17. Press `c` and hit `enter` to proceed to the partitioning options.
18. Use all space is selected by default, which meets our needs. Press `c` and hit `enter` to continue to the partitioning scheme options.
19. LVM is selected by default, which also meets our needs. Press `c` and hit `enter` to continue back to the base installation settings menu.
20. Kdump is enabled by default which meets our needs, so selection 6 can be skipped.
21. Press `7` and hit `enter` to configure network settings.
22. Press `1` and hit `enter` to set the host name.
23. Type your desired host name (e.g. `RackManager`) and press `enter`.
24. Press `2` and hit `enter` to configure device `enp1s0`.
25. The default values for selections 1-6 are acceptable, thus those selections can be skipped. To change the default if desired, press the corresponding selection number and hit `enter`.
26. If selection 7 is not enabled by default, press `7` and press `enter` to connect automatically after reboot.
27. If DSS 9000 RackManager is connected to a network via a network cable, you can press `8` and hit `enter` to apply this configuration in the installer, otherwise you can skip this selection.

**WARNING:** If DSS 9000 RackManager is not connected to a network and you try to apply configuration in installer, you will see an error message that says **Can't apply configuration, device activation failed**.

28. If you are satisfied with the network settings, press `c` and hit `enter` to continue back to the first network settings menu.
29. Press `c` and hit `enter` again to return to the base installation settings menu.
30. Press `8` and hit `enter` to provide a password for root.
31. Type the password (e.g. `password`) and press `enter`. You will then have to retype it to confirm.

**NOTE:** If the password is weak, you will see a warning, and then it will ask you if you want to proceed with the password anyway. Type `yes` and hit `enter` to proceed, or type `no` and hit `enter` to provide a stronger password.

32. Users can be created after the installation, so selection 9 can be skipped.

**NOTE:** If all spokes are not complete, then check for notification symbols [!]. Occasionally, the

source selection option will require you to look at a second time to verify that the configuration is correct.

### **Both Centos 7.1 and CentOS 7.5**

33. All the installation settings have now been set, and installation is ready to begin. Press `b` and hit `enter` to begin the installation.
34. Wait for the installation to complete. This will take approximately 10 minutes, but could take longer.
35. Once the installation is complete, you can hit `enter` to quit, and the system will reboot.
36. You should then see the prompt to login.

**NOTE:** You may need to press `enter` for the login prompt to display.

# rackmanager-toolkit -- a compressed tarball of the rackmanager toolkit repository

---

## About

**rackmanager-toolkit** is a compressed tarball of the rackmanager toolkit repository used to install various Dell Systems Management Tools

**rackmanager-toolkit** depends on the tar utility

**rackmanager-toolkit** depends on the 'yum' tool to install packages

Note that yum clean all should be executed prior to any yum commands in order to make sure all of yum's cached metadata, packages, mirrors, etc. get cleaned and updated.

## Usage

The following sections detail how to install or update the RackManager Toolkit, and also how to update the CentOS system using the provided RackManager Toolkit repository to ensure all dependencies are correct.

- [To INSTALL the RackManager Toolkit](#)
- [To UPDATE the RackManager Toolkit](#)
- [To install the RackManager Toolkit CentOS updates via a local directory](#)
- [Run RMconfig and Reboot](#)
- [To REMOVE the RackManager Toolkit](#)

## To INSTALL the RackManager Toolkit

1. Login as a user with Administration privileges on a RackManager and uncompress the repository

```
tar -xvzf rackmanager-toolkit-repo-<version>.tar.gz -C /
```

2. Clear yum's cache of metadata, packages, mirrors to make sure the new repo gets loaded

```
yum clean all
```

3. Set the current date time if not already correctly set

```
date --set="Fri May 26 13:58:00 CDT 2017"
```

4. ONLY for RMTK 1.1.0

1. Mark-install the RMTK yum group

```
yum -y group mark-install --disablerepo=* --enablerepo="dellmc-rckmgrtoolkit-local" "Dell RackManager Toolkit Local Repository"
```

2. Synchronize the RMTK packages not owned by the RMTK group with the RMTK group so these will get updated ("kernel" must be defined directly)

```
yum -y group mark-packages-sync-force --disablerepo=* --enablerepo="dellmc-rckmgrtoolkit-local" "Dell RackManager Toolkit Local Repository" kernel
```

5. Install the local RackManager Toolkit Repository

```
yum -y groupinstall "Dell RackManager Toolkit Local Repository"
```

**NOTE** If you do not have an active internet connection, you will see "Could not resolve host:

XXXXXX" errors. To avoid this, use the "disablerepo" directive to yum like so:

```
yum -y groupinstall --disablerepo=* --enablerepo="dellemc-rckmgrtoolkit-local" "Dell RackManager Toolkit Local Repository"
```

## To UPDATE the RackManager Toolkit

1. Login as a user with Administration privileges on a RackManager and uncompress the repository

```
tar -xvzf rackmanager-toolkit-repo-<version>.tar.gz -C /
```

2. Clear yum's cache of metadata, packages, mirrors to make sure the new repo gets loaded

```
yum clean all
```

3. Set the current date time if not already correctly set (very important, RPMs must be earlier time than the system)

```
date --set="Fri May 26 13:58:00 CDT 2017"
```

4. ONLY for RMTK 1.1.0

1. Mark-install the RMTK yum group

```
yum -y group mark-install --disablerepo=* --enablerepo="dellemc-rckmgrtoolkit-local" "Dell RackManager Toolkit Local Repository"
```

2. Synchronize the RMTK packages not owned by the RMTK group with the RMTK group so these will get updated ("kernel" must be defined directly)

```
yum -y group mark-packages-sync-force --disablerepo=* --enablerepo="dellemc-rckmgrtoolkit-local" "Dell RackManager Toolkit Local Repository" kernel
```

5. Update the local RackManager Toolkit Repository to the newer version

```
yum -y groupupdate "Dell RackManager Toolkit Local Repository"
```

**NOTE** If you do not have an active internet connection, you will see "Could not resolve host: XXXXX" errors. To avoid this, use the "disablerepo" directive to yum like so:

```
yum -y groupupdate --disablerepo=* --enablerepo="dellemc-rckmgrtoolkit-local" "Dell RackManager Toolkit Local Repository"
```

## To install the RackManager Toolkit CentOS updates via a local directory

This is required if the RackManager does not have a working internet connection to get updates.

1. Copy updates package to the RackManager

```
scp centos-updates-repo-20180405.tar.gz
```

2. Login as a user with Administration privileges on the RackManager and uncompress the repository

```
tar -xvzf centos7-updates-repo-20180405.tar.gz -C /
```

3. Clear yum's cache of metadata, packages, mirrors to make sure the new repo gets loaded

```
yum clean all
```

4. Update available (security-focused) CentOS packages via the local repository

```
yum -y update --disablerepo=* --enablerepo="dellemc-rckmgrtoolkit-local" --enablerepo="local-centos7-updates"
```

## Run RMconfig and Reboot

1. After either an install or an update, you should run RMconfig.

RMconfig -F config

**NOTE** If RMconfig does not exist, please log out and log back in.

2. After an update and running RMconfig, it is possible that network services may not be successfully restarted. It is best to reboot the system.

reboot

## To REMOVE the RackManager Toolkit

1. Login as a user with Administration privileges on a RackManager
2. Remove the local rackmanager toolkit yum group

```
yum -y groupremove --disablerepo=* --enablerepo="dellemc-rckmgrtoolkit-local" "Dell RackManager Toolkit Local Repository"
```

---

## Installation, Path, and Dependencies

- **rackmanager-toolkit** is released as a tar file
  - Contents:
    - rackmanager yum repository
      - rm-tools RPMs
      - 3rd-party RPMs
  - **rackmanager yum repository** :
    - /opt/dell/rm-toolkit-repo is where repository files will be located (repository directory)
    - /etc/yum.repos.d/dellemc-rackmanager-toolkit.repo - Configuration file name for RM related yum repositories
      - "[dellemc-rckmgrtoolkit-local]" - the definition header to the local filesystem repository
  - **rm-tools** is released as an RPM that contains RackManager utilities
    - /opt/dell/rm-tools is the location where rm-tools RPMs data will be stored (rm utilities directory)
- 

## See Also

- Rackmanager\_Quickstart.md (coming soon)

## Limitations

- Requires Administrator privileges for all steps
- Remote repository implementation is left for the Administrator and would require the following:
  - define a stanza in the /etc/yum.repos.d/dellemc-rackmanager-toolkit.repo that contains a definition to point to an internal/external network server (e.g. NFS, Apache, etc) which hosts the repository files contained in the toolkit tarfile.

## Known Issues

# RMconfig -- RackManager Configuration Utility

---

## About

**RMconfig** is a BASH utility used to setup (or configure) the RackManager (RM) Toolkit (RMTK) services and utilities (referred to as subsystems) after the toolkit is installed. After installation or update of a RMTK, RMconfig should always be immediately executed in order to ensure all utilities and services are properly setup and configured.

Setup and configuration includes:

- creating the RMTK network stack (ethernet configs specific to G5 and RM with VLANs, /etc/hosts, and namespaced network stacks) to isolate the internal management network from the external network
- setting up default RM users, groups, and credentials used for communications w/ G5 MCs and G5 Mgt Network Switches
- creating the RM default configs for standard linux services: dhcpd, httpd, sshd, tftp, rsyslog, redis, etc.
- creating the RM default configs for the RMTK utilities/services: RackConfig.conf, RM.conf, mc.conf, redfish.conf, etc.
- configuring linux startup services to start the proper services upon boot
- configuring the G5 MCs and internal Switches

**RMconfig** will initially configure the "RMbase" subsystem which will make sure that the paths to various utilities are setup, and that a default RM.conf file is created at /etc/opt/dell/rm-tools/RM.conf which is required to configure the other subsystems.

Once the "RMbase" subsystem has been configured, **RMconfig** by default will read the RM.conf config file to determine which other subsystems to configure (eg dhcpd, httpd, RMRedfishService, RMUsersGroupsPaths, etc.) and for each which configuration profile to use.

However, note that users can run the command with specific options/arguments to configure a single subsystem, or to start, stop, or restart a service for debug (e.g. RMconfig -s <subsystem> config OR RMconfig -s <subsystem> restart ).

Additionally, note that certain subsystem configurations (such as RMMgtNetwork) may require a system reboot in order to fully take affect. If you want the system to auto-reboot following completion of the RMconfig action, you can use the "-R" option.

All events will be logged to /var/log/rackmanager/RMconfig.log

## Usage:

```
RMconfig -V          -- display version and exit
RMconfig -h          -- display overall RMconfig usage and exit
RMconfig -h -s <subSys> -- display usage help for a specific subsystem and exit
RMconfig [-v][-F] config -- config all subsystems listed in RM.conf using the assigned profiles in RM.conf
RMconfig [-v][-F][-p <cfgProfile>] -s <subSys> <action> -- run <action> on specified <subSys>
Note that if <action>="config" above, -p <cfgProfile> can be used to specify the profile. Otherwise, by default the profile specified in RM.conf for the subsystem will be used with config.
```

### OPTIONS:

```
-h          -- display usage help
-F          -- force reconfig -- without -F, subsystems previously configured will not configure again
-s <subSys> -- specify the subsystem - if -s option is used, the <action> must also be specified --
            if -s <subSys> is not specified, RMconfig runs "config" action on all subsystems
            in RM.conf with a valid profile name set other than "None".
-R          -- will auto-reboot the RM once action is completed.
-v          -- verbose output - can repeat for additional level of verbosity
-v          -- verbose level 1 is for high-level debug info from the main script - including progress
-vv         -- verbose level 2 is for subsystem specific flow progress
```



-vvv -- verbose level 3 is for dumping detailed variable info at any level

<subSys>: one of: { RMbase, sshd, dhcpd, httpd, RMMgtNetwork, RMUsersGroupsPaths, tftp, redis, rsyslog, celery, RMTIME, RMG5MCPortMapService, RMNodePortMapService, RMRackConfigService, RMCredentials, RMg5mc, RMRedfishService, RMNodeDiscoveryService, RMPortMonitorService }

<action>: one of: { config, restart, stop, start }

note: enter 'RMconfig -h -s <subSys>' to get specific usage and actions supported for that subsystem

## Installation, Path, and Dependencies:

- **RMconfig** is included in the rackmanager-tools RPM, and is installed by default when a RackManager Toolkit is installed
- The utility and its data is installed at /opt/dell/rm-tools/RMconfig/\*
- The rackmanager-tools RPM install creates the RMconfig executable script at /opt/dell/rm-tools/bin/RMconfig
- The rackmanager-tools RPM install also places /opt/dell/rm-tools/bin/ in the default bash/sh path for all RM users
- The first line of the program includes a shebang line #!/usr/bin/bash that will direct execution using standard linux bash
- RMconfig specific logs can be found at /var/log/rackmanager/RMconfig.log

## Examples:

RMconfig -V --- prints the version and exits

RMconfig -h --- prints help info and exits

RMconfig -vv config --- runs a full configuration based on the subsystems and config profiles in RM.conf, also prints some verbose information about the execution process

RMconfig -F -s RMg5mc config --- does a force config of just the RMg5mc subsystem only using the assigned config profile in RM.conf

## Subsystems managed by RMconfig

- Under RMconfig/, there is a subsystem-specific directory for each subsystem
- Under the subsystem-specific directories, there is a profile-specific directory for each config profile with a profile-specific bash config script (subSystem\_config.sh) and config files for the subsystem/profile
  - RMconfig will use these to setup the default configurations per subsystem/profile
- The current list of subsystems include:
  - RMbase -- sets up default RM.conf config file, RM utility executables, and required initial data files
  - RMUsersGroupsPaths -- creates default rackmanager users, groups, and paths as defined by the specified profile
  - sshd -- sets up sshd service config as defined by the specified profile
  - dhcpd -- sets up dhcpd service config as defined by the specified profile
  - RMMgtNetwork -- sets up RMMgtNetworkStart service config as defined by the specified profile, creates static hosts entries, ethernet configs, and namespaced network stacks for mgmt1 and mgmt2
  - httpd -- sets up httpd config as defined by the specified profile
  - RMRedfishService -- sets up RMRedfishService service config as defined by the specified profile
  - RMCredentials -- creates/configures ssh keys and redfish auth credentials for communication with the Managed MC
  - RMg5mc -- configures G5 Managed MCs with ssh keys and required dependent MC configurations
  - tftp -- sets up tftp service config as defined by the specified profile
  - redis -- sets up redis service config as defined by the specified profile
  - rsyslog -- sets up rsyslog service config as defined by the specified profile
  - RMNodeDiscoveryService -- sets up RMNodeDiscoveryService service config as defined by the specified profile
  - celery -- sets up celery service config as defined by the specified profile

- RMTIME -- sets up RMTIMEService service config as defined by the specified profile
- RMG5MCPortMapService -- sets up RMG5MCPortMapService service config as defined by the specified profile
- RMNodePortMapService -- sets up RMNodePortMapService service config as defined by the specified profile
- RMRackConfigService -- sets up RMRackConfigService service config as defined by the specified profile

## High level description of what lower-level config does for each subsystem (by subsystem)

- RMbase
  - create the /etc/opt/dell/rm-tools/ directory with default RM.conf, .RMconfig\_times, and .RMg5update\_times data files
  - copy's executable wrapper scripts for other rackmanager-tools utilities to the /opt/dell/rm-tools/bin dir so that they will be in the user's path
- sshd, dhcpd, httpd, tftp, rsyslog, redis:
  - copy the correct RM config files depending on the specified profile to their proper locations for the service
  - execute the standard linux command for each of these services to configure it to auto start on boot
    - tftp will be disabled by default
  - additional actions that can be specified by targeting the service: start, stop, restart
- RMMgtNetwork:
  - create a default /etc/hosts file with default management network entries (based on profile in RM.conf)
  - create default /etc/sysconfig/network-scripts/ifcfg-\* files (with proper vlan eth devices) based on specified profile
  - create VLAN eth devices to tunnel the two ext mgt ports to ext ports on the IM switch
  - configure the RM network stack to totally isolates the internal mgt network from external ports using namespaces
  - configure firewall rules to allow access only to the proper services on the various RM subnets
  - configures the RMMgmtPortMonitor service to monitor the status of mgmt1/mgmt2
- RMUsersGroupsPaths
  - add the default RM groups for admin, operator, and readonly roles (RM\_ADMIN, RM\_OPER, and RM\_READONLY)
  - add the default RM users for each role (rackmanager\_adm, rackmanager\_oper, rackmanager\_readonly)
  - setup the default path for all users to pickup /opt/dell/rm-tools/bin
- RMCredentials
  - generate ssh keys and ssh config files for use when communicating with the MCs using ssh passwordless authentication
  - configure the RM credential vault w/ proper credentials that RMg5mc can use to communicate w/ managed MCs
  - configure the RM credential vault w/ proper credentials that RM utilities and services can use to communicate w/ iDracs
  - configure the RM credential vault w/ proper credentials that RM utilities and services can use to communicate w/ RM Management Network Switches
- RMg5mc

- scp the ssh public key files used by RMg5cli to the the Managed MCs
- copy the required MC configuration files to the Managed MC
- reset the MC for these changes to take effect
- RMRedfishService
  - copy the Redfish.conf file indicated by the specified profile to /etc/opt/dell/rm-tools/Redfish.conf
  - copy the RedDrum.conf file indicated by the specified profile to /etc/opt/dell/rm-tools/RedDrum.conf
  - config Linux boot script to auto start RMRedfishService
- RMNodeDiscoveryService
  - config Linux boot script to auto start RMNodeDiscoveryService
- RMG5MCPortMapService
  - create default RMG5MCPortMap.conf in /etc/opt/dell/rm-tools/
  - create default service data files in /var/opt/dell/rm-tools/
  - config Linux boot script to auto start RMG5MCPortMapService
- RMNodePortMapService
  - create default RMNodePortMap.conf in /etc/opt/dell/rm-tools/
  - create default service data files in /var/opt/dell/rm-tools/
  - config Linux boot script to auto start RMNodePortMapService
- RMRackConfigService
  - create default RackConfig.conf in /etc/opt/dell/rm-tools/
  - create default service data files in /var/opt/dell/rm-tools/
  - config Linux boot script to auto start RMRackConfigService
- celery
  - config Linux boot script to auto start celery service

## Limitations:

- No known limitations

## Known Issues:

- A full config of all subsystems can sometimes take several minutes, but should not take more than 15 minutes

# RMg5cli -- Legacy G5 Commandline Utility

---

## About

**RMg5cli** is a BASH utility that allows a user to run G5 CLI commands from the RackManager.

- If a specific MC CLI sub-command is not specified, an interactive MC CLI shell is started.
- The privilege of the user depends on the RackManager Role Group that the user is a member of:
  - users with Administrator privilege on the RM will execute commands with Admin privilege on the MC
  - users with Operator privilege on the RM will execute commands with Operator privilege on the MC
  - users with ReadOnly privilege on the RM will execute commands with ReadOnly privilege on the MC
- Commands are executed on the targeted G5 Managed MC (MMC)
  - The default MMC is MMC1 - if no MMC is specified
    - in many cases, there is only one MMC in a rack, so MMC1 is the only MMC
    - MMC1 will always be valid
  - MMCs are numbered from bottom up in the rack: MMC1, MMC2, MMC3,...

## Usage

```
RMg5cli -V          -- display version and returns
RMg5cli -h          -- display help and usage info and exit
RMg5cli [-m <mmc>] [-v]          -- connects to MMC <mmc> and starts an interactive MC CLI shell
                                <mmc> is MMC1 by default
RMg5cli [-m <mmc>] [-v] <sub-command and args> -- run the specified sub-command and args on <mmc> and return
```

### To run:

- Login to the Rackmanager via ssh
- enter RMg5cli [options]

### Options:

```
-V      --- display the version and exit
-h      --- display help and usage info and exit
-m <mmc> --- <mmc> is the alias in the RackManager hosts file for the targeted MC:
        valid values: MMC1, MMC2, MMC3, MMC4, ...
-v      --- verbose flag. can be repeated multiple times for more verbose output:
-v      ---gives the RM user group that this user is a member of
-vv     ---adds the ssh command sent to the MC,
-vvv    ---adds progname, version, & verboseLvl
```

## Installation, Path, and Dependencies:

- **RMg5cli** is included in the rackmanager-tools RPM, and is installed by default when the RackManager Toolkit is installed
  - The utility is part of the rackmanager-tools development repo
  - The utility and data is installed at /opt/dell/rm-tools/RMg5cli/\*
  - A wrapper script RMg5cli is placed in /opt/dell/rm-tools/bin by the RMconfig subsystem RMBASE
  - The first line of the program includes a shebang line #!/usr/bin/bash that will direct execution using standard linux bash

## Examples:

```
RMg5cli -V          --- prints the version and exit
```

```
RMg5cli -h          --- prints help info and exit
RMg5cli            --- start interactive legacy G5 CLI on MMC1
RMg5cli -m MMC2     --- start interactive legacy G5 CLI on MMC2 (the managed MC in management domain 2)
RMg5cli SHOW /DEVICEMANAGER/RACK1/Block1/Sled1 --- display properties and targets for Block1/Sled1 managed by MMC1
RMg5cli -m MMC2 SHOW /DEVICEMANAGER/Rack1/Block2 -- display properties and targets for Block2 managed by MMC2
```

## Limitations:

- Users must be root, or in one of the RM user groups RM\_ADMIN, RM\_OPER, or RM\_READONLY
  - These groups will be mapped to MC users: rackmanager\_adm, rackmanager\_oper, and rackmanager\_readonly
- Only "managed" MCs can be targeted. You cannot target an unmanaged MC that monitors a 2nd-ary powerbay
  - use raw ssh user@<MCx\_y> to connect to a non-managed MC for development or debug
- When using RMg5cli with no arguments, and using the interactive CLI, if you reset the MC during this session you will lose connection to the MC and may see a broken pipe error, but the reset will complete as desired
- RMg5cli does not create any logs on the RackManager since the actual events happen on the MC

## Known Issues:

- None

# RMg5update -- a BASH utility used to update the G5 infrastructure firmware

---

## About

**RMg5update** is a BASH command script that allows a user to update firmware and config files for the G5.5/DSS9000 infrastructure controllers (MCs, BC, IMs, and G5switches) from the RackManager.

- depends on bash, tftp, and a stable communication with the Managed MC.
- parses command arguments, and performs FW updates of the G5.5/DSS9000 infrastructure controllers
- tightly integrated with the G5.5/DSS9000 internal management infrastructure
- logs events to `/var/log/rackmanager/RMg5update.log`

**RMg5update** supports updates using a few different update package options:

- A generic update package - can be used to update all controllers (MCs, BC, IMs, and G5switches)
  - File name must end with `.tar`, `.tgz`, or `.tar.gz`
  - Use of a generic update package also requires a Rackconfig file unique to the Rack in use
    - Rackconfig file name can be anything
- A custom update package - can be used to update MCs, BC, and IMs
  - File name must be of format `G5_<packageName>-<ver>.tgz`
- A switch firmware `.flash` file - can be used to update the G5switches
  - File name must be of format `G5_stark_fw_v<ver>.flash`

## Usage

Usage:

```
RMg5update -V      -- display version and return
RMg5update -h      -- display usage and return
RMg5update [OPTIONS] -R <rackcfg> <RMpackage>
    -- update G5 Firmware from generic RM package based on rack configuration <rackcfg>,
    <RMpackage> is path to a generic RM G5 FW package: /path/RM_G5FW_VERSION-<ver>.tgz,
    <rackcfg> is name of a Rackconfig file in /opt/dell/rm-tools/RMg5update/Rackconfigs/
RMg5update [OPTIONS] [-C] <G5Package>
    -- update G5 Firmware from a custom G5 package
    <G5package> is path to a custom G5 FW package: /path/G5_VERSION-<ver>.tgz
RMg5update -D 1 -t G5ALLSWITCH <RMpackage>
    -- update all switches in mgt domain 1 with switch firmware from generic RM package,
    <RMpackage> is path to a generic RM G5 FW package: /path/RM_G5FW_VERSION-<ver>.tgz
RMg5update -t G5IMSWITCH <SwitchFW>
    -- update the IM switch in default mgt domain (1) with specified firmware file,
    <SwitchFW> is path to Switch FW file: /path/G5_stark_fw_v<ver>.flash
    NOTE: in order to specify the switch fw file directly, the target must
           only include switches
```

Options:

```
-h      --- display usage and exit
-V      --- display version and exit
-l      --- displays info about the update and package specified and verifies that options
        and dependencies are met, but does not update any actual firmware
-R <rackcfg> --- include Config files based on <rackcfg>,
        <rackcfg> must be file located in /opt/dell/rm-tools/RMg5update/Rackconfigs/
-C      --- include Config files if in package - always done if -R option specified,
        thus should not be used with -R
-t <target> --- specifies the update target - the default is G5MCIMBC.
        <target>={ G5ALL, G5MCIMBC, G5ALLSWITCH, G5IMSWITCH, G5BLKSWITCH}
        - G5ALL -- updates all MCs, BCs, IM, and G5switches in the mgt domain.
        - G5MCIMBC -- default, only update the MCs, BCs, and IMs
        - G5ALLSWITCH -- updates all G5switches in the mgt domain
        - G5IMSWITCH -- only update the G5 IM switch
```

- G5BLKSWITCH -- updates all G5 Block Switches
- D <mgtDom> --- specifies the management domain: <mgtDom>=[1:4], default is 1
- r <rackNum> --- specifies the specific rack in the management domain, default is 1
- v --- verbose output - can repeat for additional level of verbosity
  - v -- verbose level-1 shows general progress as the update proceeds
  - vv -- verbose level-2 shows detailed progress as the update proceeds
  - vvv -- verbose level-3 dumps detailed debug info during execution
- M --- update the mc.conf and redfish.conf on the MC from MC.conf and G5Redfish.conf on the RM after all other updates to insure that the managed MC has RM config settings

**Notes:**

- \* Following any update with RMg5update, RMconfig of the RMg5mc subsystem should be executed in order to re-sync the RM with the MC.
- \* RMconfig [-vvv] -F -s RMg5mc config

**To run:**

- login as a user with Admin permissions on the RackManager
- copy the package file to a temp file location on the RM using scp
  - ex: from the RM, copy the package from another server to the RM
  - scp <mylogin>@<myServer>:/path/to/myPkgFiles/<packagename> /var/g5updates/.
- enter RMg5update [OPTIONS] /var/g5updates/<packagename>
- once complete, run RMconfig on the RMg5mc subsystem
  - RMconfig [-vvv] -F -s RMg5mc config

**Examples:**

```
RMg5update -V          --- prints the version and exits
> Version: 1.0
```

```
RMg5update -h          --- prints the usage similar to MAN page usage section
```

```
RMg5update -v -R G55_HW_10BLK_2PB $myFwPkgs/RM_G5FW_VERSION-3.32.tgz
--- update G5 with level-1 verbose messages for rack config G55_HW_10BLK_2PB
to ver 3.32 firmware
```

```
RMg5update -l -R G55_HW_10BLK_2PB $myFwPkgs/RM_G5FW_VERSION-3.32.tgz
--- verifies that the specified pkg and rackcfg exists
before starting the update, will not perform the update
```

```
RMg5update -vvv -t G5ALLSWITCH G5_stark_fw_v1.10.0.flash
--- update all G5 switch fw using the G5_stark_fw_v1.10.0.flash fw file,
and display verbose output
```

## Updating with Generic G5 Firmware Packages

A generic G5 firmware package should contain:

- All IM firmware and conf files (for all rack configs)
- All BC firmware and conf files (for all rack configs)
- All MC firmware and conf files (for all rack configs)
- All G5 switch firmware

The package itself can have any file name that ends with .tar, .tar.gz, or .tgz

When using the generic package, the -R <Rackcfg> option must be specified

- With the -R <Rackcfg> option, the RM will create a specific HW-dependent "G5-package" that is ultimately sent to the MC and used to perform the update
  - This HW-dependent package is created based on the Rackcfg specified with the -R option
    - Note that the specified must be located in /opt/dell/rm-tools/RMg5update/Rackconfigs/
  - Once created, RMg5update will then copy the package to the /tftpboot/ directory
  - Then a ssh command is sent to the MC telling it to download the package via tftp and perform the

update

- Note that the MC does the actual update process here

## Updating with Custom G5 Firmware Packages

A custom G5 firmware package must contain only the exact files required for that specific rack configuration, as it will be used "as is" to perform the update

The package itself must have a file name in the form of: G5\_<packageName>-<ver>.tgz

When using the custom package:

- the -R <Rackcfg> option should never be used
- the -C option may or may not be used
  - The -C option tells RMg5update to include any Hardware Config files that were in the manually created package. Otherwise config files will be stripped before sending the package to the MC.

## Updating with Switch Firmware Directly

Updating G5 switches with the switch firmware directly requires the fw file in use to be the desired fw version.

The fw file itself must have a file name in the form of: G5\_stark\_fw\_v<ver>.flash

When using the switch fw directly:

- the -R <Rackcfg> option should never be used
- the -C option should never be used
- the -t must be used to specify switch targets
  - must be one of:
    - G5ALLSWITCH - all switches (including IM switch and all BCDB switches) will be updated to the specified firmware
    - G5IMSWITCH - just the IM switch will be updated to the specified firmware
    - G5BLKSWITCH - all BCDB switches will be updated to the specified firmware

## Installation, Path, and Dependencies:

- **RMg5update** is included in the rackmanager-tools RPM, and is installed by default as part of the RackManager Toolkit
- It is installed on the RM at /opt/dell/rm-tools/RMg5update/\*
- The first line of the program includes a sheebang line #!/usr/bin/bash
- RMg5update specific logs can be found at /var/log/rackmanager/RMg5update.log
- Following any update with RMg5update, RMconfig of the RMg5mc subsystem should be executed in order to re-sync the RM with the MC.
  - RMconfig [-vvv] -F -s RMg5mc config

## See Also:

- RMconfig

## Known Issues:

- When doing an update with target G5ALL or G5MCIMBC, during the update process of the IM the RackManager will lose power twice. This causes loss of output of the update progression; however, the update process, as it is being done by the MC, will still continue on as expected and the update should still take effect for the MC/IM/BC firmware. If target is G5ALL though, because of this loss of power, RMg5update will not get to the switch updates. Thus, you should then update just the switches



afterwards.

- The status of the MC/IM/BC update can be checked afterwards using RMg5cli to look at the Rack's LastUpgradeStatus value
  - e.g. RMg5cli show rack1

# RMredfishtool

## About

**RMredfishtool** is a Dell ESI customized version of the open source **redfishtool** that implements the client side of the Redfish RESTful API for Data Center Hardware Management.

Customizations include optional support for:

- setting the remote host IP at localhost to point to the local Rackmanager Redfish service
- TBD: providing G5 physical location ID aliases that to more easily point to well-known G5 resources
- TBD: performance optimizations by:
  - allowing RMredfishtool to make assumptions about how the local RM Redfish service constructs URIs within collections
  - caching some static output
- TBD: a custom AuthLocal authentication mode that uses the user's role for authorization but allows the service to skip checking password since the user has already authenticated
- TBD: providing some Dell G5-specific OEM commands eg Chassis Reseat, etc

**Redfish** is the new RESTful API for hardware management defined by the DMTF Scalable Platform Management Forum (SPMF). It provides a modern, secure, multi-node, extendable interface for doing hardware management. The initial release included hardware inventory, server power-on/off/reset, reading power draw, setting power limits, reading sensors such as fans, read/write of ID LEDs, asset tags, and went beyond IPMI in functionality to include inventory of processors, storage, Ethernet controllers, and total memory. (The current 0.9.1 version of redfishtool supports these initial features) New Redfish extensions have now been added to the spec and include firmware update, BIOS config, memory inventory, direct attached storage control, and the list grows.

**redfishtool** makes it simple to use the Redfish API from a BASH script or interactively from a client command shell.

While other generic http clients such as Linux curl can send and receive Redfish requests, **redfishtool** goes well beyond these generic http clients by automatically handling many of the hypermedia and Redfish-specific protocol aspects of the Redfish API that require a client to often execute multiple queries to a redfish service to walk the hypermedia links from the redfish root down to the detailed URI of a specific resource (eg Processor-2 of Blade-4 in a computer blade system). Specifically, redfishtool provides the following functions over curl:

- implements Redfish Session Authentication as well as HTTP Basic Auth
- walks the Redfish schema following strict interoperability processors...] to find the targeted instance based on Id, UUID, URL or other attributes
- handles GETs for collections that are returned in multiple pieces--requiring client to read in a loop until the full collection is returned
- handles ETag and If-Match headers when PATCHing a resource to write properties
- implements many common set or action operations with simple commandline syntax (eg server reset, setting LEDs, assetTag, powerLimits, etc)
- negotiates the latest redfish protocol version between client and service (demonstrating the proper way to do this)
- can read specific properties of a resource, or expand collections to include all members of the collection expanded
- supports adding and deleting users, and common Redfish account service operations
- For debug, provides multiple levels of verbose output to add descriptive headers, and show what http requests are being executed
- For debug, includes multiple levels of status display showing http status codes and headers returned and sent
- For easy parsing, outputs all responses in JSON format unless verbose or status debug options were specified

## Why redfishtool?

1. **redfishtool** was originally written during the development of the Redfish specification to help find ambiguities in the spec.
2. **redfishtool** is now also being used to test inter-operability between redfish service implementations.
3. In addition, **redfishtool** provides an example implementation for how a client can execute common server management functions like inventory; power-on/off/reset; setting power limits, indicator LEDs, and AssetTags, and searching a multi-node redfish service to find a specific node (with specific UUID, redfish Id, etc). redfishtool follows strict rules of interoperability. To support this goal, liberal comments are added throughout code to explain why each step is being executed.
4. As described above, it makes it easy to use the Redfish API from a BASH script, or as an easy-to-use interactive CLI -- but WITHOUT creating a 'new API'. All (rather most) of the responses from **redfishtool** are Redfish-defined responses. The properties and resources are defined in the redfish spec. **redfishtool** is just a tool to access the Redfish API-not a new interface itself.
  - The exception is that a 'list' operation was added for all collections to display the key properties for each of the members--rather than just the URIs to the members.

## Usage

**RMredfishtool** [ Options ] [ SubCommands ] [ Operation ] [ OtherArgs ]

- **RMredfishtool** is a python3.4+ program. It uses the python3 "requests" lib for sending http requests, and a host of other standard libs in python3.4+
- The **RMredfishtool** option/optarg parsing strictly follows the well established linux/GNU getopt syntax where arguments and options can be specified in any order, and both short (eg -r ) or long (--rhost=) syntax is supported.
- **options** are used to pass usernames, passwords, Host:port, authentication options, verbose/status flags, and also to specify how to search to find specific collection members (-l , -a (all), -M : ).
- **subCommands** indicate the general area of the API (following ipmitool convention), and align with Redfish navigation property names like "Chassis", "Systems", "AccountService", etc.
- **Operations** are specify an action or operation you want to perform like Systems setBootOverride ..., Or Systems reset.
- **OtherArgs** are any other arguments after the Operation that are sometimes required--like: Systems <setBootOverride> <enableValue> "

## Common OPTIONS:

```
-V, --version           -- show RMredfishtool version, and exit
-h, --help             -- show Usage, Options, and list of subCommands, and exit
-u <user>, --user=<usermm> -- username used for remote redfish authentication
-p <psswd>, --password=<psswd> -- password used for remote redfish authentication
-r <rhost>, --rhost=<rhost> -- remote redfish service hostname or IP:port
                        -- by default <rhost> is localhost and thus routed to the RM Redfish service
-t <token>, --token=<token> -- redfish auth session token-for sessions across multiple calls
-q, --quiet            -- quiet mode--suppress error, warning, and diagnostic messages
-c <cfgFile>, --config=<cfgFile> -- read options (including credentials) from file <cfgFile>
-T <timeout>, --Timeout=<timeout> -- timeout in seconds for each http request. Default=10
-P <property>, --Prop=<property> -- return only the specified property. Applies only to all "get" operations
-v, --verbose          -- verbose level, can repeat up to 5 times for more verbose output
                        -v(header), -vv(+addl info), -vvv(Request trace), -vvvv(+subCmd dbg),
                        -vvvvv(max dbg)
                        *** use -vvv to see all of the requests being sent for a command
-s, --status           -- status level, can repeat up to 5 times for more status output
                        -s(http_status),
                        -ss(+r.url, +r.elapsed executionTime ),
                        -sss(+requestHdrs,data,authType, +respStatus_code, +elapsed exec time,
                            AuthToken/sessId/sessUri)
                        -ssss(+response headers for debug), -sssss(+response data for debug)
```

Options used by "raw" subcommand:

-d <data> --data=<data> -- the http request "data" to send on PATCH,POST,or PUT requests

#### Options to specify top-level collection members: eg: Systems -l <sysId>

-l <Id>, --Id=<Id> -- Use <Id> to specify the collection member  
-M <prop>:<val> --Match=<prop>:<val> -- Use <prop>=<val> search to find the collection member  
-F, --First -- Use the 1st link returned in the collection or 1st "matching" link if used with -M  
-1, --One -- Use the single link returned in the collection. Return error if more than one member  
-a, --all -- Returns all members if the operation is a Get on a top-level collection like Systems  
-L <Link>, --Link=<Link> -- Use <Link> (eg /redfish/v1/Systems/1) to reference the collection member.  
-- If <Link> is not one of the links in the collection, and error is returned.

#### Options to specify 2nd-level collection members: eg: Systems -l<sysId> Processors -i<procId>

-i <id>, --id=<id> -- use <id> to specify the 2nd-level collection member  
-m <prop>:<val> --match=<prop>:<val> -- use <prop>=<val> search of 2nd-level collection to specify member  
-l <link> --link=<link> -- Use <link> (eg /redfish/v1/Systems/1/Processors/1) to reference a 2nd level resource  
-- a -l|M|F|1|L option is still required to specify the link to the top-lvl collection  
-a, --all -- Returns all members of the 2nd level collection if the operation is a Get on the  
-- 2nd level collection (eg Processors).  
-- -l|M|F|1|L still specifies the top-lvl collection.

#### Additional OPTIONS:

-W <num>:<connTimeout>, -- Send up to <num> {GET /redfish} requests with <connTimeout> TCP connection  
--Wait=<num>:<ConnTimeout> -- timeouts before sending subcommand to rhost. Default is -W 1:3  
-A <Authn>, --Auth <Authn> -- Authentication type to use: Authn={None|Basic|Session} Default is Basic  
-S <Secure>, --Secure=<Secure> -- When to use https: (Note: doesn't stop rhost from redirect http to https)  
--Secure={Always | IfSendingCredentials | IfLoginOrAuthenticatedApi | Never(default) }  
-R <ver>, --RedfishVersion=<ver> -- The Major Redfish Protocol version to use: ver={v1(default), v<n>, Latest }  
-C --CheckRedfishVersion -- tells RMredfishtool to execute GET /redfish to verify that the rhost supports  
the specified redfish protocol version before executing the sub-command.  
The -C flag is auto-set if the "-R Latest" or "-W ..." options were selected.  
was specified by the user.  
-H <hdrs>, --Headers=<hdrs> -- Specify the request header list--overrides defaults. Format "{ A:B, C:D...}  
-D <flag>, --Debug=<flag> -- Flag for dev debug. <flag> is a 32-bit uint: 0x<hex> or <dec> format

## Subcommands:

about -- display version and other information about this version of RMredfishtool  
versions -- get redfishProtocol versions supported by rhost: GET ^/redfish  
root | serviceRoot -- get serviceRoot resource: GET ^/redfish/v1/  
Systems -- operations on Computer Systems in the /Systems collection  
Chassis -- operations on Chassis in the /Chassis collection  
Managers -- operations on Managers in the /Managers collection  
AccountService -- operations on AccountService including user administration  
SessionService -- operations on SessionService including Session login/logout  
odata -- get the Odata Service Document: GET ^/redfish/v1/odata  
metadata -- get the CSDL metadata Document: GET ^/redfish/v1/\$metadata  
raw -- execute raw redfish http methods and URIs (-C option will be ignored)  
hello -- RMredfishtool hello world subcommand for dev testing

For Subcommand usage, including subcommand Operations and OtherArgs, execute:

RMredfishtool <SubCommand> -h -- prints usage and options for the specific subCommand

## Subcommand Operations and Addl Args

### Systems Operations

RMredfishtool -r <rhost> Systems -h

Usage:

RMredfishtool [OPTNS] Systems <operation> [<args>] -- perform <operation> on the system specified

<operations>:

[collection] -- get the main Systems collection. (Dflt operation if no member specified)  
[get] -- get the computerSystem object. (Default operation if collection member specified)

```

list -- list information about the Systems collection members("Id", URI, and AssetTag)
patch {A: B,C: D,...} -- patch the json-formatted {prop: value...} data to the object
reset <resetType> -- reset a system. <resetType>= On, GracefulShutdown, GracefulRestart,
ForceRestart, ForceOff, ForceOn, Nmi, PushPowerPutton
setAssetTag <assetTag> -- set the system's asset tag
setIndicatorLed <state> -- set the indicator LED. <state>=redfish defined values: Off, Lit, Blinking
setBootOverride <enabledVal> <targetVal> -- set Boot Override properties. <enabledVal>=Disabled|Once|Continuous
-- <targetVal> =None|Pxe|Floppy|Cd|Usb|Hdd|BiosSetup|Utilities|Diags|UefiTarget|
Processors [list] -- get the "Processors" collection, or list "id" and URI of members.
Processors [IDOPTN] -- get the member specified by IDOPTN: -i<id>, -m<prop>:<val>, -l<link>, -a #all

EthernetInterfaces [list] -- get the "EthernetInterfaces" collection, or list "id" and URI of members.
EthernetInterfaces [IDOPTN]-- get the member specified by IDOPTN: -i<id>, -m<prop>:<val>, -l<link>, -a #all

SimpleStorage [list] -- get the ComputerSystem "SimpleStorage" collection, or list "id" and URI of members.
SimpleStorage [IDOPTN] -- get the member specified by IDOPTN: -i<id>, -m<prop>:<val>, -l<link>, -a #all

Logs [list] -- get the ComputerSystem "LogServices" collection , or list "id" and URI of members.
Logs [IDOPTN] -- get the member specified by IDOPTN: -i<id>, -m<prop>:<val>, -l<link>, -a #all
clearLog <id> -- clears the log defined by <id>
examples -- example commands with syntax
hello -- Systems hello -- debug command

```

## Chassis Operations

RMredfishtool -r <rhost> Chassis -h

Usage:

RMredfishtool [OPTNS] Chassis <operation> [<args>] -- perform <operation> on the Chassis specified

<operations>:

```

[collection] -- get the main Chassis collection. (Dflt operation if no member specified)
[get] -- get the Chassis object. (Defalut operation if collection member specified)
list -- list information about the Chassis collection members("Id", URI, and AssetTag)
patch {A: B,C: D,...} -- patch the json-formatted {prop: value...} data to the object
setAssetTag <assetTag> -- set the Chassis's asset tag
setIndicatorLed <state> -- set the indicator LED. <state>=redfish defined values: Off, Lit, Blinking
Power -- get the full Power resource under a specified Chassis instance.
Thermal -- get the full Thermal resource under a specified Chassis instance.

```

```

getPowerReading [-i<indx>] [consumed] -- get powerControl resource w/ power capacity, PowerConsumed, and power
power limits. If "consumed" keyword is added, then only current usage of powerControl[indx]
is returned. <indx> is the powerControl array index. default is 0. normally, 0 is the only entry
setPowerLimit [-i<indx>] <limit> [<exception> [<correctionTime>]] -- set powerLimit control properties
<limit>=null disables power limiting. <indx> is the powerControl array indx (dflt=0)

```

```

Logs [list] -- get the Chassis "LogServices" collection , or list "id" and URI of members.
Logs [IDOPTN] -- get the member specified by IDOPTN: -i<id>, -m<prop>:<val>, -l<link>, -a #all
clearLog <id> -- clears the log defined by <id>
examples -- example commands with syntax
hello -- Chassis hello -- debug command

```

## Managers Operations

RMredfishtool -r <rhost> Managers -h

Usage:

RMredfishtool [OPTNS] Managers <operation> [<args>] -- perform <operation> on the Managers specified

<operations>:

```

[collection] -- get the main Managers collection. (Dflt operation if no member specified)
[get] -- get the specified Manager object. (Dflt operation if collection member specified)
list -- list information about the Managers collection members("Id", URI, and UUID)
patch {A: B,C: D,...} -- patch the json-formatted {prop: value...} data to the object
reset <resetType> -- reset a Manager. <resetType>= On, GracefulShutdown, GracefulRestart,
ForceRestart, ForceOff, ForceOn, Nmi, PushPowerPutton
setDateTime <dateTimeString> --set the date and time
setTimeOffset <offsetString> --set the time offset w/o changing time setting
NetworkProtocol -- get the "NetworkProtocol" resource under the specified manager.
setIpAddress [-i<indx>]... -- set the Manager IP address -NOT IMPLEMENTED YET

```

```

EthernetInterfaces [list] -- get the managers "EthernetInterfaces" collection, or list "id",URI, Name of members

```

EthernetInterfaces [IDOPTN] -- get the member specified by IDOPTN: -i<id>, -m<prop>:<val>, -a #all

SerialInterfaces [list] -- get the managers "SerialInterfaces" collection, or list "id", URI, Name of members.

SerialInterfaces [IDOPTN] -- get the member specified by IDOPTN: -i<id>, -m<prop>:<val>, -l<link>, -a #all

Logs [list] -- get the Managers "LogServices" collection, or list "id", URI, Name of members.

Logs [IDOPTN] -- get the member specified by IDOPTN: -i<id>, -m<prop>:<val>, -l<link>, -a #all

clearLog <id> -- clears the log defined by <id>

examples -- example commands with syntax

hello -- Systems hello -- debug command

#### AccountService Operations

RMredfishtool -r <rhost> AccountService -h

Usage:

RMredfishtool [OPTNS] AccountService <operation> [<args>] -- perform <operation> on the AccountService  
<operations>:

[get] -- get the AccountService object.

patch {A: B,C: D,...} -- patch the AccountService w/ json-formatted {prop: value...}

Accounts [list] -- get the "Accounts" collection, or list "Id", username, and Url

Accounts [IDOPTN] -- get the member specified by IDOPTN: -i<Id>, -m<prop>:<val>, -l<link>, -a #all

Roles [list] -- get the "Roles" collection, or list "Id", IsPredefined, and Url

Roles [IDOPTN] -- get the member specified by IDOPTN: -i<Id>, -m<prop>:<val>, -l<link>, -a #all

adduser <usernm> <passwd> [<roleId>] -- add a new user to the Accounts collection

-- <roleId>:{Admin | Operator | ReadOnlyUser | <a custom roleId>, dflt=Operator

deleteuser <usernm> -- delete an existing user from Accounts collection

setpassword <usernm> <passwd> -- set (change) the password of an existing user account

useradmin <userName> [enable|disable|unlock][setRoleId <roleId>]] -- enable|disable|unlock.. a user account

examples -- example commands with syntax

hello -- AccountService hello -- debug command

#### SessionService Operations

RMredfishtool -r <rhost> SessionService -h

Usage:

RMredfishtool [OPTNS] SessionService <operation> [<args>] -- perform <operation> on the SessionService  
<operations>:

[get] -- get the sessionService object.

patch {A: B,C: D,...} -- patch the sessionService w/ json-formatted {prop: value...}

setSessionTimeout <timeout> -- patches the SessionTimeout property w/ etag support

Sessions [list] -- get the "Sessions" collection, or list "Id", username, and Url

Sessions [IDOPTN] -- get the member specified by IDOPTN: -i<Id>, -m<prop>:<val>, -l<link>, -a #all

login <user> <passwd> -- sessionLogin. post to Sessions collection to create a session

logout <sessionId> -- logout or delete the session identified by <SessionId>

examples -- example commands with syntax

hello -- Systems hello -- debug command

#### raw Operations

RMredfishtool -r <rhost> raw -h

Usage:

RMredfishtool [OPTNS] raw <method> <path>

RMredfishtool raw -h# for help

RMredfishtool raw examples #for example commands

<method> is one of: GET, PATCH, POST, DELETE, HEAD, PUT

<path> is full URI path to a redfish resource--the full path following <ipaddr:port>, starting with forward slash /

Common OPTNS:

-u <user>, --user=<usernm> -- username used for remote redfish authentication

-p <passwd>, --password=<passwd> -- password used for remote redfish authentication

-t <token>, --token=<token> -- redfish auth session token-for sessions across multiple calls

-r <rhost>, --rhost=<rhost> -- remote redfish service hostname or IP:port

-X <method> --request=<method> -- the http method to use. <method>={GET,PATCH,POST,DELETE,HEAD,PUT}. Dflt=GET

-d <data>--data=<data> -- the http request "data" to send on PATCH,POST,or PUT requests

-H <hdrs>, --Headers=<hdrs> -- Specify the request header list--overrides defaults. Format "{ A:B, C:D...}"  
-S <Secure>, --Secure=<Secure> -- When to use https: (Note: doesn't stop rhost from redirect http to https)

<operations / methods>:

GET -- HTTP GET method  
PATCH -- HTTP GET method  
POST -- HTTP GET method  
DELETE -- HTTP GET method  
HEAD -- HTTP GET method  
PUT -- HTTP GET method

examples-- example raw commands with syntax  
hello -- raw hello -- debug command

## Example Usage

### System subcommand Examples

```
$ RMredfishtool -r 127.0.0.1:5000 Systems examples
RMredfishtool -r<ip> Systems # shows the systems collection
RMredfishtool -r<ip> Systems list # lists Id, Uri, AssetTag for all systems
RMredfishtool -r<ip> Systems -l <id> # gets the system with Id=<d>
RMredfishtool -r<ip> Systems -M AssetTag:12345 # gets the system with AssetTag=12345
RMredfishtool -r<ip> Systems -L <sysUrl> # gets the system at URI=<systemUrl>
RMredfishtool -r<ip> Systems -F # get the First system returned (for debug)
RMredfishtool -r<ip> Systems -1 # get the first system and verify that there is only one system
RMredfishtool -r<ip> Systems -l <id> patch {A: B,C: D,...} # patch the json-formatted {prop: value...}
data to the object
RMredfishtool -r<ip> Systems -l <id> reset <resetType> # reset a system. <resetType>=the redfish-defined
_# values: On, Off, gracefulOff...
RMredfishtool -r<ip> Systems -l <id> setAssetTag <assetTag> # set the system's asset tag
RMredfishtool -r<ip> Systems -l <id> setIndicatorLed <state> # set the indicator LED.
<state>=redfish defined values: Off, Lit, Blinking
RMredfishtool -r<ip> Systems -l <id> setBootOverride <enabledVal> <targetVal> # set Boot Override properties.
<enabledVal>=Disabled|Once|Continuous
RMredfishtool -r<ip> Systems -l<Id> Processors# get the processors Collection
RMredfishtool -r<ip> Systems -l<Id> Processors list # lists Id, Uri, & Socket for all processors in system w/ Id=<Id>
RMredfishtool -r<ip> Systems -l<Id> Processors -i 1 # get the processor with id=1 in system with Id=<Id>
RMredfishtool -r<ip> Systems -L <sysUrl> Processors -m Socket:CPU_1 # get processor with property Socket=CPU_1,
on system at url <sysUrl>
```

### Chassis subcommand Examples

```
$ RMredfishtool -r 127.0.0.1:5000 Chassis examples
RMredfishtool -r<ip> Chassis # shows the Chassis collection
RMredfishtool -r<ip> Chassis list # lists Id, Uri, AssetTag for all Chassis
RMredfishtool -r<ip> Chassis -l <id> # gets the Chassis with Id=<d>
RMredfishtool -r<ip> Chassis -M AssetTag:12345# gets the Chassis with AssetTag=12345
RMredfishtool -r<ip> Chassis -L <sysUrl> # gets the Chassis at URI=<systemUrl>
RMredfishtool -r<ip> Chassis -F # get the First Chassis returned (for debug)
RMredfishtool -r<ip> Chassis -1 # get the first Chassis and verify that there is only one system
RMredfishtool -r<ip> Chassis -l <id> patch {A: B,C: D,...} # patch the json-formatted {prop: value...} data
to the object
RMredfishtool -r<ip> Chassis -l <id> setAssetTag <assetTag># set the system's asset tag
RMredfishtool -r<ip> Chassis -l <id> setIndicatorLed <state> # set the indicator LED.
<state>=redfish defined values: Off, Lit, Blinking
RMredfishtool -r<ip> Chassis -l<Id> Power # get the full chassis Power resource
RMredfishtool -r<ip> Chassis -l<Id> Thermal # get the full chassis Thermal resource
RMredfishtool -r<ip> Chassis -l<Id> getPowerReading[-i<indx>] [consumed] # get chassis/Power powerControl[-i<indx>]
resource if optional "consumed" arg, then return only the PowerConsumedWatts prop
RMredfishtool -r<ip> Chassis -L<Url> setPowerLimit [-i<indx>] <limit> [<exception> [<correctionTime>]]
_# set power limit
```

### Managers subcommand Examples

```
$ RMredfishtool -r 127.0.0.1:5000 Managers examples
```

```

RMredfishtool -r<ip> # shows the Managers collection
RMredfishtool -r<ip> Managers list # lists Id, Uri, AssetTag for all Managers
RMredfishtool -r<ip> Managers -l <id> # gets the Manager with Id=<d>
RMredfishtool -r<ip> Managers -M AssetTag:12345 # gets the Manager with AssetTag=12345
RMredfishtool -r<ip> Managers -L <mgrUrl> # gets the Manager at URI=<mgrUrl>
RMredfishtool -r<ip> Managers -F # get the First Manager returned (for debug)
RMredfishtool -r<ip> Managers -1 # get the first Manager and verify that there is only one Manager
RMredfishtool -r<ip> Managers -l <id> patch {A: B,C: D,...} # patch the json-formatted {prop: value...} data
to the object
RMredfishtool -r<ip> Managers -l <id> reset <resetType> # reset a Manager.
<resetType>=the redfish-defined values: On, Off, gracefulOff...
RMredfishtool -r<ip> Managers -l<Id> NetworkProtocol # get the NetworkProtocol resource under the
specified manager
RMredfishtool -r<ip> Managers -l<Id> EthernetInterfaces list # lists Id, Uri, and Name for all of the NICs
for Manager w/ Id=<Id>
RMredfishtool -r<ip> Managers -l<Id> EthernetInterfaces -i 1 # get the NIC with id=1 in manager with Id=<Id>
RMredfishtool -r<ip> Managers -L <Url> EthernetInterfaces -m MACAddress:AA:BB:CC:DD:EE:FF # get NIC with MAC AA:BB...
for manager at url <Url>

```

## AccountService subcommand Examples

```

$ RMredfishtool -r 127.0.0.1:5000 AccountService examples
RMredfishtool -r<ip> AccountService # gets the AccountService
RMredfishtool -r<ip> AccountService patch { "AccountLockoutThreshold": 5 } # set failed login lockout threshold
RMredfishtool -r<ip> AccountService Accounts # gets Accounts collection
RMredfishtool -r<ip> AccountService Accounts list # list Accounts to get Id, username, url for each account
RMredfishtool -r<ip> AccountService Accounts -m UserName:john # gets the Accounts member with username: john
RMredfishtool -r<ip> AccountService Roles list # list Roles collection to get RoleId, IsPredefined, & url
for each role
RMredfishtool -r<ip> AccountService Roles -i Admin # gets the Roles member with RoleId=Admin
RMredfishtool -r<ip> AccountService adduser john 12345 Admin # add new user (john) w/ passwd "12345" and role: Admin
RMredfishtool -r<ip> AccountService deleteuser john # delete user "john"s account
RMredfishtool -r<ip> AccountService useradmin john disable # disable user "john"s account
RMredfishtool -r<ip> AccountService useradmin john unlock # unlock user "john"s account

```

## SessionService subcommand Examples

```

$ RMredfishtool -r 127.0.0.1:5000 SessionService examples
RMredfishtool -r<ip> SessionService # gets the sessionService
RMredfishtool -r<ip> SessionService setSessionTimeout <timeout> # sets the session timeout property
RMredfishtool -r<ip> SessionService Sessions # gets Sessions collection
RMredfishtool -r<ip> SessionService Sessions -l<sessUrl> # gets the session at URI=<sessUrl>
RMredfishtool -r<ip> SessionService Sessions -i<sessId> # gets the session with session Id <sessId>
RMredfishtool -r<ip> SessionService patch {A: B,C: D,...} # patch the json-formatted {prop: value...}
data to the sessionService object
RMredfishtool -r<ip> SessionService login <username> <passwd> # login (create session)
RMredfishtool -r<ip> SessionService logout <sessionId> # logout (delete session <sessId>)

```

## Known Issues, and ToDo Enhancements

1. modifications to make PATCH commands work better with Windows cmd shell quoting
2. support clearlog
3. add additional APIs that have been added to Redfish after 1.0---this version supports only 1.0 APIs
4. add custom role create and delete