

## DTC U2300:51 [INSTRUMENT CLUSTER]

id0902e8016800

<b>System malfunction location</b>	Instrument cluster configuration error
<b>Detection condition</b>	• Instrument cluster configuration error (no configuration) detected.
<b>Fail-safe</b>	—
<b>Possible cause</b>	• Instrument cluster configuration error • Instrument cluster malfunction
<b>System wiring diagram</b>	—

### Diagnostic Procedure

Diagnostic Procedure		
Step	Inspection	Action
1	<b>PERFORM INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA)</b> <ul style="list-style-type: none"><li>• Using the M-MDS, perform the instrument cluster configuration using the As-Built data. (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).)</li><li>• Clear DTC for the instrument cluster using the M-MDS. (See CLEARING DTC [INSTRUMENT CLUSTER].)</li><li>• Perform the DTC inspection for the instrument cluster using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].)</li><li>• Is the DTC U2300:51 displayed?</li></ul>	Yes Using the M-MDS, re-perform the instrument cluster configuration using the As-Built data, then go to the next step. (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).)
	No Go to Step 3.	
2	<b>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</b> <ul style="list-style-type: none"><li>• Clear DTC for the instrument cluster using the M-MDS. (See CLEARING DTC [INSTRUMENT CLUSTER].)</li><li>• Perform the DTC inspection for the instrument cluster using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].)</li><li>• Is the DTC U2300:51 displayed?</li></ul>	Yes Replace the instrument cluster, then go to the next step. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)
	No Go to the next step.	
3	<b>VERIFY IF OTHER DTCs DISPLAYED</b> <ul style="list-style-type: none"><li>• Are any other DTCs displayed?</li></ul>	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [INSTRUMENT CLUSTER].)
	No DTC troubleshooting completed.	