

---

## DC-DC CONVERTER INSPECTION [SKYACTIV-D 2.2]

id0117h6004700

### DC-DC Converter Operation Inspection

1. Perform the KOER self-test.
  - If the following DTCs are detected, repair the applicable malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [SKYACTIV-D 2.2].)
    - P058A:00, P0A8D:00, P0A94:00, U0298:00
2. Inspect the battery.
  - If there is a malfunction, recharge or replace the battery, then go to the next step. (See BATTERY RECHARGING [SKYACTIV-D 2.2].) (BATTERY INSPECTION [SKYACTIV-D 2.2].) (BATTERY REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
3. When the engine is restarted by the i-stop control, verify that the following measured voltages are not lower than **11.5V**.
  - Rain sensor (auto light sensor) supply terminal (vehicle wiring harness-side connector terminal D)
  - Audio unit supply terminal (vehicle wiring harness-side connector terminal 1B)
    - If it cannot be verified, go to the next step.
4. Inspect the wiring harness between the following terminals for an open or short circuit.
  - DC-DC converter terminal K-Rain sensor (auto light sensor) terminal D
  - DC-DC converter terminal K-audio unit terminal 1B
    - If there is any open or short circuit in the wiring harness, repair or replace the malfunctioning part.
    - If there is any open or short circuit in the wiring harness, replace the DC-DC converter. (See DC-DC CONVERTER REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)