

DTC P2610:00 [SKYACTIV-D 2.2]

id0102s4303800

DTC P2610:00	Instrument cluster internal engine off timer performance problem
DETECTION CONDITION	<ul style="list-style-type: none"> Instrument cluster internal engine off timer is damaged. Diagnostic support note <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition in two consecutive drive cycles or in one drive cycle while the DTC for the same malfunction has been stored in the PCM. PENDING CODE is available if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	<ul style="list-style-type: none"> CAN communication line malfunction between PCM and instrument cluster Instrument cluster internal engine off timer malfunction Instrument cluster power supply circuit malfunction Instrument cluster malfunction PCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes Go to the next step.
		No Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No Go to the next step.
3	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> Switch the ignition off, then ON (engine off). Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) Are any other PENDING CODEs and/or DTCs present? 	Yes Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No Go to the next step.
4	VERIFY STORED DTC IN INSTRUMENT CLUSTER <ul style="list-style-type: none"> Switch the ignition off, then ON (engine off). Retrieve the instrument cluster DTC using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) Are any DTCs present? 	Yes Go to the applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No Go to the next step.
5	INSPECT INSTRUMENT CLUSTER BACKUP VOLTAGE CIRCUIT <ul style="list-style-type: none"> Switch the ignition off. Remove the MAIN 200 A fuse and ROOM 15 A fuse. Inspect the MAIN 200 A fuse and ROOM 15 A fuse. Is there any malfunction? 	Yes Replace the malfunctioning fuse. Switch the ignition ON (engine on) and wait for 10 s or more . Switch the ignition off. Go to Step 7.
		No CAN communication line can be considered the cause. <ul style="list-style-type: none"> Reinstall the MAIN 200 A fuse and ROOM 15 A fuse. Inspect the wiring harness between instrument cluster and PCM. <ul style="list-style-type: none"> If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the suspected wiring harness, then go to Step 7. If there is no malfunction: <ul style="list-style-type: none"> Go to the next step.

STEP	INSPECTION		ACTION
6	INSPECT INSTRUMENT CLUSTER <ul style="list-style-type: none"> Inspect the instrument cluster. (See INSTRUMENT CLUSTER INSPECTION.) Is there any malfunction? 	Yes	Replace the instrument cluster, then go to the next step. (See INSTRUMENT CLUSTER REMOVAL/INSTALLATION.)
		No	Go to the next step.
7	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> Always reconnect all disconnected connectors. Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) Perform the Pending Trouble Code Access Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) Is the PENDING CODE for this DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
8	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.