

DTC P0172:00 [SKYACTIV-G 2.0]

id0102h1934300

DTC P0172:00	Fuel trim system too rich
DETECTION CONDITION	<ul style="list-style-type: none"> • When any of the following conditions is met: <ul style="list-style-type: none"> — During idling or driving, the correction amount of the fuel feedback correction plus the fuel learning correction is a volume decrease correction exceeding the specified value. — During idling or driving, the amount of the fuel feedback decrease correction reaches the upper limit. <p>Diagnostic support note</p> <ul style="list-style-type: none"> • This is a continuous monitor (fuel system). • The check engine light illuminates if the PCM detects the above malfunction condition in two consecutive drive cycles or in one drive cycle while the DTC for the same malfunction has been stored in the PCM. • PENDING CODE is available if the PCM detects the above malfunction condition during first drive cycle. • FREEZE FRAME DATA (Mode 2)/Snapshot data is available. • The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	—
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Erratic signal to PCM <ul style="list-style-type: none"> — APP sensor signal malfunction — ECT sensor signal malfunction — MAF sensor signal malfunction — TP sensor signal malfunction — Related connector or terminals malfunction — Related wiring harness malfunction • MAF sensor malfunction • A/F sensor heater malfunction • A/F sensor malfunction <ul style="list-style-type: none"> — A/F sensor loose — Exhaust system leakage — A/F sensor deterioration • Improper operation of purge control system <ul style="list-style-type: none"> — Purge solenoid valve malfunction (stuck open) — Purge solenoid hoses improper connection — Air cleaner element restricted • Improper operation of electric variable valve timing control system <ul style="list-style-type: none"> — Electric variable valve timing driver malfunction — Electric variable valve timing motor malfunction — Electric variable valve timing actuator malfunction • Improper operation of hydraulic variable valve timing control system • Improper operation of fuel injector • High-pressure side fuel delivery system malfunction <ul style="list-style-type: none"> — Fuel pressure sensor malfunction — Spill valve control solenoid valve control circuit malfunction (damage to driver in PCM caused by short circuit to ground system) — Spill valve control solenoid valve (built-into high pressure fuel pump) malfunction — Relief valve (built-into high pressure fuel pump) malfunction — High pressure fuel pump malfunction • Low-pressure side fuel delivery system malfunction <ul style="list-style-type: none"> — Low pressure side fuel line restriction (between fuel pump unit and high pressure fuel pump) — Fuel filter clogged — Pressure regulator (built-into fuel pump unit) malfunction — Fuel pump unit malfunction • Ignition system malfunction <ul style="list-style-type: none"> — Spark plug malfunction — Ignition coil malfunction — Ignition coil related wiring harness malfunction • PCV valve malfunction • Misfire • PCM malfunction
SYSTEM WIRING DIAGRAM	—

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	IDENTIFY TRIGGER DTC FOR FREEZE FRAME DATA (MODE 2) <ul style="list-style-type: none"> Perform the Freeze Frame PID Data Access Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Is the DTC P0172:00 on FREEZE FRAME DATA (Mode 2)? 	Yes	Go to the next step.
		No	Go to the troubleshooting procedure for DTC on FREEZE FRAME DATA (Mode 2). (See DTC TABLE [SKYACTIV-G 2.0].)
2	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA AND DIAGNOSTIC MONITORING TEST RESULTS HAVE BEEN RECORDED <ul style="list-style-type: none"> Have the FREEZE FRAME DATA (Mode 2)/ snapshot data and DIAGNOSTIC MONITORING TEST RESULTS (fuel system related) been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS on the repair order, then go to the next step.
3	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
4	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> Switch the ignition to off, then to ON (engine off). Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Are any other PENDING CODEs and/or DTCs present? 	Yes	If misfire DTC is present: • Go to Step 7. If other DTC is present: • Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	If drive ability concern is present: • Go to Step 7. If drive ability concern is not present: • Go to the next step.
5	VERIFY CURRENT INPUT SIGNAL STATUS <ul style="list-style-type: none"> Access the following PIDs using the M-MDS: (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) <ul style="list-style-type: none"> APP1 APP2 ECT MAF TP REL Is there any signal that is far out of specification when the ignition is switched to ON and the engine runs? (See PCM INSPECTION [SKYACTIV-G 2.0].) 	Yes	Inspect the suspected sensor and related wiring harness. Repair or replace the malfunctioning part according to the inspection results, then go to Step 27.
		No	Go to the next step.
6	VERIFY CURRENT INPUT SIGNAL STATUS UNDER FREEZE FRAME DATA (MODE 2) CONDITION <p>Caution</p> <ul style="list-style-type: none"> While performing this step, always operate the vehicle in a safe and lawful manner. When the M-MDS is used to observe monitor system status while driving, be sure to have another technician with you, or record the data in the M-MDS using the PID/DATA MONITOR AND RECORD capturing function and inspect later. <ul style="list-style-type: none"> Access the same PIDs as in Step 5 while simulating under the FREEZE FRAME DATA (Mode 2) conditions. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Is there any signal which causes drastic changes? 	Yes	Inspect the suspected sensor and related wiring harness. Repair or replace the malfunctioning part according to the inspection results, then go to Step 27.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
7	VERIFY CURRENT INPUT SIGNAL STATUS OF MAF SENSOR <ul style="list-style-type: none"> Start the engine. Access the MAF PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Verify that the MAF PID value changes quickly while increasing (racing) the engine rpm. Is the MAF PID value normal? (See PCM INSPECTION [SKYACTIV-G 2.0].) 	Yes	Go to the next step.
		No	Replace the MAF sensor/IAT sensor No.1, then go to Step 27. (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
8	INSPECT A/F SENSOR HEATER <ul style="list-style-type: none"> Inspect the A/F sensor heater. (See AIR FUEL RATIO (A/F) SENSOR INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Replace the A/F sensor, then go to Step 27. (See AIR FUEL RATIO (A/F) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
9	VERIFY CURRENT INPUT SIGNAL STATUS OF A/F SENSOR <ul style="list-style-type: none"> Reconnect all disconnected connectors. Inspect the A/F sensor. (See AIR FUEL RATIO (A/F) SENSOR INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Go to the next step.
		No	Go to Step 12.
10	INSPECT INSTALLATION OF A/F SENSOR <ul style="list-style-type: none"> Inspect installation of A/F sensor. Is the A/F sensor installed securely? 	Yes	Go to the next step.
		No	Retighten the A/F sensor, then go to Step 27. (See AIR FUEL RATIO (A/F) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
11	INSPECT EXHAUST SYSTEM FOR LEAKAGE <ul style="list-style-type: none"> Visually inspect for exhaust leakage between exhaust manifold and A/F sensor. Is there any leakage? 	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to Step 27.
		No	Replace the A/F sensor, then go to Step 27. (See AIR FUEL RATIO (A/F) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
12	INSPECT LONG TERM FUEL TRIM <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the evaporative hose (purge solenoid valve side) from intake manifold and plug opening end of hose and intake manifold. Access the LONGFT1 PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Does it shift to positive value? 	Yes	Go to the next step.
		No	Go to Step 14.
13	INSPECT PURGE CONTROL SYSTEM OPERATION <ul style="list-style-type: none"> Perform the Purge Control System Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to Step 27.
		No	Go to the next step.
14	INSPECT AIR CLEANER ELEMENT <ul style="list-style-type: none"> Remove the air cleaner element with the engine is running. (See AIR CLEANER ELEMENT REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Does the engine speed increase? 	Yes	Inspect the air cleaner element. (See AIR CLEANER ELEMENT INSPECTION [SKYACTIV-G 2.0].) <ul style="list-style-type: none"> If there is any malfunction: <ul style="list-style-type: none"> Clean or replace the air cleaner element, then go to Step 27. (See AIR CLEANER ELEMENT REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) If there is no malfunction: <ul style="list-style-type: none"> Go to the next step.
		No	Go to the next step.
15	INSPECT ELECTRIC VARIABLE VALVE TIMING DRIVER <ul style="list-style-type: none"> Inspect the electric variable valve timing driver. (See ELECTRIC VARIABLE VALVE TIMING MOTOR/DRIVER INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Replace the electric variable valve timing motor/driver, then go to Step 27. (See ELECTRIC VARIABLE VALVE TIMING MOTOR/DRIVER REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.

STEP	INSPECTION		ACTION
16	INSPECT ELECTRIC VARIABLE VALVE TIMING MOTOR <ul style="list-style-type: none"> Inspect the electric variable valve timing motor. (See ELECTRIC VARIABLE VALVE TIMING MOTOR/DRIVER INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Replace the electric variable valve timing motor/driver, then go to Step 27. (See ELECTRIC VARIABLE VALVE TIMING MOTOR/DRIVER REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
17	INSPECT ELECTRIC VARIABLE VALVE TIMING ACTUATOR <ul style="list-style-type: none"> Inspect the electric variable valve timing actuator. (See ELECTRIC VARIABLE VALVE TIMING ACTUATOR INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Replace the electric variable valve timing actuator, then go to Step 27. (See ELECTRIC VARIABLE VALVE TIMING ACTUATOR, HYDRAULIC VARIABLE VALVE TIMING ACTUATOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
18	INSPECT HYDRAULIC VARIABLE VALVE TIMING CONTROL SYSTEM OPERATION <ul style="list-style-type: none"> Perform the Hydraulic Variable Valve Timing Control System Operation Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to Step 27.
		No	Go to the next step.
19	INSPECT FUEL INJECTOR OPERATION <ul style="list-style-type: none"> Perform the Fuel Injector Operation Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to Step 27.
		No	Go to the next step.
20	INSPECT FUEL PRESSURE (HIGH-SIDE) <ul style="list-style-type: none"> Start the engine and warm it up completely. Access the FUEL_PRES PID using the M-MDS at idle. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Is the FUEL_PRES PID value approx. 3 MPa {31 kgf/cm², 435 psi}? 	Yes	Go to Step 24.
		No	Lower than 3 MPa {31 kgf/cm², 435 psi} : <ul style="list-style-type: none"> Inspect the following: <ul style="list-style-type: none"> Fuel leakage at the fuel line and fuel injector Fuel pump <ul style="list-style-type: none"> Perform the Fuel Pump (Low-pressure Side) Operation Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.0].) Fuel pressure sensor (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-G 2.0].) High pressure fuel pump (See HIGH PRESSURE FUEL PUMP INSPECTION [SKYACTIV-G 2.0].) If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the malfunctioning part according to the inspection results, then go to Step 27. If there is no malfunction: <ul style="list-style-type: none"> Go to Step 23. Higher than 3 MPa {31 kgf/cm², 435 psi} : <ul style="list-style-type: none"> Go to the next step.
21	IDENTIFY CAUSE BY FUEL PRESSURE SENSOR OR HIGH PRESSURE FUEL PUMP <ul style="list-style-type: none"> Is the vehicle acceleration performance normal? 	Yes	Go to the next step.
		No	Go to Step 23.
22	INSPECT FUEL PRESSURE SENSOR <ul style="list-style-type: none"> Inspect the fuel pressure sensor. (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Replace the fuel distributor, then go to Step 27. (See FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to Step 24.

STEP	INSPECTION	ACTION	
23	INSPECT SPILL VALVE CONTROL SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the high pressure fuel pump and PCM connectors. Inspect for continuity between high pressure fuel pump terminal A (wiring harness-side) and body ground. Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to ground, then go to Step 27.
		No	Replace the high pressure fuel pump, then go to Step 27. (See HIGH PRESSURE FUEL PUMP REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
24	INSPECT FUEL PRESSURE (LOW-SIDE) <ul style="list-style-type: none"> Connect the fuel pressure gauge between fuel pump and high pressure fuel pump. Measure the low side fuel pressure. (See FUEL LINE PRESSURE INSPECTION [SKYACTIV-G 2.0].) Is the low side fuel pressure within specification? Specification: <ul style="list-style-type: none"> 405—485 kPa {4.13—4.94 kgf/cm², 58.8—70.3 psi} 	Yes	Go to the next step.
		No	Inspect the following: <ul style="list-style-type: none"> Fuel line restriction Fuel filter clogged <ul style="list-style-type: none"> If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the malfunctioning part according to the inspection results. If there is no malfunction: <ul style="list-style-type: none"> Replace the fuel pump unit. (See FUEL PUMP UNIT REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to Step 27.
25	INSPECT IGNITION SYSTEM OPERATION <ul style="list-style-type: none"> Perform the Spark Test. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.0].) Is a strong blue spark visible at each cylinder? 	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results, then go to Step 27.
26	INSPECT PCV VALVE OPERATION <ul style="list-style-type: none"> Inspect the PCV valve operation. (See POSITIVE CRANKCASE VENTILATION (PCV) VALVE INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Replace the PCV valve, then go to the next step. (See POSITIVE CRANKCASE VENTILATION (PCV) VALVE REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
27	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> Make sure to reconnect all disconnected connectors. Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) Perform the Drive Mode 03 (Variable Valve Timing, A/F Sensor Heater, HO2S Heater, A/F Sensor, HO2S and TWC Repair Verification Drive Mode). (See OBD DRIVE MODE [SKYACTIV-G 2.0].) Stop the vehicle and access the ON BOARD READINESS TEST to inspect the Drive Mode completion status. Verify the FUEL_EVAL PID changes to yes. <ul style="list-style-type: none"> If not, perform the Drive Mode 03 (Variable Valve Timing, A/F Sensor Heater, HO2S Heater, A/F Sensor, HO2S and TWC Repair Verification Drive Mode). (See OBD DRIVE MODE [SKYACTIV-G 2.0].) Perform the Pending Trouble Code Access Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Is the PENDING CODE for this DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.

STEP	INSPECTION		ACTION
28	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.