

DTC P1260:00 [SKYACTIV-G 2.0]

id0102h1856800

DTC P1260:00	Immobilizer system problem
DETECTION CONDITION	<ul style="list-style-type: none">• The start stop unit detects an immobilizer system malfunction. Diagnostic support note <ul style="list-style-type: none">• This is a continuous monitor (other).• The check engine light does not illuminate.• FREEZE FRAME DATA (Mode 2)/Snapshot data is not available.• The DTC is not stored in the PCM memory.
FAIL-SAFE FUNCTION	—
POSSIBLE CAUSE	<ul style="list-style-type: none">• Immobilizer system malfunction• PCM malfunction
SYSTEM WIRING DIAGRAM	—

Diagnostic Procedure

STEP	INSPECTION	ACTION
1	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none">• Verify related Service Information availability.• Is any related Service Information available?	Yes Perform repair or diagnosis according to the available Service Information. <ul style="list-style-type: none">• If the vehicle is not repaired, go to the next step.
		No Go to the next step.
2	VERIFY IMMOBILIZER SYSTEM DTC <ul style="list-style-type: none">• Verify the immobilizer system DTC. (See DTC INSPECTION [IMMOBILIZER SYSTEM].)• Are any DTCs present?	Yes Go to the applicable DTC inspection. (See DTC TABLE [IMMOBILIZER SYSTEM].)
		No Go to the next step.
3	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none">• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].)• Perform the KOEO self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].)• Is the same DTC present?	Yes Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No Go to the next step.
4	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none">• Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].)• Are any DTCs present?	Yes Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No DTC troubleshooting completed.