

Im2mesh Function List and Parameters

Table of Contents

Functions.....	2
Major functions.....	2
im2mesh.....	2
im2meshBuiltIn.....	3
bounds2mesh.....	3
bounds2meshBuiltIn.....	3
bounds2geo.....	3
im2Bounds.....	4
getExactBounds.....	4
getCtrlPnts.....	4
smoothBounds.....	4
smoothBoundsCCMA.....	4
simplifyBounds.....	4
deltri1.....	4
Functions for plotting.....	5
plotMeshes.....	5
plotBounds.....	5
plotBounds2.....	5
Functions for mesh quality.....	5
tricost.....	5
MeshQualityQuads.....	5
Functions for polygonal boundary.....	6
addIntersectPnts.....	6
addPnt2Bound.....	6
insertMidPnt.....	6
insertEleSizeSeed.....	6
insertBiasedSeed.....	6
Functions for convert variable type.....	6
getPolyNodeEdge.....	6
regroup.....	6
bound2polyshape.....	7
polyshape2bound.....	7
extractMsh.....	7
bounds2pde3d.....	7
Functions for extracting surface and boundary edge.....	7
bound2SurfaceLoop.....	7
tria2Surface.....	7
tria2BoundEdge.....	8
Functions for exporting.....	8
printDxf.....	8
getNodeEle.....	8
getInterf.....	8
getBCNode.....	8
printInp2d.....	8
printBdf2d.....	9
printMsh.....	9

printTria.....	9
fixOrdering.....	9
insertNode.....	10
Other functions.....	10
xyRange.....	10
delRedundantVertex.....	10
totalNumVertex.....	10
totalNumCtrlPnt.....	10
delZeroAreaPoly.....	10
getPixelPercent.....	11
getPolyShapePercent.....	11
Deprecated functions.....	11
poly2mesh (deprecated).....	11
poly2meshBuiltIn (deprecated).....	11
printGeo (deprecated).....	11
printInp_multiPart (deprecated).....	11
printInp_multiSect (deprecated).....	12
printBdf (deprecated).....	12
Parameters.....	12
Parameters and their default values of function im2mesh.....	12
Parameters and their default values of function im2meshBuiltIn.....	12
tf_avoid_sharp_corner.....	13
lambda.....	13
mu.....	13
iters.....	13
thresh_turn.....	13
thresh_vert_smooth.....	13
tolerance.....	14
thresh_vert_simplify.....	14
grad_limit.....	14
hmax.....	14
mesh_kind.....	14
select_phase.....	14
hgrad.....	15
hmin.....	15
tf_mesh.....	15

Functions

Major functions

im2mesh

Generate triangular mesh based on grayscale segmented image using MESH2D mesh generator (Darren Engwirda)

```
[ vert, tria, tnum ] = im2mesh( im ); % default setting
[ vert, tria, tnum ] = im2mesh( im, opt );

[ vert, tria, tnum, vert2, tria2 ] = im2mesh( im );
[ vert, tria, tnum, vert2, tria2 ] = im2mesh( im, opt );
```

```
[ vert, tria, tnum, vert2, tria2, conn, bounds ] = im2mesh( im );
[ vert, tria, tnum, vert2, tria2, conn, bounds ] = im2mesh( im, opt );
```

If we do not need to generate mesh but we want to check the simplified polygonal boundary

```
opt.tf_mesh = false;
bounds = im2mesh( im, opt );
```

im2meshBuiltin

Generate triangular mesh based on grayscale segmented image using matlab built-in function generateMesh

```
[ vert, tria, tnum ] = im2meshBuiltin( im );    % default setting
[ vert, tria, tnum ] = im2meshBuiltin( im, opt );

[ vert, tria, tnum, vert2, tria2 ] = im2meshBuiltin( im );
[ vert, tria, tnum, vert2, tria2 ] = im2meshBuiltin( im, opt );

[ vert, tria, tnum, vert2, tria2, model1, model2 ] = im2meshBuiltin( im );
[ vert, tria, tnum, vert2, tria2, model1, model2 ] = im2meshBuiltin( im, opt );
% model1, model2 - MATLAB PDE model object
```

bounds2mesh

Generate meshes of parts defined by polygonal boundary. Use MESH2D mesh generator (Darren Engwirda).

```
[vert,tria,tnum] = bounds2mesh( bounds, hmax, grad_limit );
[vert,tria,tnum] = bounds2mesh( bounds, hmax, grad_limit, opt );

[vert,tria,tnum,vert2,tria2] = bounds2mesh( bounds, hmax, grad_limit );
[vert,tria,tnum,vert2,tria2] = bounds2mesh( bounds, hmax, grad_limit, opt );
```

bounds2meshBuiltin

Generate meshes of parts defined by polygonal boundary. Mesh generator: generateMesh.

```
[vert,tria,tnum] = bounds2meshBuiltin( bounds, hgrad, hmax, hmin);
[vert,tria,tnum,vert2,tria2] = bounds2meshBuiltin( bounds, hgrad, hmax, hmin);
[vert,tria,tnum,vert2,tria2,model1,model2] = bounds2meshBuiltin( bounds, hgrad, hmax, hmin);
```

bounds2geo

Generate geo file for Gmsh based on polygonal boundary

```
bounds2geo( bounds, path_to_geo )
bounds2geo( bounds, path_to_geo, opt );
```

im2Bounds

Extract exact polygonal boundaries from grayscale segmented image using `getExactBounds.m`

```
bounds = im2Bounds( im );
```

getExactBounds

Get the exact boundaries (polygonal) of binary image

```
Bs = getExactBounds( bw );
```

getCtrlPnts

Get control points in polygon boundaries

```
new_bounds = getCtrlPnts( bounds, tf_avoid_sharp_corner, size_im );
```

smoothBounds

Smooth polygon boundaries using 2d Taubin Smoothing (`taubinSmooth.m`)

```
new_bounds = smoothBounds( bounds, lambda, mu, iters, ...  
                           thresh_num_turn, thresh_num_vert );  
new_bounds = smoothBounds( bounds, lambda, mu, iters, thresh_num_turn );  
new_bounds = smoothBounds( bounds, lambda, mu, iters );  
new_bounds = smoothBounds( bounds, lambda, mu, 0 );      % no smoothing
```

smoothBoundsCCMA

Smooth polygon boundaries using CCMA smoothing algorithm (`CCMA.m`)

CCMA stand for curvature corrected moving average (<https://github.com/UniBwTAS/ccma>).

```
new_bounds = smoothBoundsCCMA( bounds, w_ma, w_cc, ...  
                               thresh_num_turn, thresh_num_vert );
```

simplifyBounds

Simplify polygon boundaries using Douglas–Peucker algorithm (`dpsimplify.m`)

```
new_bounds = simplifyBounds( bounds, tolerance, thresh_num_vert );  
new_bounds = simplifyBounds( bounds, tolerance );
```

deltri1

2d Delaunay triangulation with phase information.

```
[vert,conn,tria,tnum] = deltri1( node, edge, part );
```

Functions for plotting

plotMeshes

Plot triangular mesh. Also works for quadratic or quadrilateral elements.

```
plotMeshes( vert, ele );           % one phase
plotMeshes( vert, ele, tnum );    % multiple phases

% Setup colormap. color_code can be 0 to 10.
plotMeshes( vert, ele, [], color_code );
plotMeshes( vert, ele, tnum, color_code )
plotMeshes( vert, ele, tnum, 2 );
```

plotBounds

Plot polygon boundaries

```
plotBounds( bounds );
plotBounds( bounds, true );        % show starting and control points
plotBounds( bounds, false, '' );  % multi-color
plotBounds( bounds, false, 'k.-' ); % line spec
plotBounds( bounds, true, 'k.-' ); % line spec
```

plotBounds2

Plot two polygon boundaries

```
plotBounds2( boundsA, boundsB );
```

Functions for mesh quality

tricast

Evaluate mesh quality of triangular mesh

```
tricast(vert,tria);
```

MeshQualityQuads

Evaluate mesh quality of quadrilateral mesh

```
[Q,theta] = MeshQualityQuads( ele(:,1:4), vert(:,1), vert(:,2) );
```

Functions for polygonal boundary

addIntersectPnts

Search and add intersect points (vertex).

```
bounds = addIntersectPnts( bounds, tolerance );
```

addPnt2Bound

Add points to polygonal boundaries. Check whether points are lying near polygon bounds $\{i\}\{j\}$. If it is, add point to polygon bounds $\{i\}\{j\}$.

```
bounds = addPnt2Bound( points, bounds, tolerance );
```

insertMidPnt

Repeatedly inserts midpoints between vertices of a polyline.

```
xyNew = insertMidPnt( xy, iters );
```

insertEleSizeSeed

insert equally spaced seeds to polyline (edges).

```
xyNew = insertEleSizeSeed( xy, targetLen );
```

insertBiasedSeed

Inserts biased points between vertices of an edge

```
xyNew = insertBiasedSeed( xy, iters, ratio );
```

Functions for convert variable type

getPolyNodeEdge

Get nodes and edges of polygonal boundary

```
[ poly_node, poly_edge ] = getPolyNodeEdge( bounds );
```

regroup

Organize cell array poly_node, poly_edge into array nodeU, edgeU and cell array part for MESH2D. Array nodeU, edgeU and cell array part is planar straight-line graph (PSLG).

```
[ nodeU, edgeU, part ] = regroup( poly_node, poly_edge );
```

bound2polyshape

Convert a cell array of polygonal boundaries to a cell array of polyshape objects.

```
p = bound2polyshape( bounds );
```

polyshape2bound

Convert a cell array of polyshape objects to a cell array of polygonal boundaries.

```
bounds = polyshape2bound( p );
```

extractMsh

Extract nodes and elements from struct variable 'msh'. Struct variable 'msh' is generated by Gmsh.

```
[vert,ele,tnum] = extractMsh( msh );
```

bounds2pde3d

Create Matlab 3d pde model object based on polygonal boundaries.

```
model3d = bounds2pde3d( bounds, height, scale_factor );
```

Functions for extracting surface and boundary edge

bound2SurfaceLoop

Convert a cell array of polygonal boundaries to a nesting cell array for storing multiple loops (Gmsh).

```
[ phaseLoops, vertex, edge ] = bound2SurfaceLoop( bounds );
```

tria2Surface

Convert triangular mesh to isolated surfaces.

```
[ phaseLoops, phaseTria ] = tria2Surface( vert,conn,tria,tnum );
```

phaseTria is a nesting cell array for storing triangular mesh for each surface. phaseTria{i}{j} means the j-th plane surface within the i-th physical surface. phaseTria{i}{j} is a p-by-3 array.

tria2BoundEdge

Convert triangular mesh to boundary edges of surfaces.

```
[edge, phaseEdge] = tria2BoundEdge( tria, tnum );
```

edge is E-by-2 array. Node numbering of two connecting vertices of boundary edges in all surfaces. Each row is one edge.

phaseEdge is a cell array (1-by-num_phase). Boundary edges of surfaces in each phase

Functions for exporting

printDxf

Print polygonal boundary to dxf files.

```
printDxf( bounds, file_name );
```

getNodeEle

Get node coordinates and elements from mesh

```
[ nodecoor_list, nodecoor_cell, ele_cell ] = getNodeEle( vert, tria, tnum );
```

getInterf

Find nodes at the interface between different phases.

```
interfnod_cell = getInterf( nodecoor_cell );
```

getBCNode

Find nodes at the boundary.

```
[ xmin_node_cell, xmax_node_cell, ...  
  ymin_node_cell, ymax_node_cell ] = getBCNode( nodecoor_cell );
```

printInp2d

Write 2d finite element mesh (nodes and elements) to inp file (Abaqus).

The exported inp file will have a model with one part, which contains multiple sections. Each section corresponds to one material phase in the mesh.

Works for linear and quadratic element.

Works for triangular and quadrilateral element.

```
printInp2d( vert, ele );
printInp2d( vert, ele, [], [], [], file_name );
printInp2d( vert, ele, tnum );
printInp2d( vert, ele, tnum, [], precision );
printInp2d( vert, ele, tnum, ele_type, precision );
printInp2d( vert, ele, tnum, ele_type, precision, file_name );
```

printBdf2d

Write 2d finite element mesh (nodes and elements) to bdf file (Nastran bulk data, compatible with COMSOL).

Works for linear triangular and linear quadrilateral element.

Not work for quadratic element.

```
printBdf2d( vert, ele );
printBdf2d( vert, ele, [], [], [], file_name );
printBdf2d( vert, ele, tnum );
printBdf2d( vert, ele, tnum, [], precision );
printBdf2d( vert, ele, tnum, [], precision, file_name );
```

printMsh

Write 2d finite element mesh (nodes and elements) to msh file. msh is Gmsh mesh file format. MSH file format version: 4.1. Test in software Gmsh 4.13.1

printMsh only works for 2d triangles & linear element.

```
printMsh( vert, ele );
printMsh( vert, ele, [], [], [], file_name );
printMsh( vert, ele, tnum );
printMsh( vert, ele, [], [], precision );
printMsh( vert, ele, tnum, [], precision );
printMsh( vert, ele, tnum, [], precision );
printMsh( vert, ele, tnum, [], precision, file_name );
```

printTria

Print nodes and elements into file 'test.node' and 'test.ele'. Only support triangular element with 3 nodes.

Precision is number of digits behind decimal point, for node coordinates

```
printTria( vert, tria, tnum, precision );
```

fixOrdering

Fix node ordering in each elements of 2D finite element mesh. Node ordering in a element should be counterclockwise.

```
ele = fixOrdering( vert, ele );
```

insertNode

Inserts midpoints into all edges to form quadratic elements. Works for triangular and quadrilateral element

```
[vertU, triaU] = insertNode(vert, tria);
```

Other functions

xyRange

Get the range of x y coordinate in polygonal boundary. Input argument can be a nested cell array of polygonal boundary or a cell array of polyshape.

```
[xminG,xmaxG,yminG,ymaxG] = xyRange( inarg );
```

delRedundantVertex

Delete redundant vertices and update element data

```
function [ vert, ele ] = delRedundantVertex( vert, ele )
```

totalNumVertex

Calculate the total number of vertices in all polygonal boundaries

```
num_vert = totalNumVertex( bounds );
```

totalNumCtrlPnt

Calculate the total number of control points in all polygonal boundaries. Each polygon has at least one ccontrol point (i.e., the starting vertex).

```
num_ctrlp = totalNumCtrlPnt( bounds );
```

delZeroAreaPoly

Delete polygon with zero area

```
bounds = delZeroAreaPoly( bounds );
```

getPixelPercent

Calculate the area percentage of each grayscale in image

```
percent_pixel = getPixelPercent( im );
```

getPolyShapePercent

Calculate the area percentage of each phase in polygonal boundaries

```
percent_polyarea = getPolyShapePercent( bounds );
```

Deprecated functions

poly2mesh (deprecated)

Generate meshes of parts defined by polygons using MESH2D mesh generator (Darren Engwirda)

```
[vert,tria,tnum] = poly2mesh( poly_node, poly_edge, hmax, mesh_kind, grad_limit );  
  
[vert,tria,tnum,vert2,tria2] = poly2mesh( poly_node, poly_edge, hmax, mesh_kind, grad_limit );  
[vert,tria,tnum,vert2,tria2] = poly2mesh( poly_node, poly_edge, hmax, mesh_kind, grad_limit, op
```

poly2meshBUILTIn (deprecated)

Generate meshes of parts defined by polygons using matlab built-in function generateMesh.

```
[vert,tria,tnum] = poly2meshBUILTIn( poly_node, poly_edge, pcell, hgrad, hmax, hmin );  
[vert,tria,tnum,vert2,tria2] = poly2meshBUILTIn( poly_node, poly_edge, ...  
                                              pcell, hgrad, hmax, hmin );
```

printGeo (deprecated)

Print geo file (Gmsh input file format).

```
printGeo( C, point, line, opt, file_name );
```

printInp_multiPart (deprecated)

Print the nodes and elements into Inp file 'test_multi_parts.inp', test in software Abaqus. Each phase corresponds to one part in Abaqus.

```
printInp_multiPart( nodecoor_cell, ele_cell, ele_type, precision );  
printInp_multiPart( nodecoor_cell, ele_cell, ele_type, precision, file_name );
```

printInp_multiSect (deprecated)

Print the nodes and elements into Inp file 'test_multi_sections.inp', test in software Abaqus. One part with multiple sections. Each phase corresponds to one section in Abaqus.

```
printInp_multiSect( nodecoor_list, ele_cell, ele_type, precision );
printInp_multiSect( nodecoor_list, ele_cell, ele_type, precision, file_name );
```

printBdf (deprecated)

Print the nodes and elements into Inp file 'test.bdf'

```
printBdf( nodecoor_list, ele_cell, precision );
printBdf( nodecoor_list, ele_cell, precision, file_name );
```

Parameters

Parameters and their default values of function im2mesh

```
opt.tf_avoid_sharp_corner = false;
opt.lambda = 0.5;
opt.mu = -0.5;
opt.iters = 100;
opt.thresh_turn = 0;
opt.thresh_vert_smooth = 0;
opt.tolerance = 0.3;
opt.thresh_vert_simplify = 0;
opt.select_phase = [];
opt.grad_limit = 0.25;
opt.hmax = 500;
opt.mesh_kind = 'del aunay';
opt.tf_mesh = true;
```

Parameters and their default values of function im2meshBuiltIn

```
opt.tf_avoid_sharp_corner = false;
opt.lambda = 0.5;
opt.mu = -0.5;
opt.iters = 100;
opt.thresh_turn = 0;
opt.thresh_vert_smooth = 0;
opt.tolerance = 0.3;
opt.thresh_vert_simplify = 0;
opt.select_phase = [];
opt.hgrad = 1.25;
opt.hmax = 500;
opt.hmin = 1;
```

tf_avoid_sharp_corner

Type: boolean.

For getCtrlPnts.

Meaning: Whether to avoid sharp corner when simplifying polygon.

lambda

Type: Float. Range: $0 < \text{Lambda} < 1$.

For smoothBounds.

Meaning: How far each node is moved toward the average position of its neighbours during every second iteration.

mu

Type: Float. Range: $-1 < \text{Mu} < 0$.

For smoothBounds.

Meaning: How far each node is moved opposite the direction of the average position of its neighbours during every second iteration.

iters

Type: Integer. Range: ≥ 0 .

For smoothBounds.

Meaning: Number of iterations in Taubin smoothing. If you don't need polyline smoothing, set Iterations to 0.

thresh_turn

Type: Integer. Range: ≥ 0 .

For smoothBounds.

Meaning: Threshold value for the number of turning points in a polyline during polyline smoothing. Only those polylines with number of turning points greater than this threshold will be smoothed.

thresh_vert_smooth

Type: Integer or an array with two elements

For smoothBounds.

Meaning: Threshold value for the number of vertices in a polyline during polyline smoothing. Only those polylines with number of vertices greater than this threshold will be smoothed. See section 4 in Tutorial.pdf

tolerance

Type: Float. Range: ≥ 0 .

For simplifyBounds.

Meaning: The maximum allowable deviation of a vertex from the simplified curve. It's for Douglas-Peucker algorithm. If you don't need to simplify polylines, set tolerance to 0 or a small value, such as $1e-10$

thresh_vert_simplify

Type: Integer or an array with two elements

For simplifyBounds.

Meaning: Threshold value for the number of vertices in a polyline during polyline simplification. Only those polylines with number of vertices greater than this threshold will be simplified. See section 4 in Tutorial.pdf

grad_limit

Type: Float. Range: > 0 . Typical value: 0.2 - 0.5.

For poly2mesh & MESH2D.

Meaning: Gradient-limit, a limit on the gradient of mesh-size function.

hmax

Type: Float. Range: > 0 .

For poly2mesh & MESH2D.

Meaning: Maximum mesh edge lengths. This is an approximate upper bound on the mesh edge lengths.

mesh_kind

Value: 'delaunay' or 'delfront'

For poly2mesh & MESH2D.

Meaning: Meshing algorithm used to create mesh-size functions based on an estimate of the "local-feature-size" associated with a polygonal domain. 'delaunay' means Delaunay-refinement. 'delfront' means Frontal-Delaunay.

select_phase

Type: vector

Meaning: Select certain phases in image for meshing. If 'select_phase' is [], all the phases will be chosen.

'select_phase' is an index vector for sorted grayscales (ascending order) in an image. For example, an image with grayscales of 40, 90, 200, 240, 255. If u're interested in 40, 200, and 240, then set 'select_phase' as [1 3 4]. Those phases corresponding to grayscales of 40, 200, and 240 will be chosen to perform meshing.

hgrad

Type: Float. Range: $1 \leq \text{Mesh Growth Rate} \leq 2$. Typical value: 1.2 - 1.5.

For poly2meshBuiltIn & generateMesh

Meaning: Mesh growth rate, the rate at which the mesh transitions between regions of different edge size.

hmin

Type: Float. Range: ≥ 0 .

For poly2meshBuiltIn & generateMesh

Meaning: Min mesh edge length, an approximate lower bound on the mesh edge lengths.

tf_mesh

Boolean.

Meaning: Whether to mesh. If true, meshing. Else, no meshing and return boundary