

0		Header		0		0		FF		Address		Sub-Address		Command		Data Length		Data												
0		0		0		0		FF		0-FF		0-FF		0-FF		0-FF														
		Notes		Action		Sub-Address		Command		Command (HEX)		Data Length		Data																
Main			NOOP	0	0	0	0	0	Byte:1	2	3	4	5	6	7	8	9	10	11	12										
			Reserve for core protocol	0	1	1	0																							
		Starts planned move	Start	0	2	2	0																							
			Pause	0	3	3	0																							
		Stops planned move. Must be executed before controller will accept other commands.	Stop	0	4	4	0																							
		Toggles on/off state of debug LED	Debug LED	0	5	5	0																							
			Timing Master	0	6	6	0																							
			Set Stored Name	0	7	7	1-10																							
			Set Device Address	0	8	8	1	2-255 [Byte]																						
			Set Common Line for Step Pulsing	0	9	9	1	0.1,2 [Byte]																						
			Return Home All Motors	0	10	A	0																							
			Motors Max Step Rate	0	11	B	2	Steps/Second [Int]																						
			Alt Input Edge (RISING, FALLING, or CHANGE)	0	12	C	1	0.1,2 [Byte]																						
			Alt I/O Mode	0	13	D	2	Ring (0-255) [Byte]	Tip (0-255) [Byte]																					
			Set Joystick Watchdog	0	14	E	1	True/False (1,0) [Byte]																						
			Alt Output Before Shot Delay Time	0	15	F	2	Time (ms) [Int]																						
			Alt Output After Shot Delay Time	0	16	10	2	Time (ms) [Int]																						
			Alt Output Before Shot Time	0	17	11	2	Time (ms) [Int]																						
			Alt Output After Shot Time	0	18	12	2	Time (ms) [Int]																						
			Alt Output Trigger level	0	19	13	1	HIGH/LOW (1,0) [Byte]																						
			Max Program Run Time	0	20	14	4	Max Run Time (mS) [Ulong]																						
			Start Program Delay	0	21	15	4	Start Time Delay (seconds) [Ulong]																						
			Set SMS / Continuous Program Mode	0	22	16	1	0 (SMS), 1 (Time Lapse Cont.), 2 (Video Cont.) [Byte]																						
			Set Joystick Mode	0	23	17	1	True/False (1,0) [Byte]																						
		Causes the motors to go back and forth between the start and stop positions	Toggle Ping-Pong Flag	0	24	18	0																							
		Status Request	0	100	64	0	<Status Type>	Version #	<returns> with header and master address in front (00 00 00 00 00 FF 00 00 01 Length Data)																					
		Firmware Version	0	100	64	0	Value Type [Byte]	Version #	True/False	Time (ms)																				
		Run Status	0	101	65	0	Value Type [Byte]	True/False	Time (ms)																					
		Run Time	0	102	66	0	Value Type [Ulong]	True/False	Time (ms)																					
		Currently Exposing	0	103	67	0	Value Type [Byte]	True/False	Time (ms)																					
		Timing Master Value	0	104	68	0	Value Type [Byte]	True/False	Time (ms)																					
		Name	0	105	69	0	Value Type [String]	String [1-10 Characters, Null-terminated, Null padded]																						
		Motors Max Step Rate	0	106	6A	0	Value Type [Ulong]	Steps/Second																						
		Voltage Readings	0	107	6B	0	Value Type [Fixed]	Voltage (V) (Fixed point – must divide by 100 on master side)																						
		Current to Motors	0	108	6C	0	Value Type [Fixed]	Current (amps) (Fixed point – must divide by 100 on master side)																						
		Alt Input Edge (RISING, FALLING, or CHANGE)	0	109	6E	0	Value Type [Byte]	0.1, 2																						
		Alt I/O Mode	0	110	6F	0	Value Type [Int]	[Byte 0] Ring (0-255) [Byte 1] Tip (0-255)																						
		Limit Switch High/Low Status	0	111	70	0	Value Type [Int]	[Byte 0] Ring, High/Low (1,0) [Byte 1] Tip, High/Low (1,0)																						
		Alt Output Before Shot Delay Time	0	112	70	0	Value Type [Ulong]	Time (ms)																						
		Alt Output After Shot Delay Time	0	113	71	0	Value Type [Ulong]	Time (ms)																						
		Alt Output Before Shot Time	0	114	72	0	Value Type [Ulong]	Time (ms)																						
		Alt Output After Shot Time	0	115	73	0	Value Type [Ulong]	Time (ms)																						
		Alt Output Trigger level	0	116	74	0	Value Type [Byte]	HIGH/LOW (1,0)																						
		Start Program Delay	0	117	75	0	Value Type [Ulong]	Start Time Delay (seconds)																						
		SMS / Continuous Program Mode	0	118	76	0	Value Type [Byte]	0 (SMS), 1 (Cont.)																						
		Controller Power Cycle	0	119	77	0	Value Type [Byte]	True/False (1,0)																						
		Joystick Mode	0	120	78	0	Value Type [Byte]	True/False (1,0)																						
		Ping-Pong Flag	0	121	79	0	Value Type [Byte]	True/False (1,0)																						
		Joystick Watchdog Status	0	122	7A	0	Value Type [Byte]	True/False (1,0)																						
Motors		NOOP	1-3	0	0	0																								
		Reserve for core protocol	1-3	1	1	0																								
		Motor Sleep	1-3	2	2	1	True/False (1,0) [Byte]																							
		Motor Enable	1-3	3	3	1	True/False (1,0) [Byte]																							
		Stop Motor Now	1-3	4	4	0																								
		Set Backlash Steps	1-3	5	5	2	Steps [Ulong]																							
		Set Microstep Value	1-3	6	6	1	1, 2, 4, 8, 16 [Byte]																							
		Set Motor Max Step Speed	1-3	7	7	2	Steps/Second [Ulong]																							
		Set Direction	1-3	8	8	1	0, 1 [Byte]																							
		Saves home limit position	1-3	9	9	0																								
		Set End Limit Here	1-3	10	A	0																								
		Send Motor to Home Limit	1-3	11	B	0																								
		Send Motor to End Limit	1-3	12	C	0																								
Manual Move Commands		Does not apply to finite manual moves	1-3	13	D	4	Steps/Second [float]																							
		Does not apply to finite manual moves	1-3	14	E	4	Steps/Second*2 [float]																							
		Direct move command, does not require use of 'start' and 'stop' commands.	1-3	15	F	5	Dir (0, 1) [Byte]	Steps [Ulong]																						
Programmed Travel Commands		Set Program Start point	1-3	16	10	4	Step position [long]																							
		Set Program Stop point	1-3	17	11	4	Step position [long]																							
		Set Easing (Ramping) Mode	1-3	18	12	1	1, 2, 3																							
		How many shots should this motor wait before moving?	1-3	19	13	2	Shots [Ulong]																							
		Set Travel Shots(SMS) / Travel Time (Cont.)	1-3	20	14	4	Shots (SMS) or Total Travel Time (ms) (cont.) [Ulong]																							
		Set Program Accel	1-3	21	15	4	Accel Period – Shots (SMS) or Time in ms (Cont.) [Ulong]																							
		Set Program Decel	1-3	22	16	4	Decel Period – Shots (SMS) or Time in ms (Cont.) [Ulong]																							
		Send Motor to Program Start Point	1-3	23	17	0																								
		Send Motor to Program Stop Point	1-3	24	18	0																								

Stop-Motion Travel Commands	Manual SMS movement. Not yet implemented.	Advance One SMS Increment	1-3	25	19	0													
	Manual SMS movement. Not yet implemented.	Go Back One SMS Increment	1-3	26	1A	0													
	Sets the current position as home, disables limits, and sets start/stop positions to home position.	Reset Limits and Program Start/Stop Positions	1-3	27	1B	0													
		Auto Set Program Microsteps	1-3	30	1E	0													
General Motor Query Commands		Status Request	1-3	100			<Status Type>	<returns> with header and master address in front (00 00 00 00 FF 00 00 01 Length Data)											
		Motor Enable	1-3	100	64	0	Value Type [Byte]	True/False (1.0)											
		Backlash Steps	1-3	101	65	0	Value Type [UInt]	Steps											
		Microstep Value	1-3	102	66	0	Value Type [Byte]	1, 2, 4, 8, 16											
		Direction	1-3	103	67	0	Value Type [Byte]	0, 1											
		Motor Max Step Speed	1-3	104	68	0	Value Type [Int]	Steps/Second											
		End Limit Position	1-3	105	69	0	Value Type [Long]	Position											
		Current Motor Position	1-3	106	6A	0	Value Type [Long]	Position											
Manual Move Query Commands		Continuous Speed	1-3	108	6C	0	Value Type [Pseudo-float-Fixed point - must divide by 100 on master side]	Steps/Second											
		Motor Continuous Motion Accel/Decel Rate	1-3	109	6D	0	Value Type [Pseudo-float-Fixed point - must divide by 100 on master side]	Steps/Second*2											
Programmed Travel Query Commands		Easing (Ramping) Mode	1-3	110	6E	0	Value Type [Byte]	1, 2, 3											
		Program Start point	1-3	111	6F	0	Value Type [Long]	Position											
		Program Stop point	1-3	112	70	0	Value Type [Long]	Position											
		Travel Shots(SMS) / Travel Time (Cont.)	1-3	113	71	0	Value Type [ULong]	Shots (SMS) or Total Travel Time (ms) (cont.)											
		Lead-In Shots	1-3	114	72	0	Value Type [Int]	Shots											
		Program Accel	1-3	115	73	0	Value Type [ULong]	Accel Period - Shots (SMS) or Time in ms (Cont.)											
		Program Decel	1-3	116	74	0	Value Type [ULong]	Decel Period - Shots (SMS) or Time in ms (Cont.)											
		Max Steps/Sec for Cont. Program Move	1-3	117	75	0	Value Type [Pseudo-float-Fixed point - must divide by 100 on master side]	Steps/Second											
Cameras		NOOP	4	0	0	0													
		Reserve for core protocol	4	1	1	0													
		Camera Enable	4	2	2	1	True/False (1.0) [Byte]												
	Triggers exposure with length set by "Exposure Time" command.	Expose Now	4	3	3	0													
		Exposure Time	4	4	4	4		Exposure Time (mS) [ULong]											
		Focus Time	4	5	5	2		Focus Time (mS) [UInt]											
	The system will stop a move once it reaches the max number of camera exposures.	Max Shots	4	6	6	2		Count [UInt]											
		Exposure Delay	4	7	7	2		Delay (mS) [UInt]											
		Focus w/ Shutter	4	8	8	1	True/False (1.0) [Byte]												
	This causes two trigger signals to be sent to the camera in the event that the user has the camera in "mirror up" mode.	Mirror Up (Repeat Shot)	4	9	9	1	True/False (1.0) [Byte]												
	Length of SMS interval	Interval	4	10	A	4		Interval Time (mS) [ULong]											
		Status Request	4	100			<Status Type>	<returns> with header and master address in front (00 00 00 00 FF 00 00 01 Length Data)											
		Camera Enable	4	100	64	0	Value Type [Byte]	True/False (1.0)											
		Exposing now?	4	101	65	0	Value Type [Byte]	True/False (1.0)											
		Exposure Time	4	102	66	0	Value Type [ULong]	Exposure Time (mS)											
		Focus Time	4	103	67	0	Value Type [UInt]	Focus Time (mS)											
		Max Shots	4	104	68	0	Value Type [ULong]	Count											
		Exposure Delay	4	105	69	0	Value Type [UInt]	Delay (mS)											
		Focus w/ Shutter	4	106	6A	0	Value Type [Byte]	1, 0											
		Mirror Up (Repeat Shot)	4	107	6B	0	Value Type [Byte]	True/False (1.0)											
		Interval Time	4	108	6C	0	Value Type [ULong]	Interval Time (mS)											
Broadcasts		Address	Sub-Address	Command	Data Length	Data													
		Start	1	0	1	0													
		Stop	1	0	2	0													
		Pause	1	0	3	0													
	Use this to assign an address to a controller with an unknown address. Don't use when controllers are daisy-chained together.	Assign Address	1	0	4	1	2-255												

Note: nodes do not give a response to broadcast commands.

Query Value Types	
0	Byte
1	Unsigned Int
2	Int
3	Long
4	Unsigned Long
5	Float
6	String

The floats are actually fixed points. They are multiplied by 100 and transmitted as longs, so they need to be divided by 100 on the master side to resolve the true value.