

<http://ruuvi.com>

**NOTE:** Nordic Semiconductor's 1/4 wavelength impedance antenna design guide states:

"Impedance at 2.45GHz: If the size of available ground plane is approaching the ideal size and the antenna trace is uniformly suspended by the PCB substrate, then the antenna impedance will be approximately 50 ohms. If the ground plane is smaller than the ideal size and the antenna trace is routed close to the edge of the PCB, then the length of the antenna trace should be extended by about 30%."

•  $2.45 \times \pi \times \text{ground plane} = 2.45 \times \pi \times 30\text{mm} = 235\text{mm} \times 1.5 = 353\text{mm}$ .

There are the following two methods to tune the antenna:

- If the physical dimensions of the antenna can be altered, for example, with PCB antenna, adjusting the length will be one part of the tuning.
- If the antenna is not a PCB antenna, the antenna impedance towards the 50 ohm center point.
- If the antenna cannot be altered physically, more external components must be used to tune the antenna.

External components are called the matching network.

It is not possible to get the impedance exactly 50 ohm by adjusting the length of the antenna, a component must be used to pull the impedance to the 50 ohm point.

For more info, check Nordic Semiconductor's White Paper about tuning Google: "NXP-02\_Antenna\_Tuning"

Diagram showing the connection for the ARM debug header (P1) to the board pins:

Header Pin	Board Pin	Signal
1	VDD	
2	SWDIO	
3	GND	
4	SWDCLK	
5	GND	
6	SWO	
7	GND	
8	RESET	
9	GND	
10	RESET	

1	X	P6	FIDUCIAL
1	X	P7	FIDUCIAL

Id: 1/1