


Grove - Temperature Sensor V1.2

Introduction



The Grove - Temperature Sensor uses a [Thermistor](#) to detect the ambient temperature. The resistance of a thermistor will increase when the ambient temperature decreases. It's this characteristic that we use to calculate the ambient temperature. The detectable range of this sensor is -40 - 125°C, and the accuracy is $\pm 1.5^{\circ}\text{C}$

Note: This wiki works with Grove - Temperature sensor V1.1 as well, for V1.0 please refer to [Grove - Temperature Sensor](#)

Specifications

- Voltage: 3.3 ~ 5V
- Zero power resistance: 100 K Ω
- Resistance Tolerance: $\pm 1\%$
- Operating temperature range: -40 ~ +125 °C
- Nominal B-Constant : 4250 ~ 4299K

Tip

More details about Grove modules please refer to [Grove System](#)

Getting Started

After this section, you can make Grove - Temperature Sensor V1.1/1.2 run with only few steps.

Preparations


Now we are making a simple demo to get data from Grove - Temperature Sensor V1.1/1.2 require following modules.

- Seeeduino v4.2

Seeeduino V4.2 is fully compatible with Arduino.If this is your first time using Arduino, Please refer to [here](#) to start your Arduino journey.

Hardware Connection

Just connect Grove - Temperature Sensor into A5 connector of Seeeduino v4.2 as shown below:



Download

Launch Arduino IDE and click File>New to open a new page.

Then copy below code into Arduino IDE:

```
// Demo code for Grove - Temperature Sensor V1.1/1.2
```

```
// Loovee @ 2015-8-26
```

```
#include <math.h>
```

```
const int B=4275;           // B value of the thermistor
```

```
const int R0 = 100000;      // R0 = 100k
```

```
const int pinTempSensor = A5; // Grove - Temperature Sensor connect to A5
```

```
void setup()
```

```
{
```

```
  Serial.begin(9600);
```

```
}
```

```
void loop()
```

```
{
```

```
  int a = analogRead(pinTempSensor );
```

```
  float R = 1023.0/((float)a)-1.0;
```

```
  R = 100000.0*R;
```

```
  float temperature=1.0/(log(R/100000.0)/B+1/298.15)-273.15;//convert to temperature via datasheet
```

```
;
```

```
  Serial.print("temperature = ");
```

```
  Serial.println(temperature);
```

```
  delay(100);
```


```
}
```

Click Tools>Board to choose Arduino UNO and select respective serial port.

Now click Upload(CTRL+U) to burn testing code. Please refer to [here](#) for any error prompt and you can also add comment on forum

Review Results

After upload completed, Open Serial Monitor of your Arduino IDE, you can get the temperature:



Reference

If you want to know how the algorithm of temperature coming, please refer to the below image:

1. Zero-power Resistance of Thermistor: R
 $R = R_0 \exp B (1/T - 1/T_0)$ (1)
R: Resistance in ambient temperature T (K)
(K: absolute temperature)
 R_0 : Resistance in ambient temperature T_0 (K)
B: B-Constant of Thermistor
2. B-Constant
as (1) formula
 $B = \frac{1}{\ln} (R/R_0) / (1/T - 1/T_0)$ (2)
3. Thermal Dissipation Constant
When electric power P (mW) is spent in ambient temperature T_1 and thermistor temperature rises T_2 , there is a formula as follows
 $P = C (T_2 - T_1)$ (3)
C: Thermal dissipation constant (mW/°C)
Thermal dissipation constant is varied with dimensions, measurement conditions, etc.

