

Index

Symbols

*OPC	272
*OPC?	272
*RST	281
*WAI	272
/var directory	305
>L	250
>R	250
&LLO	250
9.91E37	
Remote control	271
10 - Hardware failure	505
11 - DSP failure	505
12 - IIC bus error	505
13 - Real time clock error	505
50 - Extern reference out of range or disconnected	504
100 - Software failure	505
101 - DSP mailbox timeout	505
102 - DSP overflow	505
120 - RDS error	505
121 - PI error	505
122 - PSN error	505
123 - Buffer overflow	505
124 - Dataset empty	505
140 - This modulation forces other modulations off	504
180 - Adjustment failed	504
182 - Adjustment data missing	504
183 - Adjustment data invalid	504
200 - Cannot access hardware	504
201 - Hardware revision out of date	504
202 - Cannot access the EEPROM	504
203 - Invalid EEPROM data	504
204 - river initialization failed	504
241 - No current list	504
242 - Unknown list type specified	504
460 - Cannot open file	505
461 - Cannot write file	505
462 - Cannot read file	505
463 - Filename missing	505
464 - Invalid filename extension	505
465 - File contains invalid data	505

A

Abort button	83
Abort calculation	83
About	
Internal adjustments	491
Selftests	491
AC supply	55
Accept	
Security Settings	121
Access denied	76
Add LAN sensor	
NRP sensor mapping	169
Add sensor	
NRP sensor mapping	169
Add USBTMC sensor	
NRP sensor mapping	169
Address mode	
Network settings	106
Adjust All	495

Adjust Analog Channels	292, 496
Adjust Level	495
Adjust Synthesis	495
Adjust Synthesis Extension	495
Adjustment active	
Reference oscillator	145
Adjustment Data	152
Adjustment frequency	
Reference oscillator	146
Adjustments	
All	495
Settings	495
ALC (automatic level control)	153, 382
ALC Auto	501
ALC On	153, 501
ALC S&H	501
ALC Table	501
All packages	
Secure update policy	121
AM Depth	205
AM Sensitivity	206
AM Source	205
AM State	205
AM Type	
amplitude modulation	205
Amplitude	
Annotation (setup security)	119
Amplitude modulation	
AM type	205
Analog modulation	
Ignore overvoltage warning	207, 210, 214
Annotation	
Amplitude (security)	119
Frequency (security)	119
Aperture time	
Power sensors	177
Application cards	18
Application notes	18
Applications of the R&S SMB	63
ARI BK Code	221, 413
ARI Deviation	221
ARI Identification	221, 414
ARI State	221, 413
Arrow keys	52
ASCII file import/export	
List Mode	192
Assemblies display	97
ATN	508
Attention	508
Attenuator Mode	151
Attenuator Settings	
Fixed Range (PEP) in	151
mode	151
RF OFF Mode	151
AttFixed	502
AUDio Identification	415
Audio Source	420
Stereo modulation	218
Auto once	
Power Sensors	177
Auto Once - Power Sensors	326
Autonegotiation	
Failed	505

Avahi	
LAN Services	118

B

Baudrate	
RS232 interface	110
Bench top, placing	21
Block data	268
Bluetooth	
RS232 Interface	109
Bluetooth Pin	121
Boolean parameters	267
Brackets	268
Brochures	17
Browser settings	
LXI	40
Buffer overflow (123)	505
BUSY	500

C

Carrying the instrument	20
Case-sensitivity	
SCPI	264
Catch range	
NRP level control	159
Center Freq	184
Change password	
Setup (security)	117
Check front panel	492
Performing	493
Settings	493
Checking the instrument	20
Cleaning	490
Clear	
NRP sensor mapping	169
Clear status	
Remote	284
Closed loop power control	
see NRP level control	155
CLPC	
see NRP level control	155
Colon	268
Column Separator Import/Export	
Pulse Train data	239
Column Separator Import/Export - User Correction data	163
Comma	268
Command sequence	
Recommendation	281
Remote	288
Commands	242
Brackets	268
Colon	268
Comma	268
Command line structure	269
Common	242
Double dagger	268
GBIP, addressed	248
GBIP, universal	247
Instrument control	242
Overlapping	271
Pipe	268
Question mark	268
Quotation mark	268
SCPI confirmed	242
Sequential	271

Syntax elements	268
White space	268
Common commands	
Syntax	263
Computer name	
Changing	31
see hostname	105
use instead of IP address	31
CONDition	276
Confirm unsigned	
Secure update policy	121
Confirm user password	
Setup (security)	117
Connecting	
Keyboard	25
LAN	24, 25
Memory stick	25
Mouse	25
Power	24
To Ref In/Ref Out	27
To RF	26
USB devices	25
Connection fault	
169.254.*.*	505
Connection to an external controller	32
Connector	
GPIB	56
IEC/IEEE	56
INSTR TRIG	56
LAN	55
LF	53
MOD EXT	53
PULSE EXT	56
PULSE VIDEO	56
REF IN	57
REF OUT	57
RF	54
S/P DIF	56
SIGNAL VALID	56
Stereo R/L	56
USB type A	55
USB type B	55
Control bus	508
Controller, external	32
Copy	
Several files	133
Copy instrument settings	133
Counter	97, 294
Coupling mode	210
Coupling mode - EXT MOD (AM)	206
Create New Directory	133
Current Freq (LF Sweep)	229
Current Freq (RF Sweep)	184
Current Index	
List Mode	196
Current Level	191
Current Sensors	101
Cursor keys	52
Customer support	507
Cut	133
D	
Data sheets	17
Data Valid	508
Dataset empty (124)	505

Date			
Setup	492		
DAV	508		
DCL	247		
Deactivate RF output	145		
Decimal Point Import/Export			
Pulse Train data	239		
Decimal Point Import/Export - List Mode data	199		
Decimal Point Import/Export - User Correction data	163		
DEF	266		
Default gateway			
Network settings	107		
Default instrument settings	29, 96		
Default values			
Remote	286		
Delay			
Double pulse	233		
Pulse generator	233		
Delay time			
NRP level control	159		
Delete instrument settings	133, 311		
Delta Phase	142		
Destination Import/Export			
Pulse Train data	239		
User Correction data	164		
Destination Import/Export - List Mode data	200		
Deviation			
Stereo modulation	218		
Device ID	100		
NRP sensor mapping	169		
Device-specific error messages	503		
DHCP	30		
Direct programming	417		
Display	71		
Lock (security)	119		
Display priority			
Power sensors	174		
DISPlay subsystem	294		
Disposal	490		
DNS server			
Network settings	107		
DNS suffix			
Network settings	107		
Documentation overview	17		
Double dagger	268		
Double Pulse	232		
Double pulse delay			
Pulse generator	233		
Double pulse width			
Pulse generator	233		
DOWN	266		
DSP failure (11)	505		
DSP mailbox timeout (101)	505		
DSP overflow (102)	505		
Dwell time			
RF sweep	186		
Dwell Time	192, 195, 230		
List Mode	195		
E			
Edit			
Pulse Train	237		
Edit Pulse Train Data	236		
Edit User Correction Data	161		
EFC mode (Electronic Frequency Control)	144		
EMF - Level display	153		
Emulation			
IDN string	112		
Language	111		
Mode	111		
Set IDN and OPT to default	112		
Enable			
LAN interface	118		
ENABLE	276		
Enable registers			
Remote	286		
Enter License Key	100		
EOI	508		
Error log	506		
Error messages	73, 499		
Adjustment data invalid (183)	504		
Adjustment data missing (182)	504		
Adjustment failed (180)	504		
Cannot access hardware (200)	504		
Cannot access the EEPROM (202)	504		
Cannot open file (460)	505		
Cannot read file (462)	505		
Cannot write file (461)	505		
Driver initialization failed (204)	504		
Extern reference out of range or disconnected (50)	504		
File contains invalid data (465)	505		
Filename missing (463)	505		
Hardware revision out of date (201)	504		
Invalid EEPROM data (203)	504		
Invalid filename extension (464)	505		
No current list (241)	504		
This modulation forces other modulations off (140)	504		
Unknown list type specified (242)	504		
Error Messages	502		
device-specific	503		
SCPI	503		
Error queue	277		
Error queue query	439, 440		
Error queues			
Recommendations	282		
ESE (event status enable register)	278		
ESR	274		
ESR (event status register)	278		
EVENT	276		
Event status enable register (ESE)	278		
Remote	284		
Event status register (ESR)	278		
Remote	284		
Exclude Frequency	131		
Exclude Level	131		
Execute			
Single trigger	234		
Execute Single			
List Mode	195		
Execute single sweep			
Frequency sweep	183		
Execute Single Sweep			
Level Sweep	190		
Execute Single Sweep - LF Sweep	228		
Expiration date of option	99		
Export Deactivation Response	101		
EXT REF	500		
Extension Import/Export			
Pulse Train data	238		
Extension Import/Export - List Mode data	199		
Extension Import/Export - User Correction data	163		
External frequency			
Reference oscillator	145		

External impedance	
Pulse generator	234
External Impedance	
Stereo modulation	219
External input impedance	234
External modulation signal	204
FM	207
PhiM	211
External modulation signal - voltage	203

F

Factory preset	122
Features of R&S SMB	63
File	
Hard copy	124
File info	
Hard copy	124
File list	308
File menu	
Save/Recall	128
File name	
Hard copy	124
File setup	
Hard copy	125
File type selection	132
Fill Table	
List Mode	197
Fill Table - List mode	200
Fill Table From	200
Fill Table Range	164, 200
Filter	
Low harmonic	150
mode (low harmonic)	150
Power Sensors	175
State (low harmonic)	151
Filter Length	
Power Sensors	175
Filter Length - Power Sensors	324, 325, 326
Firmware version	99
Floating licenses	99
FM deviation	209
FM Deviation	
Stereo modulation	218
FM mode	209
FM sensitivity	210
FM source	208
FM state	208
FM-DC mode	142
FREQ OFFSET	499
Frequency	147
Annotation (setup security)	119
LF generator	206, 209, 213, 219, 224
List Mode	197
Multiplier	141
PM	233
Power sensors	175
RF signal	138
Set Frequency	139
Stereo modulation	219
Frequency - RF sweep	183, 184
Frequency (status bar)	
RF signal	139
Frequency dialog	
RF signal	139
Frequency display	72
Front panel key emulation	68, 91

Front panel test	
Performing	493
FTP	
How to	133
LAN Services	118
Fuses	
How to replace the line fuse	490

G

Gate input polarity	234
Gated	
Pulse trigger input	234
Gated signal	
Pulse modulation	233
Gateway	107
GET	248
Goto local	
Remote channel settings	110
GPIB	110
bus address	109
Characteristics	246
Connecting	25
interface messages	247
Remote control interface	240
GPIB address	248
GTL	248
GUI Language	108

H

Hard copy	
File	124
File info	124
File name	124
File setup	125
Hardware Config	97
Hardware failure (10)	505
Hardware options	98
Help	17
HiSLIP	
Protocol	244
Resource string	243
Host name	
NRP sensor mapping	169
see Computer name	31
Hostname	
Network settings	105
see Computer name	31
How to:	
Replace the line fuse	490
HTTP	
LAN Services	118

I

Identification	
Emulation mode	111
Remote	285
Identification mode	111
IDN string	
Emulation	112
Emulation mode	112
IEC 625/IEEE 488	
Connecting	25
IFC	247, 508

Ignore level warning
 Level 150
 Ignore overvoltage warning
 Analog modulation 207, 210, 214
 IIC bus error (12) 505
 Impedance
 External input 207, 210, 214
 Impedance Audio Signal 219
 Import License Key 100
 Import/Export
 List Mode data 200
 Pulse Train data 238, 239
 User Correction data 162, 164
 Import/Export - List Mode data 198
 INF 266
 INFO key 73
 Input
 Stereo Modulation 217
 Input connector 53, 56, 57
 Installed Assembly 98
 Instrument
 Carrying 20
 Checking 20
 Lifting 20
 Operating site 20, 21
 Unpacking 20
 Instrument Config 97
 Instrument Emulations 110
 Instrument help 17
 Instrument messages 241
 Instrument settings
 Recall 130, 286, 312
 Save 128, 287, 313
 Instrument Trigger 187, 192, 198, 231
 Instrument-specific commands 242
 Interface
 functions (GPIB bus) 509
 Interface Clear 508
 Interface messages 241, 245
 Interfaces
 GPIB 246
 USB 245
 Internal adjustments
 About 491
 Interrupt 279
 Invalid results
 Remote control 271
 IP address 243
 Changing 30
 Network settings 106
 Not recognized 505
 NRP sensor mapping 169
 IP address mode 106
 IST 274
 IST flag
 Remote 285

K

Key
 Arrow key 53
 BACKSPACE 51
 Cursor key 53
 DIAGRAM 51
 ENTER 52
 ESC 51
 FILE 49, 127

FREQ 50
 HELP 49
 INFO 49
 LEVEL 50
 LOCAL 49
 MOD ON/OFF 51, 202
 ON/OFF TOGGLE 50
 PRESET 29, 49, 96
 RF ON/OFF 51
 SETUP 49, 97
 WINBAR 49
 Key - HELP 126
 Key - LOCAL 123
 Key combinations 66, 90
 Keyboard
 Layout 108
 Keyboard emulation 68
 Keyboard Language 304
 Keypad 51
 Keywords
 Mnemonics 263

L

LAN
 Configuration 30
 Connecting 24, 25
 Environment 24
 Interface 242
 IP address 243
 Remote control interface 240
 VISA 243
 VXI protocol 244
 LAN interface
 Avahi 118
 enable 118
 FTP 118
 HTTP 118
 LAN over SCPI 118
 SMB (Samba) 118
 SSH 118
 VNC 118
 LAN Interface
 Services 117
 Setup 117
 LAN Status - LXI 112
 Language
 Emulation 111
 Language Keyboard 304
 Layout
 Keyboard 108
 Learn List Mode Data 196
 Level 147
 Ignore level warning 150
 limit 149, 158
 Power sensors 173
 RF output 149
 uninterrupted setting 151
 Level - Step width 152
 Level (Avg.)
 Power sensors 173
 Level control 153, 382
 Level display 72
 Level display EMF 153
 Level limit
 RF level 149, 158

Level offset	150
Power Sensors	175
State (power sensors)	175
LEVEL OFFSET	500
Level Sweep	187
Level user correction	159
LevelSweep	501
LF frequency sweep	
Retrace	230
LF gen frequency	206, 209, 213, 224
LF gen shape	206, 209, 213, 225
LF Gen Voltage	224
LF generator	223
Frequency	206, 209, 213, 224
Shape	206, 209, 213, 225
LF output	224
LF Output	
State	224
Sweep voltage	186, 187
LF output - Source Impedance	225
LF Source Impedance	225
LF sweep	
Step lin	230
Step log	230
Step width	230
LF Sweep	229
LFGen Frequency	219
LFSweep	501
License for software option	99
License Key	100
Lifting the instrument	20
Limit	
Level	149, 158
Linux	30
Linux controller	34
List mode	192
manual processing of lists	194
List Mode Data	196
List Range In	198
ListMode	502
LLO	247
Load instrument settings	130, 286, 312
LOC-LLO	501
Local to remote switchover	249, 250
Lock	
Display (setup security)	119
Low harmonic	
Filter	150
Filter mode	150
Filter state	151
LXI	112
Browser interface	40
Browser settings	40
Configuration	39
LAN configuration	42
Ping	44
Remote trace (SCPI)	46
Web Control	45

M

Mac address	107
Maintenance	490, 491
Malfunctions	
Reacting	282
Manual Remote Control	32
MAX	266

Max Modulation Freq	220
Maximum deviation	213
FM	209
Measured level	
NRP level control	158
Menu structure	
Access denied	76
Header	76
Menu area	76
Messages	
Commands	242
Instrument	241
Instrument responses	242
Interface	241
MIN	266
Mnemonics	263
Optional	265
Mod external coupling	
AM	206
FM	210
PhiM	214
Mod Gen block	64
MOD OFF	499
MOD ON/OFF Key	202
Mode	
Emulation	111
FM	209
Level Sweep	188
LF Gen	226
LF sweep	226
List Mode	194
Low harmonic filter	150
PhiM	212
Pulse generator	232
RF frequency sweep	180
RF level	148
Mode Import/Export	
Pulse Train data	238
Mode Import/Export - List Mode data	199
Mode Import/Export - User Correction data	163
Modulation	
AM	204
FM	207
PhiM	211
PM	214
Pulse modulation	214
Stereo modulation	217
Modulation depth - AM	205
Modulation deviation	
FM	209
PhiM	213
Mounting, in a rack	22
MPX Deviation	218
Multi transmitter measurements	153
Multiple files	
Copy	133
Multiplier	
Frequency	141

N

NAN	266
NAN (not a number)	
Remote control	271
Navigation keys	52
NDAC	508

- Network
 - Connection fails 505
 - Environment 24
- Network settings 104
 - Address mode 106
 - Default gateway 107
 - DNS server 107
 - DNS suffix 107
 - Hostname 105
 - IP address 106
 - Status 105
 - Subnet mask 106
 - Workgroup 106
- Network status 105
- New password
 - Setup (security) 117
- New user password
 - Setup (security) 116
- NINF 266
- No-load voltage (EMF) 153
- NRFD 508
- NRP Info 101
- NRP level control 155
 - catch range 159
 - delay time 159
 - measured level 158
 - sensor 157
 - state 157
 - target level 158
 - use peak power 159
- NRP power control
 - RF level limit 149, 158
 - use SParameter 159, 177
- NRP power viewer
 - use SParameter 159, 177
- NRP sensor mapping
 - Add LAN sensor 169
 - Add sensor 169
 - Add USBTMC sensor 169
 - Clear 169
 - Connector 168
 - Device ID 169
 - Host name 169
 - IP address 169
 - Protocol 168
 - Scan 169
 - Sensor name 168, 169
 - Serial number 169
 - Settings 168
- NTP
 - Address 492
- NTRansition 276
- Number of licenses 99
- Numeric parameters 266
- Numeric values
 - Special 266
- O**
- OCXO 57
- Off time
 - Pulse Train 237
- Offset
 - RF signal 140
- Offset - Level 150
- Old password
 - Setup (security) 117
- Old user password
 - Setup (security) 116
- On time
 - Pulse Train 237
- Online help
 - Working with 85
- Open source acknowledgment 18
- Open source acknowledgments 99
- Operating concept 66
- Operating site
 - Choosing 20
 - Setting up the instrument 21
- Operating system 30
- Operation complete
 - Remote 285
- Operation hours 98, 294
- Operation mode
 - File menu 128
- OPT String 112
- Option
 - Hardware 98
 - Software 98
- Option: expiration date 99
- Options
 - Hard copy 124
 - Identification (remote) 285
- OSA 18
- Oscillator
 - Reference 142
 - Source (reference) 144
- Output
 - LF 224
- Output connector 53, 54, 56, 57
- Output queue 274
- Output Voltage - LF output 224
- Output voltage start 186
- Output voltage stop 187
- OvenCold 502
- Overlapped commands
 - Preventing 272
- Overlapping commands 271
- Overload 167
- OVERLOAD 500
- P**
- Parallel poll register enable
 - Remote 286
- Parameters
 - Block data 268
 - Boolean 267
 - Numeric values 266
 - SCPI 265
 - Special numeric values 266
 - String 268
 - Text 267
- Parity
 - RS232 interface 110
- Part numbers 97
- Password
 - Change (security password) 117
 - Confirm (security password) 117
 - Confirm (user password (security)) 117
 - New (security password) 117
 - New (user password (security)) 116
 - Old (security password) 117
- Paste 133

PCI bus	98
Period	
Pulse generator	233
Permanent display	
Power sensors	174
Phase	
RF signal	142
PhiM	
Mode	212
Modulation deviation	213
Source	212
PhiM Sensitivity	214
PhiM State	212
PI error (121)	505
Pilot Deviation	220
Pilot Phase	220
Pilot State	220, 418
Ping	
LXI	44
Pipe	268
Placing, on a bench top	21
Polarity	
Pulse Modulation	216
Power	
Connecting the instrument	24
List Mode	197
Power sensors	
Aperture time	177
Auto once	177
Display priority	174
Filter	175
Frequency	175
Level	173
Level (Avg.)	173
Level offset	175
NRP level control	155
Permanent display	174
Power viewer	172
Source	175
State	173
State (level offset)	175
Type	173
Unit	174
Use default aperture time	177
zero	158, 174
Power-On Count	97, 98
Power-On Counter	294
Power-On State	153
PPC	248
PPE	274
PPU	247
Preemphasis	219, 416
Preparing for use	20
Preset	29
Preset - instrument settings	96
Preset instrument settings	29
Protection	113
Protocol	
VXI	244
PSN error (122)	505
PTTransition	276
Pulse delay	
Pulse generator	233
Pulse external impedance	234
Pulse generator	231
Delay	233
Double pulse delay	233

Double pulse width	233
External impedance	234
Mode	232
Period	233
Settings	231
Signal valid as pulse sync	235
Trigger mode	233
Video-Sync signal state	232
Width	233
Pulse Generator	
Pulse Train	235
Pulse generator state	232
Pulse mode	
Pulse generator	232
Pulse Mode	232
Pulse modulation	214
repetition frequency	233
Signal valid as pulse sync	235
Source	216
State	216
Trigger mode	233
Pulse period	
Pulse generator	233
Pulse Train	232
Pulse Generator	235
Pulse Train Data	236
Pulse trigger input slope	234
Pulse width	
Pulse generator	233

Q

Queries	242, 270
Status	280
Question mark	268, 270
Questionable status register	278, 279
Quotation mark	268

R

R&S signed packages	
Secure update policy	121
Rack, mounting	22
RDS Data Set	222, 418
RDS Deviation	222
RDS error (120)	505
RDS Program Identification	222
RDS Program Service Name	222
RDS State	221, 419
RDS Traffic Announcement	223, 419
RDS Traffic Program	222, 419
Real time clock error (13)	505
Recall instrument settings	130, 131, 286, 312
Recall intermediate	286
Recall Intermediate	131
Recommendations	
Remote control programming	281
Reference	
Source (oscillator)	144
Reference frequency	
External	145
Reference oscillator	142
Adjustment active	145
Adjustment frequency	146
External frequency	145
RF off state	145
Settings	144

Source	144
synchronization bandwidth	145
Registers	274
Release notes	18
REM-LLO	501
Remote	
Bluetooth	109
RS232	109
REMOTE	501
Remote access	32
Remote channel	
GPIB address	109
Remote channel settings	109
Goto local	110
GPIB resource (VISA resource string)	110
HISLIP resource (VISA resource string)	110
Network resource (Ethernet resource string)	110
Serial	110
Socket resource (VISA resource string)	110
USB VISA resource string	110
Remote control	
Basics	240
GPIB address	248
Interfaces	240
Protocols	240
Remote Control	
GPIB	251
Remote control switchover	249
Remote trace	
LXI	46
Removing sensitive data	506
REN	508
Rename	133
File	312
Repetition	
Pulse Train	237
Replace the line fuse	
How to:	490
Reset	183
List Mode	195
Reset - RF sweep	183
Reset Delta Phase Display	142
Reset instrument settings	29, 96
Reset values	
Remote	286
Resolving network problems	107
Restart network	
Setting	107
Retrace	
LF frequency sweep	230
RF frequency sweep	185
RF level sweep	191
Reverse power protection	167
Revisions	97
RF block	65
RF During Power Search - ALC	155
RF frequency	
Multiplier	141
Settings	140
RF Frequency	
Set frequency (dialog)	140
RF frequency sweep	
Retrace	185
RF frequency vs. RF output frequency	138
RF level	
Mode	148

RF Level	
limit	149, 158
RF level limit	
NRP power control	149, 158
RF Level Sweep	
Retrace	191
RF OFF	136, 499
RF off state	
Reference oscillator	145
RF ON	136
RF ON/OFF key	136
RF output	
Power-on state	153
RF Output	136
RF output level	149
RF output state	137
RF signal	
Frequency	138
Frequency dialog	139
Frequency offset	140
Multiplier	141
Offset	140
Phase	142
Phase adjustment	142
Set frequency (status bar)	139
User variation	141
RF State	137
RF sweep	
Step lin	185
Step log	185
Step width	185
RFSweep	501
Rotary knob	52
RS232	
Baud rate	110
Parity	110
Serial interface	109
Stop bits	110
Run Update	101

S

Safety instructions	13
SAMBA/SMB	
How to	133
Sample-and-Hold mode	382
Sample&Hold mode	153
Save immediate	128
Save instrument settings	128, 287, 313
Save intermediate	287
Scan	
NRP sensor mapping	169
SCPI	
LAN Services	118
Parameters	265
Syntax	263
Version	241
SCPI - error messages	503
SCPI confirmed commands	242
SCPI remote trace	
LXI	46
Screen Saver	108
SDC	248
Search Once - ALC	155

Secure update policy		Setting commands	242
All packages	121	Setting not possible	76
Confirm unsigned	121	Setting parameters	77
R&S signed packages	121	Settings	
Security		Check front panel	493
Accept settings	121	Internal adjustments	495
Annotation amplitude (setup)	119	NRP sensor mapping	168
Annotation frequency (setup)	119	Pulse generator	231
Change password (setup)	117	Reference oscillator	144
Confirm password (setup)	117	Setup	
Confirm user password (setup)	117	Accept security settings	121
Display lock (setup)	119	Annotation amplitude (security)	119
New password (setup)	117	Annotation frequency (security)	119
New user password (setup)	116	Change password (security)	117
Old password (setup)	117	Confirm password (security)	117
Secure update policy	121	Confirm password (user)	117
Security password	117	Date	492
User interface	119	Display lock (security)	119
User password	116	LAN services	117
Security password		New password (security)	117
Security	117	New password (user)	116
Setup	117	Old password (security)	117
Security Password		Old password (user)	116
Setup	121	Performing the front panel test	493
Security settings		Secure update policy	121
LAN services	117	Security password	117
Security Settings		Time	492
Security Password	121	Timezone	492
USB storage	119	User interface (security)	119
User Name	116	User password	116
Volatile Mode	119	Setup key	97
Select ASCII Destination		Shape	
Pulse Train data	239	LF generator	206, 209, 213, 219, 225
User Correction data	163	RF Level Sweep	191
Select ASCII Destination - List Mode data	199	Shape - LF Frequency Sweep	229
Select ASCII Source		Shape - RF Sweep	184
Pulse Train data	239	Show level permanent - Power Sensors	324
User Correction data	163	Signal valid as pulse sync	
Select List	196	pulse generator	235
Select NRP File	101	pulse modulation	235
Select Pulse Train Data	236	Single Pulse	232
Select sensor		Single trigger	
Power viewer	172	Execute	234
Self-test		Slope	
Remote	288	Pulse trigger input	234
Selftest	497	SMB (Samba)	
Selftests		LAN Services	118
About	491	SMZ Info	
Sensor		FW-Version	103
NRP level control	157	MAX Freq	103
Power viewer	172	Min Freq	103
Sensor name		Revision	103
NRP sensor mapping	169	Serial number	103
Sequential commands	271	Type	103
Serial bus	98	Software failure (100)	505
Serial interface		Software options	98
RS232	109	Source	
Serial number		FM	208
NRP sensor mapping	169	Level Sweep Trigger	188
Serial numbers	97	LF sweep trigger	226
Service request (SRQ)	277, 279	List Mode	194
Service request enable register (SRE)	277	PhiM	212
Remote	287	Power sensors	175
Set frequency		Pulse modulation	216
RF signal	140	Reference oscillator	144
Set IDN and OPT to default		RF frequency sweep trigger	180
Emulation mode	112	Source - AM	205

Source - Power Sensors	328	Table	501
Source impedance - LF output	225	UCorr	502
Source Import/Export		Status registers	274
Pulse Train data	239	CONDition	276
User Correction data	164	ENABLE	276
Spacing		EVENT	276
Level Sweep	192	Model	275
Spacing - LF Sweep	229	NTRansition	276
Spacing - RF Sweep	184	Parts	275
Span (RF sweep)	184	PTRansition	276
SPD	247	Status reporting system	273
SPE	247	Application	279
SRE	274	Common commands	284
SRE (service request enable register)	277	STB	274
SRQ	508	Step	
SRQ (service request)	277, 279	Level Sweep	192
SSH		Step lin	
LAN Services	118	LF sweep	230
Standby mode	49	RF sweep	185
Start		Step log	
Power Sensors	322	LF sweep	230
Start Freq	183	RF sweep	185
Start Freq - LF sweep	229	Step width	
Start Level	190	Frequency	141
Start/Stop Display Update	103	Level Sweep	192
State		LF sweep	230
Adjustment (reference oscillator)	145	RF sweep	185
ALC	155	Stereo modulation	217
LF Output	224	Stop bits	
List mode	194	RS232 interface	110
Low harmonic filter	151	Stop Freq - LF Sweep	229
NRP level control	157	Stop Freq - RF Sweep	184
PhiM	212	Stop Level	191
Power sensors	173	Storage	490, 491
Pulse modulation	216	String in remote commands	268
Stereo modulation	218, 421	Subnet mask	
Video-Sync signal	232	Network settings	106
State - User Correction	160	Suffixes	264
Status		Support	506
Network settings	105	Sweep	
Queries	280	Retrace (LF frequency)	230
Status byte		Retrace (RF frequency)	185
Remote	284, 287	Retrace (RF level)	191
Status byte (STB)	277	RF frequency sweep	180
Status information	499	Start Level	190
Status Information	101	Stop Level	191
status messages		Trigger	183, 190
FREQ OFFSET	499	Sweep - Center frequency	184
MOD OFF	499	Sweep - LF start frequency	229
OVERLOAD	500	Sweep - LF stop frequency	229
RF OFF	499	Sweep - Trigger	228
Status messages		Sweep output voltage	186, 187
ALC On	501	Sweep shape	
AttFixed	502	RF Level Sweep	191
Auto	501	Sweep shape - LF Frequency Sweep	229
BUSY	500	Sweep shape - RF Sweep	184
EXT REF	500	Sweep spacing	
LEVEL OFFSET	500	Level Sweep	192
LevelSweep	501	Sweep spacing - RF Sweep	184
LFSweep	501	Switching	
ListMode	502	On or off	27
LOC-LLO	501	Synchronization bandwidth	
OvenCold	502	reference oscillator	145
REM-LLO	501	Syntax elements	
REMOTE	501	SCPI	268
RFSweep	501		
S&H	501		

System	
Identification	111
IDN string	112
Language	111
Network Mac address	107
Set IDN and OPT to default	112
System directory	305

T

Target level	
NRP level control	158
Test	
Check front panel	493
Test setup	
Considerations	23
Text parameters in remote commands	267
Time	
Setup	492
UTC	492
Timezone	
Setup	492
UTC	492
Toggle Summary Screen	108
Trigger	
Event (remote)	287
Trigger Input Slope	187, 192, 198, 231
Trigger mode	
Pulse modulation	233
Trigger source	
LF sweep	226
RF frequency sweep	180
Trigger Source	
Level Sweep	188
List Mode	194
Triggering sweep manually	190
Troubleshooting	499
TS-USB1	
USB adapter	109
Type	
Power sensors	173
Type - Power Sensors	329, 330

U

UCorr	502
Ultr@VNC	34
Uninterrupted level setting	151
Unit	
Power sensors	174
Units	
Input	51
UNIX controller	34
Unpacking the instrument	20
UP	266
Update sensor	101
USB	
Adapter TS-USB1	109
Interfaces	245
Remote control interface	240
USB Storage - Setup	119
Use default aperture time	
Power sensors	177
Use LF connector to output sweep voltage	186
Use peak power	
NRP level control	159

Use SParameter	
NRP power control	159, 177
NRP power viewer	159, 177
Use SParameters - Power Sensors	323
User Correction	159
User Correction Data	161
User interface	
Lock (security)	119
User manual	17
User Name - Setup	116
User password	
Security	116
Setup	116
User variation	
RF frequency settings	141
Variation active	141
Variation step	141

V

Value - User Correction	160
Variation Active	141
Variation step	141
Variation Step	141, 152
Vertical bar	268
Video-Sync signal state	
Pulse generator	232
VISA	240, 243
Libraries	241
Resource string	241, 243
VISA resource string	
Ethernet	110
GPIO	110
HISLIP	110
Serial	110
Socket	110
USB	110
VNC	
LAN Services	118
VNC connection	34
Volatile mode	
Setup	119
Voltage ramp	
RF sweep	186
VXI protocol	244

W

Wait	
Remote	288
Wait Time	108
Warnings	73, 502
Web Control	
LXI	45
White papers	18
White space	268
Width	
Double pulse	233
Pulse generator	233
Workgroup	
Network settings	106

Z

Zero	
Power sensors	158, 174
Zero - Power Sensors	330

Zeroconf	
IP address	505
Zoom	
Pulse Train	236
Zoom Position	
Pulse Train	236