

DHT22 library for Arduino

1.0.1

Generated by Doxygen 1.8.14

Contents

1	DHT22 - AM2303 temperature and humidity sensor library for Arduino	1
2	Class Index	5
2.1	Class List	5
3	File Index	7
3.1	File List	7
4	Class Documentation	9
4.1	DHT22 Class Reference	9
4.1.1	Detailed Description	9
4.1.2	Constructor & Destructor Documentation	9
4.1.2.1	DHT22()	9
4.1.3	Member Function Documentation	10
4.1.3.1	available()	10
4.1.3.2	begin()	10
4.1.3.3	readHumidity()	10
4.1.3.4	readTemperature()	11
5	File Documentation	13
5.1	DHT22.cpp File Reference	13
5.1.1	Detailed Description	13
5.2	DHT22.h File Reference	13
5.2.1	Detailed Description	14
5.2.2	Macro Definition Documentation	14
5.2.2.1	DHT22_MIN_READ_INTERVAL	14
5.2.2.2	DHT22_NUM_DATA_BITS	14
	Index	15

Chapter 1

DHT22 - AM2303 temperature and humidity sensor library for Arduino

This is a calibrated AM2303 digital temperature and relative humidity sensor on a [DHT22](#) breakout PCB.

Library features

- Read 16-bit temperature (synchronous blocking)
- Read 16-bit relative humidity (synchronous blocking)

AM2303 sensor specifications

- Voltage: 3.3 .. 5V
- Ultra-low power:
 - Typical 15uA dormancy
 - Typical 500uA measuring
- Single wire digital serial interface
- Calibrated digital signal
- Outstanding long term stability
- No additional electronic components needed
- Humidity:
 - Range: 0 .. 99.9 RH (Relative Humidity)
 - Resolution: 0.1 RH
 - Accuracy: +/- 2 RH (at 25 degree Celsius)
- Temperature:
 - Range: -40 .. +125 degree Celsius
 - Resolution: 0.1 degree Celsius
 - Accuracy: +/- 0.4 degree Celsius
- Minimum read interval: 2000 ms
- ~31ms to synchronous read humidity, temperature and parity data from sensor (5 Bytes)

Hardware

Connection [DHT22](#) - Arduino

DHT22	Arduino UNO / Nano / Pro Mini / Leonardo / Mega2560
GND	GND
VCC	5V (or 3.3V)
DAT	2 (DIGITAL pin)

Connection [DHT22](#) - ESP8266

Some ESP8266 boards uses Arduino pin 2 -> GPIO4 which is D4 text on the board. Make sure you're using the right pin.

DHT22	ESP8266 / WeMos D1 R2 / ESP12E / NodeMCU
GND	GND
VCC	3.3V
DAT	D4

Connection [DHT22](#) - WeMos LOLIN32

WeMos LOLIN32 requires an additional 100nF capacitor over the GND - VCC pins to prevent parity errors.

Use pin 0 to prevent flash problems.

DHT22	WeMos Lolin32
GND	GND
VCC	3.3V
DAT	0

Other MCU's may work, but are not tested.

Examples

- [Examples](#) | [Erriez DH22](#) | [Example](#)

Usage

Initialization

```
{c++}
#include <DHT22.h>

// Connect DHT22 DAT pin to Arduino board

// Arduino DIGITAL pin
#define DHT22_PIN 2
// Some ESP8266 boards uses D2 instead of 2
// #define DHT22_PIN D2
// LOLIN32 uses another pin
// #define DHT22_PIN 0

DHT22 sensor = DHT22(DHT22_PIN);
```

```
void setup()
{
    // Initialize serial port
    Serial.begin(115200);
    Serial.println(F("DHT22 temperature and humidity sensor example\n"));

    // Initialize sensor
    sensor.begin();
}
```

Read temperature and humidity

```
{c++}
void loop()
{
    // Check minimum interval of 2000 ms between sensor reads
    if (sensor.available()) {
        // Read temperature from sensor
        int16_t temperature = sensor.readTemperature();

        // Read humidity from sensor
        int16_t humidity = sensor.readHumidity();

        if (temperature == ~0) {
            // Print error (Check hardware connection)
            Serial.print(F("Temperature: Error"));
        } else {
            // Print temperature
            Serial.print(F("Temperature: "));
            Serial.print(temperature / 10);
            Serial.print(F("."));
            Serial.print(temperature % 10);
            Serial.println(F(" *C"));
        }

        if (humidity == ~0) {
            // Print error (Check hardware connection)
            Serial.print(F("Humidity: Error"));
        } else {
            // Print humidity
            Serial.print(F("Humidity: "));
            Serial.print(humidity / 10);
            Serial.print(F("."));
            Serial.print(humidity % 10);
            Serial.println(F(" %"));
        }

        Serial.println();
    }
}
```

Serial output

```
DHT22 temperature and humidity sensor example

Temperature: 17.7 *C
Humidity: 41.0 %

Temperature: 17.8 *C
Humidity: 41.1 %

...
```

Documentation

- [Doxygen online HTML](#)
- [Doxygen PDF](#)
- [AM2303 datasheet](#)
- [DHT22 datasheet](#)

Library dependencies

- None

Library installation

Please refer to the [Wiki](#) page.

Chapter 2

Class Index

2.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

DHT22	
DHT22 sensor class	9

Chapter 3

File Index

3.1 File List

Here is a list of all documented files with brief descriptions:

DHT22.cpp	
DHT22 (AM2303) Humidity and Temperature sensor example for Arduino	13
DHT22.h	
DHT22 (AM2303) Humidity and Temperature sensor example for Arduino	13

Chapter 4

Class Documentation

4.1 DHT22 Class Reference

DHT22 sensor class.

```
#include <DHT22.h>
```

Public Member Functions

- [DHT22](#) (uint8_t pin)
Constructor [DHT22](#) sensor.
- void [begin](#) ()
Initialize sensor.
- bool [available](#) ()
Check if new temperature or humidity read is allowed.
- int16_t [readTemperature](#) ()
Read temperature from sensor.
- int16_t [readHumidity](#) ()
Read humidity from sensor.

4.1.1 Detailed Description

DHT22 sensor class.

Definition at line 58 of file DHT22.h.

4.1.2 Constructor & Destructor Documentation

4.1.2.1 DHT22()

```
DHT22::DHT22 (
    uint8_t pin ) [explicit]
```

Constructor [DHT22](#) sensor.

Parameters

<i>pin</i>	Data pin sensor.
------------	------------------

Definition at line 37 of file DHT22.cpp.

4.1.3 Member Function Documentation

4.1.3.1 available()

```
bool DHT22::available ( )
```

Check if new temperature or humidity read is allowed.

The application should call this function and check if a new temperature and humidity can be read to prevent too fast sensor reads.

Returns

true: Available, interval between sensor reads \geq 2000 ms. false: Not available, interval between sensor reads too short.

Definition at line 79 of file DHT22.cpp.

4.1.3.2 begin()

```
void DHT22::begin ( )
```

Initialize sensor.

Call this function from setup().

Definition at line 59 of file DHT22.cpp.

4.1.3.3 readHumidity()

```
int16_t DHT22::readHumidity ( )
```

Read humidity from sensor.

Returns

Signed humidity with last digit after the point. ~ 0 : An error occurred

Definition at line 121 of file DHT22.cpp.

4.1.3.4 readTemperature()

```
int16_t DHT22::readTemperature ( )
```

Read temperature from sensor.

Returns the actual temperature, or a cached temperature when read interval is too short.

Returns

Signed temperature with last digit after the point ~0: An error occurred

Definition at line 99 of file DHT22.cpp.

The documentation for this class was generated from the following files:

- [DHT22.h](#)
- [DHT22.cpp](#)

Chapter 5

File Documentation

5.1 DHT22.cpp File Reference

DHT22 (AM2303) Humidity and Temperature sensor example for Arduino.

```
#include "DHT22.h"
```

5.1.1 Detailed Description

DHT22 (AM2303) Humidity and Temperature sensor example for Arduino.

Source: <https://github.com/Erriez/ErriezDHT22>

5.2 DHT22.h File Reference

DHT22 (AM2303) Humidity and Temperature sensor example for Arduino.

```
#include <Arduino.h>
```

Classes

- class **DHT22**
DHT22 sensor class.

Macros

- #define **DHT22_MIN_READ_INTERVAL** 2000
Enable debug prints to Serial.
- #define **DHT22_NUM_DATA_BITS** (5 * 8)
- #define **DEBUG_PRINTLN**(...) {}
Debug print configuration.

5.2.1 Detailed Description

[DHT22](#) (AM2303) Humidity and Temperature sensor example for Arduino.

Source: <https://github.com/Erriez/ErriezDHT22>

5.2.2 Macro Definition Documentation

5.2.2.1 DHT22_MIN_READ_INTERVAL

```
#define DHT22_MIN_READ_INTERVAL 2000
```

Enable debug prints to Serial.

Minimum interval between sensor reads in milli seconds

Definition at line 40 of file DHT22.h.

5.2.2.2 DHT22_NUM_DATA_BITS

```
#define DHT22_NUM_DATA_BITS (5 * 8)
```

Number of data bits is 5 Bytes * 8 bits: 1 Byte: Humidity high 1 Byte: Humidity low 1 Byte: Temperature high 1 Byte: Temperature low 1 Byte: Parity

Definition at line 48 of file DHT22.h.

Index

available

DHT22, [10](#)

begin

DHT22, [10](#)

DHT22, [9](#)

available, [10](#)

begin, [10](#)

DHT22, [9](#)

readHumidity, [10](#)

readTemperature, [10](#)

DHT22.cpp, [13](#)

DHT22.h, [13](#)

DHT22_MIN_READ_INTERVAL, [14](#)

DHT22_NUM_DATA_BITS, [14](#)

DHT22_MIN_READ_INTERVAL

DHT22.h, [14](#)

DHT22_NUM_DATA_BITS

DHT22.h, [14](#)

readHumidity

DHT22, [10](#)

readTemperature

DHT22, [10](#)