





K143	AC compressor clutch relay
B161	AC refrigerant pressure sensor
B138	Accelerator pedal position (APP) sensor
G1	Alternator
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
K46	Engine control relay
A95	Engine coolant blower motor control module
B24	Engine coolant temperature (ECT) sensor
B86	Engine oil level sensor
S389	Engine oil pressure switch
Y104	Evaporative emission (EVAP) canister purge valve
B3	Fuel gauge tank sensor
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
X28-I	Fuse box/relay plate - engine bay 1
X28-III	Fuse box/relay plate - fascia
X28-II	Fuse box/relay plate - load area
B72	Heated oxygen sensor (HO2S)
T1	Ignition coil
K79	Ignition main circuits relay
15	Ignition switch - ignition ON
Y3	Injector
A5	Instrument panel
Y102	Intake manifold air control solenoid
B69	Knock sensor (KS)
B30	Mass air flow (MAF) sensor
K4	Starter motor relay
A236	Steering column function control module
A177	Throttle control unit
B169	Throttle motor position sensor
M89	Throttle position motor