

B161	AC refrigerant pressure sensor
B138	Accelerator pedal position (APP) sensor
G1	Alternator
A16	Anti-lock braking system (ABS) control module
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
S258	Clutch pedal position (CPP) switch
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
B54	Crankshaft position (CKP) sensor
S298	Cruise control throttle switch
X1	Data link connector (DLC)
A35	Engine control module (ECM)
A95	Engine coolant blower motor control module
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump (FP)
F	Fuse
X28-I	Fuse box/relay plate, engine bay
X28-II	Fuse box/relay plate, fascia
B72-I	Heated oxygen sensor (HO2S) 1 - before cat
B72-II	Heated oxygen sensor (HO2S) 2 - after cat
T1	Ignition coil
15	Ignition switch - ignition ON
Y3	Injector
A5-I	Instrument panel 1
A5-II	Instrument panel 2
A75-I	Instrumentation control module 1
A75-II	Instrumentation control module 2
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
A11-I	Multifunction control module 1
A11-II	Multifunction control module 2
M89	Throttle motor
B169	Throttle motor position sensor
A57	Transmission control module (TCM)
VAN	Vehicle area network (data bus)

C								B								A											
<u>h1</u>	<u>g1</u>	<u>f1</u>	<u>e1</u>	<u>d1</u>	<u>c1</u>	<u>b1</u>	<u>a1</u>	<u>m1</u>	<u>h</u>	<u>k1</u>	<u>j1</u>	<u>h1</u>	<u>g1</u>	<u>f1</u>	<u>e1</u>	<u>d1</u>	<u>c1</u>	<u>b1</u>	<u>a1</u>	<u>a4</u>	<u>b4</u>	<u>c4</u>	<u>d4</u>	<u>e4</u>	<u>f4</u>	<u>g4</u>	<u>h4</u>
<u>h2</u>	<u>g2</u>	<u>f2</u>	<u>e2</u>	<u>d2</u>	<u>c2</u>	<u>b2</u>	<u>a2</u>	<u>m2</u>	<u>f2</u>	<u>k2</u>	<u>j2</u>	<u>h2</u>	<u>g2</u>	<u>f2</u>	<u>e2</u>	<u>d2</u>	<u>c2</u>	<u>b2</u>	<u>a2</u>	<u>a3</u>	<u>b3</u>	<u>c3</u>	<u>d3</u>	<u>e3</u>	<u>f3</u>	<u>g3</u>	<u>h3</u>
<u>h3</u>	<u>g3</u>	<u>f3</u>	<u>e3</u>	<u>d3</u>	<u>c3</u>	<u>b3</u>	<u>a3</u>	<u>m3</u>	<u>f3</u>	<u>k3</u>	<u>j3</u>	<u>h3</u>	<u>g3</u>	<u>f3</u>	<u>e3</u>	<u>d3</u>	<u>c3</u>	<u>b3</u>	<u>a3</u>	<u>a2</u>	<u>b2</u>	<u>c2</u>	<u>d2</u>	<u>e2</u>	<u>f2</u>	<u>g2</u>	<u>h2</u>
<u>h4</u>	<u>g4</u>	<u>f4</u>	<u>e4</u>	<u>d4</u>	<u>c4</u>	<u>b4</u>	<u>a4</u>	<u>m4</u>	<u>f4</u>	<u>k4</u>	<u>j4</u>	<u>h4</u>	<u>g4</u>	<u>f4</u>	<u>e4</u>	<u>d4</u>	<u>c4</u>	<u>b4</u>	<u>a4</u>	<u>a1</u>	<u>b1</u>	<u>c1</u>	<u>d1</u>	<u>e1</u>	<u>f1</u>	<u>g1</u>	<u>h1</u>

0002744

AC22741

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.



