


A16	ABS control module
K143	AC compressor clutch relay
B138	Accelerator pedal position (APP) sensor
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
Y81	Camshaft position (CMP) actuator
Y81-I	Camshaft position (CMP) actuator 1
Y81-II	Camshaft position (CMP) actuator 2
B132	Camshaft position (CMP) sensor
B132-I	Camshaft position (CMP) sensor 1
B132-II	Camshaft position (CMP) sensor 2
S258	Clutch pedal position (CPP) switch
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
K46	Engine control (EC) relay
A35	Engine control module (ECM)
M6	Engine coolant blower motor
B187	Engine coolant blower motor temperature sensor
B24	Engine coolant temperature (ECT) sensor
R96	Engine coolant thermostat
B156	Engine oil temperature sensor
Y104	Evaporative emission (EVAP) canister purge valve
Y141	Exhaust gas control solenoid
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
S3	Headlamp switch
B72	Heated oxygen sensor (HO2S)
B72-I	Heated oxygen sensor (HO2S) 1
B72-II	Heated oxygen sensor (HO2S) 2
B72-III	Heated oxygen sensor (HO2S) 3
B72-IV	Heated oxygen sensor (HO2S) 4
Y99	Idle air control (IAC) valve
T1	Ignition coil
S1	Ignition switch
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
K251	Injector relay
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
Y102	Intake manifold air control solenoid
B69	Knock sensor (KS)
B30	Mass air flow (MAF) sensor
M73	Secondary air injection (AIR) pump
K152	Secondary air injection (AIR) pump relay
Y111	Secondary air injection (AIR) solenoid
S365	Steering wheel multifunction switch
M89	Throttle motor
A61	Traction control module
A57	Transmission control module (TCM)

15	Under front seat, LH
B22	Wheel speed sensor, right rear



bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

