


A

a4	b4	c4	d4	e4	f4	g4	h4	j4	k4	l4	m4
a3	b3	c3	d3	e3	f3	g3	h3	j3	k3	l3	m3
a2	b2	c2	d2	e2	f2	g2	h2	j2	k2	l2	m2
a1	b1	c1	d1	e1	f1	g1	h1	j1	k1	l1	m1

h1	g1	f1	e1	d1	c1	b1	a1
h2	g2	f2	e2	d2	c2	b2	a2
h3	g3	f3	e3	d3	c3	b3	a3
h4	g4	f4	e4	d4	c4	b4	a4

a4	b4	c4	d4	e4	f4	g4	h4
a3	b3	c3	d3	e3	f3	g3	h3
a2	b2	c2	d2	e2	f2	g2	h2
a1	b1	c1	d1	e1	f1	g1	h1



A16	ABS control module
B161	AC refrigerant pressure sensor
B138	Accelerator pedal position (APP) sensor
G1	Alternator
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
Y81	Camshaft position (CMP) actuator
B132	Camshaft position (CMP) sensor
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A207	Electronic stability program (ESP) control module
A35	Engine control module (ECM)
M6	Engine coolant blower motor
A95	Engine coolant blower motor control module
K12	Engine coolant blower motor relay
B24	Engine coolant temperature (ECT) sensor
B86	Engine oil level sensor
S389	Engine oil pressure switch
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump (FP)
F	Fuse
X28-II	Fuse box/relay plate, engine bay 1
X28-III	Fuse box/relay plate, engine bay 2
X28-I	Fuse box/relay plate, fascia
B72-I	Heated oxygen sensor (HO2S) 1
B72-II	Heated oxygen sensor (HO2S) 2
T1	Ignition coil
S1	Ignition switch
15	Ignition switch - ignition ON
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
A11-I	Multifunction control module 1
A11-II	Multifunction control module 2
A81	Power steering control module
A24	Stop-start system control module
A177	Throttle control unit
M89	Throttle motor
B169	Throttle motor position sensor
A57	Transmission control module (TCM)
VAN	Vehicle area network (data bus)