





A16	ABS control module
B138	Accelerator pedal position (APP) sensor
X93	Airbag spiral cable
K208	Anti-percolation engine coolant blower relay
K271	Auxiliary heater relay
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
Y81	Camshaft position (CMP) actuator
S258	Clutch pedal position (CPP) switch
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
B54	Crankshaft position (CKP) sensor
S79	Cruise control master switch
S214	Cruise control reversing switch
S80	Cruise control selector switch
X1	Data link connector (DLC)
A130	Diagnostic module
A35	Engine control module (ECM)
K46	Engine control relay
K12	Engine coolant blower motor relay
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
X28-II	Fuse box/relay plate, engine bay
X28-I	Fuse box/relay plate, fascia 1
B72	Heated oxygen sensor (HO2S)
T1	Ignition coil
K79	Ignition main circuits relay
15	Ignition switch - ignition ON
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
S231	Power steering pressure (PSP) switch
A177	Throttle control unit
B169	Throttle motor position sensor
M89	Throttle position motor
A57	Transmission control module (TCM)
P9	Vehicle speedometer