


B161	AC refrigerant pressure sensor
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
M6	Engine coolant blower motor
K12-I	Engine coolant blower motor relay 1
K12-II	Engine coolant blower motor relay 2
K12-III	Engine coolant blower motor relay 3
R46	Engine coolant blower motor resistor
R46-I	Engine coolant blower motor resistor 1
R46-II	Engine coolant blower motor resistor 2
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
Y28	Exhaust gas recirculation (EGR) solenoid
B149	Exhaust gas recirculation (EGR) valve position sensor
M12	Fuel pump (FP)
F	Fuse
X28-IV	Fuse box/relay plate , fascia 2
X28-II	Fuse box/relay plate, engine bay 1
X28-III	Fuse box/relay plate, engine bay 2
X28-I	Fuse box/relay plate, fascia 1
B72-I	Heated oxygen sensor (HO2S) 1
B72-II	Heated oxygen sensor (HO2S) 2
Y99	Idle air control (IAC) valve
T1	Ignition coil
15	Ignition switch - ignition ON
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
A11-I	Multifunction control module 1
A11-II	Multifunction control module 2
S231	Power steering pressure (PSP) switch
M73	Secondary air injection (AIR) pump
X92-I	Shorting link connector 1
P7	Tachometer
R10	Throttle body heater
B147	Throttle position (TP) sensor
A57	Transmission control module (TCM)
VAN	Vehicle area network (data bus)
B33	Vehicle speed sensor (VSS)
P9	Vehicle speedometer



bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

