





A16	ABS control module
B138	Accelerator pedal position (APP) sensor
G1	Alternator
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
15	C pillar, LH
Y182	Camshaft position (CMP) actuator, intake
B132	Camshaft position (CMP) sensor
R99	Clutch position potentiometer
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A130	Diagnostic module
A35	Engine control module (ECM)
A95	Engine coolant blower motor control module
M50	Engine coolant pump motor
K105	Engine coolant pump relay
B24	Engine coolant temperature (ECT) sensor
B24-I	Engine coolant temperature (ECT) sensor 1
B24-II	Engine coolant temperature (ECT) sensor 2
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
B3	Fuel gauge tank sensor
Y63	Fuel pressure regulator control solenoid
K342	Fuel pressure regulator control solenoid relay
M12	Fuel pump (FP)
A107	Fuel pump control module
B186	Fuel rail pressure (FRP) sensor
F	Fuse
X28-Ib	Fuse box/relay plate, engine bay 1 - type 2
X28-II	Fuse box/relay plate, fascia 1
B72	Heated oxygen sensor (HO2S)
A52	Ignition amplifier
T1	Ignition coil
K79	Ignition main circuits relay
15	Ignition switch - ignition ON
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
B155	Intake manifold air control actuator position sensor
Y102	Intake manifold air control solenoid
B69	Knock sensor (KS)
B69-I	Knock sensor (KS)
B69-II	Knock sensor (KS)
B30	Mass air flow (MAF) sensor
A11	Multifunction control module
A236	Steering column function control module
P7	Tachometer
A177	Throttle control unit

M89	Throttle motor
B169	Throttle motor position sensor
B105	Turbocharger (TC) boost pressure sensor
Y153	Turbocharger (TC) intake divert valve
Y217	Turbocharger (TC) vane position actuator
P9	Vehicle speedometer

