


A16	ABS control module
S341	AC refrigerant triple pressure switch
B138	Accelerator pedal position (APP) sensor
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
Y81	Camshaft position (CMP) actuator
Y81-I	Camshaft position (CMP) actuator 1
Y81-II	Camshaft position (CMP) actuator 2
B132	Camshaft position (CMP) sensor
B132-I	Camshaft position (CMP) sensor 1
B132-II	Camshaft position (CMP) sensor 2
B54	Crankshaft position (CKP) sensor
S101	Cruise control brake pedal switch
S80	Cruise control selector switch
X1	Data link connector (DLC)
A35	Engine control module (ECM)
M6	Engine coolant blower motor
K12-I	Engine coolant blower motor relay 1
K12-II	Engine coolant blower motor relay 2
R46-I	Engine coolant blower motor resistor 1
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
B86	Engine oil level sensor
B156	Engine oil temperature sensor
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
F	Fuse
X28-II	Fuse box/relay plate, engine bay 1
X28-I	Fuse box/relay plate, fascia 1
X28-III	Fuse box/relay plate, fascia 2
B72	Heated oxygen sensor (HO2S)
B72-I	Heated oxygen sensor (HO2S) 1
B72-II	Heated oxygen sensor (HO2S) 2
B72-III	Heated oxygen sensor (HO2S) 3
B72-IV	Heated oxygen sensor (HO2S) 4
T1	Ignition coil
15	Ignition switch - ignition ON
15	In tailgate, RH
S39	Inertia fuel shut-off (IFS) switch
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B69-I	Knock sensor (KS) 1
B69-II	Knock sensor (KS) 2
B83	Manifold absolute pressure (MAP) sensor
A11	Multifunction control module
A81	Power steering control module
S231	Power steering pressure (PSP) switch
A171	Relay module

H111	Stop engine warning lamp
P7	Tachometer
B169	Throttle motor position sensor
M89	Throttle position motor
A57	Transmission control module (TCM)
B33	Vehicle speed sensor (VSS)
P9	Vehicle speedometer



AD72818

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

**NOTE:** In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

