





A16	ABS control module
B161	AC refrigerant pressure sensor
B138	Accelerator pedal position (APP) sensor
K271	Auxiliary heater relay
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
B54	Crankshaft position (CKP) sensor
S101	Cruise control brake pedal switch
X1	Data link connector (DLC)
A207	Electronic stability program (ESP) control module
A35	Engine control module (ECM)
M6	Engine coolant blower motor
A95	Engine coolant blower motor control module
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y28	Exhaust gas recirculation (EGR) solenoid
R64	Fuel filter heater
Y194	Fuel flow control valve
Y63	Fuel pressure regulator control solenoid
B186	Fuel rail pressure (FRP) sensor
B31	Fuel temperature sensor
B82	Fuel/water separator sensor
F	Fuse
X28-II	Fuse box/relay plate - engine bay 1
X28-I	Fuse box/relay plate - fascia
A104	Glow plug control module
R5	Glow plugs
15	Ignition switch - ignition ON
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
B30	Mass air flow (MAF) sensor
A11-I	Multifunction control module 1
A11-II	Multifunction control module 2
P7	Tachometer
VAN	Vehicle area network (data bus)
B33	Vehicle speed sensor (VSS)
P9	Vehicle speedometer