

K143	AC compressor clutch relay
S341	AC refrigerant triple pressure switch
B138	Accelerator pedal position (APP) sensor
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
Y215	Cold start injector solenoid
K312	Cold start injector solenoid relay
B54	Crankshaft position (CKP) sensor
R94	Engine breather heater
K46	Engine control (EC) relay
A35	Engine control module (ECM)
K12-I	Engine coolant blower motor relay 1
K12-II	Engine coolant blower motor relay 2
K12-III	Engine coolant blower motor relay 3
B24	Engine coolant temperature (ECT) sensor
X53	Engine diagnostic link
H63	Engine malfunction indicator lamp (MIL)
R64	Fuel filter heater
K310	Fuel filter heater relay
Y63	Fuel pressure regulator control solenoid
M12	Fuel pump
K20	Fuel pump relay
B186	Fuel rail pressure (FRP) sensor
B31	Fuel temperature sensor
F	Fuse
X28-I	Fuse box/relay plate 1 - passenger compartment
K93	Glow plug timer relay
H25	Glow plug warning lamp
K247	Glow plug warning lamp relay
R5	Glow plugs
15	Ignition switch - ignition ON
A162	Immobilizer control module
S39	Inertia fuel shut-off (IFS) switch
Y3	Injector
A5	Instrument panel
Y160	Piston cut-off solenoid
B105	Turbocharger (TC) boost pressure sensor
B33	Vehicle speed sensor (VSS)

C								B								A											
<u>h1</u>	<u>g1</u>	<u>f1</u>	<u>e1</u>	<u>d1</u>	<u>c1</u>	<u>b1</u>	<u>a1</u>	<u>m1</u>	<u>h</u>	<u>k1</u>	<u>j1</u>	<u>h1</u>	<u>g1</u>	<u>f1</u>	<u>e1</u>	<u>d1</u>	<u>c1</u>	<u>b1</u>	<u>a1</u>	<u>a4</u>	<u>b4</u>	<u>c4</u>	<u>d4</u>	<u>e4</u>	<u>f4</u>	<u>g4</u>	<u>h4</u>
<u>h2</u>	<u>g2</u>	<u>f2</u>	<u>e2</u>	<u>d2</u>	<u>c2</u>	<u>b2</u>	<u>a2</u>	<u>m2</u>	<u>f2</u>	<u>k2</u>	<u>j2</u>	<u>h2</u>	<u>g2</u>	<u>f2</u>	<u>e2</u>	<u>d2</u>	<u>c2</u>	<u>b2</u>	<u>a2</u>	<u>a3</u>	<u>b3</u>	<u>c3</u>	<u>d3</u>	<u>e3</u>	<u>f3</u>	<u>g3</u>	<u>h3</u>
<u>h3</u>	<u>g3</u>	<u>f3</u>	<u>e3</u>	<u>d3</u>	<u>c3</u>	<u>b3</u>	<u>a3</u>	<u>m3</u>	<u>f3</u>	<u>k3</u>	<u>j3</u>	<u>h3</u>	<u>g3</u>	<u>f3</u>	<u>e3</u>	<u>d3</u>	<u>c3</u>	<u>b3</u>	<u>a3</u>	<u>a2</u>	<u>b2</u>	<u>c2</u>	<u>d2</u>	<u>e2</u>	<u>f2</u>	<u>g2</u>	<u>h2</u>
<u>h4</u>	<u>g4</u>	<u>f4</u>	<u>e4</u>	<u>d4</u>	<u>c4</u>	<u>b4</u>	<u>a4</u>	<u>m4</u>	<u>f4</u>	<u>k4</u>	<u>j4</u>	<u>h4</u>	<u>g4</u>	<u>f4</u>	<u>e4</u>	<u>d4</u>	<u>c4</u>	<u>b4</u>	<u>a4</u>	<u>a1</u>	<u>b1</u>	<u>c1</u>	<u>d1</u>	<u>e1</u>	<u>f1</u>	<u>g1</u>	<u>h1</u>

AD2744

AC02744

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.



