

S341	AC refrigerant triple pressure switch
B138	Accelerator pedal position (APP) sensor
31	Battery -
30	Battery +
B223	Brake system vacuum sensor
Y81	Camshaft position (CMP) actuator
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
B54	Crankshaft position (CKP) sensor
S101	Cruise control brake pedal switch
X1	Data link connector (DLC)
A35	Engine control module (ECM)
M6	Engine coolant blower motor
K12-I	Engine coolant blower motor relay 1
K12-II	Engine coolant blower motor relay 2
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
Y28	Exhaust gas recirculation (EGR) solenoid
B149	Exhaust gas recirculation (EGR) valve position sensor
B131-I	Exhaust gas temperature sensor 1
B131-II	Exhaust gas temperature sensor 2
Y63	Fuel pressure regulator control solenoid
M12	Fuel pump
B186	Fuel rail pressure (FRP) sensor
F	Fuse
X28-II	Fuse box/relay plate, engine bay 1
X28-I	Fuse box/relay plate, fascia 1
X28-III	Fuse box/relay plate, fascia 2
B72	Heated oxygen sensor (HO2S)
B72-I	Heated oxygen sensor (HO2S) 1
B72-II	Heated oxygen sensor (HO2S) 2
T1	Ignition coil
15	Ignition switch - ignition ON
15	In tailgate, RH
S39	Inertia fuel shut-off (IFS) switch
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
A11	Multifunction control module
S231	Power steering pressure (PSP) switch
A171	Relay module
P7	Tachometer
B169	Throttle motor position sensor
M89	Throttle position motor
B33	Vehicle speed sensor (VSS)
P9	Vehicle speedometer

56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88
 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55
 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28

AD20174

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.



