


A16	ABS control module
B22	ABS wheel speed sensor, right rear
A63	AC control module
B138	Accelerator pedal position (APP) sensor
X93	Airbag spiral cable
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
K46	Engine control relay
M6	Engine coolant blower motor
B24	Engine coolant temperature (ECT) sensor
Y133	Engine mounting control solenoid
H5	Engine oil pressure warning lamp
S25	Engine oil pressure warning lamp switch
Y63	Fuel pressure regulator control solenoid
M12	Fuel pump
K20	Fuel pump relay
B186	Fuel rail pressure (FRP) sensor
B26	Fuel system pressure sensor
F	Fuse
A104	Glow plug control module
R5	Glow plugs
X	Ignition switch - accessories
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B30	Mass air flow (MAF) sensor
A193	Multi switch assembly
S365	Steering wheel multifunction switch
A61	Traction control module
A57	Transmission control module (TCM)
Y116	Turbocharger (TC) wastegate actuator
B105	Turbocharger (TC) wastegate pressure sensor
15	Under rear window shelf



bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

