


A16	ABS control module
B22	ABS wheel speed sensor, right rear
K143	AC compressor clutch relay
G1	Alternator
31	Battery -
30	Battery +
Y171	Brake servo diaphragm valve
B132	Camshaft position (CMP) sensor
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
EP	Earth point
K46	Engine control (EC) relay
A35	Engine control module (ECM)
M6	Engine coolant blower motor
B187	Engine coolant blower motor temperature sensor
B24	Engine coolant temperature (ECT) sensor
R96	Engine coolant thermostat
B86	Engine oil level sensor
H37	Engine oil level warning lamp
H5	Engine oil pressure warning lamp
S25	Engine oil pressure warning lamp switch
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump (FP)
K20	Fuel pump (FP) relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
T1	Ignition coil
K189	Ignition coil relay
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
Y102	Intake manifold air control solenoid
B69	Knock sensor (KS)
B30	Mass air flow (MAF) sensor
M73	Secondary air injection (AIR) pump
K152	Secondary air injection (AIR) pump relay
Y111	Secondary air injection (AIR) solenoid
M1	Starter motor
B147	Throttle position (TP) sensor
A61	Traction control module
A57	Transmission control module (TCM)



bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

