





**A**

**B**

94	93	92	91	90	89	88	87	86	85	84	83	82	81	80	79	78	77	76	75	74	73
72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	57	56	55	54	53	52	51
50	49	48	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32	31	30	29
28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7

6	5
4	3
2	1

60	59	58	57	56	55	54	53	52	51	50	49	48	47	46
45	44	43	42	41	40	39	38	37	36	35	34	33	32	31
30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1

A16	ABS control module
K143	AC compressor clutch relay
B161	AC refrigerant pressure sensor
B138	Accelerator pedal position (APP) sensor
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
K46	Engine control (EC) relay
A35	Engine control module (ECM)
K12-I	Engine coolant blower motor relay 1
K12-II	Engine coolant blower motor relay 2
K12-III	Engine coolant blower motor relay 3
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
B86	Engine oil level sensor
H37	Engine oil level warning lamp
Y28	Exhaust gas recirculation (EGR) solenoid
R64	Fuel filter heater
K138	Fuel heater relay
M12	Fuel lift pump
K20	Fuel lift pump relay
Y170	Fuel rail pressure (FRP) control valve
B186	Fuel rail pressure (FRP) sensor
B31	Fuel temperature sensor
F	Fuse
X28-II	Fuse box/relay plate, engine bay 1
X28-III	Fuse box/relay plate, engine bay 2
X28-I	Fuse box/relay plate, fascia
R5	Glow plug
A104	Glow plug control module
H25	Glow plug warning lamp
K28	Heater blower relay
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
B83	Manifold absolute pressure (MAP) sensor
B30	Mass air flow (MAF) sensor
A81	Power steering control module
H50	Service indicator
A123	Vehicle speed sensor (VSS) signal amplifier
B20	Wheel speed sensor, right front