


Y160	3rd piston cut-off solenoid
A63	AC control module
S341	AC refrigerant triple pressure switch
B138	Accelerator pedal position (APP) sensor
B121	Barometric pressure (BARO) sensor
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
B54	Crankshaft position (CKP) sensor
S101	Cruise control brake pedal switch
S82	Cruise control clutch pedal switch
S80	Cruise control selector switch
X1	Data link connector (DLC)
EP	Earth point
A35	Engine control module (ECM)
K12-I	Engine coolant blower motor relay 1
K12-II	Engine coolant blower motor relay 2
R93	Engine coolant heater
K242	Engine coolant heater relay
H22	Engine coolant 'hot' warning lamp
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
K270	Engine running circuits relay
Y28	Exhaust gas recirculation (EGR) solenoid
Y28-I	Exhaust gas recirculation (EGR) solenoid 1
Y28-II	Exhaust gas recirculation (EGR) solenoid 2
Y63	Fuel pressure control solenoid
M12	Fuel pump
B186	Fuel rail pressure (FRP) sensor
B31	Fuel temperature sensor
F	Fuse
X28-II	Fuse box/relay plate, engine bay 1
X28-IV	Fuse box/relay plate, engine bay 2
X28-I	Fuse box/relay plate, fascia 1
X28-III	Fuse box/relay plate, fascia 2
R5	Glow plug
K93	Glow plug timer relay
H25	Glow plug warning lamp
15	Ignition switch - ignition ON
A162	Immobilizer control module
S39	Inertia fuel shut-off (IFS) switch
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
B83	Manifold absolute pressure (MAP) sensor
B30	Mass air flow (MAF) sensor
A11	Multifunction control module
A171	Relay module
P7	Tachometer

A57	Transmission control module (TCM)
Y68	Turbocharger (TC) wastegate regulating valve
B33	Vehicle speed sensor (VSS)
P9	Vehicle speedometer



bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

