



A

B

C

44	43	42	41	40	39	38	37	36
35	34	33	32	31	30	29	28	27
25	24	23		22	21	20		
19	18	17	16	15	14	13	12	11
9	8	7	6	5	4	3	2	1

44	43	42	41	40	39	38	37	36
35	34	33	32	31	30	29	28	27
25	24	23		22	21	20		
19	18	17	16	15	14	13	12	11
9	8	7	6	5	4	3	2	1

44	43	42	41	40	39	38	37	36
35	34	33	32	31	30	29	28	27
25	24	23		22	21	20		
19	18	17	16	15	14	13	12	11
9	8	7	6	5	4	3	2	1



K143	AC compressor clutch relay
K129	AC condenser blower motor relay
B161	AC refrigerant pressure sensor
B138	Accelerator pedal position (APP) sensor
G1	Alternator
A1	Audio unit
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
Y81	Camshaft position (CMP) actuator
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
B153	Electrical load sensor
K46-I	Engine control (EC) relay 1
K46-II	Engine control (EC) relay 2
A35	Engine control module (ECM)
K12-I	Engine coolant blower motor relay 1
K12-II	Engine coolant blower motor relay 2
B24-I	Engine coolant temperature (ECT) sensor 1
B24-II	Engine coolant temperature (ECT) sensor 2
B86	Engine oil level sensor
B6	Engine oil pressure sensor
S389	Engine oil pressure switch
Y104	Evaporative emission (EVAP) canister purge valve
Y151	Exhaust gas recirculation (EGR) valve actuator
B149	Exhaust gas recirculation (EGR) valve position sensor
M12	Fuel pump (FP)
K20	Fuel pump (FP) relay
F	Fuse
X28-II	Fuse box/relay plate, engine bay 1
X28-I	Fuse box/relay plate, fascia
B72-I	Heated oxygen sensor (HO2S) 1
B72-II	Heated oxygen sensor (HO2S) 2
T1	Ignition coil
K189	Ignition coil relay
15	Ignition switch - ignition ON
S39	Inertia fuel shut-off (IFS) switch
Y3	Injector

A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
Y179	Intake manifold air control actuator
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
B30	Mass air flow (MAF) sensor
A11	Multifunction control module
Y165	Reverse gear selection solenoid
K55	Starter motor inhibitor switch relay
X87	Tachometer diagnostic link
A177	Throttle control unit
K284	Throttle control unit relay
M89	Throttle motor
B169	Throttle motor position sensor
A57	Transmission control module (TCM)
Y186-I	Transmission fluid pressure (TFP) solenoid 1
Y186-II	Transmission fluid pressure (TFP) solenoid 2
Y186-III	Transmission fluid pressure (TFP) solenoid 3
S185-I	Transmission fluid pressure (TFP) switch 1
S185-II	Transmission fluid pressure (TFP) switch 2
B133	Transmission fluid temperature (TFT) sensor
B201	Transmission input shaft speed sensor
S253	Transmission mode selection switch
Y163	Transmission park position interlock solenoid
S249	Transmission range (TR) switch
Y97	Transmission shift solenoid (SS)
B134	Transmission vehicle speed sensor

