





A16	ABS control module
B138	Accelerator pedal position (APP) sensor
G1	Alternator
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
B132	Camshaft position (CMP) sensor
R99	Clutch position potentiometer
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
R57	Crankcase breather heater
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A130	Diagnostic module
A35	Engine control module (ECM)
A95	Engine coolant blower motor control module
B24-I	Engine coolant temperature (ECT) sensor 1
B24-II	Engine coolant temperature (ECT) sensor 2
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump (FP)
K20	Fuel pump (FP) relay
K281	Fuel system primer relay
F	Fuse
X28-I	Fuse box/relay plate, engine bay 1
X28-II	Fuse box/relay plate, fascia 1
X28-V	Fuse box/relay plate, fascia 3
B72-I	Heated oxygen sensor (HO2S) 1
B72-II	Heated oxygen sensor (HO2S) 2
A52	Ignition amplifier
T1	Ignition coil
K79-I	Ignition main circuits relay 1
15	Ignition switch - ignition ON
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
Y102	Intake manifold air control solenoid
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
A11-I	Multifunction control module 1
M73	Secondary air injection (AIR) pump
K152	Secondary air injection (AIR) pump relay
K4	Starter motor relay
A236	Steering column function control module
P7	Tachometer
A177	Throttle control unit
M89	Throttle motor
B169	Throttle motor position sensor
P9	Vehicle speedometer