


A16	ABS control module
K143	AC compressor clutch relay
B138	Accelerator pedal position (APP) sensor
X93	Airbag spiral cable
G1	Alternator
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
Y81	Camshaft position (CMP) actuator
Y81-I	Camshaft position (CMP) actuator 1
Y81-II	Camshaft position (CMP) actuator 2
B132	Camshaft position (CMP) sensor
B132-I	Camshaft position (CMP) sensor 1
B132-II	Camshaft position (CMP) sensor 2
A167	Clutch control module
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
X1-I	Data link connector (DLC) 1
K46	Engine control (EC) relay
A35	Engine control module (ECM)
M6	Engine coolant blower motor
B187	Engine coolant blower motor temperature sensor
B24	Engine coolant temperature (ECT) sensor
R96	Engine coolant thermostat
B86	Engine oil level sensor
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
X28-II	Fuse box/relay plate, engine bay
X28-I	Fuse box/relay plate, fascia
B72	Heated oxygen sensor (HO2S)
B72-I	Heated oxygen sensor (HO2S) 1
B72-II	Heated oxygen sensor (HO2S) 2
T1	Ignition coil
K189	Ignition coil relay
S1	Ignition switch
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
Y66	Intake air flap control actuator
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
A192	Lamps control module
B83	Manifold absolute pressure (MAP) sensor
B30	Mass air flow (MAF) sensor
M73	Secondary air injection (AIR) pump
K152	Secondary air injection (AIR) pump relay

S365	Steering wheel multifunction switch
A177	Throttle control unit
M89	Throttle motor
B169	Throttle motor position sensor
A57	Transmission control module (TCM)
15	Under front seat, LH
A245	Variable valve lift control module
K298	Variable valve lift control module relay
M156	Variable valve lift position motor, inlet
B229	Variable valve lift position sensor, inlet
B22	Wheel speed sensor, right rear



bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

**NOTE:** In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

