


A16	ABS control module
A63	AC control module
B138	Accelerator pedal position (APP) sensor
C3	Audio unit suppressor
A39	Auxiliary warning module
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
K46	Engine control relay
M6	Engine coolant blower motor
B187	Engine coolant blower motor temperature sensor
B24	Engine coolant temperature (ECT) sensor
R96	Engine coolant thermostat
B86	Engine oil level sensor
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
X28	Fuse box/relay plate
B72	Heated oxygen sensor (HO2S)
T1	Ignition coil
K189	Ignition coil relay
15	Ignition switch - ignition ON
50	Ignition switch - start signal
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
Y102	Intake manifold air control solenoid
B69	Knock sensor (KS)
A192	Lamps control module
B30	Mass air flow (MAF) sensor
M73	Secondary air injection (AIR) pump
K152	Secondary air injection (AIR) pump relay
Y111	Secondary air injection (AIR) solenoid
B106	Steering position sensor
B147	Throttle position (TP) sensor
M89	Throttle position motor
A61	Traction control module
A57	Transmission control module (TCM)
15	Under rear window shelf



bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

