


A23	Alarm system control module
31	Battery -
30	Battery +
A31	Central locking control module
X1	Data link connector (DLC)
M125	Door mirror retract motor, passenger
A95	Engine coolant blower motor control module
S25	Engine oil pressure warning lamp switch
B75	Engine speed (RPM) sensor
S371	Exhaust gas recirculation (EGR) load switch
Y28	Exhaust gas recirculation (EGR) solenoid
M12	Fuel pump
F	Fuse
A104	Glow plug control module
S205	Glow plug engine coolant temperature switch
K22	Glow plug relay
H25	Glow plug warning lamp
R5	Glow plugs
15	Ignition switch - ignition ON
50	Ignition switch - start signal
K275	Immobilizer control module
B184	Immobilizer transponder
K268	Injection pump advance relay
Y131	Injection pump advance solenoid
A150	Injection pump assembly
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
M1	Starter motor
P7	Tachometer
B33	Vehicle speed sensor (VSS)
P9	Vehicle speedometer



bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

