





A63	AC control module
B138	Accelerator pedal position (APP) sensor
S337	Accelerator pedal position (APP) switch
G1	Alternator
A182	Auxiliary heater control module
B121	Barometric pressure (BARO) sensor
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
R57	Crankcase breather heater
B54	Crankshaft position (CKP) sensor
S79	Cruise control master switch
S80	Cruise control selector switch
X1	Data link connector (DLC)
A130	Diagnostic module
K46	Engine control (EC) relay
A35	Engine control module (ECM)
R93	Engine coolant heater
K242-I	Engine coolant heater relay 1, low output
K242-II	Engine coolant heater relay 2, high output
B24	Engine coolant temperature (ECT) sensor
B86	Engine oil level sensor
S293	Engine oil temperature switch
Y28	Exhaust gas recirculation (EGR) solenoid
B31	Fuel temperature sensor
F	Fuse
X28-I	Fuse box/relay plate, fascia 1
X28-III	Fuse box/relay plate, fascia 3
R5	Glow plug
K22	Glow plug relay
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
Y161	Intake manifold air control actuator
Y102	Intake manifold air control solenoid
B30	Mass air flow (MAF) sensor
A198	Supplementary restraint system (SRS) control module
A57	Transmission control module (TCM)
S61	Transmission kick-down switch
B105	Turbocharger (TC) boost pressure sensor
Y68	Turbocharger (TC) wastegate regulating valve
B33	Vehicle speed sensor (VSS)