



# MultiClamp™ 700B

## Commander Software

How to Control the MultiClamp 700B from Another Application

## Application Note

This document is provided to customers who have purchased Molecular Devices equipment, software, reagents, and consumables to use in the operation of such Molecular Devices equipment, software, reagents, and consumables. This document is copyright protected and any reproduction of this document, in whole or any part, is strictly prohibited, except as Molecular Devices may authorize in writing.

Software that may be described in this document is furnished under a non-transferrable license. It is against the law to copy, modify, or distribute the software on any medium, except as specifically allowed in the license agreement. Furthermore, the license agreement may prohibit the software from being disassembled, reverse engineered, or decompiled for any purpose.

Portions of this document may make reference to other manufacturers and/or their products, which may contain parts whose names are registered as trademarks and/or function as trademarks of their respective owners. Any such usage is intended only to designate those manufacturers' products as supplied by Molecular Devices for incorporation into its equipment and does not imply any right and/or license to use or permit others to use such manufacturers' and/or their product names as trademarks.

Each product is shipped with documentation stating specifications and other technical information. Molecular Devices products are warranted to meet the stated specifications. Molecular Devices makes no other warranties or representations express or implied, including but not limited to, the fitness of this product for any particular purpose and assumes no responsibility or contingent liability, including indirect or consequential damages, for any use to which the purchaser may put the equipment described herein, or for any adverse circumstances arising therefrom. The sole obligation of Molecular Devices and the customer's sole remedy are limited to repair or replacement of the product in the event that the product fails to do as warranted.

For research use only. Not for use in diagnostic procedures.

The trademarks mentioned herein are the property of Molecular Devices, LLC or their respective owners. These trademarks may not be used in any type of promotion or advertising without the prior written permission of Molecular Devices, LLC.

Patents: <http://www.moleculardevices.com/productpatents>

Product manufactured by Molecular Devices, LLC.  
1311 Orleans Drive, Sunnyvale, California, United States of America 94089.  
Molecular Devices, LLC is ISO 9001 registered.  
©2016 Molecular Devices, LLC.  
All rights reserved.

# Contents

<b>Controlling the MultiClamp 700B from Another Application .....</b>	<b>4</b>
<b>C++ Example .....</b>	<b>6</b>
<b>Command Reference.....</b>	<b>8</b>
<b>DLL Creation and Destruction .....</b>	<b>8</b>
<b>General .....</b>	<b>10</b>
<b>MultiClamp 700B Commander selection .....</b>	<b>11</b>
<b>Amplifier Mode .....</b>	<b>17</b>
<b>Holding .....</b>	<b>21</b>
<b>Test Signal.....</b>	<b>24</b>
<b>Pipette Offset .....</b>	<b>30</b>
<b>Slow Current Injection .....</b>	<b>32</b>
<b>Fast and Slow Compensation .....</b>	<b>37</b>
<b>Pipette Capacitance Neutralization .....</b>	<b>44</b>
<b>Whole Cell Compensation .....</b>	<b>47</b>
<b>Series Resistance Compensation .....</b>	<b>51</b>
<b>Oscillation Killer .....</b>	<b>56</b>
<b>Primary (or Scaled) Signal.....</b>	<b>58</b>
<b>Scope Signal .....</b>	<b>65</b>
<b>Secondary (or Raw) Signal .....</b>	<b>67</b>
<b>Output Zero .....</b>	<b>72</b>
<b>Leak Subtraction .....</b>	<b>75</b>
<b>Bridge Balance.....</b>	<b>78</b>
<b>Clear .....</b>	<b>81</b>
<b>Pulse, Zap, and Buzz.....</b>	<b>82</b>
<b>Meters .....</b>	<b>89</b>
<b>Tool Bar .....</b>	<b>91</b>
<b>Errors Handling .....</b>	<b>94</b>

## Controlling the MultiClamp 700B from Another Application

MultiClamp 700B Commander can be controlled from another application with a special API. This Application Note provides some basic guidance in how to do this.

Note that we cannot offer technical support on this matter, and the API may change without warning.

Use this document in conjunction with the header file `AxMultiClampMsg.h` and example VC++ code in the `MCCMSG_TestBed` project.

Before calling any command, you must first create the DLL object.

`MCCMSG_CreateObject` returns a handle that you must pass as a parameter to each subsequent call. The handle references a hidden window inside the DLL for capturing Windows messages. Make sure you also destroy the DLL object using `MCCMSG_DestroyObject` before exiting your application. This will prevent a memory leak.

After creating the DLL object, you must select the MultiClamp 700B Commander and headstage channel you need to control. This is done by scanning for all MultiClamp 700B devices connected to a MultiClamp 700B Commander.

In this discussion, a device is defined as one Multiclamp 700B amplifier with one headstage channel controlled by MultiClamp 700B Commander. A MultiClamp 700B amplifier therefore supports two devices when both headstages are plugged in.

`MCCMSG_FindFirstMultiClamp` and `MCCMSG_FindNextMultiClamp` uniquely identify each device based on the amplifier model, the headstage channel, or the serial number. For the MultiClamp 700A, the unique identifier could be the COM port information, but not the serial number.

If your rig has just one headstage, you will not need to call `MCCMSG_FindNextMultiClamp` because the first found device is always the correct device. After you have found the correct device, use `MCCMSG_SelectMultiClamp` to select the device you need to control. For an example of how to do this, see C++ Example on page 6.

Error handling is standard. A command always returns `FALSE` if the error parameter is set. The error can be decoded by passing the returned error code `*pnError` to `MCCMSG_BuildErrorText`.

Inside the DLL, each command is based on the Windows messaging technique. This means that commands can potentially timeout if the system is busy. The default timeout (3 second) is sufficient for all commands. To change the timeout value call `MCCMSG_SetTimeout`. In the event of a timeout, a command will block for the timeout period and return `FALSE` with timeout error code `MCCMSG_ERROR_MSGTIMEOUT`.

Some functions such as `MCCMSG_SetMode` and `MCCMSG_SetPrimarySignal` use predefined constants as parameters. For example, the following code changes the amplifier mode to voltage clamp:

```
int nError = MCCMSG_ERROR_NOERROR;
MCCMSG_SetMode(m_hMCCmsg, MCCMSG_MODE_VCLAMP, &nError);
```

A complete list of predefined constants can be found in `AxMultiClampMsg.h`.

To get started:

1. Compile the VC++ example project `MCCMSG_TestBed` in DevStudio.
2. Run the test bed and then run MultiClamp 700B Commander.
3. In the test bed, click **Create DLL**, then click **Scan**, and then choose an amplifier from the Device combo box. Notice that the MultiClamp 700B Commander changes the active mode/channel tab when the headstage channel is changed.
4. Select the voltage clamp mode by selecting the **VC** option and observe that the MultiClamp 700B Commander changes to that mode.
5. Click the Auto Fast Compensation button.
6. When the command completes, check that the **Cp Fast** and **Cp Tau** fields are filled out with the same values as MultiClamp 700B Commander. All values are in SI units, so even though these numbers are formatted in pF and  $\mu$ s, the underlying code uses the values in Farads and seconds.

It is important that you setup the correct mode before you apply a command because the DLL sends messages only to the active mode/channel tab in MultiClamp 700B Commander. For example, `MCCMSG_AutoFastComp` works only when the MultiClamp 700B amplifier is in voltage clamp mode and the active mode/channel tab is voltage clamp. If you now click the current clamp tab, the same command will fail with error `MCCMSG_ERROR_INVALIDPARAMETER`.

## C++ Example

```
#include <afxwin.h> // MFC core and standard components
#include "AxMultiClampMsg.h"

//=====
// FUNCTION: DisplayErrorMsg
// PURPOSE:  Display error as text string
//
void DisplayErrorMsg(HMCCMSG hMCCmsg, int nError)
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}

//=====
// FUNCTION:  main
// PURPOSE:   This example shows how to create the DLL handle, select the
first
//           MultiClamp, set current clamp mode, execute auto fast and
//           slow compensation, and destroy the handle.
//
int main()
{
    // check the API version matches the expected value
    if( !MCCMSG_CheckAPIVersion(MCCMSG_APIVERSION_STR) )
    {
        AfxMessageBox("Version mismatch: AXCLAMPEXMSG.DLL", MB_ICONSTOP);
        return 0;
    }

    // create DLL handle
    int nError = MCCMSG_ERROR_NOERROR;
    HMCCMSG hMCCmsg = MCCMSG_CreateObject(&nError);
    if( !hMCCmsg )
    {
        DisplayErrorMsg(hMCCmsg, nError);
        return 0;
    }

    // find the first MultiClamp
    char szError[256] = "";
    char szSerialNum[16] = ""; // Serial number of MultiClamp 700B
    UINT uModel = 0; // Identifies MultiClamp 700A or 700B model
    UINT uCOMPortID = 0; // COM port ID of MultiClamp 700A (1-16)
    UINT uDeviceID = 0; // Device ID of MultiClamp 700A (1-8)
    UINT uChannelID = 0; // Headstage channel ID
    if( !MCCMSG_FindFirstMultiClamp( hMCCmsg, &uModel, szSerialNum,
                                     sizeof(szSerialNum), &uCOMPortID,
                                     &uDeviceID, &uChannelID, &nError) )
```

```
{
    DisplayErrorMsg(hMCCmsg, nError);
    return 0;
}

// select this MultiClamp
if( !MCCMSG_SelectMultiClamp( hMCCmsg, uModel, szSerialNum,
                             uCOMPortID, uDeviceID, uChannelID, &nError) )
{
    DisplayErrorMsg(hMCCmsg, nError);
    return 0;
}

// set voltage clamp mode
if( !MCCMSG_SetMode(hMCCmsg, MCCMSG_MODE_VCLAMP, &nError) )
{
    DisplayErrorMsg(hMCCmsg, nError);
    return 0;
}

// execute auto fast compensation
if( !MCCMSG_AutoFastComp(hMCCmsg, &nError) )
{
    DisplayErrorMsg(hMCCmsg, nError);
    return 0;
}

// execute auto slow compensation
if( !MCCMSG_AutoSlowComp(hMCCmsg, &nError) )
{
    DisplayErrorMsg(hMCCmsg, nError);
    return 0;
}

// destroy DLL handle
MCCMSG_DestroyObject(hMCCmsg);
hMCCmsg = NULL;

return 0;
}
```

## Command Reference

Commands with similar functions are grouped together. Command groups are ordered as in the MultiClamp 700B Commander GUI from top to bottom and from left to right.

### DLL Creation and Destruction

#### **BOOL MCCMSG\_CheckAPIVersion(LPCSTR pszQueryVersion);**

Parameter	Description
pszQueryVersion	Pointer to null terminated string containing the version number.

#### **Remarks**

Checks the API version matches the expected value: MCCMSG\_APIVERSION\_STR.

#### **Example**

```
#include "AxMultiClampMsg.h"

if( !MCCMSG_CheckAPIVersion(MCCMSG_APIVERSION_STR) )
{
    AfxMessageBox("Version mismatch: AXMULTICLAMPMSG.DLL", MB_ICONSTOP);
    return;
}
```



**HMCCMSG MCCMSG\_CreateObject(int \*pnError);**

Parameter	Description
pnError	Address of error: return code.

**Remarks**

Create the MultiClamp 700B Commander message handler object and return a 32-bit handle. When successful, the returned handle is non-NULL. You must use this handle to call other MCCMSG functions.

**Error Codes**

MCCMSG\_ERROR\_OUTOFMEMORY

MCCMSG\_ERROR\_MCCNOTOPEN

**Example**

```
#include "AxMultiClampMsg.h"

int nError = MCCMSG_ERROR_NOERROR;
m_hMCCmsg = MCCMSG_CreateObject(&nError);
if( !m_hMCCmsg )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(NULL, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**void MCCMSG\_DestroyObject(HMCCMSG hMCCmsg);**

Parameter	Description
hMCCmsg	Handle to message handler object.

**Remarks**

Destroys the MultiClamp 700B Commander message handler object. To prevent memory leaks, call this before exiting your application.

**Example**

```
#include "AxMultiClampMsg.h"

MCCMSG_DestroyObject(m_hMCCmsg);
m_hMCCmsg = NULL;
```

## General

**BOOL MCCMSG\_SetTimeOut(HMCCMSG hMCCmsg, UINT uTimeOutMS, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
uTimeOutMS	Time out value in milliseconds.
pnError	Address of error return code.

### Remarks

Set the time out value for Windows messages between the message handler object and MultiClamp 700B Commander. Default time out is 3 seconds.

### Example

```
#include "AxMultiClampMsg.h"

UINT uTimeOut = 2000; // 2 seconds
if( !MCCMSG_SetTimeOut(m_hMCCmsg, uTimeOut, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## MultiClamp 700B Commander selection

**BOOL MCCMSG\_FindFirstMultiClamp(HMCCMSG hMCCmsg, UINT \*puModel, char \*pszSerialNum, UINT uBufSize, UINT \*puCOMPortID, UINT \*puDeviceID, UINT \*puChannelID, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
puModel	Address of return amplifier model ID.
pszSerialNum	Address of return serial number (MultiClamp 700B only).
uBufSize	Size of char buffer for serial number (MultiClamp 700B only).
puCOMPortID	Address of return COM port ID (MultiClamp 700A only)
puDeviceID	Address of return Device ID (MultiClamp 700A only)
puChannelID	Address of return Channel ID
pnError	Address of error return code.

### Remarks

Find the first open MultiClamp 700B amplifier. At least one MultiClamp 700B Commander must be open to return valid parameters.

Inside the DLL, MCCMSG\_FindFirstMultiClamp scans and stores all open devices but only returns parameters for the first. MCCMSG\_FindNextMultiClamp uses this internally stored data to access information on each device. You must therefore call MCCMSG\_FindFirstMultiClamp before calling MCCMSG\_FindNextMultiClamp. Note that you do not have to call MCCMSG\_FindNextMultiClamp if your rig has just one headstage. In this case, MCCMSG\_FindFirstMultiClamp will always find the correct device.

If you close and reopen a MultiClamp 700B Commander after executing MCCMSG\_FindFirstMultiClamp, you must refresh the internal list held by the DLL by executing MCCMSG\_FindFirstMultiClamp again.

This command supports the MultiClamp 700A and the MultiClamp 700B.

- When a MultiClamp 700A is detected, \*puModel is set to MCCMSG\_HW\_TYPE\_MC700A and \*puCOMPortID and \*puDeviceID are filled out (\*pszSerialNum is not used).
- When a MultiClamp 700B is detected, \*puModel is set to MCCMSG\_HW\_TYPE\_MC700B and \*pszSerialNum is filled out (\*puCOMPortID and \*puDeviceID are not used).

**Error Codes**

Error Code	Description
MCCMSG_ERROR_MCCNOTOPEN	MultiClamp 700B Commander not open

**Example**

```
#include "AxMultiClampMsg.h"

char szError[256]      = "";
UINT uModel            = 0; // Identifies MultiClamp 700A or 700B model
char szSerialNum[16]   = ""; // Serial number of MultiClamp 700B
UINT uCOMPortID        = 0; // COM port ID of MultiClamp 700A (1-16)
UINT uDeviceID         = 0; // Device ID of MultiClamp 700A (1-8)
UINT uChannelID        = 0; // Headstage channel ID

// find the first MultiClamp
if( !MCCMSG_FindFirstMultiClamp( m_hMCCmsg, &uModel, szSerialNum,
                                sizeof(szSerialNum), &uCOMPortID,
                                &uDeviceID, &uChannelID, &nError) )
{
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
    return;
}

// create string with device info
char szDeviceInfo[256] = "";
switch( uModel )
{
    case MCCMSG_HW_TYPE_MC700A:
        sprintf( szDeviceInfo, "MultiClamp 700A open on COM port %d,
                                device ID %d. Headstage channel %d connected.",
                                uCOMPortID, uDeviceID, uChannelID);
        break;
    case MCCMSG_HW_TYPE_MC700B:
        sprintf( szDeviceInfo, "MultiClamp 700B open on USB port
                                with serial number %s. Headstage channel %d connected.",
                                szSerialNum, uChannelID);
}

// display device info
AfxMessageBox(szDeviceInfo, MB_ICONINFORMATION);

BOOL MCCMSG_FindNextMultiClamp(HMCCMSG hMCCmsg, UINT *puModel, char
*pszSerialNum, UINT uBufSize, UINT *puCOMPortID, UINT *puDeviceID, UINT
*puChannelID, int *pnError);
```

**BOOL MCCMSG\_FindNextMultiClamp(HMCCMSG hMCCmsg, UINT \*puModel, char \*pszSerialNum, UINT uBufSize, UINT \*puCOMPortID, UINT \*puDeviceID, UINT \*puChannelID, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
puModel	Address of return amplifier model ID.
pszSerialNum	Address of return serial number (MultiClamp 700B only).
uBufSize	Size of char buffer for serial number (MultiClamp 700B only).
puCOMPortID	Address of return COM port ID (MultiClamp 700A only).
puDeviceID	Address of return Device ID (MultiClamp 700A only).
puChannelID	Address of return Channel ID.
pnError	Address of error return code.

### Remarks

Find the next open MultiClamp 700B amplifier. `MCCMSG_FindFirstMultiClamp` must be called first to create an internal list of devices. Returns `FALSE` when all devices have been found.

This command supports the MultiClamp 700A and the MultiClamp 700B.

- When a MultiClamp 700A is detected, `*puModel` is set to `MCCMSG_HW_TYPE_MC700A` and `*puCOMPortID` and `*puDeviceID` are filled out (`*pszSerialNum` is not used).
- When a MultiClamp 700B is detected, `*puModel` is set to `MCCMSG_HW_TYPE_MC700B` and `*pszSerialNum` is filled out (`*puCOMPortID` and `*puDeviceID` are not used).

**Example**

```
#include "AxMultiClampMsg.h"

// find the first MultiClamp
char szSerialNum[16] = ""; // Serial number of MultiClamp 700B
UINT uModel          = 0;  // Identifies MultiClamp 700A or 700B model
UINT uCOMPortID      = 0;  // COM port ID of MultiClamp 700A (1-16)
UINT uDeviceID       = 0;  // Device ID of MultiClamp 700A (1-8)
UINT uChannelID      = 0;  // Headstage channel ID
if( !MCCMSG_FindFirstMultiClamp(hMCCmsg, &uModel, szSerialNum,
                                sizeof(szSerialNum), &uCOMPortID,
                                &uDeviceID, &uChannelID, &nError) )
{
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
    return;
}

// find the second MultiClamp, third MultiClamp, ... etc
while(1)
{
    // create string with device info
    char szDeviceInfo[256] = "";
    switch( uModel )
    {
        case MCCMSG_HW_TYPE_MC700A:
            sprintf(szDeviceInfo, "MultiClamp 700A open on COM port %d,
                                   device ID %d. Headstage channel %d connected.",
                                   uCOMPortID, uDeviceID, uChannelID);
            break;
        case MCCMSG_HW_TYPE_MC700B:
            sprintf(szDeviceInfo, "MultiClamp 700B open on USB port
                                   with serial number %s. Headstage channel %d connected.",
                                   szSerialNum, uChannelID);
    }

    // display device info
    AfxMessageBox(szDeviceInfo, MB_ICONINFORMATION);

    // find the next MultiClamp
    if( !MCCMSG_FindNextMultiClamp(hMCCmsg, &uModel, szSerialNum,
                                    sizeof(szSerialNum), &uCOMPortID,
                                    &uDeviceID, &uChannelID, &nError) )
    {
        break;
    }
}
```

```
BOOL MCCMSG_SelectMultiClamp(HMCCMSG hMCCmsg, UINT uModel,  
char *pszSerialNum, UINT uCOMPortID, UINT uDeviceID, UINT  
uChannelID, int *pnError);
```

Parameter	Description
hMCCmsg	Handle to message handler object.
uModel	The amplifier model ID.
pszSerialNum	The serial number (MultiClamp 700B only).
uCOMPortID	The COM port ID (MultiClamp 700A only).
uDeviceID	The Device ID (MultiClamp 700A only).
uChannelID	The Channel ID.
pnError	Address of error return code.

### Remarks

Select the MultiClamp 700B amplifier to control. You must call `MCCMSG_FindFirstMultiClamp` before using this command. Use `MCCMSG_FindFirstMultiClamp` or `MCCMSG_FindNextMultiClamp` to check that a device is available before calling `MCCMSG_SelectMultiClamp`. Returns `FALSE` if the specified device is not open.

This command supports the MultiClamp 700A and the MultiClamp 700B.

- To connect to a MultiClamp 700A, set `uModel` to `MCCMSG_HW_TYPE_MC700A` and fill in `uCOMPortID` and `uDeviceID` (`szSerialNum` is not used).
- To connect to a MultiClamp 700B, set `uModel` to `MCCMSG_HW_TYPE_MC700B` and fill in `szSerialNum` (`uCOMPortID` and `uDeviceID` are not used).

### Error Codes

Error Code	Description
<code>MCCMSG_ERROR_MCCNOTOPEN</code>	MultiClamp 700B Commander not open

**Example**

```
#include "AxMultiClampMsg.h"

char szError[256]      = "";
UINT uModel            = 0; // Identifies MultiClamp 700A or 700B model
char szSerialNum[16]   = ""; // Serial number of MultiClamp 700B
UINT uCOMPortID        = 0; // COM port ID of MultiClamp 700A (1-16)
UINT uDeviceID         = 0; // Device ID of MultiClamp 700A (1-8)
UINT uChannelID        = 0; // Headstage channel ID

// find the first MultiClamp
if( !MCCMSG_FindFirstMultiClamp(m_hMCCmsg, &uModel, szSerialNum,
                                sizeof(szSerialNum), &uCOMPortID,
                                &uDeviceID, &uChannelID, &nError) )
{
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
    return;
}

// select the first MultiClamp
if( !MCCMSG_SelectMultiClamp(m_hMCCmsg, uModel, szSerialNum,
                              uCOMPortID, uDeviceID, uChannelID, &nError) )
{
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
    return;
}
```



## Amplifier Mode

**BOOL MCCMSG\_SetMode(HMCCMSG hMCCmsg, UINT uModeID, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
uModeID	The amplifier mode.
pnError	Address of error return code.

### Remarks

Set the amplifier mode to voltage clamp, current clamp or I=0. The MultiClamp 700B Commander mode radio button, and the active tab will switch to the selected mode if successful. This command must precede other commands to ensure the amplifier is in the correct mode. `uModeID` must be filled out with:

Parameter	Description
MCCMSG_MODE_VCLAMP	Voltage clamp mode
MCCMSG_MODE_ICLAMP	Current clamp mode
MCCMSG_MODE_ICLAMPZERO	I=0 mode

### Example

```
#include "AxMultiClampMsg.h"

// set mode to voltage clamp
if( !MCCMSG_SetMode(m_hMCCmsg, MCCMSG_MODE_VCLAMP, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetMode(HMCCMSG hMCCmsg, UINT \*puModeID, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
puModeID	Address of return amplifier mode.
pnError	Address of error return code.

### Remarks

Get the current amplifier mode. \*puModeID will be filled in with:

Parameter	Description
MCCMSG_MODE_VCLAMP	Voltage clamp mode
MCCMSG_MODE_ICLAMP	Current clamp mode
MCCMSG_MODE_ICLAMPZERO	I=0 mode

### Example

```
#include "AxMultiClampMsg.h"

// get the current mode
UINT uMode = 0;
if( !MCCMSG_GetMode(m_hMCCmsg, &uMode, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetModeSwitchEnable(HMCCMSG hMCCmsg, BOOL bEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
bEnable	The mode switch enable state.
pnError	Address of error return code.

**Remarks**

Set the amplifier mode switch enable state. This controls the check box on the right side of the mode radio button. When set to `TRUE`, the MultiClamp 700B Commander mode buttons can be operated from an external TTL source (ext) or can be triggered on a preset membrane potential (700B only). These options must be manually set up from the Options / Auto tab (700B only).

**Example**

```
#include "AxMultiClampMsg.h"

// set the mode switch enable state
BOOL bEnable = TRUE;
if( !MCCMSG_SetModeSwitchEnable(m_hMCCmsg, bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetModeSwitchEnable(HMCCMSG hMCCmsg, BOOL \*pbEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pbEnable	Address of return mode switch enable state.
pnError	Address of error return code.

**Remarks**

This gets the state of the checkbox on the right hand side of the mode radio button. When TRUE, the MultiClamp 700B Commander mode buttons can be operated from an external TTL source (ext) or can be triggered on a preset membrane potential (700B only). These options must be manually setup from the Options / Auto tab (700B only).

**Example**

```
#include "AxMultiClampMsg.h"

// get the mode switch enable state
BOOL bEnable = FALSE;
if( !MCCMSG_GetModeSwitchEnable(m_hMCCmsg, &bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## Holding

**BOOL MCCMSG\_SetHoldingEnable(HMCCMSG hMCCmsg, BOOL bEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
bEnable	The holding enable state.
pnError	Address of error return code.

### Remarks

Set the holding enable state. The holding level is applied to the hardware when `TRUE`. Supports voltage clamp and current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// set the holding enable state
BOOL bEnable = TRUE;
if( !MCCMSG_SetHoldingEnable(m_hMCCmsg, bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetHoldingEnable(HMCCMSG hMCCmsg, BOOL \*pbEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pbEnable	Address of return holding enable state.
pnError	Address of error return code.

**Remarks**

Get the holding enable state. Supports voltage clamp and current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the holding enable state
BOOL bEnable = FALSE;
if( !MCCMSG_GetHoldingEnable(m_hMCCmsg, &bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetHolding(HMCCMSG hMCCmsg, BOOL dHolding, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dHolding	The holding level in SI units (Volts or Amps).
pnError	Address of error return code.

**Remarks**

Set the holding level. Supports voltage clamp and current clamp. The holding level must be in SI units appropriate to the amplifier mode.

**Example**

```
#include "AxMultiClampMsg.h"

// set the holding level
double dHolding = 0;
if( !MCCMSG_SetHolding(m_hMCCmsg, dHolding, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetHolding(HMCCMSG hMCCmsg, BOOL \*pdHolding, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdHolding	Address of return holding level in SI units (Volts or Amps).
pnError	Address of error return code.

### Remarks

Get the holding level. Supports voltage clamp and current clamp. The return holding level will be in SI units appropriate to the amplifier mode.

### Example

```
#include "AxMultiClampMsg.h"

// get the holding level
double dHolding = 0;
if( !MCCMSG_GetHolding(m_hMCCmsg, &dHolding, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## Test Signal

**BOOL MCCMSG\_SetTestSignalEnable(HMCCMSG hMCCmsg, BOOL bEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
bEnable	The test signal enable state.
pnError	Address of error return code.

### Remarks

Set the test signal enable. Supports voltage clamp and current clamp. The test signal control is called "Seal Test" in voltage clamp and "Tuning" in current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// set the test signal enable state
BOOL dEnable = TRUE;
if( !MCCMSG_SetTestSignalEnable(m_hMCCmsg, dEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```



**BOOL MCCMSG\_GetTestSignalEnable(HMCCMSG hMCCmsg, BOOL \*pbEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pbEnable	Address of return test signal enable state.
pnError	Address of error return code.

### Remarks

Get the test signal enable. Supports voltage clamp and current clamp. The test signal control is called "Seal Test" in voltage clamp and "Tuning" in current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// get the test signal enable state
BOOL dEnable = FALSE;
if( !MCCMSG_GetTestSignalEnable(m_hMCCmsg, &dEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetTestSignalAmplitude(HMCCMSG hMCCmsg, double dAmplitude, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dAmplitude	The test signal amplitude (Volts or Amps).
pnError	Address of error return code.

**Remarks**

Set the test signal amplitude in Volts or Amps. Supports voltage clamp and current clamp. The test signal control is called "Seal Test" in voltage clamp and "Tuning" in current clamp. The amplitude must be in SI units appropriate to the amplifier mode.

**Example**

```
#include "AxMultiClampMsg.h"

// set the test signal amplitude
double dAmplitude = 0;
if( !MCCMSG_SetTestSignalAmplitude(m_hMCCmsg, dEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetTestSignalAmplitude(HMCCMSG hMCCmsg, double \*pdAmplitude, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdAmplitude	Address of return test signal amplitude (Volts or Amps).
pnError	Address of error return code.

**Remarks**

Get the test signal amplitude in Volts or Amps. Supports voltage clamp and current clamp. The test signal control is called "Seal Test" in voltage clamp and "Tuning" in current clamp. The return value will be in SI units appropriate to the amplifier mode.

**Example**

```
#include "AxMultiClampMsg.h"

// get the test signal amplitude
double dAmplitude = 0;
if( !MCCMSG_GetTestSignalAmplitude(m_hMCCmsg, &dAmplitude, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetTestSignalFrequency(HMCCMSG hMCCmsg, double dFrequency, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dFrequency	The test signal frequency (Hertz).
pnError	Address of error return code.

### Remarks

Set the test signal amplitude in Hertz. Supports voltage clamp and current clamp. The test signal control is called "Seal Test" in voltage clamp and "Tuning" in current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// set the test signal frequency
double dFrequency = 0;
if( !MCCMSG_SetTestSignalFrequency(m_hMCCmsg, dFrequency, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetTestSignalFrequency(HMCCMSG hMCCmsg, double \*pdFrequency, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdFrequency	Address of return test signal frequency (Hertz).
pnError	Address of error return code.

### Remarks

Get the test signal amplitude in Hertz. Supports voltage clamp and current clamp. The test signal control is called "Seal Test" in voltage clamp and "Tuning" in current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// get the test signal frequency
double dFrequency = 0;
if( !MCCMSG_GetTestSignalFrequency(m_hMCCmsg, &dFrequency, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## Pipette Offset

### **BOOL MCCMSG\_AutoPipetteOffset(HMCCMSG hMCCmsg, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pnError	Address of error return code.

#### Remarks

Execute automatic pipette offset. This calculates and compensates for potentials caused by differences in the concentration of bath and pipette solutions. A timeout value of 3 seconds is recommended for this command. Supports voltage clamp and current clamp.

#### Example

```
#include "AxMultiClampMsg.h"

// execute auto pipette offset
if( !MCCMSG_AutoPipetteOffset(m_hMCCmsg, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

### **BOOL MCCMSG\_SetPipetteOffset(HMCCMSG hMCCmsg, double dPipetteOffset, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dPipetteOffset	The pipette offset (Volts).
pnError	Address of error return code.

#### Remarks

Set the pipette offset in Volts. Supports voltage clamp and current clamp.

#### Example

```
#include "AxMultiClampMsg.h"

// set the pipette offset
double dPipetteOffset = 0.01; // 10 mV
if( !MCCMSG_SetPipetteOffset(m_hMCCmsg, dPipetteOffset, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetPipetteOffset(HMCCMSG hMCCmsg, double \*pdPipetteOffset, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdPipetteOffset	Address of return pipette offset (Volts).
pnError	Address of error return code.

### Remarks

Get the pipette offset in Volts. Supports voltage clamp and current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// get the pipette offset
double dPipetteOffset = 0;
if( !MCCMSG_GetPipetteOffset(m_hMCCmsg, &dPipetteOffset, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## Slow Current Injection

**BOOL MCCMSG\_SetSlowCurrentInjEnable(HMCCMSG hMCCmsg, BOOL bEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
bEnable	The slow current inject enable state.
pnError	Address of error return code.

### Remarks

Set the slow current inject enable state. Supports current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// enable slow current inject
BOOL bEnable = TRUE;
if( !MCCMSG_SetSlowCurrentInjEnable(m_hMCCmsg, bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```



**BOOL MCCMSG\_GetSlowCurrentInjEnable(HMCCMSG hMCCmsg, BOOL \*pbEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pbEnable	Address of return slow current inject enable state.
pnError	Address of error return code.

**Remarks**

Get the slow current inject enable state. Supports current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the slow current inject enable state
BOOL bEnable = FALSE;
if( !MCCMSG_GetSlowCurrentInjEnable(m_hMCCmsg, &bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetSlowCurrentInjLevel(HMCCMSG hMCCmsg, double dLevel, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dLevel	The slow current injection level (Volts).
pnError	Address of error return code.

**Remarks**

Set the slow current injection level in Volts. Supports current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the slow current injection level
BOOL dLevel = 0.06; // 60 mV
if( !MCCMSG_SetSlowCurrentInjLevel(m_hMCCmsg, dLevel, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetSlowCurrentInjLevel(HMCCMSG hMCCmsg, double \*pdLevel, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdLevel	Address of return slow current injection level (Volts).
pnError	Address of error return code.

### Remarks

Get the slow current injection level in Volts. Supports current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// get the slow current injection level
BOOL dLevel = 0;
if( !MCCMSG_GetSlowCurrentInjLevel(m_hMCCmsg, &dLevel, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetSlowCurrentInjSettlingTime (HMCCMSG hMCCmsg, double dSettlingTime, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dSettlingTime	The slow current injection settling time (seconds).
pnError	Address of error return code.

**Remarks**

Set the slow current injection settling time in seconds. Settling time is defined as the time to 99% of the final value when the feedback resistor equals the resistive load. Supports current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the slow current injection settling time
BOOL dSettlingTime = 1; // 1 second
if( !MCCMSG_SetSlowCurrentInjSettlingTime(m_hMCCmsg, dSettlingTime, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetSlowCurrentInjSettlingTime (HMCCMSG hMCCmsg, double \*pdSettlingTime, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdSettlingTime	Address of return slow current injection settling time (seconds).
pnError	Address of error return code.

### Remarks

Get the slow current injection settling time in seconds. Settling time is defined as the time to 99% of the final value when the feedback resistor equals the resistive load. Supports current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// get the slow current injection settling time
BOOL dSettlingTime = 0;
if( !MCCMSG_GetSlowCurrentInjSettlingTime(m_hMCCmsg, &dSettlingTime, &nError)
)
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## Fast and Slow Compensation

**BOOL MCCMSG\_SetFastCompCap(HMCCMSG hMCCmsg, double dFastCompCap, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dFastCompCap	The fast compensation capacitance (Farads).
pnError	Address of error return code.

### Remarks

Set the fast compensation capacitance in Farads. Supports voltage clamp.

### Example

```
#include "AxMultiClampMsg.h"

// set the fast compensation capacitance
double dFastCompCap = 4e-12; // 4 pF
if( !MCCMSG_SetFastCompCap(m_hMCCmsg, dFastCompCap, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_GetFastCompCap(HMCCMSG hMCCmsg, double \*pdFastCompCap, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdFastCompCap	Address of return fast compensation capacitance (Farads).
pnError	Address of error return code.

### **Remarks**

Get the fast compensation capacitance in Farads. Supports voltage clamp.

### **Example**

```
#include "AxMultiClampMsg.h"

// get the fast compensation capacitance
double dFastCompCap = 0;
if( !MCCMSG_GetFastCompCap(m_hMCCmsg, &dFastCompCap, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_SetSlowCompCap(HMCCMSG hMCCmsg, double dSlowCompCap, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dSlowCompCap	The slow compensation capacitance (Farads).
pnError	Address of error return code.

### **Remarks**

Set the slow compensation capacitance in Farads. Supports voltage clamp.

### **Example**

```
#include "AxMultiClampMsg.h"

// set the slow compensation capacitance
double dSlowCompCap = 3e-12; // 3 pF
if( !MCCMSG_SetSlowCompCap(m_hMCCmsg, dSlowCompCap, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_GetSlowCompCap(HMCCMSG hMCCmsg, double \*pdSlowCompCap, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdSlowCompCap	Address of return slow compensation capacitance (Farads).
pnError	Address of error return code.

### **Remarks**

Get the slow compensation capacitance in Farads. Supports voltage clamp.

### **Example**

```
#include "AxMultiClampMsg.h"

// get the slow compensation capacitance
double dSlowCompCap = 0;
if( !MCCMSG_GetSlowCompCap(m_hMCCmsg, &dSlowCompCap, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_SetFastCompTau(HMCCMSG hMCCmsg, double dFastCompTau, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dFastCompTau	The fast compensation time constant (seconds).
pnError	Address of error return code.

### **Remarks**

Set the fast compensation time constant in seconds. Supports voltage clamp.

### **Example**

```
#include "AxMultiClampMsg.h"

// set the fast compensation time constant
double dFastCompTau = 2e-6; // 2 μs
if( !MCCMSG_SetFastCompTau(m_hMCCmsg, dFastCompTau, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetFastCompTau(HMCCMSG hMCCmsg, double \*pdFastCompTau, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdFastCompTau	Address of return fast compensation time constant (seconds).
pnError	Address of error return code.

### Remarks

Get the fast compensation time constant in seconds. Supports voltage clamp.

### Example

```
#include "AxMultiClampMsg.h"

// get the fast compensation time constant
double dFastCompTau = 0;
if( !MCCMSG_GetFastCompTau(m_hMCCmsg, &dFastCompTau, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```



**BOOL MCCMSG\_SetSlowCompTau(HMCCMSG hMCCmsg, double dSlowCompTau, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dSlowCompTau	The slow compensation time constant (seconds).
pnError	Address of error return code.

**Remarks**

Set the slow compensation time constant in seconds. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the slow compensation time constant
double dSlowCompTau = 4e-4; // 400 μs
if( !MCCMSG_SetSlowCompTau(m_hMCCmsg, dSlowCompTau, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_GetSlowCompTau(HMCCMSG hMCCmsg, double \*pdSlowCompTau, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdSlowCompTau	Address of return slow compensation time constant (seconds).
pnError	Address of error return code.

### **Remarks**

Get the slow compensation time constant in seconds. Supports voltage clamp.

### **Example**

```
#include "AxMultiClampMsg.h"

// get the slow compensation time constant
double dSlowCompTau = 0;
if( !MCCMSG_GetSlowCompTau(m_hMCCmsg, &dSlowCompTau, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_SetSlowCompTauX20Enable (HMCCMSG hMCCmsg, BOOL bEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
bEnable	The tau x20 range enable state.
pnError	Address of error return code.

### **Remarks**

Set the slow compensation tau x20 range enable state. Supports voltage clamp.

### **Example**

```
#include "AxMultiClampMsg.h"

// enable the tau x20 range
BOOL bEnable = TRUE;
if( !MCCMSG_SetSlowCompTauX20Enable(m_hMCCmsg, bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetSlowCompTauX20Enable (HMCCMSG hMCCmsg, BOOL \*pbEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pbEnable	Address of return tau x20 range enable state.
pnError	Address of error return code.

**Remarks**

Get the slow compensation tau x20 range enable state. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the tau x20 range enable state
BOOL bEnable = FALSE;
if( !MCCMSG_SetSlowCompTauX20Enable(m_hMCCmsg, &bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_AutoFastComp(HMCCMSG hMCCmsg, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pnError	Address of error return code.

**Remarks**

Execute automatic fast compensation. This calculates and compensates for fast pipette capacitance. A timeout value of 3 seconds is recommended for this command. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// execute auto fast compensation
if( !MCCMSG_AutoFastComp(m_hMCCmsg, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_AutoSlowComp(HMCCMSG hMCCmsg, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pnError	Address of error return code.

**Remarks**

Execute automatic slow compensation. This calculates and compensates for slow pipette capacitance. A timeout value of 3 seconds is recommended for this command. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// execute auto slow compensation
if( !MCCMSG_AutoSlowComp(m_hMCCmsg, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**Pipette Capacitance Neutralization****BOOL MCCMSG\_SetNeutralizationEnable(HMCCMSG hMCCmsg, BOOL bEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
bEnable	The pipette capacitance neutralization enable state.
pnError	Address of error return code.

**Remarks**

Set the pipette capacitance neutralization enable state. Supports current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// enable pipette capacitance neutralization
BOOL bEnable = TRUE;
if( !MCCMSG_SetNeutralizationEnable(m_hMCCmsg, bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_GetNeutralizationEnable(HMCCMSG hMCCmsg, BOOL \*pbEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pbEnable	Address of return pipette capacitance neutralization enable state.
pnError	Address of error return code.

### **Remarks**

Get the pipette capacitance neutralization enable state. Supports current clamp.

### **Example**

```
#include "AxMultiClampMsg.h"

// get the pipette capacitance neutralization enable state
BOOL bEnable = FALSE;
if( !MCCMSG_GetNeutralizationEnable(m_hMCCmsg, &bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_SetNeutralizationCap(HMCCMSG hMCCmsg, double dCap, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dCap	The pipette neutralization capacitance (Farads).
pnError	Address of error return code.

### **Remarks**

Set the pipette neutralization capacitance in Farads. Supports current clamp.

### **Example**

```
#include "AxMultiClampMsg.h"

// set pipette neutralization capacitance
double dCap = 4e-12; // 4 pF
if( !MCCMSG_SetNeutralizationCap(m_hMCCmsg, dCap, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetNeutralizationCap(HMCCMSG hMCCmsg, double \*pdCap, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdCap	Address of return pipette neutralization capacitance (Farads).
pnError	Address of error return code.

### Remarks

Get the pipette neutralization capacitance in Farads. Supports current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// get pipette neutralization capacitance
double dCap = 0;
if( !MCCMSG_GetNeutralizationCap(m_hMCCmsg, &dCap, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## Whole Cell Compensation

**BOOL MCCMSG\_SetWholeCellCompEnable(HMCCMSG hMCCmsg, BOOL bEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
bEnable	The whole cell compensation enable state.
pnError	Address of error return code.

### Remarks

Set the whole cell compensation enable state. Supports voltage clamp.

### Example

```
#include "AxMultiClampMsg.h"

// enable whole cell compensation
BOOL bEnable = TRUE;
if( !MCCMSG_SetWholeCellCompEnable(m_hMCCmsg, bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetWholeCellCompEnable(HMCCMSG hMCCmsg, BOOL \*pbEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pbEnable	Address of return whole cell compensation enable state.
pnError	Address of error return code.

**Remarks**

Get the whole cell compensation enable state. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the whole cell compensation enable state
BOOL bEnable = FALSE;
if( !MCCMSG_GetWholeCellCompEnable(m_hMCCmsg, &bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetWholeCellCompCap(HMCCMSG hMCCmsg, double dCap, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dCap	The whole cell compensation capacitance (Farads).
pnError	Address of error return code.

**Remarks**

Set the whole cell compensation capacitance in Farads. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the whole cell slow compensation capacitance
double dCap = 3e-11; // 30 pF
if( !MCCMSG_SetWholeCellCompCap(m_hMCCmsg, dCap, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```



**BOOL MCCMSG\_GetWholeCellCompCap(HMCCMSG hMCCmsg, double \*pdCap, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdCap	Address of return whole cell compensation capacitance (Farads).
pnError	Address of error return code.

**Remarks**

Get the whole cell compensation capacitance in Farads. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the whole cell slow compensation capacitance
double dCap = 0;
if( !MCCMSG_GetWholeCellCompCap(m_hMCCmsg, &dCap, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetWholeCellCompResist(HMCCMSG hMCCmsg, double dResist, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dResist	The whole cell compensation resistance (Ohms).
pnError	Address of error return code.

**Remarks**

Set the whole cell compensation resistance in Ohms. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the whole cell compensation resistance
double dResist = 1e13; // 10 MOhms
if( !MCCMSG_SetWholeCellCompResist(m_hMCCmsg, dResist, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_GetWholeCellCompResist(HMCCMSG hMCCmsg, double \*pdResist, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdResist	Address of return whole cell compensation resistance (Ohms).
pnError	Address of error return code.

### **Remarks**

Get the whole cell compensation resistance in Ohms. Supports voltage clamp.

### **Example**

```
#include "AxMultiClampMsg.h"

// get the whole cell compensation resistance
double dResist = 0;
if( !MCCMSG_GetWholeCellCompResist(m_hMCCmsg, &dResist, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_AutoWholeCellComp(HMCCMSG hMCCmsg, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pnError	Address of error return code.

### **Remarks**

Execute automatic whole cell compensation. This calculates and compensates for cell membrane capacitance in whole cell experiments. A timeout value of 3 seconds is recommended for this command. Supports voltage clamp.

### **Example**

```
#include "AxMultiClampMsg.h"

// execute auto whole cell compensation
if( !MCCMSG_AutoWholeCellComp(m_hMCCmsg, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## Series Resistance Compensation

**BOOL MCCMSG\_SetRsCompEnable(HMCCMSG hMCCmsg, BOOL bEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
bEnable	The series resistance compensation enable state.
pnError	Address of error return code.

### Remarks

Set the series resistance compensation enable state. Supports voltage clamp.

### Example

```
#include "AxMultiClampMsg.h"

// enable series resistance compensation
BOOL bEnable = TRUE;
if( !MCCMSG_SetRsCompEnable(m_hMCCmsg, bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetRsCompEnable(HMCCMSG hMCCmsg, BOOL \*pbEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pbEnable	Address of return series resistance compensation enable state.
pnError	Address of error return code.

**Remarks**

Get the series resistance compensation enable state. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the series resistance compensation enable state
BOOL bEnable = FALSE;
if( !MCCMSG_GetRsCompEnable(m_hMCCmsg, &bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetRsCompBandwidth(HMCCMSG hMCCmsg, double dBandwidth, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dBandwidth	The series resistance compensation bandwidth in Hertz.
pnError	Address of error return code.

**Remarks**

Set the series resistance compensation bandwidth in Hertz. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the series resistance compensation bandwidth
double dBandwidth = 1e4; // 10 kHz
if( !MCCMSG_SetRsCompBandwidth(m_hMCCmsg, dBandwidth, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetRsCompBandwidth(HMCCMSG hMCCmsg, double \*pdBandwidth, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdBandwidth	Address of return series resistance compensation bandwidth in Hertz.
pnError	Address of error return code.

**Remarks**

Set the series resistance compensation bandwidth in Hertz. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the series resistance compensation bandwidth
double dBandwidth = 0;
if( !MCCMSG_GetRsCompBandwidth(m_hMCCmsg, &dBandwidth, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetRsCompCorrection(HMCCMSG hMCCmsg, double dCorrection, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dCorrection	The series resistance compensation correction (%).
pnError	Address of error return code.

**Remarks**

Set the series resistance compensation correction (%). Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the series resistance compensation correction
double dCorrection = 80; // 80%
if( !MCCMSG_SetRsCompCorrection(m_hMCCmsg, dCorrection, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_GetRsCompCorrection(HMCCMSG hMCCmsg, double \*pdCorrection, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dCorrection	Address of return series resistance compensation correction (%).
pnError	Address of error return code.

### **Remarks**

Get the series resistance compensation correction (%). Supports voltage clamp.

### **Example**

```
#include "AxMultiClampMsg.h"

// get the series resistance compensation correction
double dCorrection = 0;
if( !MCCMSG_GetRsCompCorrection(m_hMCCmsg, &dCorrection, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_SetRsCompPrediction(HMCCMSG hMCCmsg, double dPrediction, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dPrediction	The series resistance compensation prediction (%).
pnError	Address of error return code.

### **Remarks**

Set the series resistance compensation prediction (%). Supports voltage clamp.

### **Example**

```
#include "AxMultiClampMsg.h"

// set the series resistance compensation prediction
double dPrediction = 80; // 80%
if( !MCCMSG_SetRsCompPrediction(m_hMCCmsg, dPrediction, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetRsCompPrediction(HMCCMSG hMCCmsg, double \*pdPrediction, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dPrediction	Address of return series resistance compensation prediction (%).
pnError	Address of error return code.

**Remarks**

Get the series resistance compensation prediction (%). Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the series resistance compensation prediction
double dPrediction = 0;
if( !MCCMSG_GetRsCompPrediction(m_hMCCmsg, &dPrediction, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## Oscillation Killer

**BOOL MCCMSG\_SetOscKillerEnable(HMCCMSG hMCCmsg, BOOL bEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
bEnable	The oscillator killer enable state.
pnError	Address of error return code.

### Remarks

Set the oscillator killer enable state. Supports voltage and current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// enable the oscillator killer
BOOL bEnable = TRUE;
if( !MCCMSG_SetOscKillerEnable(m_hMCCmsg, bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```



**BOOL MCCMSG\_GetOscKillerEnable(HMCCMSG hMCCmsg, BOOL \*pbEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pbEnable	Address of return oscillator killer enable state.
pnError	Address of error return code.

### Remarks

Get the oscillator killer enable state. Supports voltage and current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// get the oscillator killer enable state
BOOL bEnable = FALSE;
if( !MCCMSG_GetOscKillerEnable(m_hMCCmsg, &bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## Primary (or Scaled) Signal

**BOOL MCCMSG\_SetPrimarySignal(HMCCMSG hMCCmsg, UINT uSignalID, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
uSignalID	The primary output signal.
pnError	Address of error return code.

### Remarks

Set the primary output signal. Supports voltage and current clamp. `uSignalID` must be filled in as one of the following values:

Parameter	Description
MCCMSG_PRI_SIGNAL_VC_MEMBCURRENT	voltage clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_VC_MEMBPOTENTIAL	voltage clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_VC_PIPOTENTIAL	voltage clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_VC_100XACMEMBPOTENTIAL	voltage clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_VC_EXTCMDPOTENTIAL	voltage clamp, 700B only
MCCMSG_PRI_SIGNAL_VC_AUXILIARY1	voltage clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_VC_AUXILIARY2	voltage clamp, 700B only
MCCMSG_PRI_SIGNAL_IC_MEMBPOTENTIAL	current clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_IC_MEMBCURRENT	current clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_IC_CMDCURRENT	current clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_IC_100XACMEMBPOTENTIAL	current clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_IC_EXTCMDCURRENT	current clamp, 700B only
MCCMSG_PRI_SIGNAL_IC_AUXILIARY1	current clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_IC_AUXILIARY2	current clamp, 700B only

### Example

```
#include "AxMultiClampMsg.h"

// set the primary output to external command potential in voltage clamp
UINT uSignalID = MCCMSG_PRI_SIGNAL_VC_EXTCMDPOTENTIAL;
if( !MCCMSG_SetPrimarySignal(m_hMCCmsg, uSignalID, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_GetPrimarySignal(HMCCMSG hMCCmsg, UINT \*puSignalID, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
puSignalID	Address of return primary output signal.
pnError	Address of error return code.

### **Remarks**

Get the primary output signal. Supports voltage and current clamp. `uSignalID` will be filled out as one of the following values:

Parameter	Description
MCCMSG_PRI_SIGNAL_VC_MEMBCURRENT	voltage clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_VC_MEMBPOTENTIAL	voltage clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_VC_PIPPOTENTIAL	voltage clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_VC_100XACMEMBPOTENTIAL	voltage clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_VC_EXTCMDPOTENTIAL	voltage clamp, 700B only
MCCMSG_PRI_SIGNAL_VC_AUXILIARY1	voltage clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_VC_AUXILIARY2	voltage clamp, 700B only
MCCMSG_PRI_SIGNAL_IC_MEMBPOTENTIAL	current clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_IC_MEMBCURRENT	current clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_IC_CMDCURRENT	current clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_IC_100XACMEMBPOTENTIAL	current clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_IC_EXTCMDCURRENT	current clamp, 700B only
MCCMSG_PRI_SIGNAL_IC_AUXILIARY1	current clamp, 700B and 700A
MCCMSG_PRI_SIGNAL_IC_AUXILIARY2	current clamp, 700B only

### **Example**

```
#include "AxMultiClampMsg.h"

// get the primary output
UINT uSignalID = 0;
if( !MCCMSG_GetPrimarySignal(m_hMCCmsg, &uSignalID, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetPrimarySignalGain(HMCCMSG hMCCmsg, double dGain, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dGain	The primary output signal gain.
pnError	Address of error return code.

**Remarks**

Set the primary output signal gain. Supports voltage and current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the primary output signal gain
double dGain = 10;
if( !MCCMSG_SetPrimarySignalGain(m_hMCCmsg, dGain, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetPrimarySignalGain(HMCCMSG hMCCmsg, double \*pdGain, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdGain	Address of return primary output signal gain.
pnError	Address of error return code.

**Remarks**

Get the primary output signal gain. Supports voltage and current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the primary output signal gain
double dGain = 0;
if( !MCCMSG_GetPrimarySignalGain(m_hMCCmsg, &dGain, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetPrimarySignalLPF(HMCCMSG hMCCmsg, double dLPF, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dLPF	The primary output signal lowpass filter frequency in Hertz.
pnError	Address of error return code.

### Remarks

Set the primary output signal lowpass filter frequency in Hertz. Supports voltage and current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// set the primary output signal lowpass filter frequency
double dLPF = 1e4; // 10 kHz
if( !MCCMSG_SetPrimarySignalLPF(m_hMCCmsg, dLPF, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetPrimarySignalLPF(HMCCMSG hMCCmsg, double \*pdLPF, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdLPF	Address of return primary output signal lowpass filter frequency in Hertz.
pnError	Address of error return code.

**Remarks**

Get the primary output signal lowpass filter frequency in Hertz. Supports voltage and current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the primary output signal lowpass filter frequency
double dLPF = 0;
if( !MCCMSG_GetPrimarySignalLPF(m_hMCCmsg, &dLPF, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetPrimarySignalHPF(HMCCMSG hMCCmsg, double dHPF, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dHPF	The primary output signal highpass filter frequency in Hertz.
pnError	Address of error return code.

### Remarks

Set the primary output signal highpass filter frequency in Hertz. Supports voltage and current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// set the primary output signal highpass filter frequency
double dHPF = 3e4; // 30 kHz
if( !MCCMSG_SetPrimarySignalHPF(m_hMCCmsg, dHPF, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetPrimarySignalHPF(HMCCMSG hMCCmsg, double \*pdHPF, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdHPF	Address of return primary output signal highpass filter in Hertz. frequency.
pnError	Address of error return code.

**Remarks**

Get the primary output signal highpass filter frequency in Hertz. Supports voltage and current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the primary output signal highpass filter frequency
double dHPF = 0;
if( !MCCMSG_GetPrimarySignalHPF(m_hMCCmsg, &dHPF, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```



## Scope Signal

**BOOL MCCMSG\_SetScopeSignalLPF(HMCCMSG hMCCmsg, double dLPF, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dLPF	The scope output signal lowpass filter frequency in Hertz.
pnError	Address of error return code.

### Remarks

Set the scope output signal lowpass filter frequency in Hertz. Supports voltage and current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// set the scope output signal lowpass filter frequency
double dLPF = 1e4; // 10 kHz
if( !MCCMSG_SetScopeSignalLPF(m_hMCCmsg, dLPF, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetScopeSignalLPF(HMCCMSG hMCCmsg, double \*pdLPF, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdLPF	Address of return scope output signal lowpass filter frequency in Hertz.
pnError	Address of error return code.

**Remarks**

Get the scope output signal lowpass filter frequency in Hertz. Supports voltage and current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the scope output signal lowpass filter frequency
double dLPF = 0;
if( !MCCMSG_GetScopeSignalLPF(m_hMCCmsg, &dLPF, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## Secondary (or Raw) Signal

**BOOL MCCMSG\_SetSecondarySignal(HMCCMSG hMCCmsg, UINT uSignalID, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
uSignalID	The secondary output signal.
pnError	Address of error return code.

### Remarks

Set the secondary output signal. Supports voltage and current clamp. `uSignalID` must be filled in as one of the following values:

Parameter	Description
MCCMSG_SEC_SIGNAL_VC_MEMBCURRENT	voltage clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_VC_MEMBPOTENTIAL	voltage clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_VC_PIPPOTENTIAL	voltage clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_VC_100XACMEMBPOTENTIAL	voltage clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_VC_EXTCMDPOTENTIAL	voltage clamp, 700B only
MCCMSG_SEC_SIGNAL_VC_AUXILIARY1	voltage clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_VC_AUXILIARY2	voltage clamp, 700B only
MCCMSG_SEC_SIGNAL_IC_MEMBPOTENTIAL	current clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_IC_MEMBCURRENT	current clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_IC_CMDCURRENT	current clamp, 700A only
MCCMSG_SEC_SIGNAL_IC_PIPPOTENTIAL	current clamp, 700B only
MCCMSG_SEC_SIGNAL_IC_100XACMEMBPOTENTIAL	current clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_IC_EXTCMDCURRENT	current clamp, 700B only
MCCMSG_SEC_SIGNAL_IC_AUXILIARY1	current clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_IC_AUXILIARY2	current clamp, 700B only

### Example

```
#include "AxMultiClampMsg.h"

// set the secondary output to external command potential in voltage clamp
UINT uSignalID = MCCMSG_PRI_SIGNAL_VC_EXTCMDPOTENTIAL;
if( !MCCMSG_SetSecondarySignal(m_hMCCmsg, uSignalID, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_GetSecondarySignal(HMCCMSG hMCCmsg, UINT \*puSignalID, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
puSignalID	Address of return secondary output signal.
pnError	Address of error return code.

### **Remarks**

Get the secondary output signal. Supports voltage and current clamp. uSignalID will be filled out as one of the following values:

Parameter	Description
MCCMSG_SEC_SIGNAL_VC_MEMBCURRENT	voltage clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_VC_MEMBPOTENTIAL	voltage clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_VC_PIPPOTENTIAL	voltage clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_VC_100XACMEMBPOTENTIAL	voltage clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_VC_EXTCMDPOTENTIAL	voltage clamp, 700B only
MCCMSG_SEC_SIGNAL_VC_AUXILIARY1	voltage clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_VC_AUXILIARY2	voltage clamp, 700B only
MCCMSG_SEC_SIGNAL_IC_MEMBPOTENTIAL	current clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_IC_MEMBCURRENT	current clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_IC_CMDCURRENT	current clamp, 700A only
MCCMSG_SEC_SIGNAL_IC_PIPPOTENTIAL	current clamp, 700B only
MCCMSG_SEC_SIGNAL_IC_100XACMEMBPOTENTIAL	current clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_IC_EXTCMDCURRENT	current clamp, 700B only
MCCMSG_SEC_SIGNAL_IC_AUXILIARY1	current clamp, 700B and 700A
MCCMSG_SEC_SIGNAL_IC_AUXILIARY2	current clamp, 700B only

### **Example**

```
#include "AxMultiClampMsg.h"

// get the secondary output
UINT uSignalID = 0;
if( !MCCMSG_GetSecondarySignal(m_hMCCmsg, &uSignalID, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetSecondarySignalGain(HMCCMSG hMCCmsg, double dGain, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dGain	The secondary output signal gain.
pnError	Address of error return code.

**Remarks**

Set the secondary output signal gain. Supports voltage and current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the secondary output signal gain
double dGain = 10;
if( !MCCMSG_SetSecondarySignalGain(m_hMCCmsg, dGain, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetSecondarySignalGain(HMCCMSG hMCCmsg, double \*pdGain, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdGain	Address of return secondary output signal gain.
pnError	Address of error return code.

**Remarks**

Get the secondary output signal gain. Supports voltage and current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the secondary output signal gain
double dGain = 0;
if( !MCCMSG_GetSecondarySignalGain(m_hMCCmsg, &dGain, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetSecondarySignalLPF(HMCCMSG hMCCmsg, double dLPF, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dLPF	The secondary output signal lowpass filter frequency in Hertz.
pnError	Address of error return code.

### Remarks

Set the secondary output signal lowpass filter frequency in Hertz. Supports voltage and current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// set the secondary output signal lowpass filter frequency
double dLPF = 1e4; // 10 kHz
if( !MCCMSG_SetSecondarySignalLPF(m_hMCCmsg, dLPF, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetSecondarySignalLPF(HMCCMSG hMCCmsg, double \*pdLPF, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdLPF	Address of return secondary output signal lowpass filter frequency in Hertz.
pnError	Address of error return code.

### Remarks

Get the secondary output signal lowpass filter frequency in Hertz. Supports voltage and current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// get the secondary output signal lowpass filter frequency
double dLPF = 0;
if( !MCCMSG_GetSecondarySignalLPF(m_hMCCmsg, &dLPF, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## Output Zero

**BOOL MCCMSG\_SetOutputZeroEnable(HMCCMSG hMCCmsg, BOOL bEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
bEnable	The output zero enable state.
pnError	Address of error return code.

### Remarks

Set the output zero enable state. Supports voltage and current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// enable output zero
BOOL bEnable = TRUE;
if( !MCCMSG_SetOutputZeroEnable(m_hMCCmsg, bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```



## **BOOL MCCMSG\_GetOutputZeroEnable(HMCCMSG hMCCmsg, BOOL \*pbEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pbEnable	Address of return output zero enable state.
pnError	Address of error return code.

### **Remarks**

Get the output zero enable state. Supports voltage and current clamp.

### **Example**

```
#include "AxMultiClampMsg.h"

// get the output zero enable state
BOOL bEnable = FALSE;
if( !MCCMSG_GetOutputZeroEnable(m_hMCCmsg, &bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_SetOutputZeroAmplitude(HMCCMSG hMCCmsg, double dAmplitude, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dAmplitude	The output zero amplitude (Volts).
pnError	Address of error return code.

### **Remarks**

Set the output zero amplitude in Volts. Supports voltage clamp and current clamp.

### **Example**

```
#include "AxMultiClampMsg.h"

// set the output zero amplitude
double dAmplitude = 0.05; // 50 mV
if( !MCCMSG_SetOutputZeroAmplitude(m_hMCCmsg, dAmplitude, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetOutputZeroAmplitude(HMCCMSG hMCCmsg, double \*pdAmplitude, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdAmplitude	Address of return output zero amplitude (Volts).
pnError	Address of error return code.

**Remarks**

Get the output zero amplitude in Volts. Supports voltage clamp and current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the output zero amplitude
double dAmplitude = 0;
if( !MCCMSG_GetOutputZeroAmplitude(m_hMCCmsg, &dAmplitude, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_AutoOutputZero(HMCCMSG hMCCmsg, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pnError	Address of error return code.

**Remarks**

Execute automatic output zero. This calculates and compensates for offset potentials at the amplifier output. A timeout value of 3 seconds is recommended for this command. Supports voltage and current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// execute auto output zero
if( !MCCMSG_AutoOutputZero(m_hMCCmsg, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## Leak Subtraction

**BOOL MCCMSG\_SetLeakSubEnable(HMCCMSG hMCCmsg, BOOL bEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
bEnable	The leak subtraction enable state.
pnError	Address of error return code.

### Remarks

Set the leak subtraction enable state. Supports voltage clamp.

### Example

```
#include "AxMultiClampMsg.h"

// enable leak subtraction
BOOL bEnable = TRUE;
if( !MCCMSG_SetLeakSubEnable(m_hMCCmsg, bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetLeakSubEnable(HMCCMSG hMCCmsg, BOOL \*pbEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pbEnable	Address of return leak subtraction enable state.
pnError	Address of error return code.

**Remarks**

Get the leak subtraction enable state. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the leak subtraction enable state
BOOL bEnable = FALSE;
if( !MCCMSG_SetLeakSubEnable(m_hMCCmsg, &bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetLeakSubResist(HMCCMSG hMCCmsg, double dResistance, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dResist	The leak subtraction resistance (Ohms).
pnError	Address of error return code.

**Remarks**

Set the leak subtraction resistance in Ohms. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the leak subtraction resistance
double dResist = 2e8; // 200 MOhms
if( !MCCMSG_SetLeakSubResist(m_hMCCmsg, dResist, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetLeakSubResist(HMCCMSG hMCCmsg, double \*pdResistance, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdResist	Address of return leak subtraction resistance (Ohms).
pnError	Address of error return code.

**Remarks**

Get the leak subtraction resistance in Ohms. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the leak subtraction resistance
double dResist = 0;
if( !MCCMSG_GetLeakSubResist(m_hMCCmsg, &dResist, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_AutoLeakSub(HMCCMSG hMCCmsg, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pnError	Address of error return code.

**Remarks**

Execute automatic leak subtraction. A timeout value of 3 seconds is recommended for this command. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// execute auto leak subtraction
if( !MCCMSG_AutoLeakSub(m_hMCCmsg, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## Bridge Balance

**BOOL MCCMSG\_SetBridgeBalEnable(HMCCMSG hMCCmsg, BOOL bEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
bEnable	The bridge balance enable state.
pnError	Address of error return code.

### Remarks

Set the bridge balance enable state. Supports current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// enable bridge balance
BOOL bEnable = TRUE;
if( !MCCMSG_SetBridgeBalEnable(m_hMCCmsg, bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetBridgeBalEnable(HMCCMSG hMCCmsg, BOOL \*pbEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pbEnable	Address of return bridge balance enable state.
pnError	Address of error return code.

**Remarks**

Get the bridge balance enable state. Supports current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the bridge balance enable state
BOOL bEnable = FALSE;
if( !MCCMSG_SetBridgeBalEnable(m_hMCCmsg, &bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetBridgeBalResist(HMCCMSG hMCCmsg, double dResistance, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dResist	The bridge balance resistance (Ohms).
pnError	Address of error return code.

**Remarks**

Set the bridge balance resistance in Ohms. Supports current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the bridge balance resistance
double dResist = 1e7; // 10 MOhms
if( !MCCMSG_SetBridgeBalResist(m_hMCCmsg, dResist, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetBridgeBalResist(HMCCMSG hMCCmsg, double \*pdResistance, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdResist	Address of return bridge balance resistance (Ohms).
pnError	Address of error return code.

**Remarks**

Get the bridge balance resistance in Ohms. Supports current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the bridge balance resistance
double dResist = 0;
if( !MCCMSG_GetBridgeBalResist(m_hMCCmsg, &dResist, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_AutoBridgeBal(HMCCMSG hMCCmsg, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pnError	Address of error return code.

**Remarks**

Execute automatic bridge balance. A timeout value of 3 seconds is recommended for this command. Supports current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// execute auto bridge balance
if( !MCCMSG_AutoBridgeBal(m_hMCCmsg, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```



## Clear

### **BOOL MCCMSG\_ClearPlus(HMCCMSG hMCCmsg, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pnError	Address of error return code.

#### **Remarks**

Execute clear plus. Delivers a large positive current step down the micropipette. Supports current clamp.

#### **Example**

```
#include "AxMultiClampMsg.h"

// execute clear plus
if( !MCCMSG_ClearPlus(m_hMCCmsg, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

### **BOOL MCCMSG\_ClearMinus(HMCCMSG hMCCmsg, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pnError	Address of error return code.

#### **Remarks**

Execute clear minus. Delivers a large negative current step down the micropipette. Supports current clamp.

#### **Example**

```
#include "AxMultiClampMsg.h"

// execute clear minus
if( !MCCMSG_ClearMinus(m_hMCCmsg, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## Pulse, Zap, and Buzz

### **BOOL MCCMSG\_Pulse(HMCCMSG hMCCmsg, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pnError	Address of error return code.

#### **Remarks**

Execute pulse. Delivers a command current or voltage down the micropipette. The pulse amplitude is set by `MCCMSG_SetPulseAmplitude` and the pulse duration is set by `MCCMSG_SetPulseDuration`. Supports current and voltage clamp.

#### **Example**

```
#include "AxMultiClampMsg.h"

// execute pulse
if( !MCCMSG_Pulse(m_hMCCmsg, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetPulseAmplitude(HMCCMSG hMCCmsg, double dAmplitude, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dAmplitude	The pulse amplitude (Volts or Amps).
pnError	Address of error return code.

**Remarks**

Set the pulse amplitude in Volts or Amps. The pulse amplitude must be in SI units appropriate to the amplifier mode. Supports voltage and current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the pulse amplitude
double dAmplitude = 1e-1; // 100 mV
if( !MCCMSG_SetPulseAmplitude(m_hMCCmsg, dAmplitude, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetPulseAmplitude(HMCCMSG hMCCmsg, double \*pdAmplitude, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdAmplitude	Address of return pulse amplitude (Volts or Amps).
pnError	Address of error return code.

**Remarks**

Get the pulse amplitude in Volts or Amps. The return value will be in SI units appropriate to the amplifier mode. Supports voltage and current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the pulse amplitude
double dAmplitude = 0;
if( !MCCMSG_GetPulseAmplitude(m_hMCCmsg, &dAmplitude, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetPulseDuration(HMCCMSG hMCCmsg, double dDuration, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dDuration	The pulse duration (seconds).
pnError	Address of error return code.

**Remarks**

Set the pulse duration in seconds. Supports voltage and current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the pulse duration
double dDuration = 1e-2; // 10 ms
if( !MCCMSG_SetPulseDuration(m_hMCCmsg, dDuration, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetPulseDuration(HMCCMSG hMCCmsg, double \*pdDuration, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdDuration	Address of return pulse duration (seconds).
pnError	Address of error return code.

**Remarks**

Get the pulse duration in seconds. Supports voltage and current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the pulse duration
double dDuration = 0;
if( !MCCMSG_GetPulseDuration(m_hMCCmsg, &dDuration, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_Zap(HMCCMSG hMCCmsg, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pnError	Address of error return code.

**Remarks**

Execute zap. Zap applies a +1 V pulse down the micropipette, used to rupture a patch when going from on-cell to whole-cell. The pulse duration is set by MCCMSG\_SetZapDuration. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// execute zap
if( !MCCMSG_Zap(m_hMCCmsg, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetZapDuration(HMCCMSG hMCCmsg, double dDuration, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dDuration	The zap duration (seconds).
pnError	Address of error return code.

**Remarks**

Set the zap duration in seconds. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the zap duration
double dDuration = 1e-2; // 10 ms
if( !MCCMSG_SetZapDuration(m_hMCCmsg, dDuration, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetZapDuration(HMCCMSG hMCCmsg, double \*pdDuration, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdDuration	Address of return zap duration (seconds).
pnError	Address of error return code.

**Remarks**

Get the zap duration in seconds. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the zap duration
double dDuration = 0;
if( !MCCMSG_GetZapDuration(m_hMCCmsg, &dDuration, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_Buzz(HMCCMSG hMCCmsg, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pnError	Address of error return code.

**Remarks**

Execute buzz. Buzz applies a brief, strong 10 kHz current down the micropipette, used to aid penetration of the cell membrane, and to clear blocked micropipette tips. The buzz duration is set by `MCCMSG_SetBuzzDuration`. Supports current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// execute buzz
if( !MCCMSG_Buzz(m_hMCCmsg, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetBuzzDuration(HMCCMSG hMCCmsg, double dDuration, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
dDuration	The buzz duration (seconds).
pnError	Address of error return code.

**Remarks**

Set the buzz duration in seconds. Supports current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// set the buzz duration
double dDuration = 1e-2; // 10 ms
if( !MCCMSG_SetBuzzDuration(m_hMCCmsg, dDuration, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetBuzzDuration(HMCCMSG hMCCmsg, double \*pdDuration, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pdDuration	Address of return buzz duration (seconds).
pnError	Address of error return code.

**Remarks**

Get the buzz duration in seconds. Supports current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the buzz duration
double dDuration = 0;
if( !MCCMSG_GetBuzzDuration(m_hMCCmsg, &dDuration, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```



## Meters

**BOOL MCCMSG\_SetMeterResistEnable(HMCCMSG hMCCmsg, BOOL bEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
bEnable	The resistance meter enable state.
pnError	Address of error return code.

### Remarks

Set the resistance meter state. Supports voltage clamp and current clamp.

### Example

```
#include "AxMultiClampMsg.h"

// enable resistance meter
BOOL bEnable = TRUE;
if( !MCCMSG_SetMeterResistEnable(m_hMCCmsg, bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetMeterResistEnable(HMCCMSG hMCCmsg, BOOL \*pbEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pbEnable	Address of return resistance meter enable state.
pnError	Address of error return code.

**Remarks**

Get the resistance meter state. Supports voltage clamp and current clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the resistance meter enable state
BOOL bEnable = FALSE;
if( !MCCMSG_GetMeterResistEnable(m_hMCCmsg, &bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_SetMeterIrmsEnable(HMCCMSG hMCCmsg, BOOL bEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
bEnable	The Irms meter enable state.
pnError	Address of error return code.

**Remarks**

Set the Irms meter state. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// enable Irms meter
BOOL bEnable = TRUE;
if( !MCCMSG_SetMeterIrmsEnable(m_hMCCmsg, bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_GetMeterIrmsEnable(HMCCMSG hMCCmsg, BOOL \*pbEnable, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pbEnable	Address of return Irms meter enable state.
pnError	Address of error return code.

**Remarks**

Get the Irms meter state. Supports voltage clamp.

**Example**

```
#include "AxMultiClampMsg.h"

// get the Irms meter enable state
BOOL bEnable = FALSE;
if( !MCCMSG_SetMeterIrmsEnable(m_hMCCmsg, &bEnable, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**Tool Bar****BOOL MCCMSG\_Reset(HMCCMSG hMCCmsg, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pnError	Address of error return code.

**Remarks**

Execute reset. Resets all MultiClamp 700B Commander options to their default values.

**Example**

```
#include "AxMultiClampMsg.h"

// execute reset
if( !MCCMSG_Reset(m_hMCCmsg, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_ToggleAlwaysOnTop(HMCCMSG hMCCmsg, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pnError	Address of error return code.

### **Remarks**

Toggle "Always On Top". Puts MultiClamp 700B Commander on top of other applications, even when it is not the active window.

### **Example**

```
#include "AxMultiClampMsg.h"

// toggle "Always On Top"
if( !MCCMSG_ToggleAlwaysOnTop(m_hMCCmsg, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## **BOOL MCCMSG\_ToggleResize(HMCCMSG hMCCmsg, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
pnError	Address of error return code.

### **Remarks**

Toggle resize. This command resizes the MultiClamp 700B Commander interface. It toggles the interface between: full display, meter panel, and manually resized (only available if you have resized the interface by dragging the edges or corners).

### **Example**

```
#include "AxMultiClampMsg.h"

// toggle resize
if( !MCCMSG_ToggleResize(m_hMCCmsg, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

**BOOL MCCMSG\_QuickSelectButton(HMCCMSG hMCCmsg, UINT uButtonID, int \*pnError);**

Parameter	Description
hMCCmsg	Handle to message handler object.
uButtonID	The Quick Select Button ID
pnError	Address of error return code.

**Remarks**

Execute the specified "Quick Select Button". A "Quick Select Button" will open a saved configuration (\*.mcc files) of the MultiClamp 700B Commander, or start an executable file (\*.exe).

**Example**

```
#include "AxMultiClampMsg.h"

// execute quick select button 1
UINT uButtonID = MCCMSG_QSB_1;
if( !MCCMSG_QuickSelectButton(m_hMCCmsg, uButtonID, &nError) )
{
    char szError[256] = "";
    MCCMSG_BuildErrorText(m_hMCCmsg, nError, szError, sizeof(szError));
    AfxMessageBox(szError, MB_ICONSTOP);
}
```

## Errors Handling

**BOOL CLXMSG\_BuildErrorText (HCLXMSG hClxmsg, int nErrorNum, LPSTR sTxtBuf, UINT uMaxLen);**

Parameter	Description
hClxmsg	Handle to message handler object.
nErrorNum	The error code.
sTxtBuf	Char buffer to return error string
uMaxLen	Size of char buffer

### Remarks

Return the error as a text string.

### Example

```
#include "AxClampexMsg.h"

// get error as a string
char szError[256] = "";
int nError = CLXMSG_ERROR_PROTOCOLPATHNOTSET;
CLXMSG_BuildErrorText(m_hClxmsg, nError, szError, sizeof(szError));
AfxMessageBox(szError, MB_ICONSTOP);
```

**Contact Us**

Phone: [+1-800-635-5577](tel:+1-800-635-5577)  
Web: [moleculardevices.com](http://moleculardevices.com)  
Email: [info@moldev.com](mailto:info@moldev.com)

Visit our website for a current listing of worldwide distributors.