

Ласточка



ВОСТОК-1

Important note

Meaning of «Vostok-1» project is not reproducing of Yuri Alexeevitch Gagarin historical flight in detail but giving to You a common vision of technical features of piloting spaceflight as whole.

That flight was automatized fully. It's hardly what You would have interest to watch mediocre imitation of it in time of one and half hour long. Other way really if You will take most part of control from liftoff to landing on Your own self.


Modern cosmonauts can land Soyuzes by hands on deorbit with 4g overloads. That flight could be as that in principle. Simply not so many people can trust man so much if other variants is acessible.

Project turn out little bit more complex than it was awaited initially. Many things in coming still. But it's already possible to fly around Earth and return back safely.

Wish to You good flight.

With respect and sympathy,
Victor Slavutinsky, vitosnet@mail.ru

Cabin view



1. Main panel
2. Left control panel
3. Panel of orientation, position and speed indication

In real Vostok-1 TV camera is on place of it what translated information about cosmonaut condition on Earth.

4. "Vzor" optical orientator
5. First three stages thrust and consumables control panel

Absented in real Vostok-1.

6. Thrust control handle

It seems it have other functions in real Vostok-1.

7. Orientation control handle
8. Right control panel

Absented in real Vostok-1.

9. Right window

Main panel



1. Latitude indicator
2. Longitude indicator
3. "Globus" position indicator

Direction from big cross to small cross shows where top of spacecraft is directed to.

4. Adjustment vernier

To be honest, have no information what it adjust. Well be happy if someone will tell me about that.

5. "Globus" mode indicator

In real Vostok-1 Globus have second mode what shows approximate landing position on base of spacecraft speeds data. It's absented in imitation at now but will be realized.

6. Duration of flight indicator adjustment gear

In unpressed state adjust minutes, in pressed hours of flight time.

7. Duration of flight indicator

8. Clock

In real Vostok-1 shows Moscow time.

9. Clock adjustment gear

In unpressed state adjust seconds, in pressed minutes.

10. Daytime indicator

In orbital flight night and day in sum have only one and half of the hour in duration. It's easy to disorientate Your self in time. Indicator allows to understand what part of orbital daytime is now.

11. Daytime indicator adjustment gear

In unpressed state adjust needle only, in pressed adjust needle and central scale relatively to outer scale.

12. Adjustment number of position data indicator

Positions what is showed by indicators it's computing results. Onboard computer accounts it on base of gyros and acceleration sensors states. So it's approximate and can drift. To normalizing of it cosmonaut can use data what is translated from Earth on communicating sessions and what is accounted in Control Center on base of spaceship observation and location. At now indicators show real exact information all the time but shift and adjustment will be realized soon.

13. Position data adjustment vernier

Central switch gives a mode, outer vernier adjust data.

14. Adjustment vernier

Same with 4 paragraph.

15. Cabin air pressure indicator

Not available currently, will be realized in case of depressurization case implementation.

16. Cabin air humidity indicator

Offline at now, maybe will be turned on in time.

17. Cabin air temperature indicator

Heating on sun and cooling in shadow will be implemented for sure.

18. Circuits counter indicator

Will be implemented.

19. Circuits counter indicator adjustment vernier

20. Cabin air oxygen percent indicator

Will be implemented with oxygen control. Too much of oxygen can cause fire, too small part can lead to blackout of cosmonaut.

21. Cabin air carbon dioxide percent indicator

22. Cabin air pressure indicator

23. Block A malfunction lamp

In real Vostok-1 lamps have different purposes. In imitation it's used for simple function/malfunction indication.

Rocket stages is:

Blocks A, B, C, D: blocks of first stage clockwise by forward block.

E: Second stage.

F: Third stage.

TDU: brake engine stage.

Spacecraft.

Most probable reason of first and second stages block malfunctioning is growing of g force beyond 4g. Most part of stages mass is oxidizer and fuel, so on end of stage functioning it have significantly less mass then on beginning. But engine thrust is same, so acceleration and g force grows considerably. Check g force indicator at stages functioning finish and reduce thrust to failure avoid.

24. Block B malfunction lamp

Other probable reason of first stage blocks malfunctioning is aerodynamic pressure overload. Force, what air flow press surface of carrier with, inverse depends of altitude and straight of pressure. If that force will grow beyond limit of five tons per square meter then carrier could be damaged. Check dynamic pressure indicator and reduce thrust as needed to keep force smaller.

25. Block C malfunction lamp

26. Block D malfunction lamp

27. Block E malfunction lamp

Check g force and thrust on end of second stage functioning to avoid second stage failure.

28. Block F malfunction lamp

Block F is intended for high altitudes using only. Attempt to ignite or use it at altitudes up to 50km would lead to malfunctioning or even exploding of it, at least in imitation.

29. TDU malfunction lamp

Same with 28 paragraph .

30. Spacecraft malfunction lamp

Probable reasons of spacecraft malfunction is cabin pressure atmosphere conditions going beyond limits or malfunctioning of main parachute system what demands of emergency ejection. Both will be implemented in time.

31. First stage functioning time completion warning lamp

Switched on when fuel and oxygen weights of first stage is less then 10% of initial state. Warnings of necessity of thrust reducing and then separating of first stage.

32. Fairings functioning time completion warning lamp

Fairings can be separated only in vacuum on altitudes beyond 50km, otherwise TDU block will be damaged by airflow. On the other hand, fairings mass is more than half of tonne, so the sooner it get away the better. If lamp is on then separate first stage fast.

33. Second stage functioning time completion warning lamp

Same with 31 paragraph.

34. Third stage functioning time completion warning lamp

35. TDU stage functioning time completion warning lamp

36. Deorbit warning lamp

Shifted on after TDU separation and stays on until landing.

37. Block A engine functioning lamp

38. Block B engine functioning lamp

- 39. Block C engine functioning lamp
- 40. Block D engine functioning lamp
- 41. Block E engine functioning lamp
- 42. Block F engine functioning lamp
- 43. TDU orientation engines functioning lamp
- 44. TDU main engine functioning lamp
- 45. Brake parachute functioning lamp
- 46. Main parachute functioning lamp
- 47. TDU handled orientation system balloons pressure indicator

Check orientation system pressure in orbital flight, use short impulses for control. After nitrogen expending orientation could be started after main TDU engine ignition only what would mean loss of some fuel part without positive effect. There is no much fuel for main engine, deorbit is questionable in that case.

- 48. TDU main engine balloons pressure indicator

Instead of real Vostok-1, TDU main engine can be used many times for orbit correction. But fuel reserves very limited still, so check remain. Se for correction only pressure down to red line and reserve other part for deorbit.

- 49. TDU automated orientation system balloons pressure indicator

TDU of real Vostok-1 have, in addition to handled orientation system, two automated orientations systems to guarantee right orientation on deorbit burn. In imitation that systems is unrealized yet, but it will be added in short time.

Left control panel



1. "Vzor" and panels lamps control button

Currently most part of left panel functions is switched off.

2. "Vzor" lightning adjust vernier
3. "Vzor" shutters switch
4. Right window shutters switch
5. Back window shutters switch

Panel of orientation, position and speed indication



1. Altitude indicator

Shows altitude over sea level. Have three needles, x100 means what “hours” needle shows hundreds of kilometers, “minutes” shows tens, “seconds” show kilometers. Because of current Flight Gear limitations flight can not be conducted on real altitudes from 150 to 300 km. At fact on altitudes beyond 150km spacecraft drop out of “vault of heaven”, hope it will be corrected soon. Right now because of that atmosphere is corrected to start become thinner by 75km and ends on 100km, while flight must be conducted on altitudes from 100km to 150km. Otherwise simulator gives message about altitude limit exceeding and asks to restart flight from the beginning.

2. Horizontal speed indicator

X10 000 kilometers/hour. Notice what it shows speed about 1000km/h while rocket is stays on the ground. It's Earth rotation speed what's added. Because Earth is rotated from west to east flight gotta be conducted in opposite direction. Otherwise it's subtracted instead of added and amount of fuel could become too small for orbital speed reaching.

3. G force indicator

Normal accelerations for rising on orbit is up to 4g, for deorbit is up to 10g. If g force goes beyond first limit then thrust and second stages can malfunction what would mean premature ending on flight and emergency landing. On third stage malfunction or going on orbit errors suborbital flight with overloads to 15g is possible. On too rough deorbit and g forces beyond

15g simulator will count flight as failed.

4. Artificial horizon

Note what horizon shows view what's correspond to view from "Vzor" visor. In horizontal flight vertical angle of horizon is 90 degrees and whole view is green or orange.

5. Compass

Normal direction of rocket on start of going to orbit is 65 degrees.

6. Descent indicator

Lamp is on when descent occurs.


7. Absolute vertical speed indicator

«Hours» needle shows hundreds of meters per second so thin needle is meters per second. Shows only absolute values, it's needed to check descent indicator to know direction of vertical speed.

8. Dynamical pressure indicator

Shows force with airflow press surface of carrier with. Check pressure and reduce thrust to keep it below five tonnes on one square meter limit.

“Vzor” optical orientator



1. Rotation direction indicator
2. Optical orientator

In case of automatic orientation system malfunction visual orientation for deorbit burn is possible. Orientate spacecraft manually to see approximate center of underlying Earth surface in center of “Vzor”. Running of Earth surface must go from sharp end of arrows to blunt end. In that position TDU engine nozzle is directed into direction of orbit and deorbit burn can go correctly.

3. Shutters closing handle

In real Vostok-1 Sun is shining so bright what cause short period of blindness if Sun itself seeing in “Vzor “ or window. In imitation that effect can be out of reach but shutters is realized, for growth and for beauty.

First three stages thrust and consumables control panel



1. Block A thrust indicator

In tonnes per seconds. On begin of liftoff weight of block, approximately sum of oxidizer and fuel weight is 40tns, thrust of maximum throttle is 83tns/sec, so block itself gives 2g acceleration and g force is 3g.

2. Block A oxidizer weight indicator

In tonnes.

3. Block A fuel weight indicator

Same with paragraph 2.

4. Block B thrust and weights indicator


5. Block C thrust and weights indicator

6. Block D thrust and weights indicator

7. Block E thrust and weights indicator, second stage

8. Block F thrust and weights indicator, third stage

Thrust control handle



1. Handle lock

Switched by mouse click or r button. Vibrations can lead handle to shift so lock it in moments when constant throttle is needed.

2. Throttle control handle

Controlled by mouse clicking on ends of base or PgUp/PgDown buttons.

3. Valve

Must be for emergency oxygen feed. Will be happy if someone enlighten about function of it.

Orientation control handle and right control panel



1. Control handle control button

Switched on by c button pressing. On going to orbit and first three stages activity phase pressing on it stabilizes and holds carrier in angles what it has on moment of pressing. On orbital TDU activity phase pressing activates control what's not work other way, it's made for fuel preservation. Shift handle a bit by needed axis then press button for short period of time to start rotation. Move handle to zero position after that and press and hold button on moment of needed angle reaching to stop rotation.

2. Orientation control handle

Have three axes. Moving up and down controls pitch, left and right controls roll and clockwise and anticlockwise controls yaw. If You have no joystick then keyboard with NumLock switched on is preferable for control. Then keys 8 and 2 controls pitch, 4 and 6 controls roll and 0 and right Enter controls yaw. 5 key sets handle to zero on all angles. If handle is in zero position on some of axes then stabilization computer holds angle on that axis, automatically on first three stages phase of flight and on button pressing in TDU activity phase. Have in mind what carrier initially stands, so rotation in plane what is parallel to Earth surface is controlled by roll, while in horizontal flight it controlled by yaw.

3. Safety right control panel door

Opened and closed by mouse click.

4. First and second stages ignition button

Panel lights up buttons what could be used next in normal flight procedure. Engine startup procedure is absent already, so unlock throttle handle and put throttle to maximum right after ignition for liftoff.

5. First stage separation button

Engines of first three stages can be ignited only once so it can be switched off only in stage separation procedure.

6. Fairings separation button

7. Second stage separation button

8. Third stage ignition button

9. Third stage separation button

10. TDU main engine ignition/stop button.

Instead of real Vostok-1, main TDU engine can be ignited and switched off many times to provide orbit correction. But amount of fuel is still real, for one and half minutes of maximum thrust only. On excess correction using lasting amount can become too small for retrning.

11. TDU separation button

12. Brake parachute deploying button


In real Vostok-1 instead of brake chute orientation and pulling chute is used.

13. Main parachute deploying button

14. Safety landing sensor extraction button

Safety landing engine was planned but absent in real Vostok-1. It was used first time in Voskhod-1 first three seat spacecraft.

Right window



1. Shutters closing handle

Shutters can be opened and closed by mouse click.

2. Earth in window

Orbital speeds for different altitudes

Altitude,km	Speed,km/h
100	28245
105	28234
110	28223
115	28212
120	28202
125	28191
130	28180
135	28169
140	28158
145	28147
150	28137

Orbital speed is 7.9km/sec only right above Earth surface. Because it depends of distance to Earth center in inverse then it bit smaller on bigger altitudes. If You will get in horizontal flight bigger speed and switch engine off after that then spacecraft will climb on bigger altitude as if was tied to it with spring or rubber band, rush it with speed, and, because where is hardly some braking in vacuum, will oscillate around it, it called “eccentricity” scientifically. Keep that in mind and reach orbital speed as exact as possible.

Liftoff and ascent to orbit

1. Unlock throttle handle
2. Open right panel and ignite first two stages.
3. Maximize throttle.
4. On 100m altitude reach begin rotation by compass to north-east direction, 55 degrees.
5. On end of turning stabilize carrier and put nose down on 30 degrees by pitch.
6. Look on dynamic pressure indicator from time to time and reduce thrust to keep pressure below 5 tons/square meter limit.
7. Restore thrust with pressure dropping.
8. Continue ascent with pitch angle growing by small amounts continuing for 500m/sec vertical speed stabilizing.
9. Correct yaw angle on need.
10. Check g force indicator and control throttle to preserve g force 4g limit exceeding.
11. Separate fairings on 50km altitude exceeding .
12. On exhaust of first stage fuel separate it and return throttle to maximum.
13. On 100km altitude reaching increase pitch angle to reduce vertical speed to values beyond 100m/sec and become zero at 125km altitude.
14. Check g force indicator and reduce thrust to keep g force in 4g limit.
15. On exhaust of second stage fuel separate it.
16. Check what control handle control button is unpressed.
17. Ignite third stage and maximize throttle.
18. Control angle to reach 28191km/h horizontal speed on zero vertical speed on altitude of 125km approximate.
19. Or closing to orbital state reduce thrust to reach it exactly.
20. On reaching of orbital state separate third stage.
21. On need ignite TDU on lower thrust and correct orbit parameters. Watch for fuel amount to keep rest of it beyond red line on indicator to guarantee correct deorbit burn later.

Deorbit and landing

1. Orientate spacecraft in plane what parallel to Earth surface below and turn it to make main engine nozzle looks into flight direction. Use "Vzor" and orientation panel to make it correctly.
2. Ignite main TDU engine and put thrust on maximum.
3. On fuel exhaust separate TDU stage.
4. If You did not do it earlier then move blackout/complete slider in view/cockpit view menu on approximately 12 value. Otherwise all will be black on most part of descent..
5. Extract brake parachute on 7km altitude.
6. Extract main parachute on 7km altitude.
7. Extract soft landing sensor on vertical speed reducing to 10m/sec.
8. Wish safe landing for You.