






Attachment axles extends forward. Note that these instructions are for an attachment on the right side as shown below. If the attachment is for the left side, some steps will be modified.





1





2



3




4




5




These black pegs will go on the other side if the attachment is mounting on the left side.




6





These blue pins will go on the other side if the attachment is mounting on the left side.





7





8




9





10





11




12




13





14





15



16




17




18



These black pegs will go on the other side if the attachment is mounting on the left side.



19



These pieces will go on the other side if the attachment is mounting on the left side.

