


# FRC Robot Programming

## MODULE 1 – Basics / Boolean In / Out


# Basic Robot Program

- **One time initialization actions**
- **Continuous execution code cycles every 20 milliseconds.**
  - Faster or slower loops can be added if needed
- **Much more about this subject later**




# WPILIB Robot Programming Palette

- **Function palette for all robot functions.**




# Template Robot Project

- Use existing template projects as the starting point for all robot code. (More about projects later.)
- For the exercises there is already a project created ready for use.




# Compiling Robot Project

- **Robot Project must be compiled, “built”, before deploying to robot. Ensure code builds without errors!**



# Deploying code to robot

- Built robot project must be deployed to robot by selecting “run as startup”. Ensure this completes!
- Then use Driver Station software to enable and test.




# Boolean Input – Limit Switch - Initialization

## ■ Initialization code

- Initialize hardware I/O
- Assign created data structure to “registry” for use by continuous execution routine.
- Note that this will be similar for ALL Input/Output (I/O) performed by the robot.


## ■ Limit Switch found under “sensors” sub palette



# Boolean Input – Limit Switch - Execution

## ■ Execution code

- Get “registry” entry for desired input
- Read current value from hardware.
- This code needs to be used every 20 milliseconds






# Network Table Variables

## ■ Network Table Variables


- **Write values for use by:**
  - Display to drivers
  - Trending operational performance and tuning
  - Debugging
- **Can both read and write values**

## ■ Sample write



# Network Table Variables

- Network tables uses “outline” style for naming variables.
  - Variable names that start with “/” start at the top level.
  - Variable names that start without a “/” start under “/SmartDashboard”
- Names must be exact – Case is different, spaces are different
  - This includes trailing spaces !!
- Sample read




# Boolean Output – Digital Out - Initialization

## ■ Initialization code

- Initialize hardware I/O
- Assign created data structure to “registry” for use by continuous execution routine.

## ■ Digital Output found under I/O sub-palette




# Boolean Output – Digital Out - Execution

## ■ Execution code

- Get “registry” entry for desired input
- Read current value from hardware.

## ■ This code needs to be used every 20 milliseconds



# Exercise

- **Do Exercise 4.2 from Control Logic Training Module 4**