





LoRaWan tutorial : Register a device on TTN

F. Ferrero, Professor @UCA


LoRaWan Tutorial Objectives

In this tutorial, you will :

- Use the UCA Education Board
- Program a microcontroller in C with Arduino IDE
- Register the board to a network server
- Transmit data with LoRa modulation
- Push data to an application server



LoRaWan Tutorial Objectives



Downloading Arduino code on Github

- For this tutorial, you are going to use Arduino codes
- Codes are available on :
[https://github.com/FabienFerrero/UCA Education Board](https://github.com/FabienFerrero/UCA_Education_Board)
- You can click on “Clone or Dowload” and “download zip”
- Then unzip it
- If you are using Github Desktop, you can use “open in Desktop”

Board for Education with LoRa

12 commits 1 branch 0 releases 1 contributor MIT

Branch: master New pull request Find File Clone or download

FabienFerrero add code Latest commit ad15230 2 days ago


Antenna	code update	last month
Code	add code	2 days ago
Libraries	LED update	last month
Schematic	code update	last month
LICENSE	Initial commit	last month
README.md	Update README.md	last month

Configuring your Arduino IDE

- After downloading the archive (.zip) and extracting the archive
- Copy the file from UCA_Education_Board\Libraries to /Document/Arduino/ Libraries/


It will install the libs needed during the tutorial

- If your using Windows or Mac, your may need to install the board USB driver (CH340C) : drivers are available [here](#)
- If Arduino IDE select in Tools (Outils)
 - Board : Arduino Pro or Pro Mini
 - Processor : AT328p 8MHz 3.3V
 - Port : Select your serial port



LoRaWan with The Thing Network

- The Things Network is a **global**, open, crowd-sourced Internet of Things data network.
- **The Things Network Backend** route messages from Nodes to the right Application, and back
- TTN is free
- 10000 LoRa gateways are connected to TTN around the world
- Any TTN can use any GWs, it is a collaborative network




Create a TTN account

- First, you have to [register](https://www.thethingsnetwork.org/) to <https://www.thethingsnetwork.org/>
- Then, give me your USERNAME, I will add you as a collaborator in our application
- You can also join a local community :

[TTN Côte d'Azur](#)


[TTN Da Nang](#)




CREATE AN ACCOUNT

Create an account for The Things Network and start exploring the world of Internet of Things with us.


USERNAME
This will be your username — pick a good one because you will **not** be able to change it.



EMAIL ADDRESS
You will receive a confirmation email, as well as occasional account related emails. If this email address is managed by a third party (such as for corporate email addresses), this third party might block emails coming from The Things Network. This email address is not public.



PASSWORD
Use at least 6 characters.



NEWSLETTER
Subscribe to the newsletter. ☐

Adding a new device

- Go to « application » and choose the available application
- Click on « register device »
- For Device ID, choose what you want (in lower case), ie « my-device »
- For device EUI, use the N° 50ff1aDA5A560XXXX and just increment XXXX. Must be 8 bytes.
- To remember it : « 50ff1a » is for « SOPHIA » and « DA5A56 » is for DaNang
- Click on Register ! It's done
- In DEVICE OVERVIEW, you get useful information on your device. Of course, status is : « Never Seen »
- First we will connect using ABP (Activation by Personalization)

REGISTER DEVICE[bulk import devices](#)

Device ID
This is the unique identifier for the device in this app. The device ID will be immutable.

Device EUI
The device EUI is the unique identifier for this device on the network. You can change the EUI later.
 8 bytes

App Key
The App Key will be used to secure the communication between you device and the network.

App EUI

DEVICE OVERVIEW

Application ID dniit

Device ID test

Activation Method OTAA

Device EUI

Application EUI

App Key

Status never seen

Frames up 0 [reset frame counters](#)

Frames down 0

Activation by Personalization (ABP)

- Go to settings
- Select ABP and save
- Go back to Overview
- You have now the Device Address and the two 128 AES keys
- You can click on Hex-C Style to have the key in the right format

Activation Method **ABP**

Device EUI

Application EUI

Device Address

Network Session Key

App Session Key

Activation by Personalization (ABP)

- Open the code UCA_Education_Board\Code\LORAWAN\ABP\Basic\UCA-ABP_Basic\UCA-ABP_Basic.ino
- Copy/Paste DEVADDR from your TTN window with « 0x » for Hex style
- Copy/Paste NWKSKEY and APPSKEY using C-style from your TTN window

[illegible]

Activation by Personalization (ABP)

- Compile and download the code on your board
- Look at the TTN device overview
- Frames up should increment each half minute as your board is sending an uplink each 30s (« TX_INTERVAL »)
- Have look on Data
- For each uplink, you can look many details as RSSI, SNR, airtime, modulation, coding rate, GW ID, etc ...
- Click on the blue triangle

Status ● 25 seconds ago

Frames up 0 [reset frame counters](#)

Frames down 0

	time	counter	port	
▲	21:45:35	3	1	payload: 48 65 6C 6C 6F 2C 20 77 6F 72 6C 64 21
▲	21:44:29	2	1	payload: 48 65 6C 6C 6F 2C 20 77 6F 72 6C 64 21
▲	21:43:22	1	1	payload: 48 65 6C 6C 6F 2C 20 77 6F 72 6C 64 21
▲	21:42:16	0	1	retry payload: 48 65 6C 6C 6F 2C 20 77 6F 72 6C 64 21

Activation by Personalization (ABP)

Frame counter security

- Now reset you board (click on the right button on your board)
- TTN is no more receiving the data
- Click on « reset frame counters » and reset you board again
- As you can see, frame counter is a security features to avoid replay attack (done by capturing and re-transmitting the messages)
- Frame counter can be disabled for debug test in Settings

Downlink

- Open your serial monitor
- In TTN overview, go to downling, add a payload like « BABA » and click on send, and go to Data
- After the next uplink, you should see the number of byte received in downlink

```
Starting
Packet queued
150865: EV_TXCOMPLETE (includes waiting for RX windows)
Received
2
  bytes of payload
BABA
```

▼ 08:59:10	1			payload: BABA
▲ 08:59:08	0	1	retry	payload: 48 65 6C 6C 6F 2C 20 77 6F 72 6C 64 21

Activation by Personalization (ABP)

Change SF, power, payload ...

- At the end of the arduino code, you can find :

`LMIC_setDrTxpow(DR_SF12,14);`

- You can change Spreading Factor(SF) from DR_SF7 to DR_SF12
- You can change the power from 2 dBm to 20 dBm
- Payload is in mydata[], and you can change the text.
- You can convert the payload in Hex to normal text using this online [tool](#)
- Change SF and Payload text ! What is the effect on Time on Air ?

Over the Air Activation (OTAA)

- In TTN Settings of your device, select OTAA and save
- Open the code UCA_Education_Board\Code\LORAWAN/OTAA/LP_Basic/LP_Basic.ino
- Copy paste after clicking on hexa-style the DEV-EUI, APP-EUI and App Key
- Be carefull !!!
 - Device EUI and Application EUI are **lsb**
 - App Key is **msb**

Device EUI	<>	⇄	lsb	{ 0x02, 0x00, 0x00, 0x00, 0x00, 0x56, 0x5A, 0xDA }	📄
Application EUI	<>	⇄	lsb	{ 0xA0, 0x99, 0x00, 0xD0, 0x7E, 0xD5, 0xB3, 0x70 }	📄
App Key	<>	⇄	👁	msb { 0xAE, 0x1A, 0xBC, 0x3B, 0xE8, 0xEA, 0x47, 0xEF, 0x34, 0xC4, 0x7C, 0x89, 0x72, 0x...	📄

Over the Air Activation (OTAA)

- Look in data
- You should see a first uplink that request the connection
- And a second packet with the first data
- On the serial monitor you can see the Joining process and then Joined and Tx.
- The device go to sleep after the Tx

COM18

```
Starting
Vbatt : 346.00
69428: EV_JOINING
745031: EV_JOINED
Datarate: SF8
Vbatt : 346.00
BV=346.00
PQ
1187429: EV_TXCOMPLETE (includes waiting for RX windows)
Datarate: SF8
Sleeping for 360 seconds = 45 x 8 + 0 x 4 + 0 x 2 + 0
```


First packet
with data

Board
request for
connection

	time	counter	port	
First packet with data	▲ 22:10:21	0	1	payload: 00 02 02 01 5A
Board request for connection	⚡ 22:10:18			dev addr: 26 01 2A 04 appeui: 70 B3 D5 7E D0 00 A3 90 dev eui: 50 FF 1A 00 00 00 00 01

Over the Air Activation (OTAA) and sensor

- You are now going to use a sensor
- Depending on the sensor available from your instructor, you may use :
 - BME280 : T°C, Humidity and Pressure with I2C connection
 - SI7021 : T°C and Humidity with I2C connection
 - TEMT6000 : Ambient light with analog output
 - SRC4+ : Distance with digital connection
 - Or else ...
- You have to wire the sensor on the breadboard on the UCA board



Over the Air Activation (OTAA) and data

- Select in UCA_Education_Board\Code\LORAWAN\OTAA\ the code that correspond to your sensor
- The code is using [Cayenne LPP format](#)
- Now you can see sensor data in the uplink packet


APPLICATION DATA|| pause 🗑 clear

Filters uplink downlink activation ack error

	time	counter	port	
	0 02 02 01 5A 03 68 43 04 73 27 65 05 02 00 3F			analog_in_2: 3.46 analog_in_5: 0.63 barometric_pressure_4: 1008.5 relative_humidity_3: 33.5 temperature_1: 22.4
⚡	22:18:34			dev addr: 26 01 29 C1 app eui: 70 B3 D5 7E D0 00 A3 90 dev eui: 50 FF 1A 00 00 00 00 01
▲	22:16:49	1	1	payload: 00 02 02 01 5A

Using Cayenne to see you data

- Go to <https://developers.mydevices.com/cayenne/features/> and sign up
- Add a device by selecting LoRa/TheThingsNetwork and Cayenne LPP.
- Just add your device EUI
- You should see your data



Downlink with LoRaWAN

- You are now going to control the LED color from CAYENNE.
- Use the code in : `LORAWAN/OTAA/LED_CONTROLLER/`
- Change APPEUI, DEVEUI and AppsKey


In LoRaWAN Class A, a downlink can be scheduled from the network server.

When the node make an uplink, the downlink is realized 1 second after the uplink.

Then the downlink latency depends on the uplink pace.

Downlink with LoRaWAN

- Upload the code
- It will send uplink all 15 seconds
- The LED are controlled by a value between 0 and 1
- Change the value in your slider to change the LED colors
- What is the control latency ?



Downlink with LoRaWAN

- When you change the slider value, look at your data in TTN
- You should see that the downlink is scheduled
- Then it is confirmed and the node send an ack


Filters

uplink	downlink	activation	ack	error
--------	----------	------------	-----	-------

	time	counter	port	
▲	14:13:28	8	1	payload: 02 02 01 51 06 03 00 00 07 03 00 FF 08 03 00 00 analog_in_2: 3.37 analog_out_6: 0 analog_out_7: 0
▼	14:13:28	99	confirmed ack	app id: campus_sophiatech
▼	14:13:16	99	confirmed	payload: 07 63 9C FF
▲	14:13:15	7	1	payload: 02 02 01 52 06 03 00 00 07 03 00 00 08 03 00 00 analog_in_2: 3.38 analog_out_6: 0 analog_out_7: 0
▼	14:13:11	99	scheduled confirmed	payload: 07 63 9C FF
▲	14:13:03	6	1	payload: 02 02 01 51 06 03 00 00 07 03 00 00 08 03 00 00 analog_in_2: 3.37 analog_out_6: 0 analog_out_7: 0

Downlink with LoRaWAN

- After each uplink, the node opens a received window for downlink
- With Cayenne, only one color can be updated at the same time



Good luck for you projects !

This board as been funded by UCA

