

# Toggles and screen management

Below, you'll find an abbreviated list of commands that can be used in AutoCAD.

## Toggle General Features

|              |                             |
|--------------|-----------------------------|
| Ctrl+G       | Toggle Grid                 |
| Ctrl+E       | Cycle isometric planes      |
| Ctrl+F       | Toggle running object snaps |
| Ctrl+H       | Toggle Pick Style           |
| Ctrl+Shift+H | Toggle Hide pallets         |
| Ctrl+I       | Toggle Coords               |
| Ctrl+Shift+I | Toggle Infer Constraints    |

## Manage Screen

|               |                            |
|---------------|----------------------------|
| Ctrl+0 (zero) | Clean Screen               |
| Ctrl+1        | Property Palette           |
| Ctrl+2        | Design Center Palette      |
| Ctrl+3        | Tool Palette               |
| Ctrl+4        | Sheet Set Palette          |
| Ctrl+6        | DBConnect Manager          |
| Ctrl+7        | Markup Set Manager Palette |
| Ctrl+8        | Quick Calc                 |
| Ctrl+9        | Command Line               |

## Manage Drawings

|                |                                           |
|----------------|-------------------------------------------|
| Ctrl+N         | New Drawing                               |
| Ctrl+S         | Save drawing                              |
| Ctrl+O         | Open drawing                              |
| Ctrl+P         | Plot dialog box                           |
| Ctrl+Tab       | Switch to next                            |
| Ctrl+Shift+Tab | Switch to previous drawing                |
| Ctrl+Page Up   | Switch to previous tab in current drawing |
| Ctrl+Page Down | Switch to next tab in current drawing     |
| Ctrl+Q         | Exit                                      |
| Ctrl+Shift+S   | Save drawing as                           |

**Toggle Drawing Modes**

|     |                             |
|-----|-----------------------------|
| F1  | Display Help                |
| F2  | Toggle text screen          |
| F3  | Toggle object snap mode     |
| F4  | Toggle 3DOsnap              |
| F5  | Toggle Isoplane             |
| F6  | Toggle Dynamic UCS          |
| F7  | Toggle grid mode            |
| F8  | Toggle ortho mode           |
| F9  | Toggle snap mode            |
| F10 | Toggle polar mode           |
| F11 | Toggle object snap tracking |

|     |                           |
|-----|---------------------------|
| F12 | Toggle dynamic input mode |
|-----|---------------------------|

Manage Workflow

|              |                                    |
|--------------|------------------------------------|
| Ctrl+A       | Select all objects                 |
| Ctrl+C       | Copy object                        |
| Ctrl+K       | Insert hyperlink                   |
| Ctrl+X       | Cut object                         |
| Ctrl+V       | Paste object                       |
| Ctrl+Shift+C | Copy to clipboard with base point  |
| Ctrl+Shift+V | Paste data as block                |
| Ctrl+Z       | Undo last action                   |
| Ctrl+Y       | Redo last action                   |
| Ctrl+[       | Cancel current command (or ctrl+\) |
| ESC          | Cancel current command             |

## A, B, C

### A

|     |                                                                                  |
|-----|----------------------------------------------------------------------------------|
| A   | ARC / Creates an arc                                                             |
| ADC | ADCENTER / Manages and inserts content such as blocks, xrefs, and hatch patterns |
| AA  | AREA / Calculates the area and perimeter of objects or of defined areas          |
| AL  | ALIGN / Aligns objects with other objects in 2D and 3D                           |
| AP  | APPLOAD / Load Application                                                       |
| AR  | ARRAY / Creates multiple copies of objects in a pattern                          |

|     |                                                                                                                    |
|-----|--------------------------------------------------------------------------------------------------------------------|
| ARR | ACTRECORD / Starts the Action Recorder                                                                             |
| ARM | ACTUSERMESSAGE / Inserts a user message into an action macro                                                       |
| ARU | ACTUSERINPUT / Pauses for user input in an action macro                                                            |
| ARS | ACTSTOP / Stops the Action Recorder and provides the option of saving the recorded actions to an action macro file |
| ATI | ATTIPEDIT / Changes the textual content of an attribute within a block                                             |
| ATT | ATTDEF / Redefines a block and updates associated attributes                                                       |
| ATE | ATTEDIT / Changes attribute information in a block                                                                 |

## B

|     |                                                                                                       |
|-----|-------------------------------------------------------------------------------------------------------|
| B   | BLOCK / Creates a block definition from selected objects                                              |
| BC  | BCLOSE / Closes the Block Editor                                                                      |
| BE  | BEDIT / Opens the block definition in the Block Editor                                                |
| BH  | HATCH / Fills an enclosed area or selected objects with a hatch pattern, solid fill, or gradient fill |
| BO  | BOUNDARY / Creates a region or a polyline from an enclosed area                                       |
| BR  | BREAK / Breaks the selected object between two points                                                 |
| BS  | BSAVE / Saves the current block definition                                                            |
| BVS | BVSTATE / Creates, sets, or deletes a visibility state in a dynamic block                             |

## C

|     |                                                                                                |
|-----|------------------------------------------------------------------------------------------------|
| C   | CIRCLE / Creates a circle                                                                      |
| CAM | CAMERA / Sets a camera and target location to create and save a 3D perspective view of objects |

|      |                                                                                                          |
|------|----------------------------------------------------------------------------------------------------------|
| CBAR | CONSTRAINTBAR / A toolbar-like UI element that displays the available geometric constraints on an object |
| CH   | PROPERTIES / Controls properties of existing objects                                                     |
| CHA  | CHAMFER / Bevels the edges of objects                                                                    |
| CHK  | CHECKSTANDARDS / Checks the current drawing for standards violations                                     |
| CLI  | COMMANDLINE / Displays the Command Line window                                                           |
| COL  | COLOR / Sets the color for new objects                                                                   |
| CO   | COPY / Copies objects a specified distance in a specified direction                                      |
| CT   | CTABLESTYLE / Sets the name of the current table style                                                   |
| CUBE | NAVVCUBE / Controls the visibility and display properties of the ViewCube tool                           |
| CYL  | CYLINDER / Creates a 3D solid cylinder                                                                   |

D, E, F

D

|      |                                                                                                                        |
|------|------------------------------------------------------------------------------------------------------------------------|
| D    | DIMSTYLE / Creates and modifies dimension styles                                                                       |
| DAN  | DIMANGULAR / Creates an angular dimension                                                                              |
| DAR  | DIMARC / Creates an arc length dimension                                                                               |
| DBA  | DIMBASELINE / Creates a linear, angular, or ordinate dimension from the baseline of the previous or selected dimension |
| DBC  | DBCCONNECT / Provides an interface to external database tables                                                         |
| DCE  | DIMCENTER / Creates the center mark or the centerlines of circles and arcs                                             |
| DCO  | DIMCONTINUE / Creates a dimension that starts from an extension line of a previously created dimension                 |
| DCON | DIMCONSTRAINT / Applies dimensional constraints to selected objects or points on objects                               |

|     |                                                                                                                        |
|-----|------------------------------------------------------------------------------------------------------------------------|
| DDA | DIMDISASSOCIATE / Removes associativity from selected dimensions                                                       |
| DDI | DIMDIAMETER / Creates a diameter dimension for a circle or an arc                                                      |
| DED | DIMEDIT / Edits dimension text and extension lines                                                                     |
| DI  | DIST / Measures the distance and angle between two points                                                              |
| DIV | DIVIDE / Creates evenly spaced point objects or blocks along the length or perimeter of an object                      |
| DJL | DIMJOGLINE / Adds or removes a jog line on a linear or aligned dimension                                               |
| DJO | DIMJOGGED / Creates jogged dimensions for circles and arcs                                                             |
| DL  | DATALINK / The Data Link dialog box is displayed                                                                       |
| DLU | DATALINKUPDATE / Updates data to or from an established external data link                                             |
| DO  | DONUT / Creates a filled circle or a wide ring                                                                         |
| DOR | DIMORDINATE / Creates ordinate dimensions                                                                              |
| DOV | DIMOVERRIDE / Controls overrides of system variables used in selected dimensions                                       |
| DR  | DRAWORDER / Changes the draw order of images and other objects                                                         |
| DRA | DIMRADIUS / Creates a radius dimension for a circle or an arc                                                          |
| DRE | DIMREASSOCIATE / Associates or re-associates selected dimensions to objects or points on objects                       |
| DRM | DRAWINGRECOVERY / Displays a list of drawing files that can be recovered after a program or system failure             |
| DS  | DSETTINGS / Sets grid and snap, polar and object snap tracking, object snap modes, Dynamic Input, and Quick Properties |
| DT  | TEXT / Creates a single-line text object                                                                               |
| DV  | DVIEW / Defines parallel projection or perspective views by using a camera and target                                  |

|    |                                                                                                                                   |
|----|-----------------------------------------------------------------------------------------------------------------------------------|
| DX | <b>DATAEXTRACTION</b> / Extracts drawing data and merges data from an external source to a data extraction table or external file |
|----|-----------------------------------------------------------------------------------------------------------------------------------|

## E

|      |                                                                                                           |
|------|-----------------------------------------------------------------------------------------------------------|
| E    | <b>ERASE</b> / Removes objects from a drawing                                                             |
| ED   | <b>DDEDIT</b> / Edits single-line text, dimension text, attribute definitions, and feature control frames |
| EL   | <b>ELLIPSE</b> / Creates an ellipse or an elliptical arc                                                  |
| EPDF | <b>EXPORTPDF</b> / Exports drawing to PDF                                                                 |
| ER   | <b>EXTERNALREFERENCES</b> / Opens the External References palette                                         |
| EX   | <b>EXTEND</b> / Extends objects to meet the edges of other objects                                        |
| EXIT | <b>QUIT</b> / Exits the program                                                                           |
| EXP  | <b>EXPORT</b> / Saves the objects in a drawing to a different file format                                 |
| EXT  | <b>EXTRUDE</b> / Extends the dimensions of a 2D object or 3D face into 3D space                           |

## F

|       |                                                                                                           |
|-------|-----------------------------------------------------------------------------------------------------------|
| F     | <b>FILLET</b> / Rounds and fillets the edges of objects                                                   |
| FI    | <b>FILTER</b> / Creates a list of requirements that an object must meet to be included in a selection set |
| FS    | <b>FSMODE</b> / Creates a selection set of all objects that touch the selected object                     |
| FSHOT | <b>FLATSHOT</b> / Creates a 2D representation of all 3D objects based on the current view                 |

## G, H, I

## G

|   |                                                                        |
|---|------------------------------------------------------------------------|
| G | <b>GROUP</b> / Creates and manages saved sets of objects called groups |
|---|------------------------------------------------------------------------|

|      |                                                                                                  |
|------|--------------------------------------------------------------------------------------------------|
| GCON | GEOCONSTRAINT / Applies or persists geometric relationships between objects or points on objects |
| GD   | GRADIENT / Fills an enclosed area or selected objects with a gradient fill                       |
| GEO  | GEOGRAPHICLOCATION / Specifies the geographic location information for a drawing file            |

## H

|    |                                                                                                       |
|----|-------------------------------------------------------------------------------------------------------|
| H  | HATCH / Fills an enclosed area or selected objects with a hatch pattern, solid fill, or gradient fill |
| HE | HATCHEDIT / Modifies an existing hatch or fill                                                        |
| HI | HIDE / Regenerates a 3D wireframe model with hidden lines suppressed                                  |

## I

|     |                                                                                                        |
|-----|--------------------------------------------------------------------------------------------------------|
| I   | INSERT / Inserts a block or drawing into the current drawing                                           |
| IAD | IMAGEADJUST / Controls the image display of the brightness, contrast, and fade values of images        |
| IAT | IMAGEATTACH / Inserts a reference to an image file                                                     |
| ICL | IMAGECLIP / Crops the display of a selected image to a specified boundary                              |
| ID  | ID / Displays the UCS coordinate values of a specified location                                        |
| IM  | IMAGE / Displays the External References palette                                                       |
| IMP | IMPORT / Imports files of different formats into the current drawing                                   |
| IN  | INTERSECT / Creates a 3D solid, surface, or 2D region from overlapping solids, surfaces, or regions    |
| INF | INTERFERE / Creates a temporary 3D solid from the interferences between two sets of selected 3D solids |
| IO  | INSERTOBJ / Inserts a linked or embedded object                                                        |

## J, K, L



## J

|     |                                                                |
|-----|----------------------------------------------------------------|
| J   | JOIN / Joins similar objects to form a single, unbroken object |
| JOG | DIMJOGGED / Creates jogged dimensions for circles and arcs     |

## K

## L

|      |                                                                                         |
|------|-----------------------------------------------------------------------------------------|
| L    | LINE / Creates straight line segments                                                   |
| LA   | LAYER / Manages layers and layer properties                                             |
| LAS  | LAYERSTATE / Saves, restores, and manages named layer states                            |
| LE   | QLEADER / Creates a leader and leader annotation                                        |
| LEN  | LENGTHEN / Changes the length of objects and the included angle of arcs                 |
| LESS | MESHSMOOTHLESS / Decreases the level of smoothness for mesh objects by one level        |
| LI   | LIST / Displays property data for selected objects                                      |
| LO   | LAYOUT / Creates and modifies drawing layout tabs                                       |
| LT   | LINETYPE / Loads, sets, and modifies linetypes                                          |
| LTS  | LTSCALE / Changes the scale factor of linetypes for all objects in a drawing            |
| LW   | LWEIGHT / Sets the current lineweight, lineweight display options, and lineweight units |

## M, N, O

## M

|    |                                                                          |
|----|--------------------------------------------------------------------------|
| M  | MOVE / Moves objects a specified distance in a specified direction       |
| MA | MATCHPROP / Applies the properties of a selected object to other objects |
| ME | MEASURE / Joins similar objects to form a single, unbroken object        |

|      |                                                                                                                                         |
|------|-----------------------------------------------------------------------------------------------------------------------------------------|
| MEA  | MEASUREGEOM / Measures the distance, radius, angle, area, and volume of selected objects or sequence of points                          |
| MI   | MIRROR / Creates a mirrored copy of selected objects                                                                                    |
| ML   | MLINE / Creates multiple parallel lines                                                                                                 |
| MLA  | MLEADERALIGN / Aligns and spaces selected multileader objects                                                                           |
| MLC  | MLEADERCOLLECT / Organizes selected multileaders that contain blocks into rows or columns, and displays the result with a single leader |
| MLD  | MLEADER / Creates a multileader object                                                                                                  |
| MLE  | MLEADEREDIT / Adds leader lines to, or removes leader lines from, a multileader object                                                  |
| MLS  | MLEADERSTYLE / Creates and modifies multileader styles                                                                                  |
| MO   | PROPERTIES / Controls properties of existing objects                                                                                    |
| MORE | MESHSMOOTHMORE / Increases the level of smoothness for mesh objects by one level                                                        |
| MS   | MSPACE / Switches from paper space to a model space viewport                                                                            |
| MSM  | MARKUP / Opens the Markup Set Manager                                                                                                   |
| MT   | MTEXT / Creates a multiline text object                                                                                                 |
| MV   | MVIEW / Creates and controls layout viewports                                                                                           |

## N

|       |                                                                                            |
|-------|--------------------------------------------------------------------------------------------|
| NORTH | GEOGRAPHICLOCATION / Specifies the geographic location information for a drawing file      |
| NSHOT | NEWSHOT / Creates a named view with motion that is played back when viewed with ShowMotion |
| NVIEW | NEWVIEW / Creates a named view with no motion                                              |

## O

|             |                                                                                               |
|-------------|-----------------------------------------------------------------------------------------------|
| O           | OFFSET / Creates concentric circles, parallel lines, and parallel curves                      |
| OFFSETSRF   | SURFOFFSET/ Creates a parallel surface or solid by setting an offset distance from a surface  |
| OP          | OPTIONS / Customizes the program settings                                                     |
| ORBIT / 3DO | 3DORBIT / Rotates the view in 3D space, but constrained to horizontal and vertical orbit only |
| OS          | OSNAP / Sets running object snap modes                                                        |

## P, Q, R

### P

|          |                                                                                                            |
|----------|------------------------------------------------------------------------------------------------------------|
| P        | PAN / Adds a parameter with grips to a dynamic block definition                                            |
| PA       | PASTESPEC / Pastes objects from the Clipboard into the current drawing and controls the format of the data |
| PAR      | PARAMETERS / Controls the associative parameters used in the drawing                                       |
| PARAM    | BPARAMETER / Adds a parameter with grips to a dynamic block definition                                     |
| PATCH    | SURFPATCH / Creates a new surface by fitting a cap over a surface edge that forms a closed loop            |
| PCATTACH | POINTCLOUDATTACH / Inserts an indexed point cloud file into the current drawing                            |
| PE       | PEDIT / Edits polylines and 3D polygon meshes                                                              |
| PL       | PLINE / Creates a 2D polyline                                                                              |
| PO       | POINT / Creates a point object                                                                             |
| POFF     | HIDEPALETTES / Hides currently displayed palettes (including the command line)                             |
| POL      | POLYGON / Creates an equilateral closed polyline                                                           |
| PON      | SHOWPALETTES / Restores the display of hidden palettes                                                     |
| PR       | PROPERTIES / Displays Properties palette                                                                   |

|        |                                                                                      |
|--------|--------------------------------------------------------------------------------------|
| PRE    | PREVIEW / Displays the drawing as it will be plotted                                 |
| PRINT  | PLOT / Plots a drawing to a plotter, printer, or file                                |
| PS     | PSPACE / Switches from a model space viewport to paper space                         |
| PSOLID | POLYSOLID / Creates a 3D wall-like polysolid                                         |
| PU     | PURGE / Removes unused items, such as block definitions and layers, from the drawing |
| PYR    | PYRAMID / Creates a 3D solid pyramid                                                 |

## Q

|      |                                                                                         |
|------|-----------------------------------------------------------------------------------------|
| QC   | QUICKCALC / Opens the QuickCalc calculator                                              |
| QCUI | QUICKCUI / Displays the Customize User Interface Editor in a collapsed state            |
| QP   | QUICKPROPERTIES / Displays open drawings and layouts in a drawing in preview images     |
| Q    | QSAVE / Saves the current drawing                                                       |
| QVD  | QVDRAWING / Displays open drawings and layouts in a drawing using preview images        |
| QVDC | QVDRAWINGCLOSE / Closes preview images of open drawings and layouts in a drawing        |
| QVL  | QVLAYOUT / Displays preview images of model space and layouts in a drawing              |
| QVLC | QVLAYOUTCLOSE / Closes preview images of model space and layouts in the current drawing |

## R

|    |                                                                                            |
|----|--------------------------------------------------------------------------------------------|
| R  | REDRAW / Refreshes the display in the current viewport                                     |
| RA | REDRAWALL / Refreshes the display in all viewports                                         |
| RC | RENDERCROP / Renders a specified rectangular area, called a crop window, within a viewport |

|     |                                                                                                 |
|-----|-------------------------------------------------------------------------------------------------|
| RE  | REGEN / Regenerates the entire drawing from the current viewport                                |
| REA | REGENALL / Regenerates the drawing and refreshes all viewports                                  |
| REC | RECTANG / Creates a rectangular polyline                                                        |
| REG | REGION / Converts an object that encloses an area into a region object                          |
| REN | RENAME / Changes the names assigned to items such as layers and dimension styles                |
| REV | REVOLVE / Creates a 3D solid or surface by sweeping a 2D object around an axis                  |
| RO  | ROTATE / Rotates objects around a base point                                                    |
| RP  | RENDERPRESETS / Specifies render presets, reusable rendering parameters, for rendering an image |
| RR  | RENDER / Creates a photorealistic or realistically shaded image of a 3D solid or surface model  |
| RW  | RENDERWIN / Displays the Render window without starting a rendering operation                   |

## S, T, U

### S

|     |                                                                                                            |
|-----|------------------------------------------------------------------------------------------------------------|
| S   | STRETCH / Stretches objects crossed by a selection window or polygon                                       |
| SC  | SCALE / Enlarges or reduces selected objects, keeping the proportions of the object the same after scaling |
| SCR | SCRIPT / Executes a sequence of commands from a script file                                                |
| SEC | SECTION / Uses the intersection of a plane and solids, surfaces, or mesh to create a region                |
| SET | SETVAR / Lists or changes the values of system variables                                                   |
| SHA | SHADEMODE / Starts the VSCURRENT command                                                                   |
| SL  | SLICE / Creates new 3D solids and surfaces by slicing, or dividing, existing objects                       |
| SN  | SNAP / Restricts cursor movement to specified intervals                                                    |

|        |                                                                                         |
|--------|-----------------------------------------------------------------------------------------|
| SO     | SOLID / Creates solid-filled triangles and quadrilaterals                               |
| SP     | SPELL / Checks spelling in a drawing                                                    |
| SPE    | SPLINEDIT / Edits a spline or spline-fit polyline                                       |
| SPL    | SPLINE / Creates a smooth curve that passes through or near specified points            |
| SPLANE | SECTIONPLANE / Creates a section object that acts as a cutting plane through 3D objects |
| SPLAY  | SEQUENCEPLAY / Plays named views in one category                                        |
| SPLIT  | MESHSPPLIT / Splits a mesh face into two faces                                          |
| SSM    | SHEETSET / Opens the Sheet Set Manager                                                  |
| ST     | STYLE / Creates, modifies, or specifies text styles                                     |
| STA    | STANDARDS / Manages the association of standards files with drawings                    |
| SU     | SUBTRACT / Combines selected 3D solids, surfaces, or 2D regions by subtraction          |

## T

|     |                                                                                       |
|-----|---------------------------------------------------------------------------------------|
| T   | MTEXT / Creates a multiline text object                                               |
| TA  | TEXTALIGN / Aligns multiple text objects vertically, horizontally, or obliquely       |
| TB  | TABLE / Creates an empty table object                                                 |
| TED | TEXTEDIT / Edits a dimensional constraint, dimension, or text object                  |
| TH  | THICKNESS / Sets the default 3D thickness property when creating 2D geometric objects |
| TI  | TILEMODE / Controls whether paper space can be accessed                               |
| TOL | TOLERANCE / Creates geometric tolerances contained in a feature control frame         |
| TOR | TORUS / Creates a donut-shaped 3D solid                                               |
| TP  | TOOLPALETTES / Opens the Tool Palettes window                                         |

|    |                                                           |
|----|-----------------------------------------------------------|
| TR | TRIM / Trims objects to meet the edges of other objects   |
| TS | TABLESTYLE / Creates, modifies, or specifies table styles |

U

|                       |                                                                                                       |
|-----------------------|-------------------------------------------------------------------------------------------------------|
| UC                    | UCSMAN / Manages defined user coordinate systems.                                                     |
| UN                    | UNITS / Controls coordinate and angle display formats and precision.                                  |
| UNHIDE /<br>UNISOLATE | UNISOLATEOBJECTS / Displays objects previously hidden with the ISOLATEOBJECTS or HIDEOBJECTS command. |
| UNI                   | UNION / Unions two solid or two region objects.                                                       |

V, W, X

V

|       |                                                                                             |
|-------|---------------------------------------------------------------------------------------------|
| V     | VIEW / Saves and restores named views, camera views, layout views, and preset views.        |
| VGO   | VIEWGO / Restores a named view.                                                             |
| VP    | VPOINT / Sets the 3D viewing direction.                                                     |
| VPLAY | VIEWPLAY / Plays the animation associated to a named view.                                  |
| VS    | VSCURRENT / Sets the visual style in the current viewport.                                  |
| VSM   | VISUALSTYLES / Creates and modifies visual styles and applies a visual style to a viewport. |

W

|       |                                                                                   |
|-------|-----------------------------------------------------------------------------------|
| W     | WBLOCK / Writes objects or a block to a new drawing file.                         |
| WE    | WEDGE / Creates a 3D solid wedge.                                                 |
| WHEEL | NAVSWHEEL / Displays a wheel that contains a collection of view navigation tools. |

X

|    |                                                                                                        |
|----|--------------------------------------------------------------------------------------------------------|
| X  | EXPLODE / Breaks a compound object into its component objects.                                         |
| XA | XATTACH / Inserts a DWG file as an external reference (xref).                                          |
| XB | XBIND / Binds one or more definitions of named objects in an xref to the current drawing.              |
| XC | XCLIP / Crops the display of a selected external reference or block reference to a specified boundary. |
| XL | XLINE / Creates a line of infinite length.                                                             |
| XR | XREF / Starts the EXTERNALREFERENCES command.                                                          |

Y - Z

Y

Z

|       |                                                                                      |
|-------|--------------------------------------------------------------------------------------|
| Z     | ZOOM / Increases or decreases the magnification of the view in the current viewport. |
| ZEBRA | ANALYSISZEBRA / Projects stripes onto a 3D model to analyze surface continuity.      |
| ZIP   | ETRANSMIT / Creates a Self-Extracting or Zipped Transmittal Package.                 |