


# Weighing Excellence

## Connection via Modbus TCP WTX120



## 1. Prerequisites

- 1. Hardware

- 2. Software

## 2. Step-by-Step

- 1. Run Example Applications

- 2. Programing own Window App Using the API

  - 1. Overview Structure & Communication Flow

  - 2. Code Example Using the API

  - 3. Change Settings of the WTX120

  - 4. Calibration

## 3. Outlook & Link Collection

## 1.1 Prerequisites – Hardware

---

- HBM WTX120 weighing terminal
- Supply voltage for WTX120 (12V-30V, DC)
- RJ45 Cable (“LAN” Cable)
- A weighing sensor, e.g. HBM PW6C
- Computer with LAN-port or which is connected to the same network as the WTX
- Visual Studio 2017 hardware requirements:
  - Min. 1.8 GHz processor (dual-core recommended)
  - Min. 2 GB RAM (4 GB recommended)
  - Around 20-50 GB hard disk space

## 1.2 Prerequisites – Software

---

- Windows operating system, min. Win7 SP1  
(for programming also macOS possible)
- Min. Visual Studio (VS) 2013
- .Net Version 4.5.2

## 1.2 VS Community License - Extract

---

*“For organizations*

*An unlimited number of users within an organization can use Visual Studio Community for the following scenarios: in a classroom learning environment, for academic research, or **for contributing to open source projects***

*For all other usage scenarios:*

*In non-enterprise organizations, up to five users can use Visual Studio Community. In enterprise organizations (meaning those with >250 PCs or >\$1 Million US Dollars in annual revenue)*

*For individuals*

*Any individual developer can use Visual Studio Community to create their own free or paid apps.”*


From <https://www.visualstudio.com/vs/community/> (02/14/2018)

After 30 days you have to log in with a Microsoft account to unlock the test version

**Everyone else needs another license!**

## 2 Step-by-Step - Installation


- You can find all required links for downloads in the Link-Collection
- Install VS with .NET-Development extension or basic version and install required packages afterwards
- Download ModbusTCP\_WTX from GitHub



Picture: VS Required Tools and Features

## 2 Step-by-Step - Connect WTX & Get Started

- Connect WTX120 with the same network as your PC  
*Note: WTX does not support DHCP currently, only fixed IP*
- Or connect directly to your PC, the IP-address in WTX must be the same, where the subnet-mask is 255, and different, where it is 0.
- Open WTXModbus.sln in the *WTXModbus* folder in the downloaded folder  
*Note: You need internet access during the first build, because WTXModbus downloads 2 NuGet- packages one-time*
- Project overview: 3 example applications: one command line application (CL), two graphic applications (GUI), and the API *WT.API*




Picture: Project overview– Solution explorer

## 2.1 Step-by-Step - Example Application

- Start a demo example: Choose an app

*Note: If you choose WTXModbusCL, you have to set the IP in the VS project properties menu as an argument. Connection establishes automatically after start.*




Picture: WTXModbusCL Project Menu (Project-> WTXModbusCL Properties... -> Debug)

- If a failure occurs during build, probably you have not installed all required VS packages




## 2.1 Step-by-Step - Example Application: GUIs

- GUI example apps can change their IP graphically, also during a run



Picture: Example User Interface "WTXModbus GUI"


WTXModbusGUI:  
Start by clicking *File* -> *Start*



Picture: Example User Interface "WTXModbus GUIsimple"

WTXModbusGUIsimple:  
Start by clicking *Connect*


## 2.2.1 Step-by-Step - Use the API: Overview Structure



- ModbusTCPConnection uses an event handler to signalize that data has been read


- IDeviceData defines the properties (attributes) for values from the WTX device and an eventhandler to check if new data has been read and converted afterwards

## 2.2.1 Step-by-Step - Use the API: Overview Communication Flow (1)




1. Create an object `ModbusConnObj` of class *ModbusTCPConnection* with an IP-address as a parameter
2. Create an object `WTXObj` of class *WTXModbus* with `ModbusConnObj` and a timer interval as a parameter
3. Call *Connect()* on `ModbusConnObj`

*Note: Code example see slide 14*




*Picture: Example User Interface "WTXModbus GUIsimple"*

## 2.2.1 Step-by-Step - Use the API: Overview Communication Flow (2)



1. Register your method `DoSomething()` to the eventhandler:  
`WTXObj.DataUpdateEvent += DoSomething`
2. `aTimer` calls periodically `Async_Call()`
3. The method `Async_Call()` updates the values in `WTXObj` via `ModbusConnObj`'s method `Read()`
4. `DataReceivedTimer()` in `WTXObj` is executed as soon as the values are up-to-date
5. The data is called up after `.Invoke()` in `WTX120Modbus` within method `UpdateEvent()` and fetched
6. `DoSomething()` is executed.

Steps 3-6 are repeated periodically.



Picture: Example User Interface  
"WTXModbus GUIsimple"

## 2.2.2 Step-by-Step - Use the API: Create your own Application

### For GUI


- Add a new *Windows Forms App* project to the Solution
- Use the VS Toolbox to create a display window (drag & drop)
- Double-click on buttons or timer to create empty methods in code
- Use F7 to switch to the programming view

### For CL

- Use *Console App* project

### For both

- Use methods as mentioned on the previous slides to create your program



Picture: VS Toolbox with an Example Window

## 2.2.2 Step-by-Step - Use the API: Code Example (1)

### Code Example

```
using Hbm.Devices.WTXModbus; // 1)
using WTXModbus;

namespace CodeExample
{
    public class ClassExample
    {
        private ModbusTCPConnection ModbusObj;
        private WTXModbus WTXObj;

        public ClassExample()
        {
            int interval=1000;
            ModbusObj = new ModbusTCP(IPAddress); // 2) 3)
            WTXObj = new WTXModbus(ModbusObj, interval);
            WTXObj.getConnection.Connect(); // 4)
            // equal to ModbusObj.Connect();
            ModbusObj.DataUpdateEvent += DoSomething; // 5)
        }

        private void DoSomething(object sender, // 6)
            NetConnectionEventArgs<ushort[]> e)
        {
            //Print Values on Console
            Console.WriteLine(WTXObj.NetValue); // 7)
            Console.WriteLine(WTXObj.GrossValue);
        }
    }
}
```

### Description

1) Required imports

2) *IPAddress* is a string like "192.168.21.1" and *interval* is in milliseconds

3) Create an object of *ModbusTCPConnection* with an IP address of the WTX device and an object of *WTX120Modbus* with the created *ModbusTCPConnection* object and a timer interval

4) Connect your device

5) Add your method *DoSomething()* to the Eventhandler *DataUpdateEvent*

6) The method is called from the API once the data is read from your WTX device and stored in *WTXObj*

7) Here *DoSomething* updates the console with the newly arrived net and gross values. Write your specific code here!

**See next slide for another example of *DoSomething***

## 2.2.2 Step-by-Step - Use the API: Code Example (2)

### Code Example

```
...
    ModbusObj.DataUpdateEvent += ValuesOnConsole;
}

private void ValuesOnConsole(object sender,
    NetConnectionEventArgs<ushort[]> e)
{
    Console.WriteLine("Some example values from WTX:");
    // To print the net value as a string:
    Console.WriteLine(WTXObj.NetValueString);
    // To print the gross value as a string:
    Console.WriteLine(WTXObj.GrossValueString);
    // To print the limit status as a string:
    Console.WriteLine(WTXObj.limitStatusString);

    // As ushort or integer values:
    Console.WriteLine(WTXObj.NetValue);
    Console.WriteLine(WTXObj.GrossValue);
    Console.WriteLine(WTXObj.limitStatus);
}
```

### Description

*ValuesOnConsole()* updates the console with the newly arrived values from your WTX device

The values like *WTX120.NetValue* and *WTX120.GrossValue* have *ushort* as type. To convert them to strings there are properties available *WTX120.PropertyNameString* like *WTX120.NetValueString*

## 2.2.3 Step-by-Step: Writing into the WTX120 device

- Establish a connection
- Call *WTXObj.Async\_Call(OpCode, CallbackMethod)*
- The callback method is called once the writing is completed to the WTX120. Choose the content by yourself.
- Choose the function with OpCode according to the table on the right.

### Code Example

```
private void buttonTare_Clicked(object sender,
EventArgs e)
{
    WTX_obj.AsyncCall(0x1, WriteDataReceived);
}

private void WriteDataReceived(IDeviceValues_obj)
{
    textBoxAusgabe.Text = "Write executed";
}
```

OpCode	Meaning
0x1	Taring
0x2	Switch Gross / NET
0x40	Zeroing
0x80	Adjust zero
0x100	Adjust nominal
0x800	Activate data
0x1000	Manual taring
0x4000	Weight storage
(For more see WTX manual, chapter PLC link)	



## 2.2.4 Step-by-Step: Calibration

There are two possibilities:

- Calculate the values for a dead load and a nominal load in a ratio in mV/V and write in into the WTX registers
  - Call *WTXObj.Calculate(preload, capacity)* on your WTX120 object with preload and capacity as double in mV/V
- Calibration with a reference weight
  - Call *WTXObj.MeasureZero()* with unloaded scale
  - Calculate a normalized weight by
 
$$\text{weight}_{\text{in\_current\_unit}} * 10^{\text{WTXObj.decimals}}$$
  - Call *WTXObj.Calibrate(normalizedWeight)* with *normalizedWeight*

### Code Example

*// Unload scale*

```
WTXObj.MeasureZero();
```

*// put reference weight e.g. 2kg on the scale. WTX display shows weights in kg (WTXObj.unit=0)*

```
Int weight = 2;
```

```
Int normalizedWeight = weight * Math.pow(10, WTXObj.decimals);
```

```
WTXObj.Calibrate(normalizedWeight);
```

## 3 Outlook

---

- If you want to implement an own application, it is recommended to be guided by the interfaces *IDeviceData* and *IModbusTCPConnection*. The latter represents the connection with TCP/Modbus to the WTX and *IDeviceData* represents the available values, which can be called via the interface from your application.
- For more details or functions have a look at the WTX120 manual or at the example app descriptions (coming soon)
- An API with Jetbus and Modbus together is in work to get more information from the WTX as well as easy and similar access to the WTX

### 3 Link Collection

---

- WTX120 Website:  
<https://www.hbm.com/en/6304/wtx120-industrial-and-legal-for-trade-weighing-terminal/>
- WTX120 Manual:  
<https://www.hbm.com/fileadmin/mediapool/hbmdoc/technical/a4500.pdf>
- ModbusTCP API on Github: *(currently unofficial)*  
[https://github.com/FelixHuettlatHBM/ModbusTCP\\_WTX](https://github.com/FelixHuettlatHBM/ModbusTCP_WTX)
- Microsoft Visual Studio:  
<https://www.visualstudio.com/vs/>

[www.hbm.com](http://www.hbm.com)