















POWER




ARDUINO PCB CONNECTORS







ARDUINO FPGA DESIGN




JTAG INTERFACE CONNECTOR








FPGA IO CONNECTORS




Power Supply 2V4 to 3V7










XC6SLX9-2TQG144C




XC6SLX9-2TQG144C




XC6SLX9-2TQG144C




XC6SLX9-2TQG144C



XC6SLX9-2TQG144C




GND





3-WAY JUMPER - POWER SUPPLY SELECT

⚡ NOTE: Disconnect power adapter and arduino USB cable prior to changing jumper settings. Risk of electric shock or damage to board.



5V0_ARD

Arduino 3V3 supply severely limits current – driving from 5V0 input into independent LDO

