

Greta Oto 寄存器定义及软硬件接口



Jun Mo

Globsky Technology Inc.

2021/6/22

说明

本文档描述了 Greta Oto 卫星导航接收机 IP 模块的寄存器定义以及软硬件接口，用以指导软件工程师对硬件进行操作和处理。

接收机 IP 的硬件接口包含总线接口和中断信号。中断来源有跟踪引擎中断、捕获引擎中断和 PPS 中断，各自有各自的中断屏蔽位和中断状态指示，统一到一个中断信号上送给 CPU。总线读写包括对全局和各模块控制寄存器的读写以及对模块内部 RAM 的读写，以同步 SRAM 的时序进行访问。

1. 地址映射

接收机 IP 在总线上总共占用 64kB 的地址空间，全部的访问都是按照 32 比特位宽进行访问，读写操作不支持字节选择。地址的前 32kB 为寄存器映射、后 32kB 为 RAM 映射。在寄存器映射中，每一个模块占用 4kB 的地址空间。模块和内存对应的地址映射如下表所示：

偏移地址范围	模块	说明
0x0000~0x0FFF	Global Registers	
0x1000~0x1FFF	Reserved	
0x2000~0x2FFF	Reserved	
0x3000~0x3FFF	Reserved	
0x4000~0x4FFF	Acquire Engine	
0x5000~0x5FFF	TE FIFO	
0x6000~0x6FFF	Tracking Engine	
0x7000~0x7FFF	Accessory	PPS etc.
0x8000~0x8FFF	TE State Buffer	4kB for 32 channels, expandable
0xC000~0xCFFF	AE Config. Buffer	
Others	Reserved	

寄存器访问模式有 RO（只读）、RW（可读写）、R/W1C（写 1 清除，通常用于中断状态控制）、WTRIG（写 1 触发，通常用于 reset）等。

2. 全局寄存器

全局寄存器的偏移地址以及寄存器中的字段定义如下表所示：

BB_ENABLE - 0x00

Bit	Mode	Name	Default	Description
31:9	-	-	23'h0	Reserved
8	R/W	TRACKING_ENGINE_ENABLE	1'b0	Enable flag of tracking engine system 0: Tracking engine is disabled, will also disable TE FIFO. 1: Tracking engine is enabled, will also enable TE FIFO.
7:0	-	-	8'h0	Reserved

BB_RESET - 0x04

Bit	Mode	Name	Default	Description
31:9	-	-	23'h0	Reserved
8	WTRIG	TE_FIFO_RESET	1'b0	Reset TE FIFO Write: 0: No effect 1: Reset TE FIFO
7:2	-	-	6'h0	Reserved

Bit	Mode	Name	Default	Description
1	WTRIG	TRACKING_ENGINE_RESET	1'b0	Write: 0: No effect. 1: Reset tracking engine
0	WTRIG	ACQUIRE_ENGINE_RESET	1'b0	Write: 0: No effect. 1: Reset acquire engine

FIFO_CLEAR - 0x08

Bit	Mode	Name	Default	Description
31:9	-	-	23'h0	Reserved
8	WTRIG	TE_FIFO_CLEAR	1'b0	Clear bit for TE FIFO Write: 0: No effect 1: Clear TE FIFO
7:1	-	-	7'h0	Reserved
0	WTRIG	TE_FIFO_LATCH	1'b0	Latch TE FIFO write address Write: 0: No effect 1: Latch TE FIFO write address

TRACKING_START - 0x0c

Bit	Mode	Name	Default	Description
31:1	-	-	31'h0	Reserved
0	R/W	TRACKING_START	1'b0	Start/resume tracking engine Read: 0: tracking engine is waiting CPU 1: tracking engine is working Write: 0: No effect 1: Start/resume tracking engine

MEASUREMENT_NUMBER - 0x10

Bit	Mode	Name	Default	Description
31:10	-	-	22'h0	Reserved
9:0	R/W	MEAS_NUMBER	10'h0	Number of blocks of data to process between measurement interrupts. For 1ms block data and 1Hz measurement, this register set to 1000.

MEASUREMENT_COUNT - 0x14

Bit	Mode	Name	Default	Description
31:10	-	-	22'h0	Reserved
9:0	R/W	MEAS_COUNT	10'h0	Counter for measurement number to generate interrupt.

INTERRUPT_FLAG - 0x18

Bit	Mode	Name	Default	Description
31:12	-	-	20'h0	Reserved
11	R/W1C	AE_INT_FLAG	1'b0	AE interrupt flag
10	R/W1C	REQ_INT_FLAG	1'b0	Request interrupt flag
9	R/W1C	MEAS_INT_FLAG	1'b0	Measurement interrupt flag
8	R/W1C	DATA_READY_INT_FLAG	1'b0	Interrupt flag indicate whether tracking engine has coherent data ready
7:0	-	-	8'h0	Reserved

REQUEST_COUNT - 0x1c

Bit	Mode	Name	Default	Description
31:1	-	-	31'h0	Reserved
9:0	R/W	REQ_COUNT	10'h0	Request interrupt counter. Will be decreased 1 if this is not zero at the same cycle MEASUREMENT_COUNT change. If it decreased to zero, the interrupt flag will be set. If host write at the same cycle when hardware decrease this value, host write takes effect.

INT_MASK - 0x20

Bit	Mode	Name	Default	Description
31:12	-	-	20'h0	Reserved
11	R/W1C	AE_INT_MASK	1'b0	AE interrupt mask
10	R/W1C	REQ_INT_MASK	1'b0	Request interrupt mask
9	R/W1C	MEAS_INT_MASK	1'b0	Measurement interrupt mask
8	R/W1C	DATA_READY_INT_MASK	1'b0	Interrupt mask indicate whether tracking engine has coherent data ready
7:0	-	-	8'h0	Reserved

BB_VERSION - 0x40

Bit	Mode	Name	Default	Description
31:24	RO	MAJOR_VERSION	8'h1	Major version
23:16	RO	MINOR_VERSION	8'h0	Minor version
15:0	RO	RELEASE_VERSION	16'h?	Release version

3. 捕获引擎

捕获引擎寄存器的偏移地址以及寄存器中的字段定义如下表所示：

AE_CONTROL- 0x04

Bit	Mode	Name	Default	Description
31:9	-	-	23'h0	Reserved
8	WTRIG	START_ACQ	1'b0	Start acquisition

Bit	Mode	Name	Default	Description
7:6	-	-	2'b0	Reserved
5:0	R/W	CHANNEL_NUMBER	6'h0	Number of channels to do acquisition, valid range 1~32

AE_BUFFER_CONTROL – 0x08

Bit	Mode	Name	Default	Description
31:10	-	-	22'h0	Reserved
9	WTRIG	RESET_RATE_ADAPT OR	1'b0	Reset registers in rate adaptor
8	WTRIG	START_FILL_BUFFER	1'b0	Start fill AE buffer.
7	-	-	1'b0	Reserved
6:0	R/W	BUFFER_THRESHOLD	7'h0	Length of AE buffer threshold indicator in unit of 1kB. When AE buffer filled to this threshold, REACH_THRESHOLD indicator will be set.

AE_STATUS – 0x0c

Bit	Mode	Name	Default	Description
31:20	-	-	12'h0	Reserved
19	R	AE_FINISH	1'b0	Clear when start acquisition and set when acquisition finished.
18	R	AE_BUFFER_FULL	1'b0	Clear when start to fill AE buffer and set when AE buffer is full.
17	R	AE_BUFFER_REACH_TH	1'b0	Clear when start to fill AE buffer and set when AE buffer filled to threshold.
16	R	AE_BUFFER_FILLING	1'b0	Clear when start to fill AE buffer and set when AE buffer is filling.
15:9	-	-	7'h0	Reserved
8:4	R	AE_CURRENT_CHANNEL	5'h0	Current channel AE is doing.
3:0	R	AE_CURRENT_STATE	4'h0	Current value of AE FSM.

AE_CARRIER_FREQ – 0x10

Bit	Mode	Name	Default	Description
31:0	R/W	CARRIER_FREQ	32'h0	Carrier frequency of code rate adaptor. Calculated by $f_{IF}/f_s * 2^{32}$.

AE_CODE_RATIO – 0x14

Bit	Mode	Name	Default	Description
31:24	-	-	8'h0	Reserved
23:0	R/W	CODE_RATE_RATIO	24'h0	Code rate decimation ratio. Calculated by $f_c/f_s * 2^{24}$. In which f_s is source sample rate, f_c is twice

Bit	Mode	Name	Default	Description
				of code rate for GPS/BDS and 16x code rate for GLONASS.

AE_THRESHOLD – 0x18

Bit	Mode	Name	Default	Description
31:8	-	-	24'h0	Reserved
7:0	R/W	QUANT_THRESHOLD	8'd37	Threshold for quantization

4. TE FIFO

TE FIFO 寄存器的偏移地址以及寄存器中的字段定义如下表所示:

TE_FIFO_CONFIG – 0x00

Bit	Mode	Name	Default	Description
31:9	-	-	23'h0	Reserved
8	R/W	TRIG_SOURCE	1'b0	Source FIFO to trigger. If multiple sources are selected, trigger will be effect whichever source send trigger signal. If this field set to 0 or only self is selected as source, trigger will NEVER happen.
7:2	-	-	6'h0	Reserved
1	R/W	FIFO_TRIG	1'h0	Read: 0: FIFO is not waiting trigger from source 1: FIFO is waiting trigger from source Write: 0: No effect 1: Force FIFO goes into disable state and start waiting trigger from source
0	R/W	DUMMY_WRITE	1'h0	0: disable FIFO dummy write 1: enable FIFO dummy write

TE_FIFO_STATUS – 0x04

Bit	Mode	Name	Default	Description
31:3	-	-	29'h0	Reserved
2	RO	FIFO_ENABLED	1'h0	Read/ Write: 0: FIFO is enabled and running 1: FIFO is not running
1	RO	GUARD_ALARM_FLAG	1'h0	Read/ Write: 0: FIFO overflow guard alarm flag negative 1: FIFO overflow guard alarm flag

Bit	Mode	Name	Default	Description
				positive
0	R/W1C	OVERFLOW_FLAG	1'h0	Read: 0: FIFO overflow flag negative 1: FIFO overflow flag positive Write: 0: No effect 1: Clear FIFO overflow flag

TE_FIFO_GUARD – 0x10

Bit	Mode	Name	Default	Description
31:16	-	-	16'h0	Reserved
15:0	R/W	FIFO_GUARD_TH	16'h0	The threshold of alarming FIFO is going to overflow. In the unit of sample. Write will align to multiple of 256 (force 8LSB to be 0).

TE_FIFO_READ_ADDR – 0x14

Bit	Mode	Name	Default	Description
31:16	-	-	16'h0	Reserved
15:0	RO	READ_ADDR	16'h0	Current FIFO read address. Address in unit of sample.

TE_FIFO_WRITE_ADDR – 0x18

Bit	Mode	Name	Default	Description
31:20	RO	WRITE_ADDR_ROUND	12'h0	Current round number of FIFO write address.
19:4	RO	WRITE_ADDR	16'h0	Current FIFO write address. Address in unit of sample.
3:0	-	-	4'h0	Reserved

TE_FIFO_BLOCK_SIZE – 0x28

Bit	Mode	Name	Default	Description
31:16	-	-	16'h0	Reserved
15:0	R/W	CLUSTER_NUM	16'h0	Number of clusters to read from FIFO.

TE_FIFO_BLOCK_ADJUST – 0x2c

Bit	Mode	Name	Default	Description
31:8	-	-	24'h0	Reserved
7:0	R/W	FIFO_BLOCK_ADJUST	8'h0	FIFO block size adjust control register, adjustment in unit of cluster, this value is signed integer.

TE_FIFO_LWADDR_CPU – 0x40

Bit	Mode	Name	Default	Description
31:20	RO	LATCHED_WRITE_A DDR_ROUND	12'h0	CPU latched current round number of FIFO write address.
19:4	RO	LATCHED_WRITE_A DDR	16'h0	CPU latched FIFO write address.
3:0	RO	LATCHED_WRITE_A DDR_SUB	4'h0	CPU latched system clock count between two samples.

TE_FIFO_LWADDR_EM – 0x44

Bit	Mode	Name	Default	Description
31:20	RO	LATCHED_WRITE_A DDR_ROUND	12'h0	Event mark latched current round number of FIFO write address.
19:4	RO	LATCHED_WRITE_A DDR	16'h0	Event mark latched FIFO write address.
3:0	RO	LATCHED_WRITE_A DDR_SUB	4'h0	Event mark latched system clock count between two samples.

TE_FIFO_LWADDR_PPS – 0x48

Bit	Mode	Name	Default	Description
31:20	RO	LATCHED_WRITE_A DDR_ROUND	12'h0	PPS latched current round number of FIFO write address.
19:4	RO	LATCHED_WRITE_A DDR	16'h0	PPS latched FIFO write address.
3:0	RO	LATCHED_WRITE_A DDR_SUB	4'h0	PPS latched system clock count between two samples.

TE_FIFO_LWADDR_AE – 0x4c

Bit	Mode	Name	Default	Description
31:20	RO	LATCHED_WRITE_A DDR_ROUND	12'h0	AE latched current round number of FIFO write address.
19:4	RO	LATCHED_WRITE_A DDR	16'h0	AE latched FIFO write address.
3:0	RO	LATCHED_WRITE_A DDR_SUB	4'h0	AE latched system clock count between two samples.

5. Tracking Engine

跟踪引擎寄存器的偏移地址以及寄存器中的字段定义如下表所示：

TE_CHANNEL_ENABLE – 0x00

Bit	Mode	Name	Default	Description
31:0	R/W	TE_CHANNEL_ENA BLE	32'h0	Read/ Write: Enable flag of each logic channel, bit0 corresponds to channel0, etc. 0: Corresponding channel is

Bit	Mode	Name	Default	Description
				disabled 1: Corresponding channel is enabled

TE_COH_DATA_READY – 0x04

Bit	Mode	Name	Default	Description
31:0	R/W	TE_COH_DATA_READY	32'h0	Read/ Write: Coherent data ready flag of each logic channel, bit0 corresponds to channel0, etc. Any correlator reach coherent number will set this flag. 0: Corresponding channel has not reached coherent number yet 1: Corresponding channel has coherent data ready to read

TE_OVERWRITE_PROTECT_CHANNEL – 0x08

Bit	Mode	Name	Default	Description
31:0	R/W	TE_CHANNEL_OVERWRITE_PROTECT	32'h0	Read/ Write: Coherent data overwrite protect flag of each logic channel, bit0 corresponds to channel0, etc. Any correlator has overwrite protect will set this flag. 0: Corresponding channel has not overwrite protect 1: Corresponding channel has overwrite protect

TE_OVERWRITE_PROTECT_ADDR – 0x10

Bit	Mode	Name	Default	Description
31:12	-	-	20'h0	Reserved
11:0	RO	OVERWRITE_PROTECT_ADDR	12'h0	Coherent address that protected by overwrite

TE_OVERWRITE_PROTECT_VALUE – 0x14

Bit	Mode	Name	Default	Description
31:16	RO	OVERWRITE_PROTECT_VALUE_I	16'h0	Overwrite protect value I
15:0	RO	OVERWRITE_PROTECT_VALUE_Q	16'h0	Overwrite protect value Q

TE_POLYNOMIAL – 0x20

Bit	Mode	Name	Default	Description
-----	------	------	---------	-------------

Bit	Mode	Name	Default	Description
31	R/W	SERIAL_PARALLEL	1'b0	Serialize/parallel select 0: 2 parallel Gold code generation 1: 1 serialize feedback shift registers
30:28	-	-	3'h0	Reserved
27:14	RW	G2_POLYNOMIAL	14'h0	Polynomial of G2 in preset code generator setting0
13:0	R/W	G1_POLYNOMIAL	14'h0	Polynomial of G1 in preset code generator setting0

TE_CODE_LENGTH – 0x24

Bit	Mode	Name	Default	Description
31:14	R/W	GLOBAL_LENGTH	18'h0	Global code length For serialize, all 32bit is used as global length.
13:0	R/W	G1_LENGTH	14'h0	Code length of G1 generator

TE_POLYNOMIAL2 – 0x28

Bit	Mode	Name	Default	Description
31	R/W	SERIAL_PARALLEL	1'b0	Serialize/parallel select 0: 2 parallel Gold code generation 1: 1 serialize feedback shift registers
30:28	-	-	3'h0	Reserved
27:14	RW	G2_POLYNOMIAL	14'h0	Polynomial of G2 in preset code generator setting0
13:0	R/W	G1_POLYNOMIAL	14'h0	Polynomial of G1 in preset code generator setting0.

TE_CODE_LENGTH2 – 0x2c

Bit	Mode	Name	Default	Description
31:14	R/W	GLOBAL_LENGTH	18'h0	Global code length. For serialize, all 32bit is used as global length
13:0	R/W	G1_LENGTH	14'h0	Code length of G1 generator

6. PPS

PPS 寄存器的偏移地址以及寄存器中的字段定义如下表所示:

TBD

Globsky Technology Inc. 版权所有