

2020

FS4500 Field Extractor

FuturePlus Systems

Rev 0.2

3/2/2020

FS4500 Field Extractor

1.0 Revisions

1.0 Initial Release

2.0 Updated Release

2.0 Introduction

The FS4500 DisplayPort Protocol Analyzer product will have Field Extractor Software that will allow the user to extract each state of the acquired trace and then extract the field(s) of interest within that state.

The FS4500 stored trace data is comprised of multiple 16 byte-states, which the Field Extractor will extract one at a time.

This tool can be downloaded from Github at: <https://github.com/FuturePlusSys/FS4500--VidAudFramer> The tool will be in a folder called Field Extractor.

This tool must also be used with the Data Extractor tool that can also be found on Github.

3.0 Extracting State Data

There is a function that extracts the state data from a stored FS4500 trace file, the function is the following.

```
byte[] Statedata = m_IProbe.GetStateData(virtualchannel, index)
```

virtualchannel = int telling probe which channel to look at

index = int telling probe which state to extract

Statedata will contain 16 bytes that make up a state.

Another option to get state data is:

```
List<byte> stateChunk = m_IProbe.GetStateDataChunk(index, 4096, vchannel)
```

Int index = the start of the state index

4096 = the number of states the stateChunk will contain. This means that the size of stateChunk will be 4096 * 16 (bytes per state).

vchannel = int for which virtual channel to get the data from.

FS4500 Field Extractor

3.1 Extracting Field Data

After the state data has been extracted, the user can extract the field data using the following function.

```
GetloopFields(fieldwidths, statedata, fldValues, startindex, endindex);
```

fieldwidths is a byte[] that contains the length of each state field. For example, later in the document, there is a picture under Saved Data Field Format. This shows the width of each field. So if the user wanted to extract the fields of MST1.2 the fieldwidths variable would equal:

```
[12,1,50,3,3,1,8,6,4,1,1,8,1,1,8,1,1,8,1,1,8]
```

The statedata is a byte[] and will contain 16 bytes.

fldValues is a list of 64 bit integers (longs) that contain all of the values for each field. This will be passed into the GetloopFields function as an empty list and after the function call, the extracted field values from the function will be added to the fldValues list.

Start index = 0 and End index = 16 everytime.

3.2 Saved Data Field Format

The organization of data fields and their widths is shown in the picture below. 1.4 MST and SST are the same as 1.2

FS4500 Field Extractor

- Each DP1.1a line or state is 128 bits long:

SPARE[17:0], TRIGGER_STATE, TIME_COUNT[49:0], DATA_ERROR, TRAIN1.1, PIXEL_NOT_REC,
127:110 109 108:59 58 57 56

EVENT[7:0], DATA_PRESENT[3:0], LOS[3:0], LN0_INV, LN0_K, LN0DAT[7:0],
55:48 47:44 43:40 39 38 37:30

LN1_INV, LN1_K, LN1DAT[7:0], LN2_INV, LN2_K, LN2DAT[7:0], LN3_INV, LN3_K, LN3DAT[7:0]
29 28 27:20 19 18 17:10 9 8 7:0

- Each DP1.2 SST-mode line or state is 128 bits long:

SPARE[20:9], TRIGGER_STATE, TIME_COUNT[49:0], ERROR[2:0], SPARE[8:6], PIXEL_NOT_REC,
127:116 115 114:65 64:62 61:59 58

EVENT[7:0], SPARE[5:0], LOS[3:0], LN0_INV, LN0_K, LN0DAT[7:0],
57:50 49:44 43:40 39 38 37:30

LN1_INV, LN1_K, LN1DAT[7:0], LN2_INV, LN2_K, LN2DAT[7:0], LN3_INV, LN3_K, LN3DAT[7:0]
29 28 27:20 19 18 17:10 9 8 7:0

- Each DP1.2 MST-mode line or state is 128 bits long:

SPARE[20:9], TRIGGER_STATE, TIME_COUNT[49:0], ERROR[2:0], VCTAG[2:0], PIXEL_NOT_REC,
127:116 115 114:65 64:62 61:59 58

EVENT[7:0], TIMESLOT[5:0], LOS[3:0], LN0_INV, LN0_K, LN0DAT[7:0],
57:50 49:44 43:40 39 38 37:30

LN1_INV, LN1_K, LN1DAT[7:0], LN2_INV, LN2_K, LN2DAT[7:0], LN3_INV, LN3_K, LN3DAT[7:0]
29 28 27:20 19 18 17:10 9 8 7:0

3.2.1 SST Field Definitions

The following chart contains all the fields in the SST format and a comment on what they do.

Field	Location	Comment
SPARE[20:9]	127:116	Spare bits unused
TRIGGER_STATE	115	Indicates that trigger has occurred
Time_Count[49:0]	114:65	Indicates number of states since the run began and can be read by the PM at any time.
ERROR[2:0]	64:62	Indicates if there is an error
SPARE[8:6]	61:59	Spare bits unused
PIXEL_NOT_REC	58	Pixel not Recognized
EVENT[7:0]	57:50	Event Code Decode see below

FS4500 Field Extractor

SPARE[5:0]	49:44	Spare bits unused
LOS[3:0]	43:40	Loss of Sync
LN0_INV	39	Invalid, this is 1, there is an error
LN0_K	38	Command, 1 = Command 0 = Data
LN0DAT[7:0]	37:30	Data found in Lane 0
LN1_INV	29	Invalid, this is 1, there is an error
LN1_K	28	Command, 1 = Command 0 = Data
LN1DAT[7:0]	27:20	Data found in Lane 1
LN2_INV	19	Invalid, this is 1, there is an error
LN2_K	18	Command, 1 = Command 0 = Data
LN2DAT[7:0]	17:10	Data found in Lane 2
LN3_INV	9	Invalid, this is 1, there is an error
LN3_K	8	Command, 1 = Command 0 = Data
LN3DAT[7:0]	7:0	Data found in Lane 3

3.2.2 SST EventCodes

This chart will help the user identify an event code based on what the field value is.

FS4500 Field Extractor

Main Link Event Code	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	VC Tag
	Vid=1 Blink=0	Field or Vert=1 Hor=0							
Pixel	1	F	0	0	1	0	0	0	= 0
Stuff (including FS/FE)	1	F	0	1	0	0	0	0	
Content Protection BS	0	VH	1	0	1	0	0	0	
Content Protection SR	0	VH	1	1	0	0	0	0	
BS	0	VH	0	0	1	0	1	0	
SR	0	VH	0	0	1	0	1	1	
BE	0	VH	0	1	0	1	0	1	
Training	0*	0*	0	0	0	T2	T1	T0	
VBID	0	VH	0	0	1	0	0	1	
MVID	0	VH	0	0	1	1	0	0	
MAUD	0	VH	0	1	0	0	0	1	
Dummy	0	VH	0	1	1	0	0	1	
MSA	0	VH	0	1	1	1	0	0	
SDP 0x02 Audio Stream	0	VH	1	0	0	0	0	0	
SDP 0x01 Audio TS	0	VH	1	0	0	1	0	0	
SDP 0x05 Audio Copy Mgmt Pkt	0	VH	1	0	1	0	1	1	
SDP 0x06 ISRC Packet	0	VH	1	1	0	0	1	0	
SDP 0x07 VSC Packet	0	VH	0	1	0	0	1	0	
SDP 0x04 Extension Packet	0	VH	1	1	1	1	0	0	
SDP 0x80+ Info Frame	0	VH	0	1	0	1	0	0	
SDP 0x00, 03, 70-7F Reserved	0	VH	1	0	0	0	1	1	
SDP 0x08 – 0F Camera (DP1.3)	0	VH	1	0	1	0	0	1	
Unknown	x	x	0	0	0	0	0	0	

3.2.3 MST File Format

The following chart contains all the fields in the SST format and a comment on what they do.

Field	Location	Comment
SPARE[20:9]	127:116	Spare bits unused
TRIGGER_STATE	115	Indicated that the trigger has occurred
TIME_COUNT[49:0]	114:65	Indicates number of states since the run began and can be read by the PM at any time.
ERROR[2:0]	64:62	Indicated if there was an error
VCTAG[2:0]	61:59	Virtual Channel Tag
PIXEL_NOT_REC	58	Pixel not Recognized

FS4500 Field Extractor

EVENT[7:0]	57:50	Event Codes see decode below
TIMESLOT[5:0]	49:44	Time allocated to a virtual channel in MST mode
LOS[3:0]	43:40	Loss of Sync
LN0_INV	39	Invalid, this is 1, there is an error
LN0_K	38	Command, 1 = Command 0 = Data
LN0DAT[7:0]	37:30	Data in Lane 0
LN1_INV	29	Invalid, this is 1, there is an error
LN1_K	28	Command, 1 = Command 0 = Data
LN1DAT[7:0]	27:20	Data in Lane 1
LN2_INV	19	Invalid, this is 1, there is an error
LN2_K	18	Command, 1 = Command 0 = Data
LN2DAT[7:0]	17:10	Data in Lane 2
LN3INV	9	Invalid, this is 1, there is an error
LN3_K	8	Command, 1 = Command 0 = Data
LN3DAT[7:0]	7:0	Data in Lane 3

3.2.4 MST EventCodes

This chart will help the user identify an event code based on what the field value is.

FS4500 Field Extractor

Main Link Event Code	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	VC Tag
	Vid=1 Blink=0	Field or Vert=1 Hor=0							
Pixel	1	F	0	0	1	0	0	0	= 1 or =2 or =3 or =4
BS	0	VH	0	0	1	0	1	0	
SR	0	0*	0	0	1	0	1	1	
BE	0	VH	0	1	0	1	0	1	
Training	0*	0*	0	0	0	T2	T1	T0	
VBID	0	VH	0	0	1	0	0	1	
MVID	0	VH	0	0	1	1	0	0	
MAUD	0	VH	0	1	0	0	0	1	
MSA	0	VH	0	1	1	1	0	0	
SDP 0x02 Audio Stream	0	VH	1	0	0	0	0	0	
SDP 0x01 Audio TS	0	VH	1	0	0	1	0	0	
SDP 0x05 Audio Copy Mgmt Pkt	0	VH	1	0	1	0	1	1	
SDP 0x06 ISRC Packet	0	VH	1	1	0	0	1	0	
SDP 0x07 VSC Packet	0	VH	0	1	0	0	1	0	
SDP 0x04 Extension Packet	0	VH	1	1	1	1	0	0	
SDP 0x80+ Info Frame	0	VH	0	1	0	1	0	0	
SDP 0x00, 03, 70-7F Reserved	0	VH	1	0	0	0	1	1	
SDP 0x08 – 0F Camera (DP1.3)	0	VH	1	0	1	0	0	1	
Stream Fill SF	0	VH	1	1	0	0	1	1	
Stream Fill SF during VIDEO	1	F	1	1	0	0	1	1	
VCPF/RG	0	VH	1	1	1	0	0	0	
VCPF/RG during VIDEO	1	F	1	1	1	0	0	0	
MTP Header = 0	0*	0*	1	1	1	1	1	1	=7
MTP Header not = SR,0 or ACT	0*	0*	1	1	0	1	0	0	
MTP Header = ACT	0*	0*	1	1	0	0	0	1	
Unprocessed VC	0*	0*	0	0	1	1	1	0	=5
Unknown	x	x	0	0	0	0	0	0	x

FS4500 Field Extractor

4.0 Example

The following example will be shown using a state captured from DP1.4 MST mode.

Before the GetloopFields function can be used, there must be an array that contains all the fieldwidths. An XML file can be used to read the field widths and then put those widths into a byte array. To read the xml File, and read data into fieldwidths, use the following code.

```
XmlReader reader = XmlReader.Create(Path); //Path is to xml file later in this doc
List<int> data = new List<int>();
while (reader.Read())
{
    if (reader.NodeType == XmlNodeType.Element && reader.Name == "MST1.4")
    {
        int width = Convert.ToInt32(reader.GetAttribute("Width"));
        data.Add(width);
    }
}

byte[] fieldwidths = new byte[data.Count];
for (int i = 0; i < data.Count; i++)
{
    fieldwidths[i] = (byte)data[i];
}
```

After the code fieldwidths = [12, 1, 50, 3, 3, 1, 8, 6, 4, 1, 1, 8, 1, 1, 8, 1, 1, 8]

Next is to use the statedata = m_IProbe.GetStateData(int virtualchannel, int index) to get the state data. For this example, statedata will be a byte array that is equal to the array below.

```
statedata = [0x00 0x00 0x00 0x00 0x00 0xC6 0x4F 0x9A 0x0A 0x20 0x40 0x28 0xCA 0x32 0x88
0xA2]
```

fldValues will be an empty list

startindex will be 0

end index will be 16

Plug these variables into the GetloopFields function.

```
GetloopFields(fieldwidths, statedata, fldValues, startindex, endindex);
```

A new list of longs must be inialized called fldvalues and it must be empty. So the DataExtractor given the bit widths of the fields and the statedata above, the fldValues will return the following.

```
fldValues = [0, 0, 6498253, 0, 1, 0, 136, 4, 0, 0, 0, 163, 0, 0, 163, 0, 0, 162, 0, 0, 162]
```

These values also come in the same order they are given, so the value for Spare is the first index in the list, the Trigger State is the 2nd index, the 3rd index is the Time_Count and so on.

FS4500 Field Extractor

4.1 XML File

The following XML File can be used to read in the width values and field names for the Field Extractor.

```
<FS4500_Data_Format>
  <DP1.1a>
    <a1.1 Name="Spare" Type="Field" Width="12" DisplayOrder="1"/>
    <a1.1 Name="Trigger_State" Type="Field" Width="1" DisplayOrder="2"/>
    <a1.1 Name="Time_Count" Type="Field" Width="50" DisplayOrder="3"/>
    <a1.1 Name="Data_Error" Type="Field" Width="1" DisplayOrder="4"/>
    <a1.1 Name="Train1.1" Type="Field" Width="1" DisplayOrder="5"/>
    <a1.1 Name="Pixel_Not_Recognised" Type="Field" Width="1" DisplayOrder="6"/>
    <a1.1 Name="Event" Type="Field" Width="8" DisplayOrder="7"/>
    <a1.1 Name="Data_Present" Type="Field" Width="4" DisplayOrder="8"/>
    <a1.1 Name="Loss_of_Sync" Type="Field" Width="4" DisplayOrder="9"/>
    <a1.1 Name="Lane0_Invalid" Type="Field" Width="1" DisplayOrder="10"/>
    <a1.1 Name="Lane0_Command" Type="Field" Width="1" DisplayOrder="11"/>
    <a1.1 Name="Lane0_Data" Type="Field" Width="8" DisplayOrder="12"/>
    <a1.1 Name="Lane1_Invalid" Type="Field" Width="1" DisplayOrder="13"/>
    <a1.1 Name="Lane1_Command" Type="Field" Width="1" DisplayOrder="14"/>
    <a1.1 Name="Lane1_Data" Type="Field" Width="8" DisplayOrder="15"/>
    <a1.1 Name="Lane2_Invalid" Type="Field" Width="1" DisplayOrder="16"/>
    <a1.1 Name="Lane2_Command" Type="Field" Width="1" DisplayOrder="17"/>
    <a1.1 Name="Lane2_Data" Type="Field" Width="8" DisplayOrder="18"/>
    <a1.1 Name="Lane3_Invalid" Type="Field" Width="1" DisplayOrder="19"/>
    <a1.1 Name="Lane3_Command" Type="Field" Width="1" DisplayOrder="20"/>
    <a1.1 Name="Lane3_Data" Type="Field" Width="8" DisplayOrder="21"/>
  </DP1.1a>
  <DP1.4SST>
    <SST1.4 Name="Spare" Type="Field" Width="12" DisplayOrder="1"/>
    <SST1.4 Name="Trigger_State" Type="Field" Width="1" DisplayOrder="2"/>
    <SST1.4 Name="Time_Count" Type="Field" Width="50" DisplayOrder="3"/>
    <SST1.4 Name="Error" Type="Field" Width="3" DisplayOrder="4"/>
    <SST1.4 Name="Spare" Type="Field" Width="3" DisplayOrder="5"/>
    <SST1.4 Name="Pixel_Not_Recognised" Type="Field" Width="1" DisplayOrder="6"/>
    <SST1.4 Name="Event" Type="Field" Width="8" DisplayOrder="7"/>
    <SST1.4 Name="Spare" Type="Field" Width="6" DisplayOrder="8"/>
    <SST1.4 Name="Loss_of_Sync" Type="Field" Width="4" DisplayOrder="9"/>
    <SST1.4 Name="Lane0_Invalid" Type="Field" Width="1" DisplayOrder="10"/>
    <SST1.4 Name="Lane0_Command" Type="Field" Width="1" DisplayOrder="11"/>
    <SST1.4 Name="Lane0_Data" Type="Field" Width="8" DisplayOrder="12"/>
    <SST1.4 Name="Lane1_Invalid" Type="Field" Width="1" DisplayOrder="13"/>
    <SST1.4 Name="Lane1_Command" Type="Field" Width="1" DisplayOrder="14"/>
    <SST1.4 Name="Lane1_Data" Type="Field" Width="8" DisplayOrder="15"/>
    <SST1.4 Name="Lane2_Invalid" Type="Field" Width="1" DisplayOrder="16"/>
    <SST1.4 Name="Lane2_Command" Type="Field" Width="1" DisplayOrder="17"/>
    <SST1.4 Name="Lane2_Data" Type="Field" Width="8" DisplayOrder="18"/>
    <SST1.4 Name="Lane3_Invalid" Type="Field" Width="1" DisplayOrder="19"/>
    <SST1.4 Name="Lane3_Command" Type="Field" Width="1" DisplayOrder="20"/>
    <SST1.4 Name="Lane3_Data" Type="Field" Width="8" DisplayOrder="21"/>
  </DP1.4SST>
  <DP1.4MST>
    <MST1.4 Name="Spare" Type="Field" Width="12" DisplayOrder="1"/>
    <MST1.4 Name="Trigger_State" Type="Field" Width="1" DisplayOrder="2"/>
    <MST1.4 Name="Time_Count" Type="Field" Width="50" DisplayOrder="3"/>
    <MST1.4 Name="Error" Type="Field" Width="3" DisplayOrder="4"/>
    <MST1.4 Name="VCTag" Type="Field" Width="3" DisplayOrder="5"/>
    <MST1.4 Name="Pixel_Not_Recognised" Type="Field" Width="1" DisplayOrder="6"/>
    <MST1.4 Name="Event" Type="Field" Width="8" DisplayOrder="7"/>
    <MST1.4 Name="Timeslot" Type="Field" Width="6" DisplayOrder="8"/>
    <MST1.4 Name="Loss_of_Sync" Type="Field" Width="4" DisplayOrder="9"/>
    <MST1.4 Name="Lane0_Invalid" Type="Field" Width="1" DisplayOrder="10"/>
    <MST1.4 Name="Lane0_Command" Type="Field" Width="1" DisplayOrder="11"/>
    <MST1.4 Name="Lane0_Data" Type="Field" Width="8" DisplayOrder="12"/>
    <MST1.4 Name="Lane1_Invalid" Type="Field" Width="1" DisplayOrder="13"/>
    <MST1.4 Name="Lane1_Command" Type="Field" Width="1" DisplayOrder="14"/>
    <MST1.4 Name="Lane1_Data" Type="Field" Width="8" DisplayOrder="15"/>
    <MST1.4 Name="Lane2_Invalid" Type="Field" Width="1" DisplayOrder="16"/>
    <MST1.4 Name="Lane2_Command" Type="Field" Width="1" DisplayOrder="17"/>
    <MST1.4 Name="Lane2_Data" Type="Field" Width="8" DisplayOrder="18"/>
    <MST1.4 Name="Lane3_Invalid" Type="Field" Width="1" DisplayOrder="19"/>
    <MST1.4 Name="Lane3_Command" Type="Field" Width="1" DisplayOrder="20"/>
    <MST1.4 Name="Lane3_Data" Type="Field" Width="8" DisplayOrder="21"/>
  </DP1.4MST>
</FS4500_Data_Format>
```

FS4500 Field Extractor

5.0 Summary

The Field Extractor allows the user to extract and use the fields of the FS4500 stored trace data. This is useful for users that want to quickly extract the EVENT[7:0] or the lane data for any or all states in the stored trace file.