

---

# **HDK example**

***Release 1.4-1***

**Software and Controls Group**

**Sep 10, 2018**

# Contents

<b>1</b>	<b>Introduction</b>	<b>1</b>
<b>2</b>	<b>HDK Hardware</b>	<b>2</b>
2.1	Connection to the DCC . . . . .	2
<b>3</b>	<b>HDK Software</b>	<b>7</b>
3.1	Clone the hdk_dcs repository . . . . .	7
3.2	Model files . . . . .	7
3.3	Code generation . . . . .	8
3.4	HDK Main Controller Behavior . . . . .	8
3.4.1	Step function. Emergency button section . . . . .	10
3.4.2	Step function. Motor control . . . . .	10
3.4.3	Step function. LEDs control . . . . .	11
3.4.4	Step function. Logs . . . . .	11
3.4.5	Step function. Heartbeat LED . . . . .	12
3.5	Compilation . . . . .	12
3.6	Running the Example . . . . .	12
3.6.1	Log client . . . . .	12
3.6.2	Telemetry client . . . . .	13
3.6.3	Component setup . . . . .	13
3.6.4	HDK operation . . . . .	13

## **INTRODUCTION**

The HDK (Hardware Development Kit) is a tool which has the purpose of serving as a template to facilitate the development of Device Control Systems (DCS).

## HDK HARDWARE

The main hardware component of the HDK is the control panel, displayed in Fig. 2.1:




Fig. 2.1: HDK Hardware Control Panel

The panel has two DIN rails with all the necessary components. The top rail contains the power section on the left, an embedded PC in the central part, and the Ethercat I/O modules on the right (Fig. 2.2), as well as an emergency button (Fig. 2.3). The lower rail contains a stepper motor on the left with a temperature probe (Fig. 2.4), the terminal blocks interface and a couple of push buttons with a led on the right side (Fig. 2.5).

For more details on the HDK hardware architecture, refer to GMT document GMT-SWC-DOC-00710.

### 2.1 Connection to the DCC

The HDK can be controlled using its embedded PC, or using a Real Time Linux DCC. In this example we will use the later option.

---

**Note:** The following instructions assume that the Linux Real Time kernel and the Ethercat drivers have been installed in the DCC, according to the instructions in the Installation Guide document.

---




Fig. 2.2: HDK I/O modules




Fig. 2.3: HDK emergency button




Fig. 2.4: HDK stepper motor




Fig. 2.5: HDK pushbuttons

The EtherCAT bus must be connected to the RJ-45 connector that is located to the left of the I/O modules block (see Fig. 2.6). The other end of the bus must be connected to the EtherCAT port of the Real Time Linux DCC.

We can check that the installation has been done correctly using the `ethercat` command in the Linux machine. If we execute:

```
$ ethercat slaves
```

then the returned output must be:

```
0 0:0 PREOP + EK1100 EtherCAT-Koppler (2A E-Bus)
1 0:1 PREOP + EL1008 8K. Dig. Eingang 24V, 3ms
2 0:2 PREOP + EL2008 8K. Dig. Ausgang 24V, 0.5A
3 0:3 PREOP + EL3002 2K.Ana. Eingang +/-10V
4 0:4 PREOP + EL3202 2K.Ana. Eingang PT100 (RTD)
5 0:5 PREOP + EL4032 2K. Ana. Ausgang +/-10V, 12bit
6 0:6 PREOP + EL7041 1K. Schrittmotor-Endstufe (50V, 5A)
7 0:7 PREOP + EL9508 Netzteilklemme 8V
8 0:8 PREOP + EL3356 1K . Ana. Eingang, Widerstandsbrücke, 16bit, hochgenau
9 0:9 PREOP + EL3356-0010 1K . Ana. Eingang, Widerstandsbrücke, 24bit, hochge
```






Fig. 2.6: HDK panel EtherCAT bus connection



## HDK SOFTWARE

### 3.1 Clone the `hdk_dcs` repository

On the real-time DCC, clone the repository in the development folder:

```
$ cd $GMT_LOCAL/modules
$ gds clone hdk_dcs -d gmt0
```

where the `-d` option defines the git repository owner. The output of the command will be:

```
Cloning into 'ocs_hdk_dcs'...
remote: Counting objects: 548, done.
remote: Compressing objects: 100% (44/44), done.
remote: Total 548 (delta 7), reused 19 (delta 1), pack-reused 503
Receiving objects: 100% (548/548), 97.69 KiB | 1.81 MiB/s, done.
Resolving deltas: 100% (247/247), done.
[INF] [gds] clone module hdk_dcs
[INF] [hdk_dcs] Cloning module: hdk_dcs
```

### 3.2 Model files

The model files can be found in the `$GMT_LOCAL/modules/ocs_hdk_dcs/model/` folder.

**webpack.config.coffee** It has the `webpack` directives which are needed to build the model

**hdk\_dcs\_ld.coffee** It is the “loader” file. It contains the ``require`` directives to load the rest of the files.

**hdk\_dcs.coffee** Lists the connectors between the components and the external environment.

**hdk\_dcs\_def.coffee** High-level definition file, representing the WBS for the submodule. It lists the components, as well as their implementation language, and other properties.

**hdk\_dcs\_types.coffee** Definitions of structs and data types used by the HDK components.

**hdk\_dcs.rst** Text file, in RST format, describing the module.

**hdk\_ctrl\_pkg/hdk\_ctrl\_fb.coffee** Fieldbus definitions for the HDK control package.

**hdk\_ctrl\_pkg/hdk\_ctrl\_pkg.coffee** Lists the connectors between the components of the *hdk\_ctrl\_pkg* package.

**hdk\_ctrl\_pkg/hdk\_main\_ctrl.coffee** Definition of the *Main HDK Controller* component. State variables, input and output ports are specified here. A single instance called **hdk\_main\_ctrl** will be created.

**hdk\_ctrl\_pkg/hdk\_hw\_adapter.coffee** Definition of the *Hardware Adapter* component, used to interface with the HDK Actuators and Sensors. State variables, input and output ports are specified here. A single instance called **hdk\_hw1\_adapter** will be created.

hdk_main_ctrl		hdk_hw_adapter		EtherCAT FB
+-----+		+-----+		+-----+
hmi_inputs	<----	operator_buttons		
motor_state	<----	motor_state		
temperatures	<----	temperatures		
			<---->	
hmi_outputs	---->	operator_leds		
motor_ctrl	---->	motor_ctrl		
sdo_config	---->	sdo_in		
+-----+		+-----+		+-----+

### 3.3 Code generation

The hdk\_dcs repository already has the source code of the HDK, so it is not needed to generate it.

**Warning:** If the source code is generated again using *gds*, all the source files will be overwritten, including the step function implementations. By default, *gds* will preserve the step function files by copying the the previous version of the `<component>_step.cpp` files to <component>_step.cpp.preserve``

If the source code needs to be generated again (for example, if some feature to the components must be added), then it can be done using the standard procedure:

```
$ cd $GMT_LOCAL/modules/ocs_hdk_dcs/model
$ webpack
$ gds gen hdk_dcs
```

### 3.4 HDK Main Controller Behavior

The behavior of the HDK is defined in the *hdk\_main\_ctrl* component, and more specifically, in the *step()* function of this controller.

The file that contains the HDK controller step function is `hdk_main_ctrl_step.cpp``. To visualize or edit it:

```
$ cd $GMT_LOCAL/modules/ocs_hdk_dcs/src/cpp/
$ cd hdk_ctrl_pkg/hdk_main_ctrl
$ vi hdk_main_ctrl_step.cpp
```

The contents of the file is:

```
#include "hdk_main_ctrl.h"

using namespace gmt;

void HdkMainCtrl::step(bool setup_ok) {
    if (setup_ok)
```

```

{
    if (!hmi_inputs.emergency_button)
    {
        motor_ctrl.velocity = 0;
        motor_ctrl.enable = false;
    }
    else if (motor_state.ready && !motor_state.enabled)
    {
        // enable motor if not enabled
        motor_ctrl.enable = true;
    }

    if (motor_state.enabled)
    {
        if (hmi_inputs.green_push_button)
        {
            motor_ctrl.velocity++;
        }

        if (hmi_inputs.red_push_button)
        {
            motor_ctrl.velocity--;
        }

        if (!hmi_inputs.emergency_button)
        {
            motor_ctrl.velocity = 0;
            motor_ctrl.enable = false;
        }
    }

    bool moving                = motor_state.moving_positive || motor_state.
↪moving_negative;
    hmi_outputs.pilot          = moving; // pilot on when moving
    hmi_outputs.emergency_light = !hmi_inputs.emergency_button; // ligh on when_
↪button pressed

    float estimated_temperature = temperatures.temp_sensor1 / 10.0; // 10.0 will_
↪be a property

    if (is_step_rate(100))    // every 100 steps = 1 second
    {
        // following values should go to user interface
        log_info("Green button = " + std::to_string(hmi_inputs.green_push_
↪button));
        log_info("Red button   = " + std::to_string(hmi_inputs.red_push_button));
        log_info("Emergency    = " + std::to_string(hmi_inputs.emergency_button));
        log_info("Temperature  = " + std::to_string(estimated_temperature));
        log_info("Temperature1 = " + std::to_string(temperatures.temp_sensor1));
        log_info("Temperature2 = " + std::to_string(temperatures.temp_sensor2));
        log_info("Axis Ready   = " + std::to_string(motor_state.ready));
        log_info("Axis Enabled = " + std::to_string(motor_state.enabled));
        log_info("Axis Warning = " + std::to_string(motor_state.warning));
        log_info("Axis Error   = " + std::to_string(motor_state.error));
        log_info("Axis Moving+ = " + std::to_string(motor_state.moving_positive));
        log_info("Axis Moving- = " + std::to_string(motor_state.moving_negative));
    }
}

```

```

    if(is_step_rate(500))  // every 500 steps = 5 seconds
    {
        // flip bit to indicate component is alive
        hmi_outputs.heartbeat = !hmi_outputs.heartbeat;
    }
}

```

This step function has 5 parts:

1. Emergency button
2. Motor control
3. LEDs control
4. Logs
5. Heartbeat LED

### 3.4.1 Step function. Emergency button section

The first code block of the step function is

```

if (!hmi_inputs.emergency_button)
{
    motor_ctrl.velocity = 0;
    motor_ctrl.enable = false;
}
else if (motor_state.ready && !motor_state.enabled)
{
    // enable motor if not enabled
    motor_ctrl.enable = true;
}

```

In the field `emergency\_button` of the `hmi\_inputs` input port we have the state of the emergency button, in inverse logic (so it is False when it is pushed, and True when not). The above code block disables the stepper motor and sets the velocity to 0 when the emergency button is activated, and enables the motor if not.

### 3.4.2 Step function. Motor control

The next section of code implements the motor control:

```

if (motor_state.enabled)
{
    if (hmi_inputs.green_push_button)
    {
        motor_ctrl.velocity++;
    }

    if (hmi_inputs.red_push_button)
    {
        motor_ctrl.velocity--;
    }

    if (!hmi_inputs.emergency_button)
    {

```

```

        motor_ctrl.velocity = 0;
        motor_ctrl.enable = false;
    }
}

```

In the `green_push_button` field of the `hmi_inputs` input port we have the state of the green push button of the HDK panel (True when pushed, False when not) and in the field `red_push_button` we have the state of the red button (see Fig. 2.5).

The `motor_ctrl` output port has 3 fields: the `velocity` field, which will be forwarded to the stepper motor as the velocity set point; the `enable`, which will control if the motor is enabled or not; and the `reset`, which resets the motor in case of failure.

The logic of the section is straightforward: if the green button is pushed, the velocity will be increased; if the red button is pushed the velocity will be decreased; and if the emergency button is pushed then the motor is disabled.

### 3.4.3 Step function. LEDs control

The next code section takes care of the control of the LEDs:

```

bool moving = motor_state.moving_positive || motor_state.moving_negative;
hmi_outputs.pilot = moving; // pilot on when moving
hmi_outputs.emergency_light = !hmi_inputs.emergency_button; // light on when button_
↳pressed

```

In the first line we read the motion state of the stepper motor, and in the second line we light the white led (see Fig. 2.5) if the motor is moving. In the third line, we light the red led (Fig. 2.3) if the emergency button is pushed.

### 3.4.4 Step function. Logs

Once each second, the HDK application produces some logs to inform about the slaves readings:

```

if (is_step_rate(100)) // every 100 steps = 1 second
{
    // following values should go to user interface
    log_info("Green button = " + std::to_string(hmi_inputs.green_push_button));
    log_info("Red button   = " + std::to_string(hmi_inputs.red_push_button));
    log_info("Emergency    = " + std::to_string(hmi_inputs.emergency_button));
    log_info("Temperature  = " + std::to_string(estimated_temperature));
    log_info("Temperature1 = " + std::to_string(temperatures.temp_sensor1));
    log_info("Temperature2 = " + std::to_string(temperatures.temp_sensor2));
    log_info("Axis Ready   = " + std::to_string(motor_state.ready));
    log_info("Axis Enabled  = " + std::to_string(motor_state.enabled));
    log_info("Axis Warning = " + std::to_string(motor_state.warning));
    log_info("Axis Error   = " + std::to_string(motor_state.error));
    log_info("Axis Moving+ = " + std::to_string(motor_state.moving_positive));
    log_info("Axis Moving- = " + std::to_string(motor_state.moving_negative));
}

```

The `is_step_rate(num)` function returns true once each `num` steps, so the above code gets executed once each 100 steps. As the HDK scan rate is 100 Hz, this section is entered once each second.

Inside the `if` statement we have several `log_info` to show the different variables. The `log_info` method is inherited from the `BaseComponent` base class, and it sends the given string to the Log Service.

### 3.4.5 Step function. Heartbeat LED

Finally, the section

```
if(is_step_rate(500)) // every 500 steps = 5 seconds
{
    // flip bit to indicate component is alive
    hmi_outputs.heartbeat = !hmi_outputs.heartbeat;
}
```

inverts the state of the heartbeat LED, with a period of 5 seconds. This digital output is not actually wired to any hardware device, but the change is visible in the LED array of the digital output EL2008 Ethercat slave.

## 3.5 Compilation

To compile the C++ Control Package code of the HDK, edit the module.mk file to contain the correct library definitions:

```
$ vi $GMT_LOCAL/modules/ocs_hdk_dcs/src/cpp/hdk_ctrl_pkg/module.mk
```

Ensure that the following lines are defined:

```
# Add in this file the compile flags for the package, eg:
MOD_BUILD_LDFLAGS += -lcore_core_pkg -lio_core_pkg -lctrl_core_pkg -lio_ethercat_pkg
MOD_BUILD_LDFLAGS += -lethercat -lopcuacore -lopcuaclient
```

Run **make** to compile the code:

```
$ cd $GMT_LOCAL/modules/ocs_hdk_dcs/src/cpp
$ make
```

## 3.6 Running the Example

Start the logging and telemetry services:

```
$ log_server &
$ tele_server &
```

Start the HDK application in the background

```
$ hdk_ctrl_app &
```

The application is running in the background and will not provide any console output. All output will be directed to the logging service after the components have been successfully set up.

### 3.6.1 Log client

In a separate terminal (for example, *tty2*), **start the logging service client**.

```
$ log_client
```



### 3.6.2 Telemetry client

In a separate terminal (for example *tty3*), **start the telemetry service client**.

```
$ tele_client
```

### 3.6.3 Component setup

In the first terminal (*tty1*), **initialize all components**

```
$ cd $GMT_LOCAL/modules/ocs_hdk_dcs/src/etc  
$ ./send_config.coffee
```

Switch to the session running the logging service client (*tty2*), and confirm that the expected components are logging step info.

### 3.6.4 HDK operation

Now the HDK is available to be operated. The behaviour of the system will be the described one:

- If the emergency button is pressed, then the stepper motor will be disabled, and the red led of the emergency button will be on.
- If the emergency button is released, then the stepper motor will be enabled, and the red led of the emergency button will be off.
- When the emergency button is released, if the green button is pushed then the velocity of the stepper motor will be increased.
- When the emergency button is released, if the red button is pushed then the velocity of the stepper motor will be decreased.
- If the motor is moving, then the pilot led between the buttons will be on.