


Notes on how to install the WinUSB driver needed by the Winrad DLL for the HPSPDR

Alberto, I2PHD


These notes presume that you have already downloaded and executed the installer for Winrad V1.33 – Suppose that you have specified D:\Winrad as the destination directory. You should now have in it a subdirectory named WinUSB that contains the files needed to install the driver. What follows exemplifies an installation under Windows XP + SP3, but under Vista there should be only minor differences.

Most probably you have already installed the libusb USB driver needed by PowerSDR or the other programs that are normally used with the HPSPDR. That driver must be replaced by the WinUSB one.

Open the Device Manager panel, with the HPSPDR hardware switched on, and you will find in it this entry :




which was placed there by the libusb installer. Right-click on the second yellow line above, and select the choice to update the driver :




Windows will then present you a sequence of questions, that must be answered as follows :




Then :




Windows will now ask you where is the directory that contains the INF file of the new driver. You should specify D:\Winrad\WinUSB, or anyway the directory where you installed Winrad. The example below is specific to my PC, where I used a different directory name :




Select now the correct driver in the next panel :




The driver installation will start. At a certain point it will reach a stage where the Windows co-installer searches on the Microsoft site for an updated version of the libraries. This step can take some time, a few minutes, and you could have the false impression that the installation is hanging. Wait patiently, and it will complete...




Finally, you will be greeted by the announce by Windows that everything went smoothly...




And now, if you reopen the Device Manager panel, you will find this :



The WinUSB installation is complete. Now you can start Winrad with the HPSDR hardware turned on, and select it by clicking the ShowOptions button :



You will see now the DLL panel that allows you to control various aspects of the HPSDR hardware :



From now on, use Winrad as you would have done with any other input hardware.

Enjoy !

Alberto, I2PHD